385/485/585/685/785
885+XL/248/258/278
HYD 268/HYD 85

Operator's Manual

1135080R5

CASE IH AGRICULTURE

MidWestTech | Case 385, 485, 585, 685, 785, 885+XL/248/258/278, HYD 268/85 Tractor Operator's Manual | Publication 1135080

Order the manual at mid-west-tech.com >

CONTENTS

INTRODUCTION 1-4
SERIAL NUMBER LOCATION 3

INSTRUMENTS AND CONTROLS 5-8
XL Tractors 5
Gear Drive, Other than XL 6
Hydrostatic hand control 7
Hydrostatic foot control 8

WARNING LIGHTS AND GAUGES 9

HEATER CONTROLS 10

BEFORE STARTING ENGINE 11-12

STARTING ENGINE 13-15

AFTER STARTING 16

DRIVING GEAR DRIVE TRACTORS 17-18

DRIVING HAND CONTROLLED HYDROSTATIC TRACTORS 19

DRIVING FOOT CONTROLLED HYDROSTATIC TRACTORS 20

DIFFERENTIAL LOCK 21

STEERING THE TRACTOR 22

STOPPING GEAR DRIVE TRACTORS 23

STOPPING HYDROSTATIC TRACTORS 24

STOPPING ENGINE 25

GENERAL NOTES ON HYDROSTATIC TRACTORS 26

HYDRAULIC SYSTEM CONTROLS 27-32
Three point linkage controls 27
Position control 28
Adjustable stop 28
Draft control 29
Raise response 30
Drop response 31
Control lever positioning 31
Auxiliary valve controls 32

AUTOMATIC HITCH CONTROLS 33

INDEPENDENT POWER TAKE OFF 34
Safety shields 34

PREPARING TRACTOR FOR WORK 35-44
Cooling system 35
Lubrication 35
Fuel system 36
Front wheel tread widths 37
Rear wheel tread widths 38
Front end weights 39
Rear wheel weights 39
Water ballasting 40
Front tyre loads and inflation pressures 40
Rear tyre loads and inflation pressures 41
Three point linkage 42-44
Telescopic lower links 42
Tractor hitch points 43
Upper links 43
Lift links 44
Check chains 44

LUBRICANT SPECIFICATION AND LUBRICATION GUIDE 45

MidWestTech | Case 385, 485, 585, 685, 785, 885+XL/248/258/278, HYD 268/85 Tractor Op... Order the manual at mid-west-tech.com >

CONTENTS

INITIAL SERVICING	46-49	HEATER FILTERS	73
Fan belt adjustment	46		
Transmission filter	46		
Hydrostatic filter	47	ELECTRICAL SYSTEM	75-79
Air cleaning system	47	Fuses	75
Battery	48	Lights	75
		Wiring diagrams	
		XL Tractors	76-77
ROUTINE SERVICING	50-60	Other than XL Tractors	78-79
Every 10 hours	50-52		
Every 200 hours	53-54		
Every 800 hours	55-58	ATTACHMENTS	81-89
Routine servicing shedule	60		
		FOUR WHEEL DRIVE	81
MAINTENANCE	61-73	Operation	81
Automatic hitch adjustment	61	Front tyre loads and inflation	
XL tractors		pressures	82
Other than XL tractors	62	Tyre combination chart	83
Engine clutch	63	Static load	84
XL Tractors		Front wheel tread adjustment	84
Other than XL tractors	64	Lubrication guide	85
Foot-n-inch valve	65	Routine servicing	86
Hydrostatic foot controls	66	Front wheel alignment	87
Dump valve	67	Specifications	88
Brakes	68-71		
Pedal height adjustment			
XL Tractors	68	OIL BATH AIRCLEANER	89
Other than XL Tractors	69		
Bleeding the brakes	69		
Parking brake	71	DRUM BRAKES	89
WHEEL ALIGNMENT	72	BELT PULLEY	89
FUEL SYSTEM	73	SPECIFICATIONS	90-117

MidWestTech | Case 385, 485, 585, 685, 785, 885+XL/248/258/278, HYD 268/85 Tractor Op... Order the manual at mid-west-tech.com >