W8E/W9E/W10E Loaders

Parts Catalog

1141

CASE CONSTRUCTION

MidWestTech | Case W8E, W9E, W10E Loader Parts Catalog | Publication 1141

Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.

Indented Description

Indented parts in the descriptive list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF.	PART NO.	DESCRIPTION	REQ'D
	A 55159	CYLINDER ASSY. - rear steering	1
28	A 56208	SOCKET ASSY. rear cylinder	1
29	NSS	PLUG - adjusting, socket assy	1
30	NSS	SEAT - socket ball	2
31	NSS	SPRING - socket	1
32	NSS	SEAT - socket spring	1
33	G 45175	CLAMP ASSY. - socket assy.	1
	16- 836	BOLT - 1/2" x 2-1/4" N.F. hex.	1
34	132- 104	PIN - cotter, 3/16" x 3"	UAR
35	A 55889	STUD - ball, socket & cylinder	2
36	13- 410	BOLT - 1/4" x 5/8" N.C., hex	4
37	92- 4	LOCKWASHER - 1/4" SAE	4

NOTE **NSS** IN PART NO. COLUMN INDICATES THIS PART IS NOT SERVICED SEPARATELY.
UAR IN AMT. REQ'D COLUMN INDICATES THIS PART IS USED AS REQUIRED.

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of this machine are determined by standing at the rear of the unit and facing in the direction of forward travel.

Order the manual at mid-west-tech.com >

MODEL W8E, W9E AND W10E LOADERS
ALPHABETICAL INDEX
-ENGINE SECTION-

A

Air Cleaners - Engine, Diesel 99
Air Cleaners - Engine, Gasoline 101
Alternator - Electrical, Diesel Engine 63
Alternator - Electrical, Gasoline Engine 65

B

Belt - Drive, Fan and Alternator 77, 85
Block - Cylinder, Diesel 17
Block - Cylinder, Gasoline 39

C

Camshaft - Engine, Diesel 15
Camshaft - Engine, Gasoline 37
Carburetor - Engine, Gasoline 55, 57
Coil - Electrical, Gasoline Engine 59
Crankshaft - Engine, Diesel 19
Crankshaft - Engine, Gasoline 41

D

Distributor - Electrical, Gasoline Engine 59, 61
Dipstick - Engine Oil, Diesel 17
Dipstick - Engine Oil, Gasoline 39

E

Electrical System - Diesel 77-83, 93
Electrical System - Gasoline 85-93

F

Fan - Engine Cooling 7, 7B
Filter - Engine Oil, Diesel 25
Filter - Engine Oil, Gasoline 47
Filter - Fuel, Diesel 31
Flywheel - Engine, Diesel 19
Flywheel - Engine, Gasoline 41
Fuel Tank - Diesel Engine 153
Fuel Tank - Gas Engine 155

G

Gasket Kits - Engine, Diesel 27
Gasket Kits - Engine, Gasoline 49
Gauges - Instrument Panel, Diesel Engine 81, 83
Gauges - Instrument Panel, Gasoline Engine 89, 91
Governor - Engine, Gasoline 53

H

Head - Cylinder, Diesel 13
Head - Cylinder, Gasoline 35

I

Ignition System - Engine, Gasoline 59
Index - Basic Tractor 5
Index - Loader 5, 5A
Index - Numerical 278
Injection System - Fuel, Diesel 29
Injector - Fuel, Diesel 29

K

Kits - Piston and Sleeve, Diesel Engine 21
Kits - Piston and Sleeve, Gasoline Engine 43
Kit - Starting Aid - Diesel 11B

L

Linkage - Throttle Control, Diesel 103
Linkage - Throttle Control, Gasoline 105

M

Manifold - Exhaust, Diesel Engine 9
Manifold - Exhaust, Gasoline Engine 11
Manifold - Intake, Diesel Engine 9
Manifold - Intake, Gasoline Engine 11
Manifold - Water 7, 7B
Muffler - Exhaust, Diesel Engine 9
Muffler - Exhaust, Gasoline Engine 11

P

Pan - Engine Oil, Diesel 25
Pan - Engine Oil, Gasoline 47
Panel - Instrument 81, 89
Pistons - Engine, Diesel 21
Pistons - Engine, Gasoline 43
Pump - Fuel Injection, Diesel 33
Pump - Engine Oil, Diesel 23
Pump - Engine Oil, Gasoline 45
Pump - Water 7, 7B

R

Radiator - Engine Cooling 141
Rings - Piston, Diesel 21
Rings - Piston, Gasoline 43
Rocker Arm - Engine, Diesel 15
Rocker Arm - Engine, Gasoline 37
Rod - Connecting, Diesel 21
Rod - Connecting, Gasoline 43
Rod - Push, Diesel 15
Rod - Push, Gasoline 37
Rotor - Distributor, Gasoline Engine 61

S

Sleeve - Engine, Diesel 21
Sleeve - Engine, Gasoline 43
Solenoid - Starter 75
Spark Plug - Ignition, Gasoline Engine 59
Starter - Engine, Diesel 67, 69
Starter - Engine, Gasoline 71, 73

T

Thermostat - Coolant Temperature 7, 7B
Timing Gear Cover - Engine, Diesel 33
Timing Gear Cover - Engine, Gasoline 51

V

Valve Cover - Engine, Diesel 13
Valve Cover - Engine, Gasoline 35
Valve Guides - Engine, Diesel 15
Valve Guides - Engine, Gasoline 37
Valves - Engine, Diesel 15
Valves - Engine, Gasoline 37
Ventilation - Crankcase 11B

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX
-BASIC TRACTOR SECTION-

A

Accumulator - Hydraulic 271
Alternator - Electrical, Diesel Engine 63
Alternator - Electrical, Gasoline Engine 63
Axle - Rigid, Front 185-191
Axle - Steering, Rear 193-213

B

Batteries - Electrical 93
Battery Cables - Electrical 93
Brake - Parking, Transmission 171
Brake Controls - Foot 117
Brake Controls - Parking 139
Brake System - Hydrovac, Diesel 125,127
Brake System - Hydrovac, Gasoline 129,131

C

Chassis - Tractor 147
Cleaner - Air, Hydrovac 137
Clutch - High Gear, Transmission 171
Clutches - Forward, Reverse and Low Gear Transmission 169
Clutch Control - Brake 117
Converter - Torque 177,179
Cooling System - Converter and Transmission 163
Counterweights - Rear 149
Cylinder - Hydrovac 133,135
Cylinder - Master, Brake 119
Cylinder - Wheel, Brake (Front Axle) 187
Cylinder - Wheel, Brake (Rear Axle) 209

D

Decals - Tractor 277
Differential - Tractor, Front Axle 189,191
Differential - Tractor, Rear Axle 201,211
Drive Shafts - Transmission and Axle 217
Drum - Brake, Front Axle 187
Drum - Brake, Rear Axle 199,209

E

Electrical System - Tractor, Diesel 77-83,93
Electrical System - Tractor, Gasoline 85-93

F

Fenders - Tractor 151
Filter - Air, Hydrovac 137
Filter - Converter Oil 165
Filter - Hydraulic Oil 157
Floor Plates - Tractor 145

G

Gauges - Instrument Panel, Diesel Engine 81,83
Gauges - Instrument Panel, Gasoline Engine 89,91
Grille - Radiator Guard 141

H

Horn - Tractor 97
Hood - Engine 143
Hydraulics - Power Steering 111

I

Index - Engine 4
Index - Loader 5A
Index - Numerical 279
Instrument Panel - Tractor 81,89

L

Lights - Dash 97
Lights - Front and Rear 95
Lights - Stop 95
Lights - Turn Signal 275
Linkage - Steering 109

M

Mounts - Engine 147
Muffler - Exhaust, Diesel Engine 9
Muffler - Exhaust, Gasoline Engine 11

P

Panel - Instrument 81,89
Panels - Engine Side 143
Pedal - Throttle Control 103,105
Pedals - Brake, Hydrovac 117
Plates - Floor 145
Platform - Operator Compartment 145
Pump - Charging, Torque Converter 181
Pump - Power Steering 115
Pump - Vacuum, Hydrovac 137

R

Radiator - Engine Cooling 141
Reservoir - Power Steering 115

S

Seat - Operator 145
Shaft - Input, Transmission 169
Shaft - Output, Transmission 173
Shift Controls - Transmission 159-161
Shift-Out - Rear Axle 173
Shutter - Radiator 141
Side Panels - Engine 143
Starter - Electrical, Diesel 67,69
Starter - Electrical, Gasoline 71,73
Steering Cylinder - Hydraulic 113
Steering Gear - Tractor 107
Steering Hydraulics - Tractor 111
Steering Wheel - Tractor 107

T

Tank - Fuel, Diesel Engine 153
Tank - Fuel, Gasoline Engine 155
Tank - Hydraulic Oil 157
Tank - Reserve, Hydrovac 125,133
Transmission - Case and Covers 167
Transmission Controls - Tractor 159,161

U

Universal Joints - Drive Shaft 217

V

Valve - Accumulator 273
Valve - Check, Hydrovac 137
Valve - Clutch Control 139
Valve - Control, Transmission 175
Valve - Power Steering Cylinder 113
Valve - Regulating, Torque Converter 183

W

Wheels - Drive 215

Order the manual at mid-west-tech.com >