W9B & W10B Loader

Parts Catalog

1144


CASE CONSTRUCTION


MidWestTech | Case W9B, W10B Loader Parts Catalog | Publication 1144

Order the manual at mid-west-tech.com >


MODEL W9B AND W10B LOADERS


SERIAL NUMBER LOCATION














Order the manual at mid-west-tech.com >

Indexes

This Parts Catalog is arranged for easy identification of Genuine CASE Service Parts. An alphabetical index is provided at the front of this Catalog to locate the major groups or assemblies. A numerical index at the rear of the Catalog gives the part numbers and the pages on which they are described.

Illustrations

All parts are illustrated in "Exploded Views" which show the individual parts in their normal relationship to each other. Reference numbers are used in the illustrations. These numbers correspond to those in the "Reference Number" column and are followed by the part number, description and quantity required.

Orders

Orders should plainly specify correct part number, full description, quantity required, machine model and engine model, machine and engine serial numbers, method of shipment and shipping address.

Changes

When changes to the machine make it necessary, revised pages for this book will be issued. The revised pages will be issued with the same page number as those they replace and the "issue" number and date will be advanced.

It is imperative that revised Parts Book pages be inserted into their respective Parts Books as soon as received. Failure to do so will lead to confusion and defeat the purpose of the book.


Indented Description

Indented parts in the description list are a part of the preceding assembly or sub-assembly. The quantity shown in the "Number Required" column is the number of parts used on a machine except where parts are indented in descriptive list. In this case the quantity shown is the number required for the preceding assembly or sub-assembly.

REF		PART NO.	DESCRIPTION	REQ'D.
	A	55159	CYLINDER ASSY. - rear steering	1
28	A	56208	SOCKET ASSY. - rear cylinder	1
29	A	55956	PLUG - adjusting, socket assy.	1
30	A	55957	SEAT - socket ball	2
31	A	56210	SPRING - socket	1
32	A	56209	SEAT - socket spring	1
33	G	45175	CLAMP ASSY. - socket assy.	1
34	16-	836	HHCS - 1/2" - 20 NF x 2-1/4"	1
35	132-	104	PIN - cotter, 3/16" dia. x 3"	1

Terms "Right Hand" and "Left Hand"

"Right Hand" and "Left Hand" sides of the loader are determined by sitting in the operator's seat facing the loader.



690766

Order the manual at mid-west-tech.com >

MODEL W9B AND W10B LOADERS

ALPHABETICAL INDEX

- ENGINE SECTION -

A

Air Cleaners - engine, diesel 15B
Air Cleaners - engine, gasoline 39D
Alternator - electrical, diesel engine 55,55B
Alternator - electrical, gasoline engine .. 61H,69

B

Belt - drive, fan and alternator 53,61D,67B
Block - cylinder, diesel 7,7B
Block - cylinder, gasoline 31,31B

C

Camshaft - engine, diesel 9
Camshaft - engine, gasoline 33
Carburetor - engine, gasoline 49,49B
Coil - electrical, gasoline engine ... 61D,63,67D
Crankshaft - engine, diesel 9B
Crankshaft - engine, gasoline 33B

D

Decompressor - engine, diesel 27
Distributor - electrical, gasoline engine 63D,63F,65
Dipstick - engine oil, diesel 7,7B
Dipstick - engine oil, gasoline 31,31B

E

Electrical Systems - diesel 53-61B
Electrical Systems - gasoline 61D-81

F

Fan - engine cooling 51
Filter - engine oil, diesel 13B
Filter - engine oil, gasoline 37B
Filter - fuel, diesel 21
Flywheel - engine, diesel 9B
Flywheel - engine, gasoline 33B
Fuel Tank - diesel engine 23B
Fuel Tank - gas engine 47

G

Gasket Kits - engine, diesel 17
Gasket Kits - engine, gasoline 41
Gauges - instrument panel, diesel engine 61
Gauges - instrument panel, gasoline engine . 71-81
Generator - electrical, diesel engine 57B
Generator - electrical, gasoline engine 63B
Governor - engine, gasoline 45

H

Head - cylinder, diesel 5
Head - cylinder, gasoline 29

I

Index - basic tractor 3A,3B
Index - loader 3B
Index - numerical 253-262
Injection System - fuel, diesel 23
Injector - fuel, diesel 23

K

Kits - piston and sleeve, diesel engine 11
Kits - piston and sleeve, gasoline engine 35

Order the manual at mid-west-tech.com >