A TEREX COMPANY

Service Manual

Serial Number Range

GRC™-12

from GRC08-000101

Part No. 115370

Rev A1

January 2011

Order the manual at mid-west-tech.com >

Table of Contents

Introduction

Important Information ii
Serial Number Legend iii

Section 1 **Safety Rules**

General Safety Rules v

Section 2 **Rev** **Specifications**

A Machine Specifications ..... 2 - 1
Performance Specifications ..... 2 - 2
Hydraulic Specifications ..... 2 - 2
Manifold Component Specifications ..... 2 - 3
Hydraulic Hose and Fitting Torque Specifications ..... 2 - 4
SAE and Metric Fasteners Torque Charts ..... 2 - 6

Section 3 **Rev** **Scheduled Maintenance Procedures**

Introduction ..... 3 - 1
Pre-delivery Preparation Report ..... 3 - 3
Maintenance Inspection Report ..... 3 - 5

A **Checklist A Procedures**

A-1 Inspect the Manuals and Decals ..... 3 - 6
A-2 Perform Pre-operation Inspection ..... 3 - 7
A-3 Perform Function Tests ..... 3 - 7
A-4 Perform 30 Day Service ..... 3 - 8
A-5 Grease the Steer Yokes ..... 3 - 8

MidWestTech | Terex Genie GRC-12 Personnel Lift Service Manual | Publication 115370 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Section 3	Rev	Scheduled Maintenance Procedures, continued	
	A	**Checklist B Procedures**	
		B-1 Inspect the Batteries	3 - 9
		B-2 Inspect the Electrical Wiring	3 - 11
		B-3 Inspect the Tires and Wheels (including castle nut torque)	3 - 12
		B-4 Test the Emergency Stop	3 - 12
		B-5 Test the Key Switch	3 - 13
		B-6 Test the Automotive-style Horn (if equipped)	3 - 13
		B-7 Inspect the Voltage Inverter (if equipped)	3 - 14
		B-8 Test the Drive Brakes	3 - 15
		B-9 Test the Drive Speed - Stowed Position	3 - 16
		B-10 Test the Drive Speed - Raised Position	3 - 17
		B-11 Test the Slow Drive Speed	3 - 18
		B-12 Test the Flashing Beacons	3 - 19
		B-13 Test the Motion Alarm (if equipped)	3 - 19
		B-14 Perform Hydraulic Oil Analysis	3 - 20
		B-15 Inspect the Breather Cap	3 - 21
	A	**Checklist C Procedure**	
		C-1 Replace the Hydraulic Tank Breather Cap - Models with Optional Hydraulic Oil	3 - 22
	A	**Checklist D Procedure**	
		D-1 Replace the Hydraulic Tank Return Filter	3 - 23
	A	**Checklist E Procedure**	
		E-1 Test or Replace the Hydraulic Oil	3 - 24

MidWestTech | Terex Genie GRC-12 Personnel Lift Service Manual | Publication 115370 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

Section 4	Rev	Repair Procedures	
		Introduction	4 - 1
	A	**Platform Controls**	
		1-1 Circuit Boards	4 - 2
		1-2 Controller Adjustments	4 - 3
		1-3 Software Configuration	4 - 8
	A	**Platform Components**	
		2-1 Platform	4 - 12
		2-2 Platform Extension	4 - 12
	A	**Mast Components**	
		3-1 Mast	4 - 14
		3-2 Wear Pads	4 - 25
		3-3 Lift Cylinder	4 - 26
		3-4 Lift Cylinder Wear Block	4 - 28
		3-5 Mast Coil Cord	4 - 28
	A	**Ground Controls**	
		4-1 Level Sensor	4 - 29
	A	**Hydraulic Pump**	
		5-1 Function Pump	4 - 32
	A	**Function Manifold**	
		6-1 Function Manifold Components	4 - 34
		6-2 Valve Adjustments - Function Manifold	4 - 36
		6-3 Valve Coils	4 - 40
	A	**Hydraulic Tank**	
		7-1 Hydraulic Tank	4 - 42

MidWestTech | Terex Genie GRC-12 Personnel Lift Service Manual | Publication 115370 Order the manual at mid-west-tech.com >

Specifications

REV A

Machine Specifications

Batteries, Standard	
Voltage	6V DC
Group	GC2
Type	T-105
Quantity	4
Battery capacity, maximum	225AH
Reserve capacity @ 25A rate	447 minutes

Batteries, Maintenance-free (option)	
Voltage	6V DC
Group	GC2
Type	6V-AGM
Quantity	4
Battery capacity, maximum	200AH
Reserve capacity @ 25A rate	380 minutes

Fluid capacities	
Hydraulic tank	1.5 gallons 5.7 liters
Hydraulic system (including tank)	2.2 gallons 8.3 liters

Height, stowed maximum	
GRC-12	66.6 in 1.69 m

For operational specifications, refer to the Operator's Manual.

Tires and wheels	
Tire size (solid rubber)	10 x 3 in 25.4 x 2.5 cm
Tire contact area	6.5 sq in 41.9 cm^2
Castle nut torque, dry	225 ft-lbs 305 Nm
Castle nut torque, lubricated	175 ft-lbs 237 Nm

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.

MidWestTech | Terex Genie GRC-12 Personnel Lift Service Manual | Publication 115370 Order the manual at mid-west-tech.com >

Fault Code Chart

REV A


Fault Code	Problem	Possible Causes	Solution
01	Internal ECM error.	EPROM not programmed.	Replace ECM.
02	ECM/Platform communication error.	Malfunctioning control cable OR malfunctioning platform controls.	Troubleshoot control cable OR troubleshoot platform controls.
03	Undefined platform DIP switch settings.	DIP switch settings incorrect.	Correct DIP switch settings.
12	Chassis up/down toggle closed at start up.	Malfunctioning up/down switch.	Troubleshoot up/down switch.
18	Pothole guard failure.	Malfunctioning pothole switch OR obstruction in pothole guard linkage.	Troubleshoot pothole switch OR remove obstruction.
19	Limit switch failure.	Malfunctioning limit switch OR wire disconnected from limit switch.	Troubleshoot limit switch OR inspect wire connection.
42	Platform left turn switch fault.	Malfunctioning steer left microswitch.	Troubleshoot steer left microswitch.
43	Platform right turn switch fault.	Malfunctioning steer right microswitch.	Troubleshoot steer right microswitch.
46	Platform drive enable switch fault.	Malfunctioning drive enable switch.	Troubleshoot drive enable switch.
47	Platform joystick fault.	Joystick potentiometer not centered.	Verify potentiometer setting.
52	Forward coil fault.	Malfunctioning coil OR wire disconnected from coil.	Troubleshoot coil OR inspect wire connection.
53	Reverse coil fault.	Malfunctioning coil OR wire disconnected from coil.	Troubleshoot coil OR inspect wire connection.
54	Up coil fault.	Malfunctioning coil OR wire disconnected from coil.	Troubleshoot coil OR inspect wire connection.
55	Down coil fault.	Malfunctioning coil OR wire disconnected from coil.	Troubleshoot coil OR inspect wire connection.
56	Steer right coil fault.	Malfunctioning coil OR wire disconnected from coil.	Troubleshoot coil OR inspect wire connection.
57	Steer left coil fault.	Malfunctioning coil OR wire disconnected from coil.	Troubleshoot coil OR inspect wire connection.
58	Brake coil fault.	Malfunctioning coil OR wire disconnected from coil.	Troubleshoot coil OR inspect wire connection.
59	Series/parallel coil fault.	DIP switch settings are incorrect.	Troubleshoot and correct DIP switch settings.
68	Low battery voltage.	Batteries discharged.	Charge batteries.
88	ECM has been erased.	Static strap may be missing from the machine.	Replace static strap.

MidWestTech | Terex Genie GRC-12 Personnel Lift Service Manual | Publication 115370 Order the manual at mid-west-tech.com >

Electrical Schematic

REV A

Part 2 of 2



MidWestTech | Terex Genie GRC-12 Personnel Lift Service Manual | Publication 115370 Order the manual at mid-west-tech.com >