A TEREX BRAND

Parts Manual

Serial Number Range

Z-62/40

from SN Z6215A-101 to
Z6216A-1086

from Z6216N-1087 to
Z6216N-2999

Part No. 1257686

Rev D6

November 2018

MidWestTech | Terex Genie Z-62/40 Articulated Boom Lift Parts Manual | Publication 1257686

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

001 Parts Stocking List
001.1 Parts Stocking List....10

100 Decals
101.1 Decals with Words, Hydraulic Tank side (ANSI & AUS)....12
102.1 Decals with Words, Engine side (ANSI & AUS)....14
103.1 Decals with Words, Boom (ANSI & AUS)....16
104.1 Decals with Words, Platform (ANSI & AUS)....18
105.1 Decals with Symbols, Hydraulic Tank side (ANSI & CE)....20
106.1 Decals with Symbols, Engine side (ANSI & CE)....22
107.1 Decals with Symbols, Boom (ANSI & CE)....24
108.1 Decals with Symbols, Platform (ANSI & CE)....26

200 Drive Chassis Components
201.1 Steer End (2WS) & Square End (4WS)....28
202.1 Non-steer End, 2 Wheel Steer....32
203.1 Circle End, 4 Wheel Steer....36
204.1 Drive Hub Assembly....38
205.1 TraX Option Steer End....40
206.1 TraX Option Non-steer End....42
207.1 TraX Option Components....44

300 Turntable Components
301.1 Hydraulic and Fuel Tanks - Gasoline/LPG Models....46
301.2 Fuel Hoses - Gasoline/LPG Models....48
302.1 Hydraulic and Fuel Tanks - Diesel Models....50
303.1 Battery, Function Manifold, and Auxiliary Power Unit Installation (to SN Z6216N-1524)....52
303.2 Battery, Function Manifold, and Auxiliary Power Unit Installation (from SN Z6216N-1525)....54
304.1 Turntable Rotation and Hydraulic Rotary Coupler Installation....56
305.1 Ground Controls, with Hour Meter, External View....60
306.1 Ground Controls, with Hour Meter, Internal View....62
307.1 Ground Controls, with LCD Readout Screen, External View....64
308.1 Ground Controls, with LCD Readout Screen, Internal View....66
309.1 Turntable Covers....68
310.1 Turntable Counterweight....70
311.1 Wire Harness Diagram....72

400 Engine Components
401.1 Perkins 404F-22, View 1....76
402.1 Perkins 404F-22, View 2....78
403.1 Perkins 404F-22, View 3....80
404.1 Perkins 404F-22, View 4....82
405.1 Perkins 404D-22 ROW/TPEM....84
406.1 Deutz D2011L03i ROW/TPEM....88
407.1 Deutz D2.9L4, View 1....92
408.1 Deutz D2.9L4, View 2....94
409.1 Deutz D2.9L4, View 3....96
410.1 Deutz D2.9L4, View 4....98
411.1 Deutz D2.9L4, View 5....100
412.1 Deutz TD2011L04i, View 1....102
413.1 Deutz TD2011L04i, View 2....104
414.1 Deutz TD2.9L4, View 1....106
415.1 Deutz TD2.9L4, View 2....108
416.1 Deutz TD2.9L4, View 3....110
417.1 Deutz TD2.9L4, View 4....112
418.1 Deutz TD2.9L4, View 5....114
419.1 Ford MSG-425, View 1....116
420.1 Ford MSG-425, View 2....118
421.1 Ford MSG-425, View 3....120
422.1 Ford MSG-425, View 4....122
423.1 Engine Tray Components....124

500 Boom Components
500.1 Boom Layout....126
501.1 Secondary Boom and Mid Pivot, View 1 (to SN Z6216N-1682)....128
501.2 Secondary Boom and Mid Pivot, View 1 (from SN Z6216N-1683 to Z6216N-2999)....130
502.1 Secondary Boom and Mid Pivot, View 2 (to SN Z6216N-1682)....132
502.2 Secondary Boom and Mid Pivot, View 2 (from SN Z6216N-1683 to Z6216N-2999)....134
503.1 Mid Pivot and Primary Boom Rests (to SN Z6216N-1682)....136

MidWestTech | Terex Genie Z-62/40 Articulated Boom Lift Parts Manual | Publication 1257... Order the manual at mid-west-tech.com >

503.2 Mid Pivot and Primary Boom Rests (from SN Z6216N-1683)....138
504.1 Upper Pivot (to SN Z6216N-1682)....140
504.2 Upper Pivot (from SN Z6216N-1683)....142
505.1 Primary and Extension Booms....144
506.1 Cable Track....146
507.1 Jib Boom and Platform Rotator....148

600 Platform Components
601.1 Platform Configuration....150
602.1 Platform Components (to SN 1821)....152
602.2 Platform Components (from SN 1822)....154
603.1 Platform Control Box, External View....156
604.1 Platform Control Box, Internal View....160
605.1 Joysticks....162

700 Hydraulic Components
701.1 Traction Manifold - 2WD....164
702.1 Traction Manifold - 4WD....166
703.1 Brake & 2-Speed Manifold....168
704.1 Function Manifold, View 1....170
704.2 Function Manifold, View 2....172
704.3 Function Manifold, View 3....174
705.1 Platform Rotate and Jib Boom/Platform Manifold....176
706.1 Hydraulic Pumps....178
707.1 Oscillate Valve....180
708.1 Turntable Rotate Manifold....182
709.1 Steer Select Manifold, 4 Wheel Steer....184
710.1 Hydraulic Hoses and Fittings - 2WD....186
711.1 Hydraulic Hoses and Fittings - 4WD....188
712.1 Hydraulic Hoses and Fittings - 4 Wheel Steer, View 1....190
713.1 Hydraulic Hoses and Fittings - 4 Wheel Steer, View 2....192
714.1 Hydraulic Hoses and Fittings - Oscillate....194
715.1 Hydraulic Hoses and Fittings - Turntable....196
716.1 Hydraulic Hoses and Fittings - Boom....198

800 Accessories
801.1 Hydraulic Generator....200
802.1 Hydraulic Generator Option - Hoses and Fittings....202
803.1 Hydraulic Oil Cooler - Hoses and Fittings....204
804.1 Generator - Hose Routing....206
804.2 Welder Option - Chassis Components....208
804.3 Welder Option - Platform Components....210
804.4 Welder Option - Manifold Components....212
805.1 Power to Platform....214
806.1 Circuit Board Heater Option....216
807.1 Drive Lights and Flashing Beacons....218
808.1 Aircraft Protection Package....220
809.1 Air Line to Platform....222
810.1 Platform Overload Option....224
811.1 Platform Control Cover Option....226
812.1 Fall Arrest Bar....228
813.1 Operators Protection Alarm (to January 2017)....230
813.2 Lift Guard Contact Alarm Option (from January 2017)....232
814.1 Operator Protective Structure....234
815.1 Tow Package....236
816.1 Half Mesh and Swing Gate (to SN Z6216N-1821)....238
816.2 Half Mesh with Side Entry (from SN Z6216N-1822)....240
817.1 Panel Cradle and Pipe Cradle....242
818.1 Hostile Environment Package - View 1....244
819.1 Hostile Environment Package - View 2....246
820.1 Gauge Options....248
821.1 Pinch Guard and Tool Tray - Front Single Entry Platform....250
821.2 Pinch Guard and Tool Tray - Side Swing Gate Platform....252
822.1 Positive Air Shutoff....254

Indices
Part Number Index....256
Part Description Index....264

Cross References
Fittings Cross Reference....278

MidWestTech | Terex Genie Z-62/40 Articulated Boom Lift Parts Manual | Publication 1257... Order the manual at mid-west-tech.com >

304.1 Turntable Rotation and Hydraulic Rotary Coupler Installation (continued)


Item	Part No.	Description	Qty.
30	824027GT	NUT,TL FLG,1/4-20,G,ZAG	2

MidWestTech | Terex Genie Z-62/40 Articulated Boom Lift Parts Manual | Publication 1257... Order the manual at mid-west-tech.com >

603.1 Platform Control Box, External View (continued)

Item	Part No.	Description	Qty.
31	128202GT	SWITCH TOGGLE ASSY DPDT 3P MOM	1
		jib boom up/down switch	
32	229567GT	PLUG,SANTOPRENE .5 BLACK DOME	1
		option: load sense	
33	824879GT	LIGHT,LED IND. RED 12V NH	1
		machine not level indicator light	

MidWestTech | Terex Genie Z-62/40 Articulated Boom Lift Parts Manual | Publication 1257... Order the manual at mid-west-tech.com >



MidWestTech | Terex Genie Z-62/40 Articulated Boom Lift Parts Manual | Publication 1257... Order the manual at mid-west-tech.com >