A TEREX BRAND

Parts Manual

Serial Number Range

GS-3384	from GS8414-42254 to GS8416-42382
GS-3390	from GS8416F-42383 to GS8416F-44999
GS-4390	from GS9014-49458 to GS9016-51063
GS-5390	from GS9016F-51064 to GS9016F-51999

Part No. 1260677

Rev B6

November 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number.....3
Parts Stocking List.....9
How to Order Parts.....10
Service Parts Fax Order Form.....11

Electronic Version

Click on any page number to view the figure.

001 Parts Stocking List

001.1 Parts Stocking List.....12

100 Decals

101.1 Words, GS-3384 RT, Ground Control Side.....14
102.1 Words, GS-3384 RT, Hydraulic Tank Side.....16
103.1 Words, GS-3384 RT, Outrigger and Links.....18
104.1 Words, GS-3384 RT, Platform - Ground Control Side, ANSI & CSA.....20
105.1 Words, GS-3384 RT, Platform - Hydraulic Tank Side, ANSI & CSA.....22
106.1 Words, GS-3384 RT, Platform - Ground Control Side, Australia.....24
107.1 Words, GS-3384 RT, Platform - Hydraulic Tank Side, Australia.....26
108.1 Symbols, GS-3384 RT, Ground Control Side.....28
109.1 Symbols, GS-3384 RT, Hydraulic Tank Side.....30
110.1 Symbols, GS-3384 RT, Outrigger and Links.....32
111.1 Symbols, GS-3384 RT, Platform - Ground Control Side, ANSI & CSA.....34
112.1 Symbols, GS-3384 RT, Platform - Hydraulic Tank Side, ANSI & CSA.....36
113.1 Symbols, GS-3384 RT, Platform - Ground Control Side, CE.....38
114.1 Symbols, GS-3384 RT, Platform - Hydraulic Tank Side, CE.....40
115.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Ground Control Side.....42
116.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Hydraulic Tank Side.....44
117.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Outrigger and Links.....46
118.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, ANSI & CSA.....48
119.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, ANSI & CSA.....50
120.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, Australia.....52
121.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, Australia.....54
122.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Ground Control Side.....56
123.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Hydraulic Tank Side.....58
124.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Outrigger and Links.....60
125.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, ANSI & CSA.....62
126.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, ANSI & CSA.....64
127.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, CE.....66
128.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, CE.....68

200 Drive Chassis Components

201.1 Steer Axle Linkage, Wheels and Drive Hubs - GS-3384.....70
202.1 Steer Axle Linkage, Wheels and Drive Hubs - GS-3390 RT, GS-4390 RT and GS-5390.....72
203.1 Steer Axle Oscillate (option) - GS-3390 RT, GS-4390 RT and GS-5390.....76
204.1 Non-steer Axle, Wheels and Drive Hubs (all models).....78
205.1 Non-steer Axle Oscillate (option) - GS-3390, GS-4390 and GS-5390.....80
206.1 Drive Manifold (all models).....82
207.1 Function Manifold, Models with Outriggers (all models).....84
208.1 Function Manifold, Models without Outriggers (all models).....86
209.1 Oscillate Manifold (option) - GS-3390 RT, GS-4390 RT and GS-5390.....88
210.1 Hydraulic Hoses and Fittings, Function Manifold - GS-3384.....90
211.1 Hydraulic Hoses and Fittings, 4WD Manifold - GS-3384.....92
212.1 Hydraulic Hoses and Fittings, GS-3390, GS-4390 and GS-5390 Function Manifold.....96
213.1 Hydraulic Hoses and Fittings, GS-3390, GS-4390 and GS-5390 4WD Manifold.....98
214.1 Hydraulic Hoses and Fittings, GS-3390, GS-4390 and GS-5390 Oscillate Manifold.....102
215.1 Electrical Wiring Diagram (all models).....104

MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

216.1 Power Cables (all models).....108

300 Engine Components

301.1 Ford MSG-425 EFI Engine, View 1.....110
302.1 Ford MSG-425 EFI Engine, View 2.....112
303.1 Ford MSG-425 EFI Engine, View 3.....114
304.1 Ford MSG-425 EFI Engine, View 4.....116
305.1 Deutz D2011L03i Engine, View 1.....118
306.1 Deutz D2011L03i Engine, View 2.....120
307.1 Deutz D2011L03i Engine, View 3.....122
308.1 Deutz D2.9L4 Engine, View 1.....124
309.1 Deutz D2.9L4 Engine, View 2.....126
310.1 Deutz D2.9L4 Engine, View 3.....128
311.1 Deutz D2.9L4 Engine, View 4.....130
312.1 Deutz D2.9L4 Engine, View 5.....132

400 Chassis and Engine Tray Components

401.1 Engine Tray Components.....134
402.1 Engine Covers.....136
403.1 Cable Track.....138
404.1 Drive Chassis Trays.....140
405.1 Tank Side, View 1, Ford MSG-425 Gasoline/LPG Models.....142
406.1 Tank Side, View 1, Deutz D2011L03i Diesel Models.144
407.1 Tank Side, View 1, Deutz D2.9L4 Diesel Models.....146
408.1 Tank Side, View 2, All Models.....148
409.1 Fuel Pump Installation, Gasoline/LPG Models (Ford).....150
410.1 Fuel Pump and Filter Installation, Duetz D2.9L4 Models.....152
411.1 Ground Controls Side, View 1.....154
412.1 Ground Controls Side, View 2.....156
413.1 Filters and Accumulator Installation.....158
414.1 Ground Controls, Models with Hour Meter.....160
415.1 Ground Controls, Models with LCD Display.....162

500 Scissor Components

501.1 Scissor to Chassis Installation (all models).....164
502.1 Cylinders and Pins Installation (all models).....166
503.1 Inner Arm, Cable Routing (all models).....168
504.1 Arms and Links Installation, GS-3384 and GS-3390.170
505.1 Arms and Links Installation, GS-4390.....172
506.1 Arms and Links Installation, GS-5390.....174
507.1 Chock Installation (all models).....176

600 Platform Components

601.1 Platform Installation.....178
602.1 Platform Rails and Entry Gate.....182
603.1 Platform Extension Deck, Steer End.....184
604.1 Platform Extension Deck, Non-steer End, View 1.....186
605.1 Platform Extension Deck, Non-steer End, View 2.....188
606.1 Platform Extension Deck, Non-steer End, View 3.....190
607.1 Platform End Rail Installation.....192
608.1 Platform Flooring and Super Deck Roller Brackets..194
609.1 Platform Controls Installation.....196
610.1 Platfrom Controls.....198
611.1 Joystick Controller.....200

700 Accessories

701.1 Power to Platform (all models).....202
702.1 Hydraulic Hoses and Fittings, Outriggers (all models).....204
703.1 Outrigger Cylinder and Footpad Assembly (all models).....206
704.1 Outrigger Components, View 1.....208
705.1 Outrigger Components, View 2 (all models).....210
706.1 Link Guard Assembly - GS-3384 and GS-3390.....212
707.1 Link Guard Assembly - GS-4390 and GS-5390.....214
708.1 Generator (all models).....216
709.1 Hydraulic Hoses and Fittings, Generator option (to SN GS9015-50184).....218
709.2 Hydraulic Hoses and Fittings, Generator option (from SN GS9015-50185).....220
710.1 Hydraulic Hoses and Fittings, Oscillate Manifold with Generator option, (to SN GS9015-50184).....222
710.2 Hydraulic Hoses and Fittings, Oscillate Manifold with Generator option, (from SN GS9015-50185).....224
711.1 Flashing Beacon (all models).....226
712.1 Oil Cooler (all models).....228
713.1 Hydraulic Hoses and Fittings, Oil Cooler, GS-84 (to GS8416F-45086) GS-90 (to SN GS9015-50184).....230
713.2 Hydraulic Hoses and Fittings, Oil Cooler, GS-90 (from SN GS9015-50185 to GS9016F-58236).....232
713.3 Hydraulic Hoses and Fittings, Oil Cooler, GS-84 (from GS8416F-45087) GS-90 (from SN GS9016F-52837).....234
714.1 Air Line to Platform (all models).....236
715.1 Spare LPG Tank (all models).....238
716.1 Cold Start Package, Ford and Deutz Engines (all models).....240
717.1 Welder Option, Generator Components (all models).242
718.1 Welder Option, Hydraulic Hoses and Fittings (all models).....244
719.1 Welder Option, Platform Components (all models)...246
720.1 Platform Work Light.....248

800 Platform Overload Components

801.1 Platform Overload Components.....250
802.1 Platform Overload Hydraulic Components.....252

MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >


Table of Contents (continued)

Indices
Part Number Index.....254
Part Description Index.....260

Cross References
Fittings Cross Reference.....270

MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >


710.1 Hydraulic Hoses and Fittings, Oscillate Manifold with Generator option, (to SN GS9015-50184)



MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >


713.3 Hydraulic Hoses and Fittings, Oil Cooler, GS-84 (from GS8416F-45087) GS-90 (from SN GS9016F-52837)

MODELS WITHOUT OSCILLATE AXLE
- WITH GENERATOR
- WITHOUT GENERATOR






MODELS WITH OSCILLATE AXLE
- WITH GENERATOR
- WITHOUT GENERATOR



MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >



MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >