A TEREX BRAND

# Parts Manual

Serial Number Range

## SX-180

from SN SX18015-293

to SX18016-317

and from SN SX180016H-318

to SX180H-599

and from SN SX180H-600

Part No. 1263380
Rev: A16
September 2019



Order the manual at mid-west-tech.com >

| Description | Page |
|---|---|
| **001 Parts Stocking List** | **12** |
| 001.1 Parts Stocking List | 12 |
| **100 Decals** | **16** |
| 101.1 Decals with Words, Hydraulic Tank Side, (ANSI & Australia) | 16 |
| 102.1 Decals with Words, Hydraulic Tank Side, (chassis) (ANSI & Australia) | 18 |
| 103.1 Decals with Words, Engine Side, (ANSI & Australia) | 20 |
| 104.1 Decals with Words, Engine Side, (chassis) (ANSI & Australia) | 22 |
| 105.1 Decals with Words, Boom, (ANSI & Australia) | 24 |
| 106.1 Decals with Words, Platform, (ANSI & Australia) | 26 |
| 107.1 Decals with Symbols, Hydraulic Tank Side, (ANSI & CE) | 28 |
| 108.1 Decals with Symbols, Hydraulic Tank Side, (chassis) (ANSI & CE) | 30 |
| 109.1 Decals with Symbols, Engine Side, (ANSI & CE) | 32 |
| 110.1 Decals with Symbols, Engine Side, (chassis) (ANSI & CE) | 34 |
| 111.1 Decals with Symbols, Boom, (ANSI & CE) | 36 |
| 112.1 Decals with Symbols, Platform, (ANSI & CE) | 38 |
| **200 Drive Chassis Components** | **40** |
| 201.1 Chassis Components, Top View | 40 |
| 202.1 Chassis Components, Bottom View | 42 |
| 203.1 Chassis Components, Tank Side | 46 |
| 204.1 Chassis Components, Engine Side | 50 |
| 205.1 Steer Yoke, Wheel Drive and Motor | 54 |
| **300 Turntable Components** | **58** |
| 301.1 Turntable Center Components - View 1 | 58 |
| 302.1 Turntable Center Components - View 2 | 62 |
| 303.1 Turntable Covers - Engine Side | 66 |
| 303.2 Turntable Covers - Engine Side | 68 |
| 304.1 Engine Side Components, Fuel Tank | 72 |
| 305.1 Engine Side, Hose Clamps and Guides | 74 |
| 306.1 Engine Side, Welder GEN. Bulkhead Assembly | 76 |
| 307.1 Engine Side, Relay Fuse Assembly | 80 |
| 307.2 Fuse Assembly Deutz TD 2.9L4 and Perkins 854F-E34T - View 1 | 84 |
| 307.3 Fuse Assembly Deutz TD 2.9L4 and Perkins 854F-E34T - View 2 | 86 |
| 308.1 Welder Generator Enclosure (7.5 kW, 208/120 60HZ) | 88 |
| 308.2 Welder Generator Enclosure (12 kW, 208/120 60HZ) | 90 |
| 308.3 Welder Generator Enclosure (7.5 kW, 110/55 50HZ) | 92 |
| 308.4 Welder Generator Enclosure (7.5 kW, 240/415 50HZ) | 94 |
| 308.5 Welder Generator Enclosure (7.5 KW,230VAC,1PH,50HZ,AU) | 96 |
| 309.1 Turntable Covers,Tank Side | 98 |



MidWestTech | Terex Genie SX180 Telescopic Boom Lift Parts Manual | Publication 1263380 Order the manual at mid-west-tech.com >

| Description | Page |
|---|---|
| 309.2 Turntable Covers,Tank Side | 100 |
| 310.1 Tank Side, Swing Drive, Hose Clamps and Guides | 104 |
| 311.1 Tank Side, Battery Bulkhead Assembly | 108 |
| 312.1 Hydraulic Tank Components | 110 |
| 313.1 Ground Control Box Deutz TD2011-L04i and Perkins 1104D-44T - View 1 | 114 |
| 313.2 Ground Control Box Deutz TD2011-L04i and Perkins 1104D-44T - View 2 | 118 |
| 314.1 Ground Control Box - View 1 | 122 |
| 314.2 Ground Control Box - View 2 | 126 |
| 315.1 Wire Harness Diagram - View 1 | 130 |
| 316.1 Wire Harness Diagram - View 2 | 136 |
| **400 Engine Components** | **138** |
| 401.1 Deutz TD2011-L04i Engine - View 1 | 138 |
| 402.1 Deutz TD2011-L04i Engine - View 2 | 142 |
| 403.1 Deutz TD2011-L04i Engine - View 3 | 148 |
| 404.1 Deutz TD 2.9L4 Engine - View 1 | 152 |
| 405.1 Deutz TD 2.9L4 Engine - View 2 | 156 |
| 406.1 Deutz TD 2.9L4 Engine - View 3 | 160 |
| 407.1 Deutz TD 2.9L4 Engine - View 4 | 164 |
| 408.1 Deutz Engine Attached Components | 168 |
| 409.1 Perkins 1104D-44T Engine - View 1 | 170 |
| 410.1 Perkins 1104D-44T Engine - View 2 | 174 |
| 411.1 Perkins 1104D-44T Engine - View 3 | 180 |
| 412.1 Perkins 854F-E34T Engine - View 1 | 186 |
| 413.1 Perkins 854F-E34T Engine - View 2 | 190 |
| 414.1 Perkins 854F-E34T Engine - View 3 | 194 |
| 415.1 Perkins 854F-E34T Engine - View 4 | 198 |
| 416.1 Perkins Engine Attached Components | 202 |
| **500 Boom Components** | **204** |
| 501.1 Boom Components | 204 |
| 502.1 Boom Lift Cylinder | 206 |
| 503.1 Cable Track Installation | 208 |
| 504.1 Secondary Extend Cylinder | 214 |
| 505.1 Primary Extend Cylinder | 216 |
| 506.1 Cable Assembly - View 1 | 218 |
| 507.1 Cable Assembly - View 2 | 222 |
| 508.1 Cable Assembly - View 3 | 226 |
| 509.1 Boom Tube Zero - Wear Pads | 228 |
| 510.1 Boom Tube Zero - Inner Cable Track | 230 |
| 511.1 Boom Tube One - Wear Pads | 234 |
| 512.1 Boom Tube Two - Wear Pads | 236 |



MidWestTech | Terex Genie SX180 Telescopic Boom Lift Parts Manual | Publication 1263380 Order the manual at mid-west-tech.com >

| Description | Page |
|---|---|
| 513.1 Boom Tube Three - Wear Pads, View 1 | 240 |
| 514.1 Boom Tube Three - Wear Pads, View 2 | 244 |
| 514.2 Boom Tube Three - Wear Pads, View 2 | 248 |
| 515.1 Boom Tube Four - Wear Pads | 252 |
| 516.1 Jib Rotator Installation | 254 |
| 517.1 Jib Rotator Housing | 258 |
| 518.1 Jib Boom and Platform Rotator | 262 |
| **600 Platform Components** | **266** |
| 601.1 Platform Installation - View 1 | 266 |
| 602.1 Platform Installation - View 2 (to SN 354) | 270 |
| 602.2 Platform Installation - View 2 (from SN 355) | 274 |
| 602.3 Platform Installation (From SN SX180H-685) | 278 |
| 603.1 Platform Controls | 282 |
| 604.1 Platform J Box Assembly | 288 |
| 605.1 Joysticks | 292 |
| **700 Hydraulic Components** | **294** |
| 701.1 Traction Manifold | 294 |
| 702.1 Steer and Axle Manifold (to SN SX180H-604) | 298 |
| 702.2 Steer and Axle Manifold (from SN SX180H-605) | 304 |
| 703.1 Function Manifold - View 1 | 310 |
| 703.2 Function Manifold - View 2 | 314 |
| 704.1 Jib, Level and Rotation Manifolds (to SN SX180H-612) | 316 |
| 704.2 Jib, Level and Rotation Manifold (from SN SX180H-613) | 320 |
| 705.1 Generator Manifold and Function Enable Valve | 324 |
| 706.1 Hydraulic Pumps | 326 |
| 707.1 Hydraulic Hoses and Fittings, Drive System | 328 |
| 708.1 Hydraulic Hoses and Fittings, Steering System | 332 |
| 709.1 Hydraulic Hoses and Fittings - Turntable | 334 |
| 710.1 Hydraulic Hoses and Fittings - Turntable | 340 |
| 711.1 Hydraulic Hoses and Fittings - Boom Components | 344 |
| **800 Accessories** | **348** |
| 801.1 Platform Accessories (to SN 354) | 348 |
| 801.2 Platform Accessories (from SN 355) | 350 |
| 802.1 Half-Mesh and Pipe Cradle Options (to SN 354) | 352 |
| 802.2 Half-Mesh and Pipe Cradle Options (from SN 355) | 354 |
| 802.3 Half-Mesh and Pipe Cradle Options (from SN 355) | 356 |
| 803.1 Operator Protection Structure | 358 |
| 804.1 Drive and Work Light Package | 360 |
| 805.1 Platform Control Box Cover | 362 |



MidWestTech | Terex Genie SX180 Telescopic Boom Lift Parts Manual | Publication 1263380 Order the manual at mid-west-tech.com >

514.1 Boom Tube Three - Wear Pads, View 2

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| 27 | 231530GT | SCREW,HHF,M10-1.5X25,DIN6921,10.9,ZAB | |



MidWestTech | Terex Genie SX180 Telescopic Boom Lift Parts Manual | Publication 1263380 Order the manual at mid-west-tech.com >

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| 23 | 215818GT | SCREW,HHF,M10-1.5X100,DIN6921, | 2 |
| 24 | 231529GT | NUT,TL FLG,M10-1.5,DIN6927,10, | |
| 25 | | Ref. MANIFOLD,PLAT LVL,PLAT ROT,JIB (Refer to 704.1) | |



MidWestTech | Terex Genie SX180 Telescopic Boom Lift Parts Manual | Publication 1263380 Order the manual at mid-west-tech.com >

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| 29 | 48995GT | VALVE,BALL,12 MSAE-12 FSAE | 1 |
| 30 | 48997GT | NIPPLE,DIAGNOSTIC,#4 | 1 |
| 31 | 49207GT | NIPPLE,DIAGNOSTIC,ORFS,FM,SWIV | 1 |
| 32 | 48880GT | CAP,DIAGNOSTIC NIPPLE | 1 |



MidWestTech | Terex Genie SX180 Telescopic Boom Lift Parts Manual | Publication 1263380 Order the manual at mid-west-tech.com >