A TEREX BRAND

Parts Manual

Serial Number Range

Z-34/22Bi-Energy	from SN Z3413-9607 to Z3415-10688
Z-34/22DC	from SN Z3416F-10689 to Z3416F-11999
.	.
Z-34/22N	from SN Z34N13-10886 to Z34N15-12453
	from Z34N16F-12454 to Z34N16F-13999

Part No. 1265425

Rev B5

January 2019

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

001 Parts Stocking List
001.1 Parts Stocking List....10

100 Decals
101.1 Word Decals, Z-34/22N & Z-34/22DC, Chassis/Battery Box....12
102.1 Word Decals, Z-34/22N & Z-34/22DC, Turntable....14
103.1 Word Decals, Z-34/22N & Z-34/22DC, Boom....16
104.1 Word Decals, Z-34/22N & Z-34/22DC, Platform....18
105.1 Word Decals, Z-34/22BE, Chassis....20
106.1 Word Decals, Z-34/22BE, Turntable....22
107.1 Word Decals, Z-34/22BE, Boom....24
108.1 Word Decals, Z-34/22BE, Platform....26
109.1 Symbol Decals, Z-34/22N & Z-34/22DC, Chassis/Battery Box....28
110.1 Symbol Decals, Z-34/22N & Z-34/22DC, Turntable....30
111.1 Symbol Decals, Z-34/22N & Z-34/22DC, Boom....32
112.1 Symbol Decals, Z-34/22N & Z-34/22DC, Platform....34
113.1 Symbol Decals, Z-34/22BE, Chassis....36
114.1 Symbol Decals, Z-34/22BE, Turntable....38
115.1 Symbol Decals, Z-34/22BE, Boom....40
116.1 Symbol Decals, Z-34/22BE, Platform....42

200 Chassis Components
201.1 Steer End....44
202.1 Non-Steer End, Electronic Control Module....46
203.1 Battery Charger....50
204.1 Battery Packs....52
205.1 Power Cable Diagram, Z-34/22N & Z-34/22DC....54
206.1 Power Cable Diagram, Z-34/22BE....56

300 Turntable Components
301.1 Turntable Rotator....58
302.1 Ground Control Side, Z-34/22N & Z-34/22DC....60
303.1 Ground Controls Side, Z-34/22BE, View 1....62
304.1 Ground Controls Side, Z-34/22BE, View 2....64
305.1 Hydraulic Tank Side, Z-34/22N & Z-34/22DC....66
306.1 Turntable Covers, Z-34/22N & Z-34/22DC....68
307.1 Turntable Covers, Z-34/22BE....70
308.1 Ground Control Panel, Z-34/22N & Z-34/22DC....72
309.1 Ground Control Box, Z-34/22BE, External View....74
310.1 Ground Control Box, Z-34/22BE, Internal View....76
311.1 Wire Harness Diagram, Z-34/22N and Z-34/22DC....78
312.1 Wire Harness Diagram, Z-34/22BE....80

400 Engine Components
401.1 Engine Pivot Plate....82
402.1 Kubota Z482 E4B, Diesel Engine, View 1....84
403.1 Kubota Z482 E4B, Diesel Engine, View 2....86
404.1 Kubota Z482 E4B, Diesel Engine, View 3....88

500 Boom Components
500.1 Boom Layout....90
501.1 Secondary Boom, View 1....92
502.1 Secondary Boom, View 2....94
503.1 Upper Pivot....96
504.1 Primary and Extension Booms....98
505.1 Cable Track....100
506.1 Jib Boom and Platform Rotator....102

600 Platform Components
601.1 Platform....104
602.1 Platform Control Box, External View....106
603.1 Platform Control Box, Internal View....108
604.1 Joystick Controller, Drive/Steer Functions....110
605.1 Rotation Controller, Boom Function Speed....112

700 Hydraulic Components
701.1 Function Manifold....114
702.1 Jib Boom and Platform Rotate Manifold....116
703.1 Drive Chassis Hoses....118
704.1 Turntable Hoses....120
705.1 Boom Hoses....122
706.1 Hydraulic Power Unit....124

800 Accessories
801.1 Air Line to Platform....126
802.1 Aircraft Protection....128
803.1 Auxiliary Rail Assembly....130
804.1 Flashing Beacon and Alarm....132

MidWestTech | Terex Genie Z-34/22 Bi-Energy, Z-34/22DC, Z-34/22N Articulated Boom Lift... Order the manual at mid-west-tech.com >

805.1 Hostile Environment, Wiper.....134
806.1 Hostile Environment, Cylinder Bellows.....136
807.1 Cold Start for Bi-Energy.....138
808.1 Drive Light.....140
809.1 Inverter, 120V.....142
810.1 Platform Control Box Cover, Tool Tray and Work Light.....144
811.1 Platform Half Mesh, Swing Gate and Pipe Cradle....146
812.1 Platform Overload, CE and AUS.....148
813.1 Operators Protection Alarm (to January 2017).....150
813.2 Lift Guard Contact Alarm (from January 2017).....152

Indices
Part Number Index.....154
Part Description Index.....159

Cross References
Fittings Cross Reference.....166

MidWestTech | Terex Genie Z-34/22 Bi-Energy, Z-34/22DC, Z-34/22N Articulated Boom Lift... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
--	74468GT	SPRING, RETURN (FOR 74267)	
--	74469GT	FIXED CONTACT (FOR 74267)	
--	74470GT	MOVING CONTACT (FOR PN 74267)	

MidWestTech | Terex Genie Z-34/22 Bi-Energy, Z-34/22DC, Z-34/22N Articulated Boom Lift...
Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	56929GT	MANIFOLD,ROTATOR,180 DEG,***.....1 *includes 2 and 3*	
--	62507GT	O-RING, ROTATOR MANIFOLD	
2	62506GT	VALVE - COUNTERBALANCE** *platform rotate right*	
--	43018GT	SEAL KIT (39345)	
3	62506GT	VALVE - COUNTERBALANCE** *platform rotate left*	
--	43018GT	SEAL KIT (39345)	
4	139560GT	SOLENOID VALVE W/NUT*** *jib boom up/down*	
--	139561GT	COIL, SOLENOID VALVE, 24V***	
5	139560GT	SOLENOID VALVE W/NUT*** *platform rotate left/right (order coil separately)*	
--	139561GT	COIL, SOLENOID VALVE, 24V***	
6	48916GT	CONN, 520120-6	
7	48905GT	CONNECTOR, 520120-4	
8	48916GT	CONN, 520120-6	
9	48905GT	CONNECTOR, 520120-4	
10	139462GT	MANIFOLD,JIB, 24V NON RJ***.....1 *includes 4-12*	
--	139564GT	SEAL KIT, JIB MANIFOLD, NON RJ	
11	48905GT	CONNECTOR, 520120-4	
12	48916GT	CONN, 520120-6	

MidWestTech | Terex Genie Z-34/22 Bi-Energy, Z-34/22DC, Z-34/22N Articulated Boom Lift... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
--	70707GT	COLD START PKG,120V BI-ENERGY *includes items 1 and 2*	
1	28853GT	BLANKET,BATTERY	1
2	70683GT	FREEZE PLUG HEATER,Z45	1

MidWestTech | Terex Genie Z-34/22 Bi-Energy, Z-34/22DC, Z-34/22N Articulated Boom Lift... Order the manual at mid-west-tech.com >