A TEREX BRAND

Parts Manual

Serial Number Range

GS-3384
GS-3390
GS-4390
GS-5390

from SN GS8416F-45000

to GS8416F-45499

from SN GS84F-45500

from SN GS9016F-5200

to SN GS9016F-53299

from SN GS90F-53300

Part No. 1267840GT
Rev: A10
September 2019

Order the manual at mid-west-tech.com >

Description — Page

001 Parts Stocking List 12

001.1 Parts Stocking List 12

100 Decals 16

101.1 Words, GS-3384 RT, Ground Control Side 16
102.1 Words, GS-3384 RT, Hydraulic Tank Side 20
103.1 Words, GS-3384 RT, Outrigger and Links 22
104.1 Words, GS-3384 RT, Platform - Ground Control Side, ANSI & CSA 24
105.1 Words, GS-3384 RT, Platform - Hydraulic Tank Side, ANSI & CSA 26
106.1 Words, GS-3384 RT, Platform - Ground Control Side, Australia 28
107.1 Words, GS-3384 RT, Platform - Hydraulic Tank Side, Australia 30
108.1 Symbols, GS-3384 RT, Ground Control Side 32
109.1 Symbols, GS-3384 RT, Hydraulic Tank Side 34
110.1 Symbols, GS-3384 RT, Outrigger and Links 36
111.1 Symbols, GS-3384 RT, Platform - Ground Control Side, ANSI & CSA 38
112.1 Symbols, GS-3384 RT, Platform - Hydraulic Tank Side, ANSI & CSA 40
113.1 Symbols, GS-3384 RT, Platform - Ground Control Side, CE 42
114.1 Symbols, GS-3384 RT, Platform - Hydraulic Tank Side, CE 44
115.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Ground Control Side 46
115.2 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Ground Control Side 50
116.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Hydraulic Tank Side 54
116.2 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Hydraulic Tank Side 56
117.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Outrigger and Links 58
117.2 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Outrigger and Links 60
117.3 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Outrigger and Links 62
118.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, ANSI & CSA 64
118.2 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, ANSI & CSA 66
118.3 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, ANSI & CSA 68
119.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, ANSI & CSA 70
119.2 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, ANSI & CSA 72
119.3 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, ANSI & CSA 74
120.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, Australia 76
120.2 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, Australia 78
120.3 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, Australia 80
121.1 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, Australia 82
121.2 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, Australia 84
121.3 Words, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, Australia 86
122.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Ground Control Side 88
122.2 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Ground Control Side 90
123.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Hydraulic Tank Side 92
123.2 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Hydraulic Tank Side 94

MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

Description — Page

124.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Outrigger and Links 96
124.2 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Outrigger and Links 98
124.3 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Outrigger and Links 100
125.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, ANSI & CSA 102
125.2 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, ANSI & CSA 104
125.3 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, ANSI & CSA 106
126.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, ANSI & CSA 108
126.2 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, ANSI & CSA 110
126.3 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, ANSI & CSA 112
127.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, CE 114
127.2 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, CE 116
127.3 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Ground Control Side, CE 118
128.1 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, CE 120
128.2 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, CE 122
128.3 Symbols, GS-3390 RT, GS-4390 RT and GS-5390 RT, Platform - Hydraulic Tank Side, CE 124

200 Drive Chassis Components 126

201.1 Steer Axle Linkage, Wheels and Drive Hubs - GS-3384 126
202.1 Steer Axle Linkage, Wheels and Drive Hubs - GS-3390 RT, GS-4390 RT and GS-5390 130
203.1 Steer Axle Oscillate (option) - GS-3390 RT, GS-4390 RT and GS-5390 136
204.1 Non-steer Axle, Wheels and Drive Hubs (all models), GS-3384 RT 140
204.2 Non-steer Axle, Wheels and Drive Hubs (all models), GS-3390 142
205.1 Non-steer Axle Oscillate (option) - GS-3390, GS-4390 and GS-5390 144
206.1 Drive Manifold (all models) 146
207.1 Function Manifold, Models with Outriggers (all models) 148
208.1 Function Manifold, Models without Outriggers (all models) 152
209.1 Oscillate Manifold (option) - GS-3390 RT, GS-4390 RT and GS-5390 154
210.1 Hydraulic Hoses and Fittings, Function Manifold - GS-3384 156
211.1 Hydraulic Hoses and Fittings, 4WD Manifold - GS-3384 160
212.1 Hydraulic Hoses and Fittings, GS-3390, GS-4390 and GS-5390 Function Manifold 166
212.2 Hydraulic Hoses and Fittings, GS-3390, GS-4390 and GS-5390 Function Manifold 170
213.1 Hydraulic Hoses and Fittings, GS-3390, GS-4390 and GS-5390 4WD Manifold 174
214.1 Hydraulic Hoses and Fittings, GS-3390, GS-4390 and GS-5390 Oscillate Manifold 180
215.1 Electrical Wiring Diagram (all models), GS-3384, GS-3390 182
215.2 Electrical Wiring Diagram (all models), GS-4390 188
215.3 Electrical Wiring Diagram (all models), GS-5390 194
216.1 Power Cables (all models) 200

300 Engine Components 202


301.1 Ford MSG-425 EFI Engine, View 1 202
302.1 Ford MSG-425 EFI Engine, View 2 206
303.1 Ford MSG-425 EFI Engine, View 3 210

MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

Description	Page
304.1 Ford MSG-425 EFI Engine, View 4	216
305.1 Deutz D2011L03i Engine, View 1	222
306.1 Deutz D2011L03i Engine, View 2	226
307.1 Deutz D2011L03i Engine, View 3	230
308.1 Deutz D2.9L4 Engine, View 1	234
309.1 Deutz D2.9L4 Engine, View 2	238
310.1 Deutz D2.9L4 Engine, View 3	242
311.1 Deutz D2.9L4 Engine, View 4 (to SN GS84F-45572, GS90F-54232)	248
311.2 Deutz D2.9L4 Engine, View 4 (from SN GS84F-45573, GS90F-54233)	252
312.1 Deutz D2.9L4 Engine, View 5	254
400 Chassis and Engine Tray Components	**258**
401.1 Engine Tray Components	258
402.1 Engine Covers	262
403.1 Cable Track	264
404.1 Drive Chassis Trays	266
405.1 Tank Side, View 1, Ford MSG-425 Gasoline/LPG Models	268
406.1 Tank Side, View 1, Deutz D2011L03i Diesel Models	270
407.1 Tank Side, View 1, Deutz D2.9L4 Diesel Models	272
408.1 Tank Side, View 2, All Models, GS-3384, GS-3390	274
408.2 Tank Side, View 2, All Models, GS-4390, GS-5390	276
409.1 Fuel Pump Installation, Gasoline/LPG Models (Ford)	278
410.1 Fuel Pump and Filter Installation, Duetz D2.9L4 Models	280
411.1 Ground Controls Side, View 1	282
412.1 Ground Controls Side, View 2	284
413.1 Filters and Accumulator Installation, GS-3384, GS-3390, GS-4390	286
413.2 Filters and Accumulator Installation, GS-5390	288
414.1 Ground Controls, Models with Hour Meter	290
415.1 Ground Controls, Models with LCD Display	294
500 Scissor Components	**298**
501.1 Scissor to Chassis Installation (all models), GS-3384, GS-3390	298
501.2 Scissor to Chassis Installation (all models), GS-4390	302
501.3 Scissor to Chassis Installation (all models), GS-5390	306
502.1 Cylinders and Pins Installation (all models), GS-3384, GS-3390	310
502.2 Cylinders and Pins Installation (all models), GS-4390	312
502.3 Cylinders and Pins Installation (all models), GS-5390	314
503.1 Inner Arm, Cable Routing (all models), GS-3384, GS-3390	316
503.2 Inner Arm, Cable Routing (all models), GS-4390	318
503.3 Inner Arm, Cable Routing (all models), GS-5390	320
504.1 Arms and Links Installation, GS-3384 and GS-3390	322
505.1 Arms and Links Installation, GS-4390	324


MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

311.1 Deutz D2.9L4 Engine, View 4 (to SN GS84F-45572, GS90F-54232)





MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

715.1 Spare LPG Tank (all models)



MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >





MidWestTech | Terex Genie GS-3384, GS-3390, GS-4390, GS-5390 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >