Model W14H
Articulated Loader

Parts Catalog

1268

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accelerator and Linkage 63
Air Cleaner 59
Alternator 35
  Mounting And Adjusting Strap 35,43
Axle Assemblies
  Axle Brakes 107
  Axle Housing And Planetary 103,105
  Front Axle And Differential 95,97
  Rear Axle Differential 99,101
Axle Mounting 103,105

B

Backup Alarm 69B
Batteries 51
  Cables 51
Beacon, rotating 171,173
Belts
  Alternator 43
  Compressor 43
  Seat 159
Block, engine cylinder 17
Block Heater 17
Brake Assemblies And Circuits
  Air Compressor And Related Parts 113,117,119
  Air Pressure Protection Valve 127,135
  Alcohol Evaporator 115
  Axle Brake 107
  Brake Valve 129
  Emergency Brake To Safety Chamber 111
  Governor, air compressor 121
  Master Cylinder 123,131
  Master Cylinder To Wheel Cylinders 125
  Parking Brake, transmission 77
  Treadle Assembly 129
  Treadle To Master Cylinder And Reservoir 123
  Treadle To Hydraulic Tank And Horn 127
Buckets
  Standard 177
  Teeth 177,179B
  4-in-1 Bucket 179,179B

C

Cab, operators 165-165D
Camshaft, engine 13
Clutch, transmission 71,73,75
Cold Starting System (Ether Injection) 55
Compartment, operators 159
Compressor, air 113,117,119
Connecting Rods, engine 21
Control Levers
  Clutch Cutout 123
  Loader Height And Leveling 203
  Loader Lift And Dump 199,201
  Pedal, accelerator 63
  Pedal, brake (Treadle) 123,127,129
  Transmission 87,89
Crankshaft, engine 19
Cushions, seat 159

C

Cylinders, brake
  Master 123,131
  Slave 107
Cylinders, hydraulic
  Bucket Clam 195
  Bucket Dump 193
  Loader Lift 191
  Steering 145

D

Decals
  Bucket (4-in-1) 179
  Engine Data 13
  Kit 217
Defroster, cab 167
Defroster, fan 167B
Dipsticks
  Engine Oil 17
  Hydraulic Tank 155
  Transmission Oil 85
Driveshaft
  Center Bearing 91
  Front, axle end 91
  Front, transmission end 93
  Rear 93

E

Electrical Systems
  Bucket Height 203
  Cab Wiring 165-169
  Cold Starting System 55
  Harnesses 49,51
  Instrument Panels 47
  Return-To-Dig 203
Emblem, slow moving vehicle 217
Engine Mounts 43
Engine Subassemblies
  Alternator 35
  Balancer 25
  Camshaft 13
  Crankshaft 19
  Cylinder Block 17
  Cylinder Head And Cover 13
  Flywheel And Housing 19
  Fuel Filter System 33
  Fuel Injection System 31
  Gasket Kits 27
  Injector Nozzles 33B
  Injection Pump 33B
  Injection Pump Drive 29
  Oil Filter And Heat Exchanger 23
  Oil Pump And Pan 25
  Manifolds, intake and exhaust 11
  Piston And Connecting Rods 21
  Starter 37-41
  Timing Gear Cover 29
  Valve Mechanism 15
  Water Manifold And Thermostat 9
  Water Pump 9
Evaporator, alcohol 115
Exhaust, pipe and mufflers 61

740324

Printed in U.S.A. Issued January, 1974

MidWestTech | Case W14H Articulated Loader Parts Catalog | Publication 1268 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

F

Fan, radiator 43
  Mounting 9,43
Fenders 153,157
Filters
  Air Cleaner 59
  Air, governor 121
  Engine Oil 23
  Fuel 33,33B,149-149D
  Hydraulic Tank 155
  Transmission Oil 67,83
Flasher Lights 161,163
Flywheel, engine 19
Frames
  Articulated, front 157
  Articulated, rear 147
  Loader Lift 175
Fuel Injector 31,33B
Fuel Lines 31,33,149,149B
Fuel Tank (Without electric fuel pump) 149
Fuel Tank (With electric fuel pump) 149B

G

Gaskets, engine (Service Kits) 27
Gauges 47,53,111
Gears
  Engine (See Engine Subassemblies)
  Transmission (See Transmission Subassemblies)
Governor, air compressor 119,121
Grille 151
Guards
  Engine Side Panels 151,153
  Roll-Over Protection 165

H

Head, engine 13
Heater
  Block, engine 17
  Cab 167,169
  Manifold 11,51
Hood 151
Horn, air 127,135
Hose, radiator 43
Hoses (See Fuel Lines, Brake Assemblies And
  Hydraulic Circuits)
Hydraulic Circuits
  Loader Bucket (Clam) 179,189
  Loader Bucket (Dump) 187
  Loader Lift 185
  Primary 181
  Pump To Loader Valve 183
  Steering, pump to cylinders 143
  Steering, pump to reservoir 141
  Transmission 83
Hydraulic Tank Assemblies 155

I

Index, numerical 218-on
Instrument Panels 47
Instruments (See Gauges)

L

Lights 47-51,57,161,163
Loader Arm, mechanical parts 175
Lockup Parts 151B

M

Manifold
  Exhaust 11
  Heater 11,51
  Intake 11
  Water 9
Mounts
  Axle 103,105
  Engine 43
  Radiator 43
  Transmission 85
Mufflers 61

N

Nozzle, fuel injector 33B

O

Oil Cooler, engine 23
Oil Pan, engine 25

P

Parking Brake 77,111
Pedal, accelerator 63
Pedal, brake (Treadle) 127,129
Piston Assemblies, engine 21
Pulleys
  Air Compressor 113
  Alternator 28
  Alternator And Fan Drive 19
  Fan Mounting 9
  Pump Drive, water 9
Pumps
  Engine, oil 25
  Fuel Injection 33B
  Fuel, electric 149D
  Fuel, primer 33B
  Hydraulic Oil 141,181,197
  Steering 137,139
  Torque Converter 65
  Transmission Charging 79
  Water, engine 9

MidWestTech | Case W14H Articulated Loader Parts Catalog | Publication 1268 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

R

Radiator, cooling 43
Regulator, voltage 51
Reservoirs
  Air 123
  Fuel 149
  Hydraulic Oil 155
Rims, wheel 109
Rings, engine piston 21
Rocker Arms, engine 15
Rods, connecting 21
Rods, push 15
Rollover Protection Canopy 165

S

Safety Chamber 111,133
Seat Assemblies 159
Shafts
  Axle (See Axle Assemblies)
  Engine (See Engine Subassemblies)
  Transmission (See Transmission Subassemblies)
Shroud, radiator 151
Side Panels, engine 151,153
Sleeve, piston 21
Solenoid
  Manifold Heater 51
  Starter 41
Starter, engine 37-41,51
Starting Aid (Ether Injection) 55
Steps 157

T

Thermostat, water temperature 9
Timing Gear And Cover, engine 29
Tire Inflation Kit 113
Tools, service 217
Torque Converter 65
Transmission Mounts 85
Transmission Subassemblies
  Axle Output Shaft and Parking Brakes 77
  Charging Pump 79
  Control Valve 79
  Converter Housing, Gears And Transmission Housing 67

T

  Forward Clutch And Planetary 71
  Front Cover, Input Shaft And Torque Converter 65
  High Range Clutch And Transfer Gear 75
  Hydraulic System 83
  Oil Filter 83
  Overhaul Kit 81
  Reverse Clutch And Planetary 73
  Turbine Driven Gears And Freewheel Unit . . 69
Trunnion, rear frame 147
Turn Signals 161,163

V

Valve Mechanism, engine 15
Valve Parts, loader control 209-215
Valves
  Air Pressure Protection 127,135
  Air Pressure Regulator 127,133
  Air Shutoff 127
  Brake Control 127,129
  Breather, axle 103
  Breather, transmission 67
  Check, double 123,133
  Clutch Cutout 123
  Drain
    Air Reservoir 123
    Engine Oil Cooler 23
    Radiator 43
  Emergency Brake 111,133
  Flow Control, steering 141
  Horn 127,135
  Loader Control, 2 spool 199,205
  Loader Control, 3 spool 201,207
  Tire, valve stem 109
  Torque Converter 67
  Transmission Control 79

W

Wheel, steering 137
Wheel, tire 109
Wiper, windshield 161,165B
Wire (See Electrical Circuits)

740326

Printed in U.S.A. Issued January, 1974

MidWestTech | Case W14H Articulated Loader Parts Catalog | Publication 1268 Order the manual at mid-west-tech.com >