A TEREX BRAND

Parts Manual

Serial Number Range

GS-2046
GS-2646
GS-3246

from SN GS4615A-137427

to 16A-138361

from SN GS4616P-138362

to GS4616P-141799

from SN GS46P-141800

Part No. 1273390GT
Rev: B4
September 2019

Order the manual at mid-west-tech.com >

Description	Page
001 Parts Stocking List	**10**
001.1 Parts Stocking List	10
100 Decals	**12**
101.1 Word Decals, GS-2046, Battery Side, ANSI & Australia	12
102.1 Word Decals, GS-2046, Ground Control Side, ANSI and Australia	14
102.2 Word Decals, GS-2046, Ground Control Side, ANSI and Australia	18
103.1 Word Decals, GS-2046, Platform, ANSI	22
104.1 Word Decals, GS-2046, Platform, Australia	24
105.1 Word Decals, GS-2646, Battery Side, ANSI & Australia	26
106.1 Word Decals, GS-2646, Ground Control Side, ANSI and Australia	28
106.2 Word Decals, GS-2646, Ground Control Side, ANSI and Australia	32
107.1 Word Decals, GS-2646, Platform, ANSI	36
108.1 Word Decals, GS-2646, Platform, Australia	38
109.1 Word Decals, GS-3246, Battery Side, ANSI & Australia	40
110.1 Word Decals, GS-3246, Ground Control Side, ANSI and Australia	42
110.2 Word Decals, GS-3246, Ground Control Side, ANSI and Australia	46
111.1 Word Decals, GS-3246, Platform, ANSI	50
112.1 Word Decals, GS-3246, Platform, Australia	52
113.1 Symbol Decals, GS-2046, Battery Side, ANSI & CE	54
114.1 Symbol Decals, GS-2046, Ground Control Side, ANSI and CE	56
114.2 Symbol Decals, GS-2046, Ground Control Side, ANSI and CE	58
115.1 Symbol Decals, GS-2046, Platform, ANSI	60
116.1 Symbol Decals, GS-2046, Platform, CE	62
116.2 Symbol Decals, GS-2046, Platform, CE	64
117.1 Symbol Decals, GS-2646, Battery Side, ANSI & CE	66
118.1 Symbol Decals, GS-2646, Ground Control Side, ANSI and CE	68
118.2 Symbol Decals, GS-2646, Ground Control Side, ANSI and CE	70
119.1 Symbol Decals, GS-2646, Platform, ANSI	72
120.1 Symbol Decals, GS-2646, Platform, CE	74
120.2 Symbol Decals, GS-2646, Platform, CE	76
121.1 Symbol Decals, GS-3246, Battery Side, ANSI & CE	78
122.1 Symbol Decals, GS-3246, Ground Control Side, ANSI and CE	80
122.2 Symbol Decals, GS-3246, Ground Control Side, ANSI and CE	82
123.1 Symbol Decals, GS-3246, Platform, ANSI	84
124.1 Symbol Decals, GS-3246, Platform, CE	86
124.2 Symbol Decals, GS-3246, Platform, CE	88
200 Drive Chassis Components	**90**
201.1 Steer Linkage and Wheels, GS-2046, GS-2646	90
201.2 Steer Linkage and Wheels, GS-3246	94

MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >


Description	Page
202.1 Non-steer Axle Installation, GS-2046	98
202.2 Non-steer Axle Installation, GS-2646	100
202.3 Non-steer Axle Installation, GS-3246	102
203.1 Level Sensor Installation	104
203.2 Level Sensor Installation	108
204.1 Pothole Protection Assembly	110
205.1 Battery Pack Module	114
205.2 Battery Pack Module	116
206.1 Battery Charger	118
206.2 Battery Charger	120
207.1 Power Unit Module (to SN GS4616P-139987)	122
207.2 Power Unit Module (from SN GS4616P-139988)	126
207.3 Power Unit Module (from SN GS4616P-139988)	130
208.1 Ground Controls	134
209.1 Electrical Wiring, GS-2046	138
209.2 Electrical Wiring, GS-2046	142
209.3 Electrical Wiring, GS-2646	146
209.4 Electrical Wiring, GS-2646	150
209.5 Electrical Wiring, GS-3246	154
209.6 Electrical Wiring, GS-3246	158
210.1 Power Cables	162
210.2 Power Cables	164
211.1 Function Manifold and Accumulator Components	166
300 Scissor Components	**168**
301.1 Scissor Assembly Installation	168
302.1 Scissor Assembly, GS-2046	170
303.1 Scissor Assembly, GS-2646	174
304.1 Scissor Assembly, GS-3246	180
400 Platform Components	**186**
401.1 Platform Components	186
402.1 Power to Platform, GS-2046	192
402.2 Power to Platform, GS-2046	196
402.3 Power to Platform, GS-2646	200
402.4 Power to Platform, GS-2646	204
402.5 Power to Platform, GS-3246	208
402.6 Power to Platform, GS-3246	212
403.1 Platform Controls	216
404.1 Joystick Controller	218
500 Hydraulic Components	**220**

MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

Description	Page
501.1 Hydraulic Components	220
501.2 Hydraulic Components	222
502.1 Function Manifold	224
503.1 Brake Release Hand Pump Manifold	228
504.1 Hydraulic Power Unit, All Models	230
505.1 Lift Cylinder Assembly, All Models, GS-2046	232
505.2 Lift Cylinder Assembly, All Models, GS-2646	234
505.3 Lift Cylinder Assembly, All Models, GS-3246	236
506.1 Hydraulic Hoses and Fittings, GS-2046, GS-2646	238
506.2 Hydraulic Hoses and Fittings, GS-3246	242
600 Accessories	**246**
601.1 Alarm, Horn and Flashing Beacons	246
601.2 Alarm, Horn and Flashing Beacons	250
602.1 Air Line to Platform, GS-2046	252
602.2 Air Line to Platform, GS-2646	254
602.3 Air Line to Platform, GS-3246	256
603.1 Platform Work Light, GS-2046	258
603.2 Platform Work Light, GS-2646	260
603.3 Platform Work Light, GS-3246	262
604.1 Voltage Inverter	264
605.1 Pipe Cradle Assembly	266
606.1 Panel Carrier Assembly, GS-2046, GS-2646 (ANSI/CSA models)	268
607.1 RCBO	270
608.1 PCON Guard	272
700 Platform Overload Components	**274**
701.1 Platform Overload	274
Part Number Index	**276**


MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

207.3 Power Unit Module (from SN GS4616P-139988)




MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

603.1 Platform Work Light, GS-2046



MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

607.1 RCBO



MOUNTING LOCATION ON LINKSTACK

MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >