A TEREX BRAND

# Parts Manual

*Serial Number Range*

***Z-34/22*** *from SN Z34F-12000*

***BiEnergy***

***Z-34/DC*** *from SN Z34F-12000*

***Z-34/22N*** *from SN Z34NF-14000*

*Part No. 1284225GT*
*Rev: A6*
*September 2019*



Order the manual at mid-west-tech.com >

## Description — Page

**001 Parts Stocking List ..... 10**

001.1 Parts Stocking List ..... 10

**100 Decals ..... 12**

101.1 Word Decals, Z-34/22N & Z-34/22DC, Chassis/Battery Box ..... 12
101.2 Word Decals, Z-34/22N & Z-34/22DC, Chassis/Battery Box ..... 14
102.1 Word Decals, Z-34/22N & Z-34/22DC, Turntable ..... 16
103.1 Word Decals, Z-34/22N & Z-34/22DC, Boom ..... 18
104.1 Word Decals, Z-34/22N & Z-34/22DC, Platform ..... 20
105.1 Word Decals, Z-34/22BE, Chassis ..... 22
106.1 Word Decals, Z-34/22BE, Turntable ..... 24
107.1 Word Decals, Z-34/22BE, Boom ..... 26
108.1 Word Decals, Z-34/22BE, Platform ..... 28
109.1 Symbol Decals, Z-34/22N & Z-34/22DC, Chassis/Battery Box ..... 30
110.1 Symbol Decals, Z-34/22N & Z-34/22DC, Turntable ..... 32
111.1 Symbol Decals, Z-34/22N & Z-34/22DC, Boom ..... 34
112.1 Symbol Decals, Z-34/22N & Z-34/22DC, Platform ..... 36
113.1 Symbol Decals, Z-34/22BE, Chassis ..... 38
114.1 Symbol Decals, Z-34/22BE, Turntable ..... 40
115.1 Symbol Decals, Z-34/22BE, Boom ..... 42
116.1 Symbol Decals, Z-34/22BE, Platform ..... 44

**200 Chassis Components ..... 46**

201.1 Steer End ..... 46
201.2 Steer End, Z-34/22N ..... 50
202.1 Non-Steer End, Electronic Control Module ..... 54
202.2 Non-Steer End, Electronic Control Module, Z-34/22N ..... 62
203.1 Battery Charger ..... 68
204.1 Battery Packs ..... 70
205.1 Power Cable Diagram, Z-34/22N & Z-34/22DC ..... 74
206.1 Power Cable Diagram, Z-34/22BE ..... 76

**300 Turntable Components ..... 78**

301.1 Turntable Rotator ..... 78
302.1 Ground Control Side, Z-34/22N & Z-34/22DC ..... 82
303.1 Ground Controls Side, Z-34/22BE, View 1 ..... 86
304.1 Ground Controls Side, Z-34/22BE, View 2 ..... 90
305.1 Hydraulic Tank Side, Z-34/22N & Z-34/22DC ..... 92
306.1 Turntable Covers, Z-34/22N & Z-34/22DC ..... 96
307.1 Turntable Covers, Z-34/22BE ..... 100
308.1 Ground Control Panel, Z-34/22N & Z-34/22DC ..... 104



MidWestTech | Terex Genie Z-34/22 BiEnergy, Z-34/DC, Z-34/22N Articulated Boom Lift Par... Order the manual at mid-west-tech.com >

| Description | Page |
|---|---|
| 309.1 Ground Control Box, Z-34/22BE, External View | 106 |
| 310.1 Ground Control Box, Z-34/22BE, Internal View | 110 |
| 311.1 Wire Harness Diagram, Z-34/22N and Z-34/22DC | 114 |
| 312.1 Wire Harness Diagram, Z-34/22BE | 118 |
| **400 Engine Components** | **122** |
| 401.1 Engine Pivot Plate | 122 |
| 402.1 Kubota Z482 E4B, Diesel Engine, View 1 | 128 |
| 403.1 Kubota Z482 E4B, Diesel Engine, View 2 | 132 |
| 404.1 Kubota Z482 E4B, Diesel Engine, View 3 | 136 |
| **500 Boom Components** | **140** |
| 500.1 Boom Layout | 140 |
| 501.1 Secondary Boom, View 1 | 142 |
| 502.1 Secondary Boom, View 2 | 146 |
| 503.1 Upper Pivot | 148 |
| 504.1 Primary and Extension Booms | 150 |
| 505.1 Cable Track | 154 |
| 506.1 Jib Boom and Platform Rotator | 156 |
| **600 Platform Components** | **160** |
| 601.1 Platform | 160 |
| 602.1 Platform Control Box, External View | 166 |
| 603.1 Platform Control Box, Internal View | 170 |
| 604.1 Joystick Controller, Drive/Steer Functions | 174 |
| 605.1 Rotation Controller, Boom Function Speed | 176 |
| **700 Hydraulic Components** | **178** |
| 701.1 Function Manifold | 178 |
| 702.1 Jib Boom and Platform Rotate Manifold | 184 |
| 703.1 Drive Chassis Hoses | 186 |
| 704.1 Turntable Hoses | 188 |
| 705.1 Boom Hoses | 192 |
| 706.1 Hydraulic Power Unit | 194 |
| **800 Accessories** | **196** |
| 801.1 Air Line to Platform | 196 |
| 802.1 Aircraft Protection | 198 |
| 803.1 Auxiliary Rail Assembly | 202 |
| 804.1 Flashing Beacon and Alarm | 204 |
| 805.1 Hostile Environment, Wiper | 206 |
| 806.1 Hostile Environment, Cylinder Bellows | 208 |



MidWestTech | Terex Genie Z-34/22 BiEnergy, Z-34/DC, Z-34/22N Articulated Boom Lift Par... Order the manual at mid-west-tech.com >

| Description | Page |
|---|---|
| 807.1 Cold Start for Bi-Energy | 210 |
| 808.1 Drive Light | 212 |
| 809.1 Inverter, 120V | 214 |
| 810.1 Platform Control Box Cover, Tool Tray and Work Light | 216 |
| 811.1 Platform Half Mesh, Swing Gate and Pipe Cradle | 218 |
| 812.1 Platform Overload, CE and AUS | 220 |
| 813.1 Operators Protection Alarm (to January 2017) | 222 |
| **Part Number Index** | **226** |



MidWestTech | Terex Genie Z-34/22 BiEnergy, Z-34/DC, Z-34/22N Articulated Boom Lift Par... Order the manual at mid-west-tech.com >

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| 20B | 1285850GT | ASSEMBLY,AMBER LIGHT,CONTACT ALARM | |



MidWestTech | Terex Genie Z-34/22 BiEnergy, Z-34/DC, Z-34/22N Articulated Boom Lift Par... Order the manual at mid-west-tech.com >

601.1 Platform

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| 29 | | Ref. Platform Control Box refer to 602.1 and 603.1 | 1 |



MidWestTech | Terex Genie Z-34/22 BiEnergy, Z-34/DC, Z-34/22N Articulated Boom Lift Par... Order the manual at mid-west-tech.com >

813.1 Operators Protection Alarm (to January 2017)

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| 22 | 1255489GT | SENSOR,RUBBER EDGE<br>4-ft and 5-ft platforms | 1 |
| 23 | 1255033GT | HARN,PIGTAIL,TAPESWITCH,OPA | 1 |



MidWestTech | Terex Genie Z-34/22 BiEnergy, Z-34/DC, Z-34/22N Articulated Boom Lift Par... Order the manual at mid-west-tech.com >