A TEREX BRAND

Parts Manual

Serial Number Range

Z-45/22 DC

Z-45/22 GP

from SN 4587-124 to 4592-3600

Part No. 139544

Rev A15

October 2013

MidWestTech | Terex Genie Z-45/22 DC, Z-45/22 GP Articulated Boom Lift Parts Manual | Publication 139544

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals and Paint
101.1 Decals - DC Models - View 1....10
101.2 Decals - DC Models - View 2....12
101.3 Decals - DC Models - View 3....14
102.1 Decals - GP Models - View 1....16
102.2 Decals - GP Models - View 2....18
102.3 Decals - GP Models - View 3....20

200 Drive Chassis Module
201.1 Steering Linkage Installation....22
202.1 Battery Box Assembly....24
203.1 Battery and LP Tank Installation....26
204.1 Fuel Tank Assembly....28
205.1 Rotation Limit Switch Assembly....30
206.1 Hydraulic Tank Assembly....32
207.1 Hydraulic Assembly - Drive....34
208.1 Drive Installation - DC Model....36
209.1 Battery Charger Assembly....38
210.1 Power Panel Assembly - DC Models....40
211.1 Drive Installation - GP Models....42
212.1 LPG Regulator/Vaporizer Assembly....46
213.1 Power Panel Assembly - GP Models....48
214.1 12 Volt Start Panel Assembly....50
215.1 Drive Manifold....52

300 Swing Chassis Module
301.1 Swing Chassis Covers....54
302.1 AC Power To Plaform Source....56
303.1 Swing Drive Motor/Brake Installation....58
304.1 Function Manifold and Ground Controls Installation....60
305.1 Ground Station Control Box Assembly....62
306.1 Ground Station Control Box Controls....64
307.1 Function Manifold....66

400 Boom Elevate Module
401.1 Elevate Assembly....68
402.1 Elevate Cylinder Assembly....70
403.1 Boom Reach Pivot Installation....72


500 Boom Reach Module
501.1 Cable and Hose Track Assembly....74
502.1 Primary Boom Assembly, "Short Nose" (from SN 4587-1420)....76
503.1 Primary Boom Assembly, "Long Nose" (to SN 4587-1419)....78
504.1 Boom Extension Assembly, "Short Nose" (from SN 4587-1420)....80
505.1 Boom Extension Assembly, "Long Nose" (to SN 4587-1419)....82

600 Platform Module
601.1 Platform Assembly....84
602.1 Platform Gearbox Assembly....86
603.1 Platform Control Box Assembly....88
604.1 Platform Controls....90
605.1 Footswitch Assembly....92

Indices
Part Number Index....94
Part Description Index....97


Cross References
Fittings Cross Reference....102

MidWestTech | Terex Genie Z-45/22 DC, Z-45/22 GP Articulated Boom Lift Parts Manual |... Order the manual at mid-west-tech.com >



MidWestTech | Terex Genie Z-45/22 DC, Z-45/22 GP Articulated Boom Lift Parts Manual |... Order the manual at mid-west-tech.com >

605.1 Footswitch Assembly



MidWestTech | Terex Genie Z-45/22 DC, Z-45/22 GP Articulated Boom Lift Parts Manual |... Order the manual at mid-west-tech.com >

This Page Intentionally Left Blank

MidWestTech | Terex Genie Z-45/22 DC, Z-45/22 GP Articulated Boom Lift Parts Manual |... Order the manual at mid-west-tech.com >