
SERVICE MANUAL

RS45, RS46



FORM 1458785 Rev. 12/03

MidWestTech | Hyster RS45, RS46 Reach Stacker Service Manual | Publication 1458785 Order the manual at mid-west-tech.com >

RS45, RS46
SERVICE MANUAL CONTENTS

Section	SRM Number	Rev Date
FRAME	0100 SRM 0631	09/97
FOUR-SPEED PS TRANSMISSION-DESCR / OPER	1300 SRM 0634	11/03
FOUR-SPEED PS TRANSMISSION-REPAIR	1300 SRM 0635	11/03
DIFFERENTIAL	1400 SRM 0046	11/03
PLANETARY GEAR AXLE	1400 SRM 0047	11/03
STEERING SYSTEM	1600 SRM 0637	10/97
STEERING AXLE	1600 SRM 0639	04/98
BRAKE SYSTEM	1800 SRM 0640	09/99
BRAKE SYSTEM (SN A222E1533 AND UP)	1800 SRM 0979	06/01
ACCUMULATOR	1800 SRM 1036	09/02
PARKING BRAKE	1800 SRM 1037	02/03
SERVICE BRAKES (Later Units)	1800 SRM 1038	11/03
AUXILARY BRAKE CALIPER	1800 SRM 1040	04/03
HYDRAULIC SYSTEM	1900 SRM 0641	01/98
LOAD SENSING SYSTEM-TROUBLESHOOTING	1900 SRM 0642	11/97
HYDRAULIC SYSTEM (SN A222E1533 AND UP)	1900 SRM 0953	02/01
HYDRAULIC PUMPS	2000 SRM 0644	10/97
INSTRUMENT PANEL INDICATORS and SENDERS	2200 SRM 0143	12/03
ELECTRICAL SYSTEM	2200 SRM 0647	01/98
CONTAINER ATTACHMENT	4500 SRM 0648	01/98
BOOM	4500 SRM 0649	01/98
EXTENDABLE CONTAINER ATTACHMENT	5000 SRM 0776	11/03
INTERMODAL CONTAINER ATTACHMENT	5000 SRM 0777	04/00
INCH (SAE) and METRIC FASTENERS	8000 SRM 0231	03/03
PERIODIC MAINTENANCE	8000 SRM 0592	06/00
DIAGRAMS	8000 SRM 0594	01/98
CAPACITIES and SPECIFICATIONS	8000 SRM 0616	02/98
CAPACITIES and SPECIFICATIONS (SN 1222E1533 and UP)	8000 SRM 0949	12/00
PERIODIC MAINTENANCE (SN A222E1533 AND UP)	8000 SRM 0950	12/00
DIAGRAMS (SN A222E1533 AND UP)	8000 SRM 0952	02/01
PERIODIC MAINTENANCE - TIER 2 EMISSIONS ENGINE	8000 SRM 1051	04/03

PART NO. 1458785

Rev. 12/03

MidWestTech | Hyster RS45, RS46 Reach Stacker Service Manual | Publication 1458785 Order the manual at mid-west-tech.com >