
snorkel

# S4732E




CE

# REPAIR PARTS MANUAL

Part Number 1502792
September 2017

Serial number 000000 and after
Replaces 1501797 July 2016


Order the manual at mid-west-tech.com >

| Objekt | Teilenr. | Name | Anzahl | Maßeinheit (ME) |
|---|---|---|---|---|
| - | 1503022FR | DECAL ASSEMBLY CSA S4732E FRENCH | | EA |
| 1 | 0073043FR | DECAL OPERATING INFORMATION INSIDE, FRENCH | 1 | EA |
| 2 | 0073224FR | DECAL MANUAL REORDER FRENCH | 1 | EA |
| 3 | 0074311FR | DECAL, DANGER CYLINDER FAILURE, FRENCH | 3 | EA |
| 4 | 0083427 | DECAL, ANCHOR TIE-DOWN/LIFT | 4 | EA |
| 5 | 508862-000 | DECAL, OPERATORS CHECKLIST | 1 | EA |
| 6 | 508863-000 | DECAL - BEWARE DESCENDING PLAT | 1 | EA |
| 7 | 511176-000 | DECAL DNGR TIPOVER HAZARD | 2 | EA |
| 8 | 508867-000 | DECAL, CYLINDER DANGER | 2 | EA |
| 9 | 0361533 | DECAL, EMERGENCY BLEED DOWN | 1 | EA |
| 10 | 0361661FR | DECAL, ANSI/CSA COMPLIANT | 1 | EA |
| 11 | 1502097FR | DECAL CHK BTRY BEFORE CHARGING | 2 | EA |
| 12 | 451986FR | DECAL. DNGR DO NOT ALTER SW | 1 | EA |
| 13 | 501453-000 | DECAL, FOOT TRAP | 2 | EA |
| 14 | 512224-000 | DECAL, SNORKEL | 3 | EA |
| 15 | 969249 | DECAL, STRIPE YE/BLK 2" | 47 | A/R |
| 16 | 1500839 | DECAL S4732E MODEL | 2 | EA |
| 17 | 1500840 | DECAL, FORKLIFT | 2 | EA |
| 18 | 1500842FR | MANUAL, OPERATORS S3219E CE | 1 | EA |
| 19 | 1501475FR | DECAL, DNGR TIPOVER/ELEC HAZARD LH | 1 | EA |
| 20 | 1501476FR | DECAL, DNGR TIPOVER/ELEC HAZARD RH | 1 | EA |



MidWestTech | Snorkel S4732E Scissor Lift Repair Parts Manual | Publication 1502792(2) Order the manual at mid-west-tech.com >

| Objekt | Teilenr. | Name | Anzahl | Maßeinheit (ME) |
|---|---|---|---|---|
| - | 6047139 | CYLINDER STEER BLK-PB | | EA |
| 1 | 6047139 | CYLINDER STEER BLK-PB | 1 | EA |
| * | 6047207 | SEAL KIT-PB | | |
| 500 | 6091710 | SEAL KIT- ROSENBOOM | 1 | EA |
| 6 | KIT ITEM | O-RING | 1 | EA |
| 7 | KIT ITEM | O-RING | 2 | EA |
| 8 | KIT ITEM | BACKUP RING DYNAMIC | 2 | EA |
| 9 | KIT ITEM | BACKUP RING | 2 | EA |
| 10 | KIT ITEM | DISO-PAC | 1 | EA |
| 11 | KIT ITEM | BT U-CUP | 2 | EA |
| 12 | KIT ITEM | HD ROD WIPER, SEALED OD | 2 | EA |
| 13 | KIT ITEM | WEARBAND | 1 | EA |
| 14 | KIT ITEM | ROUND WRAP-IN WIRE | 1 | EA |
| 15 | KIT ITEM | SQUARE WRAP-IN WIRE | 2 | EA |



MidWestTech | Snorkel S4732E Scissor Lift Repair Parts Manual | Publication 1502792(2) Order the manual at mid-west-tech.com >


Anhang B:Teileverzeichnis


000561-000 2-72
0071584 5-13
0073043 2-74, 2-75, 2-76, 2-77, 2-79, 2-80, 2-81, 2-83, 2-84, 2-85, 2-86
0073043CN 2-78
0073043FR 2-87
0073043P 2-88
0073224 2-74, 2-75, 2-76, 2-77, 2-79, 2-80, 2-81, 2-83, 2-84, 2-85, 2-86
0073224CN 2-78
0073224FR 2-87
0073224P 2-88
0074311 2-74, 2-75, 2-76, 2-77, 2-79, 2-80, 2-81, 2-83, 2-84, 2-85, 2-86
0074311CN 2-78
0074311FR 2-87
0074311P 2-88
0083426 2-74, 2-76
0083427 2-75, 2-77, 2-78, 2-79, 2-80, 2-81, 2-83, 2-84, 2-85, 2-86, 2-87, 2-88, 2-88
0084468 2-48
0084470 2-48
0084826 5-17
0084827 5-17
009442-003 2-62, 2-65, 2-66
010154-000 2-28, 2-30, 2-31
0101800 5-34
011239-010 2-4, 2-5
0162311 2-74, 2-77, 2-78, 2-83
0181276 5-12
0181276-3 5-12
0181562 2-84
0181562ES 2-88
026551-004 2-46, 2-47, 2-48, 2-49, 2-52, 2-53, 2-54, 2-55, 2-56, 2-57, 2-58, 2-59, 2-61, 2-65, 2-66, 2-67, 4-17, 5-21, 5-22
030899-002 5-21, 5-22, 5-28, 5-29, 5-30, 5-34, 5-46
031051-040 5-21, 5-22, 5-23
031051-082 5-21, 5-22, 5-23
0351039 2-19, 2-20, 2-21, 2-22, 2-23, 2-24, 2-25, 2-26
0361259 2-74, 2-75, 2-76, 2-77, 2-79, 2-80, 2-81, 2-83, 2-84, 2-85, 2-86
0361259CN 2-78
0361259P 2-88
0361367 2-74, 2-75, 2-76, 2-77, 2-79, 2-80, 2-81, 2-83, 2-84, 2-85, 2-86, 2-87, 2-88
0361533 2-74, 2-75, 2-76, 2-77, 2-78, 2-79, 2-80, 2-81, 2-83, 2-84, 2-85, 2-86, 2-87, 2-88
0361562 2-74, 2-76
0361661 2-85, 2-86
0361661FR 2-87
0372063 2-74, 2-76
0410091 5-34
056057-055 2-41, 2-45
056059-025 2-3, 2-51
056059-100 2-41, 2-45
056060-050 2-47, 5-21
056060-055 2-46, 2-47, 2-48, 2-49, 2-52, 2-53, 2-54, 2-55, 2-56, 2-57, 2-58, 2-59, 2-60, 2-61, 2-62, 2-63, 2-64, 2-65, 2-66, 2-69, 5-21
056060-060 2-46, 2-48, 2-49, 2-67, 2-69, 5-18
056060-065 2-47, 2-52, 2-53, 2-54, 2-55, 2-56, 2-57, 2-58, 2-59, 2-60, 2-61, 2-62, 2-63, 2-64, 2-65, 2-66, 5-21, 5-38
056060-070 2-67




MidWestTech | Snorkel S4732E Scissor Lift Repair Parts Manual | Publication 1502792(2) Order the manual at mid-west-tech.com >

| EZ230 CONNECTIONS | |
|---|---|
| P1-1 | 5V TO JOYSTICK (LOW CURRENT) |
| P1-3 | 0V TO JOYSTICK (LOW CURRENT) |
| P1-4 | Joystick analog input |
| P1-7 | LOW BATTERY LIGHT (0V) |
| P1-8 | OVERLOAD LIGHT (0V) |
| P1-9 | FLASHING LIGHT (0V) |
| P2-2 | ANGLE SENSOR #1 INPUT |
| P2-3 | 0V (LOW CURRENT) |
| P2-4 | PRESSURE SENSOR INPUT |
| P2-5 | ANGLE SENSOR #2 INPUT |
| P2-7 | SENSOR VOLTAGE (LOW CURRENT) |
| P2-8 | STACK LOWER (0V = ACTIVE) |
| P2-9 | OVERLOAD AND MOTION ALARM |
| P3-1 | PLATFORM INPUT |
| P3-2 | VALVE SUPPLY |
| P3-3 | 2-SPEED SWITCH (B+ = ACTIVE) |
| P3-6 | DRIVE SWITCH (B+ = ACTIVE) |
| P3-7 | LIFT SWITCH (B+ = ACTIVE) |
| P3-8 | STEER RIGHT (B+ = ACTIVE) |
| P3-9 | STEER LEFT (B+ = ACTIVE) |
| P3-12 | JOYSTICK ENABLE (B+ = ACTIVE) |
| P4-1 | GROUND CONTROL INPUT |
| P4-3 | LOADING CONTROL ENABLE |
| P4-4 | GROUND CONTROL LOWER |
| P4-5 | GROUND CONTROL LIFT |
| P4-7 | POTHOLE SENSOR INPUT |
| P4-8 | LOADING - STEER LEFT |
| P4-9 | LOADING - STEER RIGHT |
| P4-11 | LOADING - DRIVE FORWARD |
| P4-12 | LOADING - DRIVE REVERSE |
| P5-1 | CONTACTOR OUTPUT |
| P5-2 | FORWARD VALVE OUTPUT |
| P5-3 | REVERSE VALVE OUTPUT |
| P5-6 | STEER LEFT VALVE OUTPUT |
| P5-8 | STEER RIGHT VALVE OUTPUT |
| P5-9 | 2 SPEED VALVE OUTPUT |
| P5-11 | LIFT VALVE OUPUT |
| P5-12 | LOWER VALVE OUTPUT |
| P6-1 | DISPLAY SUPPLY |
| P6-2 | DISPLAY RECEIVE |
| P6-3 | DISPLAY TRANSMIT |
| P6-4 | DISPLAY 0V RETURN |





Order the manual at mid-west-tech.com >