
Motiverition | Terex TR45 Cummins QSK19-C525 Off-Highway Truck Parts Manual | Publication 15272702



TEREX

Parts Book

Part Number 15272702

TR45 Off-Highway Truck

(Cummins QSK19-C525 Powered)

From Serial No. T7541001

17 August 98
Revised Feb 00

PUBLISHED BY:
TECHNICAL PUBLICATIONS DEPARTMENT

TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND

Order the manual at mid-west-tech.com »

Truck

TEREX

STANDARD SECTIONS

CHASSIS	100
ENGINE	110
TRANSMISSION	120
DRIVELINE	130
FRONT AXLE	140
REAR AXLE	160
BRAKE PARTS	165
SUSPENSION SYSTEM	180
ELECTRICAL SYSTEM	190
FUEL SYSTEM	200
COOLING SYSTEM	210
STEERING SYSTEM	220
BODY SYSTEM	230
BRAKING SYSTEM	250
CAB	260
BODY	270
DECALS	290
MISCELLANEOUS	300

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS FOR MODEL TR45 QSK19C ENG FROM SERIAL NO T7541001 01/02/00

SECT - PAGE - PLI DESCRIPTION

SECTION 100 CHASSIS
100 - 0010 - 7541 CHASSIS
100 - 0040 - 7541 HOOD AND MOUNTING
100 - 0070 - 7541 FENDERS AND MOUNTING
100 - 0090 - 7541 LADDERS AND HANDRAILS
100 - 0100 - 7541 RADIATOR GUARD AND MOUNTING
100 - 0140 - 7541 MUDGUARDS

SECTION 110 ENGINE
110 - 0020 - 7541 ENGINE ORDERING INSTRUCTIONS
110 - 0030 - 7541 ENGINE AND MOUNTING R1 01-99
110 - 0050 - 7541 AIR CLEANER
110 - 0060 - 7541 AIR CLEANER PIPES AND HOSES
110 - 0070 - 7541 EXHAUST AND MOUNTING R1 01-99
110 - 0070 - 7541 EXHAUST AND MOUNTING 01-99
110 - 0130 - 7541 POWER TAKEOFF - ENG PTO
110 - 0130 - 7541 POWER TAKEOFF - ENG PTO 01-99

SECTION 120 TRANSMISSION
120 - 0010 - 7541 TRANSMISSION MOUNTING R1 01-99
120 - 0010 - 7541 TRANSMISSION MOUNTING 01-99
120 - 0020 - 7541 TRANSMISSION BREAKDOWN
120 - 0020 - 7541 TRANSMISSION BREAKDOWN 01-99
120 - 0050 - 7541 CONTROL VALVE
120 - 0070 - 7541 SHIFT CONTROL R2 02/00
120 - 0090 - 7541 POWER TAKEOFF - TRANS
120 - 0100 - 7541 FILTER
120 - 0110 - 7541 OIL LINES-TRANSMISSION
120 - 0200 - 7541 FRONT COVER & CONVERTER GROUP
120 - 0210 - 7541 CONVERTER HOUSING GROUP
120 - 0220 - 7541 OIL PUMP
120 - 0230 - 7541 FILTER ADAPT/REGULATOR VALVES
120 - 0240 - 7541 LOCKUP VALVE
120 - 0250 - 7541 ATEC LOCKUP DROP OUT
120 - 0260 - 7541 RETARDER GROUP
120 - 0280 - 7541 SPLITTER GEARING AND CLUTCHES
120 - 0290 - 7541 MAIN HOUSING GROUP
120 - 0300 - 7541 HIGH RANGE GEARING & CLUTCHES
120 - 0310 - 7541 INTER RANGE GEARING & CLUTCHES
120 - 0320 - 7541 LOW RANGE GEARING & CLUTCHES
120 - 0330 - 7541 REV RANGE GEARING & CLUTCHES

SECT - PAGE - PLI DESCRIPTION

SECTION 120 TRANSMISSION
120 - 0340 - 7541 REAR COVER GROUP
120 - 0360 - 7541 THROTTLE SENSOR AND MOUNTING R1 01-99

SECTION 130 DRIVELINE
130 - 0010 - 7541 FRONT DRIVELINE
130 - 0010 - 7541 FRONT DRIVELINE 01-99
130 - 0020 - 7541 REAR DRIVELINE
130 - 0020 - 7541 REAR DRIVELINE 01-99

SECTION 140 FRONT AXLE
140 - 0040 - 7541 WHEEL, RIM AND TYRE-FRONT

SECTION 160 REAR AXLE
160 - 0020 - 7541 DIFFERENTIAL-REAR
160 - 0020 - 7541 DIFFERENTIAL-REAR 01-99
160 - 0030 - 7541 AXLE GROUP-REAR R1 01-99
160 - 0040 - 7541 PLANETARY GEARING-REAR R1 01-99
160 - 0050 - 7541 WHEEL, RIM AND TYRE-REAR

SECTION 165 BRAKE PARTS
165 - 0020 - 7541 BRAKE PARTS-FRONT WHEEL-RIGIDS
165 - 0030 - 7541 BRAKE PARTS-REAR WHEEL-RIGIDS R1 01-99
165 - 0030 - 7541 BRAKE PARTS-REAR WHEEL-RIGIDS 01-99

SECTION 180 SUSPENSION SYSTEM
180 - 0030 - 7541 FRONT RIDE CYLINDER
180 - 0050 - 7541 REAR RIDE CYLINDER

SECTION 190 ELECTRICAL SYSTEM
190 - 0010 - 7541 TERMINALS
190 - 0011 - 7541 CONNECTORS
190 - 0030 - 7541 CABLES/HARNESSES-CAB
190 - 0040 - 7541 CABLES/HARNESSES-CHASS/ENG R1 01-99
190 - 0040 - 7541 CABLES/HARNESSES-CHASS/ENG 01-99
190 - 0070 - 7541 BATTERY AND CABLES
190 - 0080 - 7541 BATTERY MOUNTING
190 - 0100 - 7541 ELECTRICAL LIGHTING SYSTEM
190 - 0210 - 7541 REVERSE ALARM
190 - 0270 - 7541 SWITCHES AND SENSORS R1 01-99

MidWestTech | Terex TR45 Cummins QSK19-C525 Off-Highway Truck Parts Manual | Publication 15272702 Order the manual at mid-west-tech.com >

100-0140-7541 MUDGUARDS
FROM SERIAL NO. T7541001

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	001	001	15249109	MUDFLAP		
	002	001	15249123	ANGLE-MOUNTING		
	003	001	15255372	ANGLE-MOUNTING		
	004	048	00179885	BOLT		
	005	054	00103329	LOCKWASHER		
	006	036	00120378	NUT		
	007	001	15255371	MUD FLAP		
	008	001	15233492	PLATE-MOUNTING		
	009	001	15255381	PLATE-CLAMPING		
	010	001	15300760	MUDFLAP		
	011	001	15300761	ANGLE		
	012	001	15300756	CLAMP PLATE		
	013	002	15302137	MUDFLAP		
	014	002	09013704	BAR		
	015	002	15300750	MUDFLAP		
	016	002	15300753	PLATE		
	017	001	15300755	BRACKET		
	018	006	00179883	BOLT		
	019	001	15300754	CLAMP PLATE		
	020	001	15302138	MUDFLAP		
	021	001	15300823	CLAMP PLATE		
	022	001	15300824	CLAMP PLATE		

Order the manual at mid-west-tech.com >

120-0220-7541 OIL PUMP
FROM SERIAL NO. T7541001

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	001	004	00179845	BOLT		
	002	004	00103321	LOCKWASHER		
	003	001	06758218	GASKET		
	004	006	09418964	BOLT		
	005	006	00103321	LOCKWASHER		
	006	004	00179839	BOLT		
	007	004	09415545	WASHER		
	008	001	06769729	TUBE-FLANGED		
	009	001	06758218	GASKET		
	010	001	06880125	PUMP ASSY		
	011	004	00103321	.LOCKWASHER		
	012	004	00179848	.BOLT		
	013	001	06834181	.BODY-SCAV		
	014	001	06834182	..PUMP BODY		
	015	002	00148415	..BEARING		
	016	001	06758530	.ROLLER		
	017	002	06834180	.GEAR		
	018	001	06769413	.GASKET		
	019	001	06834183	.PLATE		
	020	001	06838429	..STOP		
	021	001	06834184	..PLATE		
	022	001	06838429	..STOP		
	023	001	06769722	.GEAR-DRIVE		
	024	001	06769720	.GEAR-DRIVE		
	025	001	06756124	.GASKET		
	026	001	06880127	.BODY ASSY		
	027	002	00148415	..BEARING		
	028	001	06880128	..BODY-INPU		
	029	006	06880124	.RING-STAR		
	030	001	06776451	SCREEN		
	031	001	06756002	GASKET		
	032	001	06881547	COUPLING		

Order the manual at mid-west-tech.com >

260-0010-7541 CAB ASSEMBLY
FROM SERIAL NO. T7541001

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	075	010	15270895	.PLATE		
	076	001	15270793	.DOOR ASSY		
	077	003	15270781	.BOLT		
	078	003	15270840	.WASHER		
	079	002	15270798	.STOPPER		
	080	001	15270797	.LOCK		
	081	002	15270799	.SCREW		
	082	001	15270794	.FILTER-AIR		
	083	001	15270796	.SUPPORT-FILTER		
	084	007	15270781	.BOLT		
	085	007	15270840	.WASHER		
	086	007	15270832	.WASHER		
	087	007	15270833	.NUT		
	088	ASR	15272067	.HOSE BULK-PLASTIC		
	089	004	15272068	.RING-PLASTIC		
	090	002	15272069	.STRIKER		
	091	006	15272070	.SCREW		
	092	006	15271185	.WASHER		
	093	002	15272052	.NUT		
	094	001	15272071	.CONSOLE		
	095	006	06441020	.BOLT		
	096	006	15270800	.WASHER		
	097	001	15272072	.PLATE		
	098	006	15270829	.SCREW		
	099	001	15272073	.SUPPORT		
	100	002	15270840	.WASHER		
	101	002	15270833	.NUT		
	102	001	15272074	.COVER		
	103	001	15272075	.LATCH		
	104	001	15272076	.ROD		
	105	002	15272077	.CLIP		
	106	001	15272078	.COVER-SIDE		
	107	007	15270829	.SCREW		
	108	001	15272079	.SUPPORT-LEVER		
	109	003	15270840	.WASHER		
	110	003	15270833	.NUT		
	111	001	15272080	.CONSOLE-SHIFT		
	112	001	15270896	.PLASTIC HOSE-BULK		
	113	001	15270895	.PLATE		
	114	006	15272082	.CAP PLASTIC		
	115	002	15270858	.WASHER		
	116	001	15270789	.SCREW		
	117	001	15272062	.WASHER		
	118	006	15272068	.RING-PLASTIC		
	119	006	15272052	.NUT		
	120	004	15270921	.NUT		
	121	001	15272083	.TRIM PANEL-SIDE FIX		
	122	003	15270754	.SCREW		
	123	001	15272084	.TRIM PANEL-ROOF FIX		
	124	001	15272085	.BUTTON		
	125	001	15270992	.PLATE-IDENTITY		
	126	001	15272265	.PLATE		
	127	001	15272086	.TRIM-REAR SIDE LH		
	128	001	15272087	.TRIM-REAR SIDE RH		
	129	001	15272088	.TRIM-FRONT SIDE LH		
	130	001	15272089	.TRIM-FRONT SIDE RH		
	131	002	15272090	.UPPER FIXATION		
	132	002	15272091	.LOWER FIXATION		
	133	008	15270871	.RIVET		
	134	001	15272092	.TRIM-REAR UPPER		
	135	001	15272093	.TRIM-REAR LOWER		
	136	001	15272094	.UPPER FIXATION-REAR		
	137	003	15270829	.SCREW		
	138	001	15272266	.INSULATION		
	139	008	15272267	.SOCKET		
	140	001	15271180	.SUPPORT-BOTTLE RACK		
	141	002	15270845	.SCREW		
	142	001	15271004	.SUPPORT-GLASS		

Order the manual at mid-west-tech.com >