
MidwestTech | Terex TS14G Detroit Diesel Series 40E Overhung Scraper Parts Manual | Publication 15273661



TEREX

Parts Book

Part Number 15273661

TS14G Overhung Scraper

(Detroit Diesel Series 40E Powered)

From Serial No. S7901001

Mar 00
Revised Feb 02

PUBLISHED BY:
PRODUCT SUPPORT DEPARTMENT

TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND

Order the manual at midwest-tech.com >

INDENTATIONS - Parts which are indented under another part are Sub-groups of a Major Assembly or Sub-assembly. Parts which are not indented are major assemblies or individual component parts which do not belong to a major assembly.

EXAMPLE -	1	9052564	Pump Assy.
	2	9058512	. Shaft
	3	9024169	. Ring
	4	9058132	. Control Assy.
	5	9058135	. . Spring
	6	9072162	Gasket

- If you order Item 1, you will receive Items 1 - 5.
- If you order Item 4, you will receive Items 4 and 5.
- If you order Item 6, you will receive only Item 6.

NOTES - Whenever there is an alphabetical symbol to the left of the item number, refer to the corresponding note at the bottom of the form for information regarding ordering or application of the particular part number(s) noted.

ABBREVIATIONS - The abbreviations in this book have the following meanings -

Amps ..... Amperes	Hsg ..... Housing	N.I ..... Not Illustrated
As R ..... As Required	I.D ..... Inside Diameter	N.L.A ..... No Longer Available
Assy ..... Assembly	L.H ..... Left Hand	N.S.S ..... Not Sold Separately
Brkt ..... Bracket	L.W ..... Lockwasher	O.D ..... Outside Diameter
Cad-Pltd ..... Cadium Plated	Lg ..... Long	Pr ..... Pair
Comm ..... Commencement of production	Lkg ..... Linkage	P.T.O ..... Power-Take-Off
E.S.N ..... Elastic Stop Nut	Mtg ..... Mounting	R.H ..... Right Hand
Ftgs ..... Fittings	N.C ..... Note Code	Std ..... Standard

Order the manual at mid-west-tech.com >

110-0050-7911 AIR CLEANER
FROM SERIAL NO. S7901001

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	001	001	15257411	AIR CLEANER		
	002	001	15271478	.ELEMENT ASSY-MAIN		
	003	001	15271479	.ELEMENT ASSY-SAFETY		
	004	001	15271480	.COVER-END		
	005	001	15270191	..LATCH		
	006	001	15270192	.VALVE-VACUATOR		

Order the manual at mid-west-tech.com >

120-0790-7911 MAIN CASE GROUP
FROM SERIAL NO. S7901001

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	001	001	15271489	HOUSING-REAR		
	002	001	15270641	HOUSING-FRONT		
	003	001	15270642	GASKET		
	004	001	15270643	MANIFOLD-SUCTION		
	005	001	15270644	SCREEN-SUCTION		
	006	001	15270645	TUBE-SUCTION		
	007	002	15270646	FITTING		
	008	002	15270581	CAPSCREW		
A	009	001	15271490	DIPSTICK		
A	010	001	15270648	TUBE-DIPSTICK		
	011	006	15271491	HOSE		
	012	001	15271492	PLUG		
	013	002	15270651	CAPSCREW		
	014	001	15270556	O RING		
	015	003	15270652	PIN-DOWEL		
	016	018	15270534	SCREW		
	017	001	15270653	PLUG		
	018	001	15271493	SENSOR-MAG PICKUP		
	019	002	15270560	O RING		
	020	001	15270558	COVER-MAG PICKUP		
	021	002	15270559	SCREW		
	022	002	15270561	LOCKWASHER		
	023	002	15270562	WASHER		
	024	001	15270655	BUSHING-INPUT		
	025	001	15270656	TROUGH-OIL		
	026	002	15270657	CAPSCREW		
	027	004	15270658	SLEEVE-BORE		
	028	002	15271495	CLAMP		
	029	001	15271496	RING-SNAP		
	030	001	15271484	SENSOR-MAG PICKUP		
	031	001	15271497	O-RING		
	032	002	15270659	PLUG		
	033	001	15270660	TUBE-BAFFLE SUCTION		
	034	001	15270661	GASKET		
	035	001	15270662	PLUG-CUP		
	036	002	15270663	CUP-BEARING		
	037	001	15270664	VALVE-LUBE		
	038	001	15270665	PLATE-IDENTIFICATION		
	039	002	15270666	SCREW		
	040	001	15271494	ELBOW		

120-0790-7911 MAIN CASE GROUP
FROM SERIAL NO. S7901001

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	041	001	15270668	BRACKET		

NOTES:
A NOTE: REAR TRANSMISSION ONLY, ITEMS 9 AND 10 NOT USED, REPLACED BY TEREX PARTS, REFER TO TRAILER SECT 120-0010

Order the manual at mid-west-tech.com >

260-0010-7911 CAB ASSEMBLY
FROM SERIAL NO. S7901047

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	081	001	15273514	..BOX RH		
	082	004	15270829	..SCREW		
	083	001	15305227	..FRESH AIR FILTER KIT		
	084	004	15270900	..SCREW		
	085	004	15270790	..WASHER		
	086	001	15273515	..RH CONSOLE		
	087	011	15270829	..SCREW		
	088	002	15273516	..NUT		
	089	001	15273517	..COVER		
	090	002	15270829	..SCREW		
	091	001	15273518	..LOWER LINER LH		
	092	001	15273519	..REAR LOWER LINER		
	093	001	15273520	..LOWER LINER RH		
	094	001	15273521	..REAR LOW PILLAR LINE		
	095	002	15270829	..SCREW		
	096	001	15273522	..FRT LOW PILLAR LINE		
	097	002	15270829	..SCREW		
	098	001	15273523	..FRT UPP PILLAR LINE		
	099	ASR	15270920	..TAPE-ADHESIVE		
	100	002	15270829	..SCREW		
	101	001	15273516	..NUT		
	102	003	15270829	..SCREW		
	103	001	15273524	..FRT UPP PILLAR LINE		
	104	003	15270829	..SCREW		
	105	001	15273516	..NUT		
	106	002	15273525	..LINER SUPPORT		
	107	004	15270845	..SCREW		
	108	002	15273526	..WASHER		
	109	001	15273527	..REAR UPP PILLAR LINE		
	110	004	15270829	..SCREW		
	111	002	15273516	..NUT		
	112	001	15273528	..REAR UPP PILLAR LINE		
	113	002	15273529	..GROMMET		
	114	002	15270829	..SCREW		
	115	002	15273516	..NUT		
	116	001	15271004	..MUG/CAN HOLDER		
	117	001	15271180	..SUPPORT-BOTTLE RACK		
	118	002	15270845	..SCREW		
	119	002	15271183	..SCREW		
	120	001	15270861	..HAMMER		

260-0010-7911 CAB ASSEMBLY
FROM SERIAL NO. S7901047

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	121	002	15270871	..RIVET		
	122	001	15271322	..STRAP		
	123	001	15273530	..FRONT UPPER LINER		
	124	009	15270829	..SCREW		
	125	001	15270757	..SUNBLIND		
	126	002	15270845	..SCREW		
	127	002	15270829	..SCREW		
	128	001	15273531	..REAR UPPER LINER		
	129	003	15270829	..SCREW		
	130	001	15273532	..UPPER LINER LH		
	131	008	15270829	..SCREW		
	132	001	15273533	..UPPER LINER RH		
	133	008	15270829	..SCREW		
	134	001	15271362	..LIGHT-CAB INTERIOR		
	135	002	15270845	..SCREW		
	136	001	15273534	..ROOF LINER		
	137	001	15273535	..LINER FIXATION LH		
	138	002	15270829	..SCREW		
	139	001	15273536	..REAR LINER FIXATION		
	140	003	15270829	..SCREW		
	141	001	15273537	..EXTERIOR INSUL RH		
	142	001	15273538	..EXTERIOR INSUL RH		
	143	ASR	15270896	..HOSE-BULK PLASTIC		
	144	ASR	15270896	..HOSE-BULK PLASTIC		
	145	ASR	15270896	..HOSE-BULK PLASTIC		
	147	001	15273539	..INTERIOR HANDLE		
	148	002	15273540	..SCREW		
	149	002	15270790	..WASHER		
	150	001	15270847	..NUT		
	151	003	15272057	..SCREW		
	152	001	15273541	..DOOR LOCKING BOLT		
	153	003	15273540	..SCREW		
	154	003	15271185	..WASHER		
	155	003	15272052	..NUT		
	156	003	15272057	..SCREW		
	157	004	15272267	..SOCKET		
	158	004	15272053	..LIFTING EYE NUT		
	159	004	15270873	..WASHER		
	160	004	15270874	..WASHER-FIBRE		
	161	001	15270992	..PLATE-IDENTITY		

MidWestTech | Terex TS14G Detroit Diesel Series 40E Overhung Scraper Parts Manual | Publication 15273661

Order the manual at mid-west-tech.com >

MidWestTech | Terex TS14G Detroit Diesel Series 40E Overhung Scraper Parts Manua...

TABLE OF CONTENTS FOR MODEL TS14G TRACT FROM SERIAL NO S7901001 22/02/02

SECT - PAGE - PLI	DESCRIPTION	
SECTION 100	**CHASSIS**	
100-0010-7911	CHASSIS	R1 04/01
100-0040-7911	HOOD AND MOUNTING	
100-0040-7911	HOOD AND MOUNTING	R1 04/01
100-0040-7911	***HOOD AND MOUNTING***	***R1 02/02***
100-0070-7911	FENDERS AND MOUNTING	R1 04/01
100-0070-7911	FENDERS AND MOUNTING	04/01
100-0100-7911	RADIATOR GUARD AND MOUNTING	
100-0100-7911	RADIATOR GUARD AND MOUNTING	ECN 102340
100-0130-7911	***DRAWBAR AND STEERING TRUNNION***	***R1 02/02***
SECTION 110	**ENGINE**	
110-0020-7911	ENGINE ORDERING INSTRUCTIONS	
110-0030-7911	ENGINE AND MOUNTING	R2 08/01
110-0050-7911	AIR CLEANER	
110-0060-7911	AIR CLEANER PIPES AND HOSES	R1 04/01
110-0070-7911	EXHAUST AND MOUNTING	R2 08/01
110-0070-7911	EXHAUST AND MOUNTING	08/01
110-0100-7911	LUBRICATION LINES	
110-0130-7911	***POWER TAKEOFF - ENG***	***R1 02/02***
SECTION 120	**TRANSMISSION**	
120-0010-7911	TRANSMISSION MOUNTING	
120-0020-7911	***TRANSMISSION BREAKDOWN***	***R2 02/02***
120-0110-7911	OIL LINES-TRANSMISSION	R1 04/01
120-0670-7911	FRONT COVER GROUP	
120-0680-7911	INPUT ASSEMBLY-FRONT COVER	
120-0690-7911	***MIDSHIP MOUNTING GROUP***	***R1 02/02***
120-0700-7911	CONVERTOR ASSEMBLY	
120-0710-7911	GEAR RATIO GROUP	
120-0720-7911	1ST STAGE SHAFT ASSEMBLY	
120-0730-7911	2ND STAGE SHAFT ASSEMBLY	
120-0740-7911	3RD STAGE SHAFT ASSEMBLY	
120-0750-7911	4TH STAGE SHAFT ASSEMBLY	
120-0760-7911	5TH STAGE SHAFT ASSEMBLY	
120-0770-7911	6TH STAGE SHAFT ASSEMBLY	
120-0780-7911	OUTPUT GROUP	
120-0790-7911	MAIN CASE GROUP	
120-0800-7911	CONTROL VALVE GROUP	
120-0810-7911	CONTROL VALVE ASSEMBLY	
120-0820-7911	YOKE GROUP	
SECTION 120	**TRANSMISSION**	
120-0830-7911	CONVERTOR LOCKUP VALVE	
120-0840-7911	CHARGE PUMP GROUP	
SECTION 130	**DRIVELINE**	
130-0010-7911	***FRONT DRIVELINE***	***R1 02/02***
130-0010-7911	***FRONT DRIVELINE***	***02/02***
130-0020-7911	***REAR DRIVELINE***	***R1 02/02***
130-0020-7911	***REAR DRIVELINE***	***02/02***
SECTION 140	**FRONT AXLE**	
140-0020-7911	AXLE GROUP-FRONT	
140-0030-7911	PLANETARY GEARING-FRONT	R1 04/01
140-0040-7911	WHEEL, RIM AND TYRE-FRONT	R1 04/01
140-0060-7911	DIFFERENTIAL-FRONT	
SECTION 165	**BRAKE PARTS**	
165-0031-7911	BRAKE PARTS-SCRAPERS	
165-0050-7911	BRAKE GUARDS	R1 04/01
165-0060-7911	SLACK ADJUSTER	
SECTION 190	**ELECTRICAL SYSTEM**	
190-0010-7911	TERMINALS	
190-0011-7911	CONNECTORS	
190-0030-7911	CABLES/HARNESSES-CAB	
190-0040-7911	***CABLES/HARNESSES-CHASS/ENG***	***R1 02/02***
190-0070-7911	BATTERY AND CABLES	
190-0080-7911	BATTERY MOUNTING	R1 04/01
190-0100-7911	ELECTRICAL LIGHTING SYSTEM	
190-0110-7911	ALTERNATOR	
190-0270-7911	SWITCHES AND SENSORS	R1 04/01
190-0300-7911	***RADIO CASSETTE AND SPEAKERS***	***R1 02/02***
SECTION 200	**FUEL SYSTEM**	
200-0010-7911	FUEL TANK AND MOUNTING	
200-0010-7911	FUEL TANK AND MOUNTING	ECN 102340
200-0040-7911	FUEL LINES	R1 04/01
200-0040-7911	FUEL LINES	04/01
200-0050-7911	ACCELERATOR LINKAGE	

Order the manual at mid-west-tech.com >