
Motherwell | Terex TA30 Cummins MTA11-C300 27 6WG-260-II Articulated Truck Parts Manual | Publication 15274055

P10401



TEREX

Parts Book

Part Number
15274055

TA30 Articulated Truck

(Cummins MTA11-C300 Powered with ZF 6WG-260-II Transmission)

From Serial No. A7991001

8 May 2000
Revised Feb 02

PUBLISHED BY:
PRODUCT SUPPPORT DEPARTMENT

TEREX EQUIPMENT LIMITED
MOTHERWELL, SCOTLAND

Order the manual at mid-west-tech.com >

Articulated Truck

TEREX

TRACTOR SECTIONS

CHASSIS	100
ENGINE	110
TRANSMISSION	120
DRIVELINE	130
FRONT AXLE	140
BRAKE PARTS	165
SUSPENSION SYSTEM	180
ELECTRICAL SYSTEM	190
FUEL SYSTEM	200
COOLING SYSTEM	210
STEERING SYSTEM	220
BODY HOIST SYSTEM	230
BRAKING SYSTEM	250
CAB	260
DECALS	290

Order the manual at mid-west-tech.com >

110-0140-8001 COUPLING
FROM SERIAL NO. A7991432

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
A	001	001	15311591	ENGINE COUPLING	A7991432	A7991488
A	001	001	15313950	ENGINE COUPLING	A7991489	
	002	001	15237988	GUARD-FLYWHEEL		

NOTES:
A NON-SERVICEABLE ITEM, AVAILABLE AS A COMPLETE ASSEMBLY ONLY

MidWestTech | Terex TA30 Cummins MTA11-C300 ZF 6WG-260-II Articulated Truck Parts Manual | Publication 15274055 Order the manual at mid-west-tech.com >

260-0010-8001 CAB ASSEMBLY
SERIAL NO. A7991001 TO A7991012

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	080	001	15270885	.ADDITIVE-TRIM SIDE		
	081	001	15272748	.TRIM PANEL-SIDE		
	082	001	15272749	.LINING		
	083	002	15270888	.GRILLE-SPEAKER		
	084	008	15271182	.SCREW		
	085	008	15270995	.CLIP		
	086	001	15272750	.DASHBOARD		
	087	001	15270899	.SUPPORT-DASH		
	088	002	15270901	.HOUSING-SWITCHES		
	089	004	15270829	.SCREW		
	090	004	15270900	.SCREW		
	091	004	15270790	.WASHER		
	092	001	15272932	.TEE & TUBE ASSY-RH		
	093	001	15272931	.TEE & TUBE ASSY-LH		
	094	009	15270895	.CLAMP		
	095	ASR	15270896	.HOSE-BULK PLASTIC		
	096	ASR	15270896	.HOSE-BULK PLASTIC		
	097	002	15270897	.CLIP		
	098	ASR	15270898	.SEAL-BULK		
	099	ASR	15270898	.SEAL-BULK		
	100	004	15303871	.DIFFUSER-AIR		
	101	006	15270997	.SCREW		
	102	002	15270891	.AIR DIFFUSER		
	103	004	15270892	.SCREW		
	104	004	15270781	.BOLT		
	105	004	15270840	.WASHER		
	106	001	15272753	.COVER		
	107	002	15270903	.FASTNER		
	108	001	15270904	.COVER-RADIO		
	109	001	15272754	.COVER		
	110	003	15270829	.SCREW		
	111	001	15270906	.BRACKET-DASH		
	112	002	15270996	.WASHER		
	113	002	15270833	.NUT		
	114	001	15270913	.SCREW		
	115	001	15270996	.WASHER		
	116	001	15270833	.NUT		
	117	001	15270913	.SCREW		
	118	001	15270996	.WASHER		
	119	001	15270833	.NUT		

260-0010-8001 CAB ASSEMBLY
SERIAL NO. A7991001 TO A7991012

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	120	001	15270907	.BRACKET-DASHSUPPORT		
	121	001	15270781	.BOLT		
	122	001	15270996	.WASHER		
	123	001	15270908	.SUPPORT-FUSE BOX		
	124	004	15270789	.SCREW		
	125	004	15270790	.WASHER		
	126	ASR	15270909	.SEAL-BULK		
	127	001	15270910	.GROMMET		
	128	001	15272767	.CONSOLE-RH		
	129	001	15272768	.PLATE-SUPPORT		
	130	001	15271527	.REINFORCING PLATE		
	131	002	15270900	.SCREW		
	132	002	15270790	.WASHER		
	133	002	15271528	.CONTACTOR SUPPORT		
	134	003	15270767	.SCREW		
	135	003	15270998	.WASHER		
	136	006	15270858	.WASHER		
	137	003	15270833	.NUT		
	138	002	15270829	.SCREW		
	139	002	15270829	.SCREW		
	140	002	15270858	.WASHER		
	141	002	15270859	.NUT		
	142	001	15270914	.SUPPORT		
	143	001	15270791	.CAP		
	144	002	15270916	.PLATE-SPEAKER		
	145	001	15271323	.WIPER MOTOR-REAR		
	146	001	15270918	.ARM-REAR WIPER		
	147	003	15270829	.SCREW		
	148	003	15270921	.NUT		
	149	001	15270919	.BLADE-REAR WIPER		
	150	ASR	15270920	.TAPE-ADHESIVE		
	151	004	15271000	.FIXING		
	152	ASR	15271001	.FOAM		
	153	ASR	15271002	.SEAL		
	154	002	15272277	.SCREW		
	155	001	15272757	.LINING-RH		
	156	001	15271004	.MUG/CAN HOLDER		
	157	002	15271018	.SPRAY NOZZLE		
	158	002	15270845	.SCREW		
	159	001	15271019	.CLAMP		

Order the manual at mid-west-tech.com >

260-0015-8001 CAB MOUNTING

SERIAL NO. A7991001 TO A7991012

NC	REF	QTY	PART NO.	DESCRIPTION	SER.NO. FROM	SER.NO. TO
	001	004	15235693	MOUNT-ENG ISOLATION		
	002	004	15247919	WASHER		
	003	002	15247864	BOLT		
	004	002	15247862	BOLT		
	005	004	15247891	LOCKNUT		
A	006	001	15300241	GUARD-REAR WINDOW		
	007	004	00179839	BOLT		
	008	004	00108580	LOCKWASHER		
	009	004	00106263	WASHER		
	010	002	15256889	WELDMENT-MIRROR ARM		
	011	002	09077400	MIRROR		
	012	001	15301931	FLOORMAT		
	013	002	15251642	WASHER-HARDENED		
	014	004	06351255	BOLT		
	015	008	09068666	WASHER-HARDENED		
	016	004	06471201	LOCKNUT		
	017	001	15247523	HINGE		
	018	001	15247524	HINGE		
	019	004	06351030	BOLT		
	020	001	06470801	NUT (Not used)		
	021	004	06471001	LOCKNUT		
	022	001	15247424	PLATE		
	023	004	00171715	SCREW		
	024	001	15308431	BARRIER MAT-FIREWALL		
	025	001	15253175	BRACKET-DEFLECTOR (Not used)		
	026	002	15246087	MIRROR-WIDE ANGLE		
	027	002	07150815	WASHER (Not Used)		
	028	001	15300123	QUILT REAR WALL OF CAB		
	029	003	06351025	BOLT		
	030	003	15300370	WASHER		
	031	001	15258158	FLOORMAT LINER		
	032	001	15258844	INSULATION PANEL CAB		

NOTE:
A UNITS WITH HEATED BODY USE 15300253 GUARD

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS FOR MODEL TA30 FROM SERIAL NO A7991001 11/02/02

SECT - PAGE - PLI	DESCRIPTION	
SECTION 100	**CHASSIS**	
100-0010-8011	CHASSIS	R2 06/01
100-0020-8011	ARTIC & OSCILLATION PIVOT	R1 02/01
100-0020-8011	ARTIC & OSCILLATION PIVOT	R1 08/01
100-0020-8011	***ARTIC & OSCILLATION PIVOT***	***R1 02/02***
100-0020-8011	***ARTIC & OSCILLATION PIVOT***	***02/02***
SECTION 130	**DRIVELINE**	
130-0020-8011	REAR DRIVELINE	R1 06/01
130-0020-8011	REAR DRIVELINE	06/01
SECTION 150	**CENTRE AXLE**	
150-0010-8011	AXLE COMPLETE-CENTRE	R1 02/01
150-0010-8011	AXLE COMPLETE-CENTRE	02/01
150-0020-8011	DIFFERENTIAL-CENTRE	R2 06/01
150-0020-8011	DIFFERENTIAL-CENTRE	06/01
150-0030-8011	AXLE GROUP-CENTRE	R1 06/01
150-0030-8011	AXLE GROUP-CENTRE	06/01
150-0040-8011	PLANETARY GEARING-CENTRE	R1 06/01
150-0040-8011	PLANETARY GEARING-CENTRE	06/01
SECTION 160	**REAR AXLE**	
160-0010-8011	AXLE COMPLETE-REAR	R1 02/01
160-0010-8011	***AXLE COMPLETE-REAR***	***R1 02/02***
160-0020-8011	DIFFERENTIAL-REAR	R1 06/01
160-0020-8011	DIFFERENTIAL-REAR	06/01
160-0030-8011	AXLE GROUP-REAR	R1 06/01
160-0030-8011	AXLE GROUP-REAR	06/01
160-0040-8011	PLANETARY GEARING-REAR	R1 06/01
160-0040-8011	PLANETARY GEARING-REAR	06/01
SECTION 165	**BRAKE PARTS**	
165-0010-8011	BRAKE PARTS-ARTICS	R2 06/01
165-0010-8011	BRAKE PARTS-ARTICS	06/01
165-0050-8011	BRAKE GUARDS	R1 02/01
165-0050-8011	BRAKE GUARDS	02/01
SECTION 170	**PARKING BRAKE**	
170-0010-8011	PARKING BRAKE	
170-0020-8011	PARKING BRAKE MOUNTING	

SECT - PAGE - PLI	DESCRIPTION	
SECTION 180	**SUSPENSION SYSTEM**	
180-0040-8011	***REAR SUSPENSION***	***R4 02/02***
180-0040-8011	***REAR SUSPENSION***	***R2 02/02***
SECTION 190	**ELECTRICAL SYSTEM**	
190-0050-8011	CABLES/HARNESSES-REAR FRAME	R1 02/01
190-0050-8011	CABLES/HARNESSES-REAR FRAME	02/01
190-0100-8011	ELECTRICAL LIGHTING SYSTEM	R1 02/01
190-0100-8011	ELECTRICAL LIGHTING SYSTEM	02/01
190-0190-8011	ALARM SYSTEM	
SECTION 230	**BODY HOIST SYSTEM**	
230-0020-8011	LINES AND FITTINGS-BODY HOIST	R2 02/01
230-0130-8011	HOIST CYLINDERS	
SECTION 250	**BRAKING SYSTEM**	
250-0010-8011	***BRAKE LINES-AIR***	***R2 02/02***
250-0020-8011	***BRAKE LINES-HYDRAULIC***	***R2 02/02***
250-0260-8011	BRAKE CHAMBER/PRESS CONVERTER	
250-0280-8011	RELAY VALVE	
SECTION 270	**BODY**	
270-0010-8011	BODY ASSEMBLY	

Order the manual at mid-west-tech.com >

Articulated Truck

TEREX

TRACTOR OPTIONAL SECTIONS

CHASSIS	100
ENGINE	110
BRAKE PARTS	165
ELECTRICAL SYSTEM	190
FUEL SYSTEM	200
CAB	260
MISCELLANEOUS	300

Order the manual at mid-west-tech.com >