snorkel

SR626



CE

REPAIR PARTS MANUAL

Part Number 159-0004-000
April 2018

Order the manual at mid-west-tech.com >

Item	Part No.	Name	Qty	Uom
-	010.000.000-SR626-SR5719	ENGINE ASSEMBLY STAGE 5		EA
1	REF. TAB. 010.001.000-SR626-SR5719	YANMAR 52 KW STAGE V ENGINE ASSEMBLY	1	EA
2	REF. TAB. 010.001.001-SR626-SR5719	YANMAR 52 KW STAGE V EAT ASSEMBLY	1	EA
3	REF. TAB. 010.001.002-SR626-SR5719	ENGINE SUPPORTS ASSEMBLY FR00 52 KW	1	EA
4	REF. TAB. 010.001.003-SR626-SR5719	YANMAR 52 KW ENGINE FAN ASSEMBLY	1	EA
5	REF. TAB. 010.002.000-SR626-SR5719	FR00 AIR FILTER ASSEMBLY 52 KW STAGE V	1	EA
6	REF. TAB. 010.003.000-SR626-SR5719	FR00 EXCHANGER ASSEMBLY 52 KW STAGE V	1	EA
7	REF. TAB. 010.004.000-SR626-SR5719	52 KW ENGINE CONTROL UNIT ASSEMBLY STAGE 5	1	EA
8	REF. TAB. 010.005.000-SR626-SR5719	FR00 FILTER ASSEMBLY 52 KW STAGE V	1	EA
9	REF. TAB. 010.006.000-SR626-SR5719	FR00 52 KW DIESEL PUMP ASSEMBLY	1	EA
10	REF. TAB. 010.007.000-SR626-SR5719	FR00 TANK ASSEMBLY 52 KW STAGE V	1	EA

MidWestTech | Snorkel SR626 Telehandler Repair Parts Manual | Publication 159-0004-000 Order the manual at mid-west-tech.com >

Item	Part No.	Name	Qty	Uom
28	SN-7631410	SENSOR FLYWHEEL	1	EA
29	SN-7631411	GASKET INJECTOR	1	EA
30	SN-7631412	RETAINER INJECTOR	1	EA
31	SN-7631413	WSHR INJECTOR	1	EA
32	SN-7631414	BAFFEL BREATHER	1	EA
33	SN-7631415	GASKET 8 X 1.0	1	EA
34	SN-7631416	PLATE CENTER	1	EA
35	SN-7631417	PLATE BREATHER	1	EA
36	SN-7631418	SPRING DIAPHRAGM	1	EA
37	SN-7631419	GASKET BONNET	1	EA
38	SN-7631420	PIPE BREATHER	1	EA
39	SN-7631421	SENSOR PRESSURE	1	EA
40	SN-7631422	PLUG	1	EA
41	SN-7631423	O-RING 1PA12.0	1	EA
42	SN-7631424	HARNESS WIRE	1	EA
43	SN-7631425	PLUG GLOW	1	EA
44	SN-7631426	CONNECTOR GLOW PLUG	1	EA
45	SN-7631427	HOSE ASSY BREATHER	1	EA
46	SN-7631728	GASKET MANIFOLD	1	EA
47	SN-7631429	SENSOR TEMPERTURE	1	EA
48	SN-7631430	GASKET COLLECTOR	1	EA
49	SN-7631431	COLLECTOR ASSY	1	EA
50	SN-7631432	SENSOR TEMPERTURE	1	EA
51	SN-7631433	O-RING TEMP SENSOR	1	EA
52	SN-7631434	GASKET EGR-V SPACER	1	EA
53	SN-7631435	WSHR SEAL 14	1	EA
54	SN-7631436	THROTTLE INTAKE	1	EA
55	SN-7631437	GASKET THROTTLE	1	EA
56	SN-7631438	GASKET MANIFOLD	1	EA

MidWestTech | Snorkel SR626 Telehandler Repair Parts Manual | Publication 159-0004-000
Order the manual at mid-west-tech.com >


REF. TAB. 010.005.000-SR626-SR5719-STAGE3 2-6
REF. TAB. 010.006.000-SR626-SR5719 2-5, 2-6
REF. TAB. 010.007.000-SR626-SR5719 2-5, 2-6
REF. TAB. 040.001.000-SR626-SR5719 2-36
REF. TAB. 040.002.000-SR626-SR5719 2-36
REF. TAB. 040.003.000-SR626-SR5719 2-36
REF. TAB. 055.001.000-SR626-SR5719 2-55
REF. TAB. 055.002.000-SR626-SR5719 2-55
REF. TAB. 055.003.000-SR626-SR5719 2-55
REF. TAB. 080.000.002-SR626-SR5719 2-78
REF. TAB. 080.000.003-SR626-SR5719 2-79
REF. TAB. 080.000.004-SR626-SR5719 2-78
REF. TAB. 080.000.005-SR626-SR5719 2-78
REF. TAB. 080.000.006-SR626-SR5719 2-79
REF. TAB. 080.000.008-SR626-SR5719 2-78
REF. TAB. 080.000.009-SR626-SR5719 2-79
REF. TAB. 080.000.010-SR626-SR5719 2-78, 2-79
REF. TAB. 090.001.001-SR626-SR5719 5-13
REF. TAB. 090.001.002-SR626-SR5719 5-13
S1N-20126001 2-28
SH-7631464 2-31
SN - 113005000 2-82, 2-85, 2-86, 2-87, 2-88
SN - 122052001 2-82, 2-84, 2-85, 2-86, 2-87, 2-88
SN - 122062001 2-82, 2-84, 2-86, 2-87
SN - 123421600 2-82, 2-86, 2-87
SN - 130050005 2-82, 2-83, 2-84, 2-84, 2-85, 2-86, 2-87, 2-88
SN - 235115 2-82, 2-84, 2-85, 2-86, 2-87, 2-88
SN - 522105001 2-95
SN - 800220100 2-95
SN - 804002020 2-95
SN - 804003106 2-84
SN - 804003120 2-95
SN - T25023250 2-96
SN - T25026250 2-96
SN - T25027550 2-96
SN - T25027650 2-96
SN - T25063750 2-82
SN - T26000751 2-90
SN - T26000752 2-90
SN - T26000753 2-90
SN - T26000754 2-90
SN - T26000755 2-90
SN - T26000756 2-90
SN - T26000757 2-90
SN - T28063850 2-95
SN - T28063950 2-95
SN - T30181650 2-86, 2-87
SN - T30181750 2-82, 2-86, 2-87
SN - T30182751 2-80
SN - T30182752 2-80

MidWestTech | Snorkel SR626 Telehandler Repair Parts Manual | Publication 159-0004-000 Order the manual at mid-west-tech.com >

REPAIR PARTS



MidWestTech | Snorkel SR626 Telehandler Repair Parts Manual | Publication 159-0004-000 Order the manual at mid-west-tech.com >



MidWestTech | Snorkel SR626 Telehandler Repair Parts Manual | Publication 159-0004-000
Order the manual at mid-west-tech.com >

CONNECTORS LEGEND FOR FR00

CONNECTORS	FUNCTION
X1	WURTH BOARD CONNECTOR
X2	WURTH BOARD CONNECTOR
X3	WURTH BOARD CONNECTOR
X4	WURTH BOARD CONNECTOR
X5	WURTH BOARD CONNECTOR
X6	WURTH BOARD CONNECTOR
X7	WURTH BOARD CONNECTOR
X8	WURTH BOARD CONNECTOR
X9	WURTH BOARD CONNECTOR
X10	WURTH BOARD CONNECTOR
X11	WURTH BOARD CONNECTOR
X12	WURTH BOARD CONNECTOR
X13	WURTH BOARD CONNECTOR
X14	WURTH BOARD CONNECTOR
X16	WURTH BOARD CONNECTOR
X18.1	KEYBOARD CONNECTOR 1
X18.2	KEYBOARD CONNECTOR 2
X19.1	ROOF CONNECTOR 1
X21	LOAD CELL VISHAY CONNECTOR
X24	FRAME-ENGINE CONNECTOR
X26.1	CONNECTOR INSTRUMENT ALGA J
X26.2	CONNECTOR INSTRUMENT ALGA K
X27	AIR CONDITIONING PREDISPOSITION CONNECTOR
X28	ENGINE DIAGNOSTICS CONNECTOR
X29	AIR SEAT CONNECTOR
X30	WINCH PREDISPOSITION CONNECTOR
X31	ANTI ROLLOVER SYS. CONNECTOR
X33	INDICATOR LIGHT KEYBOARD CONNECTOR
X34	BATTERY CHARGER CONNECTOR
X35	WIPER PUMP CONNECTOR
X36	FRONT WORK LIGHTS CABIN / LEFT HEATED MIRROR
X37	POWER CLIMATRONIC CONNECTOR
X38	CABIN FAN CONNECTOR
X39	CLIMATRONIC SIGNALS CONNECTOR
X40	AIR CONDITIONING TAP CONNECTOR
X41	AIR RECYCLING CONNECTOR
X42	FASTON THERMOSTAT CONNECTOR
X43	CAR RADIO GREY CONNECTOR
X44	CAR RADIO BROWN CONNECTOR
X45	FASTON RIGHT LOUDSPEAKER CONNECTOR

CONNECTORS	FUNCTION
X59	GLOW PLUGS RELAY CONNECTOR
X60	YANMAR OIL RESISTANCE BULB CONNECTOR
X62	OIL PRESSURE BULB CONNECTOR
X64	LOAD RESISTANCES YANMAR ACCELERATOR CONNECTOR
X66	DPF PRS YANMAR SENSOR CONNECTOR
X67	DPF INLET YANMAR SENSOR CONNECTOR
X68	DPS INSIDE SENSOR YANMAR CONNECTOR
X69	60 POLES ECU YAMNAR CONNECTOR
X70	94 POLES ECU YAMNAR CONNECTOR
X74	PEB (BOOM ELECTRIC SOCKET)
X76	GLOW PLUGS CONNECTOR
X77	CSD COIL YANMAR CONNECTOR
X78	WIPER CONNECTOR
X79	CREEPER LIMIT CONNECTOR
X81	EGR VALVE YANMAR CONNECTOR
X82	ENGINE INTERFACE 1 YANMAR CONNECTOR
X83	ENGINE INTERFACE 2 YANMAR CONNECTOR
X84	ENGINE INTERFACE 3 YANMAR CONNECTOR
X85	ENGINE INTERFACE 4 YANMAR CONNECTOR
X86	SPEED SENSOR YANMAR ENGINE CONNECTOR
X87	WATER TEMPERATURE YANMAR ECU CONNECTOR
X88	RACK ACTUATOR YANMAR ECU CONNECTOR
X89	WATER TEMPERATURE YANMAR BULB CONNECTOR
X90	CABIN-FRAME CONNECTOR 1
X91	CABIN-FRAME CONNECTOR 2
X93	CABIN POWER CONNECTOR
X94	CABIN-FRAME CONNECTOR 4
X95	PROPEL PEDAL YANMAR 3A CONNECTOR
X99	BASKET SAFETY PREDISPOSITION CONNECTOR
X106	YANMAR 3A ECU CONNECTOR
X110	DRIVER SEAT HUB CAN-BUS 1 CONNECTOR
X111	DRIVER SEAT HUB CAN-BUS 2 CONNECTOR
X112	DRIVER SEAT HUB CAN-BUS 3 CONNECTOR
X113	DRIVER SEAT HUB CAN-BUS 4 CONNECTOR
X114	DRIVER SEAT HUB CAN-BUS 5 CONNECTOR
X115	DRIVER SEAT HUB CAN-BUS 6 CONNECTOR
X130	LEVER LIGHTS CONNECTOR
X131	LEVER GEARS CONNECTOR
X132	START-UP KEY 9,5 CONNECTOR
X133	START-UP KEY 6,3 CONNECTOR

COLORS LEGEND

SIGN	COLOR
B	WHITE
C	ORANGE
G	YELLOW
H	GREY
L	BLUE
M	BROWN
N	BLACK
R	RED
S	PINK
V	GREEN
Z	VIOLET

Order the manual at mid-west-tech.com >