
TEREX AERIALS

LIFTING



SCISSOR LIFT, MODELS:

TS20	ABOVE S/N 99320000
TS20W	ABOVE S/N 99330000
TS26	ABOVE S/N 99340000
TS26W	ABOVE S/N 99350000
TS30	ABOVE S/N 99360000

FOR PARTS OR SERVICE CONTACT:

PARTS MANUAL

Terex Worldwide Parts Distribution Center
8800 Rostin Road
Southaven, MS 38671-0923
(601) 393-1351/53

Terex Aerials
10600 W. Brown Deer Road
Milwaukee, WI 53224
U.S.A.

Telephone: (414) 362-9300
Facsimile: (414) 355-0832

Terex Aerials
106 12th Street S. E.
Waverly, IA 50677
U.S.A.

Telephone: (319) 352-3920
Facsimile: (319) 352-5727

Terex Aerials
Courtstown Industrial Park
Little Island, Co.
Cork, Ireland


Telephone: (353) 21-353011
Facsimile: (353) 21-353368


Issued: MARCH '99

17273-1

MidWestTech | Terex TS20, TS20W, TS26, TS26W, TS30 Scissor Lift Parts Manual | Publication 17273-1

Order the manual at mid-west-tech.com >






Ref.	Part No.	Description	Qty.	Remarks
1	135704	Assembly, Base - TS20	1	See Section 3 for Details
	135618	Assembly, Base - TS20W, TS26	1	See Section 3 for Details
	135741	Assembly, Base - TS26W	1	See Section 3 for Details
2	135102	Assembly, Scissor - TS20W	1	See Section 4 for Details
	135616	Assembly, Scissor - TS20W	1	See Section 4 for Details
	135581	Assembly, Scissor - TS26, TS26W	1	See Section 4 for Details
3	135202	Assembly, Platform - TS20 (Std.)	1	See Section 5 for Details
	135682	Assembly, Platform - TS26,TS20W (Std.)	1	See Section 5 for Details
	135739	Assembly, Platform - TS26W (Std.)	1	See Section 5 for Details
4	135705	Hydraulic Assembly - TS20	1	See Page 2-19 for Details
	135620	Hydraulic Assembly - TS20W, TS26, TS26W	1	See Page 2-23 for Details
5	03751200	Aerial Control Box Assembly	1	See Page 2-17 for Details
7	135119	Wear Pad - TS20	1	
	135538	Wear Pad - TS20W, TS26, TS26W	2	
8	135333	Wear Pad	2	
9	135304	Bracket, Proximity Switch	2	

WHEN ORDERING PARTS, SPECIFY MODEL NUMBER, SERIAL NUMBER AND DESCRIPTION OF PART REQUIRED

MidWestTech | Terex TS20, TS20W, TS26, TS26W, TS30 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

PROXIMITY SWITCHES




DETAIL "A"

DETAIL "B"


Ref.	Part No.	Description	Qty.	Remarks
10	1233-37	Machine Screw, #8 - 32 X 1/2	2	
11	62632	Machine Screw, #8 - 32 X 2-1/4	4	
	63412	Flat Washer, #8	6	
	61325	Hex Nut, Self Locking 8 - 32	6	
12	135344	Bracket, Proximity Switch - TS20	1	
	135598	Bracket, Proximity Switch - TS20W, TS26 TS26W	1	
13	441 6834	Switch, Proximity	2	
14	441 6835	Cable, Proximity Switch	2	
15	331 1000	Flat Washer, #10	2	

MidWestTech | Terex TS20, TS20W, TS26, TS26W, TS30 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

SERVICE STAND



DETAIL "C"



DETAIL "D"

Ref.	Part No.	Description	Qty.	Remarks
"C"	(Detail "C")	Pin Assembly		
16	135201	Pin	2	
17	1200-15	Capscrew, 1/4 NC X 2-1/2 GR5	2	
18	1200-11	Capscrew, 1/4 NC X 2 GR5	2	
19	61312	Locknut, 1/4 - 20	4	
"D"	(Detail "D")	Service Stand Assembly	1	
20	135133	Service Stand	1	
21	135136	Clamp, Service Stand	2	
22	1209-4	Flatwasher, 3/8	1	
23	1200-71	Capscrew, 3/8 - 16 X 2-1/2 GR5	1	
24	1205-45	Locknut, 3/8 - 16	1	

MidWestTech | Terex TS20, TS20W, TS26, TS26W, TS30 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >