TEREX

# Parts Manual

Serial Number Range

## RL4

from SN RL412-101

Part No. 216241

Rev B19

November 2018

MidWestTech | Terex RL4 Light Tower Parts Manual | Publication 216241

Order the manual at mid-west-tech.com >

# Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.


How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9


**Electronic Version**

Click on any page number to view the figure.


## 100 Decals

101.1 Decals with Words, Roadside....10
102.1 Decals with Words, Curbside....12
103.1 Decals with Words, Lights....14
104.1 Decals with Symbols, Roadside....16
105.1 Decals with Symbols, Curbside....18
106.1 Decals with Symbols, Lights....20

## 200 Chassis Components

201.1 Chassis....22
202.1 Fuel Tank and Hoses....24
202.2 Fuel Tank and Hoses (from SN RL414-11467)....26
203.1 Axle....28
204.1 Hitches....30
205.1 Ballast Box Assembly....32
206.1 Cabinet....34
206.1 Cabinet (from SN RL413-6092 to RL414-10859)....36
206.2 Cabinet (from SN RL414-10860)....38
207.1 Winch....40

## 300 Engine and Generator Components

301.1 Kubota D1105-E3BG, View 1....42
302.1 Kubota D1105-E3BG, View 2....44
303.1 Kubota D1105-E3BG, View 3....46
304.1 Kubota D1105-E3BG, View 4....48
305.1 Perkins 403D-11G, View 1....50
306.2 Perkins 403D-11G, View 2 (from serial number RL4011-4236)....52
307.1 Generators....54

## 400 Electrical Components

401.1 Control Box, 60HZ, View 1 (from SN RL413-6092 to RL415-12444)....56
401.2 Control Box, 60HZ, View 1 (from RL415-12445)....58
402.1 Control Box, 60HZ, View 2 (from SN RL413-6092 to RL415-12444)....60
402.2 Control Box, 60HZ, View 2 (from RL415-12445)....62
403.1 Control Box, 50HZ, View 1 (from SN RL413-6092 to RL415-12444)....64
403.2 Control Box, 50HZ, View 1 (from RL415-12445)....66
404.1 Control Box, 50HZ, View 2 (from SN RL413-6092 to RL415-12444)....68
404.2 Control Box, 50HZ, View 2 (from RL415-12445)....70
405.1 Electrical Wiring and Power Cables....72

## 500 Mast Components

501.1 Mast Assembly and Winch Cable Routing (to SN RL413-6832)....74
501.2 Mast Assembly and Winch Cable Routing (from SN RL413-6833)....76
502.1 Mast Components (to SN RL413-6832)....78
502.2 Mast Components (from SN RL413-6833)....80
503.1 Upper Mast Components (to SN RL413-6832)....82
503.2 Upper Mast Components (from SN RL413-6833)....84
504.1 Light Assembly, 19" Round....86
504.2 Light Assembly, 16" Round....88
505.1 Light Assembly, Square....90

## 600 Accessories

601.1 Safety and Convenience....92
602.1 Engine Options....94

## Indices

Part Number Index....96
Part Description Index....99

## Cross References




MidWestTech | Terex RL4 Light Tower Parts Manual | Publication 216241 Order the manual at mid-west-tech.com >

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| -- | | DECAL KIT,SYMBOL,COMPLETE<br>*refer to 104.1* | |
| 1 | 133149GT | DECAL,LABEL-ELEC HAZ,SERV MAN | 3 |
| 2 | T108023GT | DECAL,BODILY INJURY SYMBOL | 1 |
| 3 | T108024GT | DECAL,BURN HAZARD SYMBOL | 2 |



MidWestTech | Terex RL4 Light Tower Parts Manual | Publication 216241 Order the manual at mid-west-tech.com >

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| 1 | 839154GT | DIPSTICK,OIL,KUBOTA | |
| 2 | 839244GT | KUBOTA HEAD COVER GASKET | |
| 3 | 839151GT | KUBOTA OIL FILLER PLUG,V1305 | |
| 4 | 839034GT | KUBOTA O-RING | |
| 5 | 44191GT | VALVE COVER, D905 | |
| 6 | 866101GT | STARTER,KUBOTA,D1105/905 | |
| 7 | 101208GT | STUD,EXHAUST MANIFOLD | |
| 8 | 101209GT | NUT,EXHAUST MANIFOLD | |
| 9 | 32191GT | GASKET,EXHAUST MANIFOLD,D905 | |
| 10 | 839246GT | KUBOTA EXHAUST MANIFOLD | |
| 11 | 832128GT | GASKET,MUFFLER,KUBOTA D905/11 | |
| 12 | 839103GT | KUBOTA 01123-50820 BOLT | |
| 13 | 865055GT | KUBOTA NUT | |
| 14A | 865276GT | MUFFLER,KUBOTA | |
| -- | 866825GT | KUBOTA 66711-54520COV<br>*(muffler cover)* | |
| 15 | 125395GT | TAILPIPE,8K EXHAUST | |
| 16 | 116833GT | KUBOTA DYNAMO STAY | |
| 17 | 866090GT | ALTERNATOR,KUBOTA* | |
| 18 | 866081GT | KUBOTA BELT COVER | |
| 19 | 30973GT | BUMPER,RUBBER-1 X 1.25 | |
| 20 | 116503GT | BUSHING, 630DX.328ID .375T | |
| 21 | 6782GT | NUT,NYLOCK,5/16-18 | |
| 22 | 839190GT | SWITCH,LOW OIL PRESS,KUBOTA | |
| 23A | 52532GT | PLUG,ENGINE OIL DRAIN,D-905***.....1<br>*bottom of oil pan (not shown)* | |
| 23A | 52533GT | GASKET (52532) OIL DRAIN, D905.....1<br>*for 52532GT* | |
| 23B | 234842GT | PLUG, ENGINE OIL, D1105.....1<br>*bottom of oil pan (not shown)* | |
| 23B | 84042GT | GASKET-DRAIN PLUG,ENG OIL PAN....1<br>*for 234842GT* | |
| 23C | 974800GT | KIT:OIL DRAIN W/VALVE,KUBOTA<br>*(inlcudes valve, clamp and hose)* | |
| 24 | 116523GT | KUBOTA HOSE,D905, D1105 | |
| 25 | 32185GT | CLAMP,HOSE | |
| 26 | 866394GT | KUBOTA WATER PIPE | |
| 27 | 839209GT | V-BELT,KUBOTA | |
| 28 | 839134GT | FAN,PUSHER,KUBOTA 15263-12370 | |
| 29 | 839027GT | KUBOTA FLANGE BOLT | |
| 30 | 52531GT | PULLEY,FAN,KUBOTA, D-905,GS68 | |
| 31 | 101201GT | WATER PUMP ASSY,KUBOTA | |
| 32 | 32199GT | GASKET,WATER PUMP | |
| 33 | 32069GT | CLAMP,HOSE,KUBOTA WG750 | |
| 34 | 839011GT | KUBOTA WATER PIPE 16241-73350 | |
| 35 | 865435GT | KUBOTA 16221-73270GASKET | |
| 36 | 139278GT | THERMOSTAT | |
| 37 | 139279GT | THERMOSTAT COVER | |
| 38 | 62296GT | SCREW,M8 X 35MM | |



MidWestTech | Terex RL4 Light Tower Parts Manual | Publication 216241 Order the manual at mid-west-tech.com >

| Item | Part No. | Description | Qty. |
|---|---|---|---|
| 1 | 84812GT | PIPE,INJECTOR 1, 403C-11 | |
| 2 | 84813GT | PIPE,INJECTOR 2, 403C-11 | |
| 3 | 84814GT | PIPE,INJECTOR 3, 403C-11 | |
| 4 | 84860GT | VALVE COVER BREATHER | |
| 5 | 65636GT | CAP, OIL FILLER | |
| 5 | 65638GT | SEAL, OIL FILLER CAP | |
| 6 | 139272GT | FUEL INJECTOR | |
| 7 | 84815GT | GLOW PLUG, 403C-11 | |
| 8 | 237707GT | HOSE,FUEL LEAK-OFF,403D-11G | |
| 9 | 89764GT | HOSE, WATER PUMP (PERKINS 404) | |
| 10 | 101341GT | FAN | |
| 11 | 101319GT | FAN PULLEY | |
| 12 | 101322GT | PUMP,WATER | |
| -- | 89764GT | HOSE, WATER PUMP (PERKINS 404) | |
| -- | 97483GT | GASKET,WATER PUMP, 403C-11 | |
| 13 | 85071GT | BELT-FAN, PERKINS (103.10) | |
| 14 | 97427GT | PULLEY,CRANK, 403C-11 | |
| 15 | 116519GT | FP-ENG MNT RT FOOT CS PERK T4 | |
| 16 | 85140GT | GASKET-OIL PAN,PERKINS 103.10 | |
| 17 | 237774GT | PLUG,OIL DRAIN,PERKINS 403D-11G | |
| -- | 85124GT | GASKET,SOLENOID,PERKINS 72350 | |
| 18 | 116729GT | ISOLATOR,ENGINE,70D | |
| 19 | 116518GT | FP-ENG MNT RT FOOT RS PERK T4 | |
| 20 | 990415GT | WASHER,FLAT,SNUB 1/2X2-3/4 ZN | |
| 21 | 991650GT | WASHER LOCK 1/2ZP | |
| 22 | 990270GT | SCREW,HHC,1/2-13 X 3.5 GR8 | |
| 23 | R981095GT | SCREW,HHC,M12X1.25X30MM,GR8.8 | |
| 24 | 237776GT | SWITCH,OIL PRES,PERK 403D-11G | |
| 25 | 85069GT | FILTER, OIL-PERKINS (103-10)** | |
| 26 | 101320GT | DIPSTICK,STRAIGHT SHORT | |
| 27 | 97461GT | DIPSTICK TUBE,PERKINS(403C-11) | |
| 28 | 106663GT | SOLENOID,SHUT DOWN PERKIN40422 | |
| 29 | 72348GT | PUMP,LIFT(FUEL) PERKINS(54555) | |
| 29 | 89761GT | O-RING, LIFT PUMP,(PERKINS 404 | |
| 30 | 236046GT | HOSE, FUEL FILTER -INJ., 403D | |
| 31 | 94889GT | FUEL FILTER ASSEMBLY | |
| -- | 62421GT | FILTER,FUEL,PERKINS | |
| 32 | | Ref., FUEL HOSE<br>*refer to 202.1* | |



MidWestTech | Terex RL4 Light Tower Parts Manual | Publication 216241 Order the manual at mid-west-tech.com >