A TEREX BRAND

Parts Manual

Serial Number Range

GTH-644

from serial number
GTH0610-14001 to
GTH0612-16605

GTH-844

from serial number
GTH0810-14001 to
GTH0812-16605

Part No. 226648

Rev B2

November 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

0100 Decals
101.1 Decals, Engine Side....10
102.1 Decals, Cab Side....12
103.1 Decals, Cab and Instrument Panel....14

0200 Drive Chassis Components
201.1 Power Train Assembly, JD-4045 Tier II....16
202.1 Drive Shaft Assembly, Front & Rear....18
203.1 Fuel Tank Assembly....20
204.1 Battery Box Assembly....22
205.1 General Assembly, View 1....24
206.1 General Assembly, View 2....26
207.1 Engine Enclosure Assembly....30

0300 Transmission Components
301.1 Transmission Converter Housing Assembly, T12000....32
302.1 Transmission Case and Plate Assembly, T12000....34
303.1 Transmission Torque Converter Assembly, T12000....36
304.1 Transmission Gear Assembly, T12000....38
305.1 Transmission Pump Drive Assembly, T12000....40
306.1 Transmission Charging Pump Assembly, T12000....42
307.1 Transmission Reverse Idler Assembly, T12000....44
308.1 Transmission Forward and Reverse Shaft Assembly, T12000....46
309.1 Transmission Third Shaft Assembly, T12000....48
310.1 Transmission First and Second Shaft Assembly, T12000....50
311.1 Transmission Output Shaft Assembly, T12000....52
312.1 Transmission Control Assembly, T12000....54
313.1 Transmission Modulation Valve Assembly, T12000....56
314.1 Transmission Drive Plate Assembly, T12000....58

0400 Front and Rear Axle Components
401.1 Axle Gear Box and Covers, Front and Rear Axle....60
402.1 Differential Assembly, Front Axle....62
403.1 Axle Differential Assembly, Rear Axle....64
404.1 Axle Steering Assembly, Front and Rear Axle....66
405.1 Trunnion Mount Assembly, Front and Rear....68
406.1 Service Brakes and Parking Brakes, Front Axle....70
407.1 Disc Brake Assembly, Rear Axle....72
408.1 Steering Arm Assembly, Front and Rear Axle....74
409.1 Steering Cylinder Assembly, Front and Rear Axle....76

0500 Engine Components
501.1 Engine and pump Assembly, JD-4045....78
502.1 Starter Relay, Sender Assembly, JD-4045....80
503.1 Engine Assembly, Deutz BF42012, View 1....82
504.1 Engine Assembly, Deutz BF42012, View 2....84
505.1 Engine Assembly, Deutz BF42012, View 3....86
506.1 Engine Components, Deutz BF42012, View 4....88
507.1 Engine Components, Perkins 1104C Tier 2 and Tier 3, View 1....90
508.1 Engine Assembly, Perkins 1104C, Tier 2 and Tier 3, View 2....92
509.1 Engine Assembly, Perkins 1104C, Tier 2 and Tier 3, View 3....94
510.1 Exhaust Assembly, JD-4045 and Deutz BF4M2012....96
511.1 Exhaust Assembly, Perkins 1104C....98
512.1 Air Cleaner Assembly, All Models....100

0600 Cab Components
601.1 Operators Compartment Assembly, View 1....102
602.1 Operators Compartment Assembly, View 2....106
603.1 Operators Compartment Assembly, View 3....108
604.1 Foot Brake Assembly....110
605.1 Accelerator Assembly with Pedal End....112
606.1 Instrument Panel Assembly....114
607.1 4-Way Controller Assembly....116

0700 Boom Components
701.1 Boom Assembly, View 1....118
702.1 Boom Assembly, View 2....120
703.1 Boom Assembly, View 3....122
704.1 Boom Assembly, View 4....124
705.1 Boom Assembly, View 5....126
706.1 Boom Assembly, View 6....128
707.1 Boom Assembly, View 7....130
708.1 Boom Assembly, View 8....132
709.1 Boom Assembly, View 9....134

MidWestTech | Terex Genie GTH-644, GTH-844 Articulated Boom Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

710.1 Boom Assembly, View 10....136

0800 Hydraulic Hoses and Fittings

801.1 Circuit,Pump, Oil Reservoir....138
802.1 Circuit, Lift-Tilt, GTH-844....140
803.1 Circuit, Lift-Tilt, GTH-644....142
804.1 Circuit, Boom....144
805.1 Circuit, 4 Way Controller....146
806.1 Circuit, Steering....148
807.1 Circuit, Sway....150
808.1 Circuit, Rear Lock-Up....152
809.1 Circuit, Parking Brake, GTH-844....154
810.1 Circuit, Parking Brake, GTH-644....156
811.1 Circuit, Pressure Checks....158
812.1 Circuit, Brake - Differential Lock, GTH-844....160
813.1 Circuit, Brake, GTH-644....162
814.1 Circuit, Oil Cooler, JD-4045, Tier II....164
815.1 Circuit, Oil Cooler, Perkins, 1104C....166
816.1 Circuit, Fuel, JD-4045, Tier II and Deutz....168
817.1 Circuit, Fuel, Perkins 1104C....170

0900 Hydraulic Components

901.1 Lift Cylinder, GTH-844....172
902.1 Lift Cylinder, GTH-644....174
903.1 Tilt Cylinder....176
904.1 Boom Cylinder....178
905.1 Sway-rear Lock up Cylinder....180
906.1 Motion Valve, Base Tilt Cylinder....182
907.1 Motion Valve, Head Tilt Cylinder....184
908.1 Motion Valve, Boom Cylinder....186
909.1 Motion Valve, Base Lift Cylinder....188
910.1 Dual Pilot Check Valve....190
911.1 Orbital Assembly....192
912.1 Selector Valve, Steering....194
913.1 Return Filter Assembly....196
914.1 Control Block Assembly....198
915.1 Main Valve Assembly (before GTH0611-14658 and GTH0811-14658)....200
915.2 Main Valve Assembly (from GTH0611-14658 and GTH0811-14658)....202
916.1 Hydraulic Pump Assembly, View 1....204
917.1 Hydraulic Pump Assembly, View 2....206
918.1 Electric Valve, 4 -Way....208
919.1 Electric Valve Assembly, 4 -Way....210
920.1 Valve, Boom Activated Rear-Lock....212
921.1 Valve, Parking Brake and Differential Lock....214
922.1 Rear Lockup Manifold....216

1000 Accessories

1001. 1 Fully Enclosed Cab Assembly, View 1....218
1003. 1 Fully Enclosed Cab Assembly, View 3....220
1004. 1 Fully Enclosed Cab Assembly, View 4....222
1005. 1 Fully Enclosed Cab Assembly, View 5....224
1006. 1 Fork Frame Rotate Assembly....226
1007. 1 Rotate Cylinder Assembly....228
1008. 1 Dual Pilot Check Valve....230
1009. 1 Circuit, Fork Rotate....232
1010. 1 Circuit, Auxillary Hydraulics, 3 -7 GPM....234
1011. 1 Road and Work Light Accessory....236
1012. 1 Road Light Harnesses....238
1013. 1 Work Light Harnesses....240
1014. 1 HVAC Components....242
1015. 1 HVAC Unit....244
1016. 1 Condenser Assembly, HVAC....246
1017. 1 Fender Assembly....248

Indices

Part Number Index....250
Part Description Index....256

Cross References

Fittings Cross Reference....264

MidWestTech | Terex Genie GTH-644, GTH-844 Articulated Boom Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

This Page Intentionally Left Blank

MidWestTech | Terex Genie GTH-644, GTH-844 Articulated Boom Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	7-367-05GT	COIL	1
2	7-367-14GT	CARTRIDGE	1
3	7-367-04GT	BODY	1
4	7-367-18GT	SEAL KIT	Ref.

MidWestTech | Terex Genie GTH-644, GTH-844 Articulated Boom Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
--	123910GT	KIT,AC BRACKETS,644/8XX *(includes condenser and dryer bracket)*	
1	231144GT	COVER	
2	231142GT	HEATER COIL	
3	231140GT	BLOWER, 12V	
4	231145GT	RELAY, 12V	
5	231146GT	THERMOSTAT	
6	231143GT	CASING	
7	231151GT	COPPER TUBE, 5/8	
8	231149GT	MOTORIZED VALVE	
9	231150GT	CLAMP	
10	231148GT	BLOCK VALVE	
11	231141GT	EVAPORATOR COIL	

MidWestTech | Terex Genie GTH-644, GTH-844 Articulated Boom Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >