A TEREX BRAND

Parts Manual

Serial Number Range

GS-1530	from SN GS3010A-110000 to GS3015A-141945
GS-1532	from SN GS-3011C-10000 to GS3016C-23999
GS-1930	from SN GS30C-24000 to GS30C-24457
GS-1932	

Part No. 229145GT

Rev D10

December 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

001 Parts Stocking List
001.1 Parts Stocking List....10

100 Decals
101.1 Decals with Words, GS-1530, Battery Side, ANSI & Australia....12
102.1 Decals with Words, GS-1530, Ground Controls Side, ANSI & Australia....14
103.1 Decals with Words, GS-1530, Platform, ANSI....16
104.1 Decals with Words, GS-1530, Platform, Australia....18
105.1 Decals with Symbols, GS-1530 Battery Side, ANSI & CE....20
106.1 Decals with Symbols, GS-1530 Ground Control Side, ANSI & CE....22
107.1 Decals with Symbols, GS-1530 Platform, ANSI....24
108.1 Decals with Symbols, GS-1530 Platform, CE....26
109.1 Decals with Words, GS-1532, Battery Side, Australia....28
110.1 Decals with Words, GS-1532 Ground Controls Side, Australia....30
111.1 Decals with Words, GS-1532 Platform, Australia....32
112.1 Decals with Symbols, GS-1532 Battery Side, CE....34
113.1 Decals with Symbols, GS-1532 Ground Control Side, CE....36
114.1 Decals with Symbols, GS-1532 Platform, CE....38
115.1 Decals with Words, GS-1930 Battery Side, ANSI & Australia....40
116.1 Decals with Words, GS-1930 Ground Controls Side, ANSI & Australia....42
117.1 Decals with Words, GS-1930 Platform, ANSI....44
118.1 Decals with Words, GS-1930 Platform, Australia....46
119.1 Decals with Symbols, GS-1930 Battery Side, ANSI & CE....48
120.1 Decals with Symbols, GS-1930 Ground Control Side, ANSI & CE....50
121.1 Decals with Symbols, GS-1930 Platform ANSI....52
122.1 Decals with Symbols, GS-1930 Platform CE....54
123.1 Decals with Words, GS-1932 Battery Side, Australia....56
124.1 Decals with Words, GS-1932 Ground Controls Side, Australia....58
125.1 Decals with Words, GS-1932 Platform, Australia....60
126.1 Decals with Symbols, GS-1932 Battery Side, CE....62
127.1 Decals with Symbols, GS-1932 Ground Control Side, CE....64
128.1 Decals with Symbols, GS-1932 Platform CE....66

200 Drive Chassis Components
201.1 Steer Linkage and Wheels....68
202.1 Non-steer Axle Installation, All Models....70
203.1 Level Sensor Installation, All Models....72
204.1 Pothole Protection Assembly....74
205.1 Battery Pack Module....76
206.1 Battery Charger....78
207.1 Power Unit Module....80
208.1 Ground Controls, All Models....82
209.1 Electrical Wiring....84
210.1 Power Cables (models without contactor)....86
210.2 Power Cables (models with contactor to SN GS3014A-136972 and to GS3015C-18038)....88
210.3 Power Cables (from SN GS3014A-136973 and from GS3015C-18039)....90
211.1 Function Manifold and Accumulator Components....92

300 Scissor Components
301.1 Scissor Assembly Installation....94
302.1 Scissor Assembly, GS-1530/1532....96
303.1 Scissor Assembly, GS-1930/1932....98

400 Platform Components
401.1 Platform Components, GS-1530....100
402.1 Platform Components, GS-1532 (to SN GS3016C-22616, GS3015A-141945)....104
402.2 Platform Components, GS-1532 (from SN GS3016C-22617)....108
403.1 Platform Components, GS-1930....112
404.1 Platform Components, GS-1932 (to SN GS3016C-22616, GS3015A-141945)....116
404.2 Platform Components, GS-1932 (from SN GS3016C-22617)....120
405.1 Platform Gates....124

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

406.1 Power to Platform.....126
407.1 Platform Controls, 6 Button (2 Speed Lift).....128
408.1 Platform Controls, 4 Button (Proportional Lift).....130
409.1 Joystick Controller.....132

500 Hydraulic Components
501.1 Hydraulic Components.....134
502.1 Function Manifold.....136
503.1 Check Valve Manifold.....138
504.1 Brake Release Hand Pump Manifold.....140
505.1 Hydraulic Power Unit, All Models.....142
506.1 Lift Cylinder Assembly, All Models.....144
507.1 Hydraulic Hoses and Fittings.....146

600 Accessories
601.1 Alarm, Horn and Flashing Beacons.....148
602.1 Air Line to Platform.....150
603.1 Platform Work Light.....152
604.1 Voltage Inverter.....154
605.1 Padded Auxiliary Rail, GS-1930.....156


700 Platform Overload Components
701.1 Platform Overload.....158

Indices
Part Number Index.....160
Part Description Index.....164

Cross References
Fittings Cross Reference.....170

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

210.3 Power Cables (from SN GS3014A-136973 and from GS3015C-18039)




MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

402.1 Platform Components, GS-1532 (to SN GS3016C-22616, GS3015A-141945) (continued)

Item	Part No.	Description	Qty.
35B	24514GT	BOX,INSTRUCTION STORAGE *Europe/Asia/South America (decal required; refer to Section100)*	
36	66030GT	PIN, WIRE LOCK 3/8 X 2 -1/2	4
–	78022GT	LANYARD,BLACK NYLON,TYPE 1*** *(CE & Australia models)*	
37		Ref. SWING GATE ASSEMBLY *(refer to 405.1)*	
38	1259223GT	BOLT,SHS,3/8X.375X5/16-18,ZAG	1
39	12013GT	SHIM,.375 X .063	1
40	14033GT	SCREW,HHC,3/8-16 X 2.75	5

MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >

404.1 Platform Components, GS-1932 (to SN GS3016C-22616, GS3015A-141945)



MidWestTech | Terex Genie GS-1530, GS-1532, GS-1930, GS-1932 Scissor Lift Parts Manu... Order the manual at mid-west-tech.com >