Genie®
A TEREX BRAND

Parts Manual

Serial Number Range

SX-180

from SN SX18013-005 to
SX18015-292

Part No. 235134

Rev B20

November 2018

MidWestTech | Terex SX-180 Telehandler Parts Manual | Publication 235134

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals

101.1 Decals with Words, Hydraulic Tank Side....10
102.1 Decals with Words, Hydraulic Tank Side (chassis)....12
103.1 Decals with Words, Engine Side, ANSI....14
104.1 Decals with Words, Engine Side, AUS....16
105.1 Decals with Words, Engine Side (chassis)....18
106.1 Decals with Words, Boom....20
107.1 Decals with Words, Platform, ANSI & CSA....22
108.1 Decals with Words, Platform, AUS....24
109.1 Decals with Symbols, Hydraulic Tank Side, ANSI....26
110.1 Decals with Symbols, Hydraulic Tank Side, CE....28
111.1 Decals with Symbols, Hydraulic Tank Side (chassis)....30
112.1 Decals with Symbols, Engine Side....32
113.1 Decals with Symbols, Engine Side (chassis)....34
114.1 Decals with Symbols, Boom....36
115.1 Decals with Symbols, Platform, ANSI....38
116.1 Decals with Symbols, Platform, CE....40

200 Drive Chassis Components

201.1 Chassis Components, Top View....42
202.1 Chassis Components, Bottom View....44
203.1 Chassis Components, Tank Side....46
204.1 Chassis Components, Engine Side....48
205.1 Steer Yoke, Wheel Drive and Motor....50

300 Turntable Components

301.1 Turntable Center Components - View 1....52
302.1 Turntable Center Components - View 2....54
303.1 Turntable Covers - Engine Side....56
304.1 Engine Side Components, Fuel Tank....58
305.1 Engine Side, Hose Clamps and Guides....60
306.1 Engine Side, Welder GEN, Bulkhead Assembly....62
307.1 Engine Side, Relay Fuse Assembly....64
307.2 Engine Side, Relay Fuse Assembly, Deutz TD 2.9L4....66
308.1 Welder Generator Enclosure (7.5 kW, 208/120 60HZ)....68
308.2 Welder Generator Enclosure (12 kW, 208/120 60HZ)....70
308.3 Welder Generator Enclosure (7.5 kW, 110/55 50HZ)....72
308.4 Welder Generator Enclosure (7.5 kW, 240/415 50HZ)....74
309.1 Tank Side, Turntable Covers....76
310.1 Tank Side, Swing Drive, Hose Clamps and Guides....78
311.1 Tank Side, Battery Bulkhead Assembly....80
312.1 Hydraulic Tank Components....82
313.1 Ground Control Box - View 1....84
313.2 Ground Control Box - View 2....86
314.1 Ground Control Box, Deutz TD 2.9L4 - View 1....88
314.2 Ground Control Box, Deutz TD 2.9L4 - View 2....90
315.1 Wire Harness Diagram - View 1....92
316.1 Wire Harness Diagram - View 2....94

400 Engine Components

401.1 Deutz TD2011-L04i Engine - View 1....96
402.1 Deutz TD2011-L04i Engine - View 2....98
403.1 Deutz TD2011-L04i Engine - View 3....100
404.1 Deutz Engine Attached Components....102
405.1 Deutz TD 2.9L4 Engine - View 1....104
406.1 Deutz TD 2.9L4 Engine - View 2....106
407.1 Deutz TD 2.9L4 Engine - View 3....108
408.1 Deutz TD 2.9L4 Engine - View 4....110
409.1 Perkins 1104D-44T Engine - View 1....112
410.1 Perkins 1104D-44T Engine - View 2....114
411.1 Perkins 1104D-44T Engine - View 3....116
412.1 Perkins Engine Attached Components....118

500 Boom Components

501.1 Boom Components....120
502.1 Boom Lift Cylinder....122
503.1 Cable Track Installation....124
504.1 Secondary Extend Cylinder....126
505.1 Primary Extend Cylinder....128
506.1 Cable Assembly - View 1....130
507.1 Cable Assembly - View 2....132
508.1 Cable Assembly - View 3....134
509.1 Boom Tube Zero - Wear Pads....136

MidWestTech | Terex SX-180 Telehandler Parts Manual | Publication 235134 Order the manual at mid-west-tech.com >

510.1 Boom Tube Zero - Inner Cable Track....138
511.1 Boom Tube One - Wear Pads....140
512.1 Boom Tube Two - Wear Pads....142
513.1 Boom Tube Three - Wear Pads, View 1....144
514.1 Boom Tube Three - Wear Pads, View 2....146
515.1 Boom Tube Four - Wear Pads....148
516.1 Jib Rotator Installation....150
517.1 Jib Rotator Housing....152
518.1 Jib Boom and Platform Rotator....154

600 Platform Components
601.1 Platform Installation - View 1....156
602.1 Platform Installation - View 2....158
603.1 Platform Controls....160
604.1 Platform J Box Assembly....164
605.1 Joysticks....166

700 Hydraulic Components
701.1 Traction Manifold....168
702.1 Steer and Axle Manifold....170
703.1 Function Manifold - View 1....172
703.2 Function Manifold - View 2....174
704.1 Jib, Level and Rotation Manifolds....176
705.1 Generator Manifold and Function Enable Valve....178
706.1 Hydraulic Pumps....180
707.1 Hydraulic Hoses and Fittings, Drive System....182
708.1 Hydraulic Hoses and Fittings, Steering System....184
709.1 Hydraulic Hoses and Fittings - Turntable....186
710.1 Hydraulic Hoses and Fittings - Turntable....190
711.1 Hydraulic Hoses and Fittings - Boom Components..192

800 Accessories
801.1 Platform Accessories....196
802.1 Half-Mesh and Pipe Cradle Options....198
803.1 Operator Protection Structure....200
804.1 Drive and Work Light Package....202
805.1 Platform Control Box Cover....204
806.1 Engine Air Precleaner....206
807.1 Air Line to Platform....208
808.1 Load Sense....210
809.1 Cold Start Package....212
810.1 Cold Start Heater....214
811.1 Ground Control LCD Heater....216
812.1 Platform Level Recovery and Rocker Joystick....218
813.1 Welder Option....220
814.1 Anemometer Option....222
815.1 Hostile Package - View 1....224
815.2 Hostile Package - View 2....226
816.1 Fall Arrest Bar....228
817.1 Operators Protection Alarm....230

Indices
Part Number Index....232
Part Description Index....239


Cross References
Fittings Cross Reference....250

MidWestTech | Terex SX-180 Telehandler Parts Manual | Publication 235134 Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1		Ref. WELDMENT,BOOM #0 *(Refer to 509.1 and 510.1)*	
2		Ref. WELDMENT,BOOM #1 *(Refer to 511.1)*	
3		Ref. WELDMENT,BOOM #2 *(Refer to 512.1)*	
4		Ref. WELDMENT,EXT. BOOM #3 *(Refer to 513.1 and 514.1)*	
5		Ref. WELDMENT,EXT. BOOM #4 *(Refer to 515.1)*	
6		Ref. WELDMENT, 10FT JIB *(Refer to 518.1)*	
7		Ref. WELDMENT, 8 FT PLATFORM *(Refer to 602.1)*	
8		Ref. BELLCRANK AND JIB ROTATOR *(Refer to 516.1 and 517.1)*	

MidWestTech | Terex SX-180 Telehandler Parts Manual | Publication 235134 Order the manual at mid-west-tech.com >

815.2 Hostile Package - View 2



MidWestTech | Terex SX-180 Telehandler Parts Manual | Publication 235134 Order the manual at mid-west-tech.com >

Fitting Cross References

Genie PN	Parker PN	Description
12342	8-4 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
13757	4 R6X-S	RUN TEE,SWIVEL NUT,ORFS
19685	12-10 C5OX-S	ELBOW,90° STRAIGHT THREAD TO FLARE TUBE
22664	12-10 C5OX	ELBOW,90° STRAIGHT THREAD TO FLARE TUBE
27431	8-12 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
28579	AS-B-33	SLEEVE,NYLON,1.81" ID
39871	6 WETX-WLN-S	UNION,90° BULKHEAD W/NUT,FLARE TUBE
39872	4 R5OX-S	RUN TEE,STRAIGHT THREAD
39873	6 C6OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE
39874	8-8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE
39875	4-8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE
39876	6-8 C5OX-S	ELBOW,90°,STRAIGHT THREAD TO FLARE TUBE
39877	4 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
39878	6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
39879	4-8 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
39880	6-10 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
39881	4-6 F5OX-S	CONNECTOR,STRAIGHT THREAD TO FLARE TUBE
39882	4-HP5ON-S	PLUG,STRAIGHT THREAD
39883	8-8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE
39885	269HB 12-12	ELBOW,90°,BEADED HOSE BARB TO MALE PIPE
39886	431-8	HOSE,5/8 INCH ID
39887	540N-2	HOSE,1/8 INCH ID
39888	801-8	HOSE,1/2 INCH ID
39889	801-12	HOSE,3/4 INCH ID
39890	10643-8-8	HOSE END,FEMALE SWIVEL,JIC
39891	13943-8-8	HOSE END,90° FEMALE SWIVEL,JIC
39892	13743-8-8	HOSE END,45° FEMALE SWIVEL,JIC
39894	30682-8-8	HOSE END,FEMALE SWIVEL,JIC
39895	30682-10-12	HOSE END,FEMALE SWIVEL,JIC
42286	8-8 CTX-S	ELBOW,90°,MALE PIPE TO FLARE TUBE
42756	8-12 CLO-S	ELBOW,90 MALE PIPE TO ORFS
42757	8-12 FLO-S	CONNECTOR,MALE PIPE TO ORFS
42758	4 JLO-S	UNION TEE,ORFS
42759	4-4 FLO-S	CONNECTOR,MALE PIPE TO ORFS
42760	8-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
42761	1J143-8-4	HOSE END,90° FEMALE SWIVEL,SEAL LOK
42762	1J743-8-4	HOSE END,45° FEMALE SWIVEL,SEAL LOK
42765	1JO43-4-4	HOSE END,MALE,SEAL LOK
42776	801-8	HOSE,1/2 INCH ID
42777	1J743-16-16	HOSE END,45° FEMALE SWIVEL,SEAL LOK
42786	16 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
42787	16 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
42788	16-8 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
42789	6-6 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
42790	8-10 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
42791	3/4 CD-S	ELBOW,90°,MALE TO FEMALE PIPE
42792	3/4 X 1/2 PTR-S	REDUCER,MALE TO FEMALE PIPE
42793	1/2 CR-S	ELBOW,90°,MALE PIPE

Genie PN	Parker PN	Description
42794	1 CR-S	ELBOW,90°,MALE PIPE
42795	BV-0839	BALL VALVE
42796	BV-0838	BALL VALVE
42974	6-8 CLO-S	ELBOW,90°,MALE PIPE TO ORFS
42912	13943-8-4	HOSE END,90° FEMALE SWIVEL,JIC
42920	BV-0840	BALL VALVE,90°
42932	AS-B-17	SLEEVE,NYLON,1.22" ID
42936	10243-2-4	HOSE END,FEMALE PIPE
42953	1/2 DD-S	ELBOW,90°,FEMALE PIPE
42956	6 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS
45349	8 V5OX-S	ELBOW,45°,STRAIGHT THREAD TO FLARE TUBE
45351	4 V5OX-S	ELBOW,45°,STRAIGHT THREAD TO FLARE TUBE
47223	10343-6-6	HOSE END,MALE,JIC
47419	PS690503-6-6	SWIVEL,90°,STRAIGHT THREAD TO 37° FLARE
48750	421-4	HOSE,1/4 INCH ID
48751	451TC-4	HOSE,1/4 INCH ID
48752	482TC-4	HOSE,1/4 INCH ID
48753	451TC-6	HOSE,3/8 INCH ID
48754	482TC-6	HOSE,3/8 INCH ID
48755	381-6	HOSE,3/8 INCH ID
48756	451TC-8	HOSE,1/2 INCH ID
48757	482TC-8	HOSE,1/2 INCH ID
48758	381-8	HOSE,1/2 INCH ID
48759	381-10	HOSE,5/8 INCH ID
48760	451TC-10	HOSE,5/8 INCH ID
48761	482TC-12	HOSE,3/4 INCH ID
48762	451TC-12	HOSE,3/4 INCH ID
48763	772-12	HOSE,3/4 INCH ID
48764	881-16	HOSE,1 INCH ID
48765	772-16	HOSE,1 INCH ID
48766	AS-B-15	SLEEVE,NYLON,1.06" ID
48767	AS-B-22	SLEEVE,NYLON,1.42" ID
48770	881-8	HOSE,1/2 INCH ID

MidWestTech | Terex SX-180 Telehandler Parts Manual | Publication 235134 Order the manual at mid-west-tech.com >