KOBELCO

# PARTS CATALOG

# HYDRAULIC EXCAVATOR

# SK250 IV
# SK250LC IV
# SK250NLC IV

Applicable: SK250 IV LQU0101~
SK250LC IV LLU1801~
SK250NLC IV LLU5059~

2421R418D4-00 07/98

MidWestTech | Kobelco SK250 IV, SK250LC IV, SK250NLC IV Hydraulic Excavator Parts Catalog | Publication 2421R418D4

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


**00. GENERAL MAINTENANCE**

FILTER LIST ..... 004-49
HYDRAULIC SERVICE COMPONENTS ..... 005-01
HYDRAULIC LINE WRENCHES ..... 005-01-2
KOBELCO OILS AND LUBRICANTS ..... 005-01-2
KOBELCO PAINTS ..... 005-01-2
KOBELCO WIRING HARNESS MASTER REPAIR KIT ..... 005-01-3

**0. UPPER GROUP**

UPPER FRAME ASSEMBLY ..... 011-49
UPPER FRAME ASSEMBLY ..... 011-60
UPPER FRAME (REWORK FOR BREAKER OR NIBBLER & BREAKER) ..... 014-60
UPPER FRAME (REWORK FOR EXTRA & BREAKER OR EXTRA) ..... 014-73
UPPER FRAME (REWORK FOR LEFT LOWER MIRROR MOUNT) ..... 014-75
COUNTERWEIGHT ASSEMBLY (CAST) ..... 015-49
ADDITIONAL COUNTERWEIGHT KIT (FOR CAST) ..... 015-52
COUNTERWEIGHT INSTALLATION (FABRICATED) ..... 015-57
COUNTERWEIGHT ASSEMBLY ..... 015-60
SWING MOTOR ASSEMBLY ..... 025-49
HYDRAULIC TANK ASSEMBLY ..... 041-49
FUEL TANK ASSEMBLY ..... 045-49

**1. CAB & SHEET METAL GROUP**

CAB INSTALLATION ..... 051-49
CAB ASSEMBLY ..... 055-49
MIRROR INSTALLATION (FRAME) ..... 059-50
FLOOR PLATE ASSEMBLY ..... 064-49
SEAT GROUP ..... 071-50
SEAT ASSEMBLY ..... 074-50
MACHINERY COVERS & SHEET METAL (GUARD ASSY) ..... 081-49
COVER ASSEMBLY (ENGINE HOOD) ..... 101-49
UNDER COVER ASSEMBLY ..... 115-49

**2. CONTROL GROUP**

CONTROLS, OPERATORS ..... 121-49
CONTROL BOX ASSEMBLY ..... 124-49
WRIST CONTROL & PILOT LINE GROUP (REMOTE CTL. ASSY) ..... 161-49
SAFETY VALVE NOTICE ..... 161-50
REWORK, REMOTE CONTROL (SAFETY VALVES) ..... 161-50~161-53
REWORK, REMOTE CONTROL (NIBBLER & BREAKER) ..... 161-60
REWORK, REMOTE CONTROL (BREAKER) ..... 162-30
REWORK, REMOTE CONTROL (EXTRA) ..... 163-73
REWORK, REMOTE CONTROL (EXTRA & BREAKER) ..... 164-50
REWORK, REMOTE CONTROL (BUCKET CUT SYSTEM) ..... 165-49
FOOT PEDAL & CONTROL LEVER ASSEMBLY ..... 201-49



MidWestTech | Kobelco SK250 IV, SK250LC IV, SK250NLC IV Hydraulic Excavator Parts C... Order the manual at mid-west-tech.com >

## 3. UPPER HYDRAULICS GROUP


UPPER HYDRAULICS (N.A. & S.A.) STANDARD ..... 221-49
UPPER HYDRAULICS (EC) STANDARD ..... 221-50
UPPER HYDRAULICS (N.A. & S.A.) REWORK FOR SAFETY VALVES ..... 221-51
UPPER HYDRAULICS (EC) REWORK FOR SAFETY VALVES ..... 221-52
UPPER HYDRAULICS (REWORK FOR NIBBLER & BREAKER) ..... 221-60
UPPER HYDRAULICS (REWORK FOR BREAKER) ..... 222-50
UPPER HYDRAULICS (REWORK FOR EXTRA) ..... 223-50
UPPER HYDRAULICS (REWORK FOR EXTRA & BREAKER) ..... 221-51


## 4. ENGINE INSTALLATION & CONTROL GROUP


ENGINE INSTALLATION ..... 291-50
ENGINE ASSEMBLY ..... 295-49
POWER TAKE-OFF ASSEMBLY (HYDRAULIC PUMP) ..... 301-49
AIR CLEANER ASSEMBLY ..... 318-49
RADIATOR & COOLER ASSEMBLY ..... 321-49
ENGINE THROTTLE CONTROL ASSEMBLY (STEPPING MOTOR) ..... 371-49
INSTRUMENT PANEL ASSEMBLY ..... 381-49
CONTROLLER INSTALLATION ..... 384-51
CONTROLLER ASSEMBLY (TYPICAL VIEW) ..... 385-55
CONTROLLER ASSEMBLY ..... 385-58
CLUSTER GAUGE ASSEMBLY ..... 386-50
FUSE BOX ASSEMBLY ..... 387-49
HEATER & DEFROSTER INSTALLATION (RED DOT R-1550) ..... 392-50
HEATER ASSEMBLY (RED DOT R-1550) ..... 393-50
CONTROL PANEL ASSEMBLY (RED DOT R-1550) ..... 394-49
HEATER INSTALLATION ..... 395-49
HEATER AND HEATER AIR CONDITIONER ASSEMBLY (RED DOT R-1550) ..... 398-50
AIR CONDITIONER KIT INSTALLATION (RED DOT R-1550) ..... 399-49


## 5. ELECTRICAL COMPONENTS


ELECTRICAL WIRING ASSEMBLY ..... 411-50
HARNESS ASSEMBLY (INSTRUMENT PANEL) ..... 415-49
HARNESS ASSEMBLY (CONTROLLER) ..... 416-58
BATTERY ASSEMBLY ..... 421-49
LAMP ASSEMBLY (COMPLETE MACHINE) ..... 423-49
SWING FLASHER ASSEMBLY (RED) ..... 427-49
REAR LAMP ASSEMBLY (CLEAR) ..... 428-49


## 6. LOWER GROUP


CROSS REFERENCE TABLE ..... 441-00


## LOWER INSTALLATION


STANDARD CRAWLER - (SC) ..... 441-51
LONG CRAWLER - (LC) ..... 444-50
NARROW LONG CRAWLER - (NLC) ..... 446-50
HEAVY DUTY LONG CRAWLER - (HDLC) ..... 447-49
HEAVY DUTY NARROW LONG CRAWLER - (HDNLC) ..... 448-49
HEAVY DUTY HIGH & WIDE CRAWLER - (HDHW) ..... 450-49


## IDLER ASSEMBLY


STANDARD DUTY ..... 451-49



MidWestTech | Kobelco SK250 IV, SK250LC IV, SK250NLC IV Hydraulic Excavator Parts C... Order the manual at mid-west-tech.com >

HEAVY DUTY ..... 451-58
**LOWER ROLLER ASSEMBLY**
STANDARD DUTY ..... 461-49
HEAVY DUTY ..... 461-58
**UPPER ROLLER ASSEMBLY**
STANDARD DUTY ..... 467-49
HEAVY DUTY ..... 467-58
**IDLER ADJUSTER ASSEMBLY**
STANDARD DUTY ..... 471-49
HEAVY DUTY ..... 471-58
**PROPEL MOTOR ASSEMBLY** ..... 481-49
**LOWER HYDRAULICS**
STANDARD CRAWLER - (SC) ..... 491-51
LONG CRAWLER - (LC) ..... 494-50
NARROW LONG CRAWLER - (NLC) ..... 496-50
HEAVY DUTY - (HDLC) ..... 497-54
HEAVY DUTY NARROW LONG CRAWLER- (HDNLC) ..... 498-48
HEAVY DUTY HIGH & WIDE CRAWLER- (HDHW) ..... 499-49
**CRAWLER TRACK INSTALLATION**
STANDARD DUTY ..... 511-52
HEAVY DUTY ..... 516-49

**7. FRONT ATTACHMENT GROUP**
BOOM ASSEMBLY, 6.02M (N.A.,E.C.) STANDARD ..... 621-49
BOOM ASSEMBLY, 6.02M (NIBBLER & BREAKER OR BREAKER) ..... 621-60
BOOM ASSEMBLY, 6.02M (EXTRA & BREAKER) ..... 621-62
BOOM ASSEMBLY, 6.02M (EXTRA) ..... 621-73
SAFETY VALVE NOTE ..... 622-50
BOOM ASSEMBLY, 6.02M (BOOM SAFETY)* ..... 622-50
BOOM ASSEMBLY, 6.02M (BOOM SAFETY)** ..... 625-49
BOOM ASSEMBLY, 6.02M [NIBBLER & BREAKER OR BREAKER(BOOM SAFETY)]* ..... 622-60
BOOM ASSEMBLY, 6.02M [NIBBLER & BREAKER OR BREAKER(BOOM SAFETY)]** ..... 625-49
BOOM ASSEMBLY, 6.2M [EXTRA & BREAKER(BOOMSAFETY)]* ..... 622-62
BOOM ASSEMBLY, 6.2M [EXTRA & BREAKER(BOOMSAFETY)]** ..... 625-49
BOOM ASSEMBLY, 6.02M [EXTRA(BOOM SAFETY)]* ..... 622-73
BOOM ASSEMBLY, 6.02M [EXTRA(BOOM SAFETY)]** ..... 625-49
BOOM ASSEMBLY, 6.02M (BOOM & ARM SAFETY)* ..... 622-73
BOOM ASSEMBLY, 6.02M (BOOM & ARM SAFETY)** ..... 625-49
BOOM ASSEMBLY, 6.02M [NIBBLER & BREAKER OR BREAKER(BOOM & ARM SAFETY)]* 623-60
BOOM ASSEMBLY, 6.02M [NIBBLER & BREAKER OR BREAKER(BOOM & ARM SAFETY)]**627-49
BOOM ASSEMBLY, 6.02M [EXTRA & BREAKER (BOOM & ARM SAFETY)]* ..... 623-62
BOOM ASSEMBLY, 6.02M [EXTRA & BREAKER (BOOM & ARM SAFETY)]** ..... 627-49
BOOM ASSEMBLY, 6.02M [EXTRA (BOOM & ARM SAFETY)]* ..... 623-73
BOOM ASSEMBLY, 6.02M [EXTRA (BOOM & ARM SAFETY)]** ..... 627-49
ARM ASSEMBLY, 2.98M (N.A. STANDARD) ..... 631-49
ARM ASSEMBLY, 2.98M (EC) STANDARD ..... 631-50
ARM ASSEMBLY, 2.98M (S.A.) STANDARD ..... 631-57
ARM ASSEMBLY, 2.98M (NIBBLER & BREAKER) ..... 631-57
ARM ASSEMBLY, 2.98M (EXTRA & BREAKER) ..... 631-62
ARM ASSEMBLY, 2.98M (BREAKER) ..... 631-63
ARM ASSEMBLY, 2.98M (EXTRA) ..... 631-73
BUCKET ASSEMBLY, STANDARD ..... 641-49
HENDRIX BUCKETS FOR LATIN AMERICA ..... 641-50

* NABCO SAFETY VALVES
** OIL CONTROL SAFETY VALVES

MidWestTech | Kobelco SK250 IV, SK250LC IV, SK250NLC IV Hydraulic Excavator Parts C... Order the manual at mid-west-tech.com >