Illustrated Parts Manual

Models

G15-44A

31211076

February 21, 2018

An Oshkosh Corporation Company

MidWestTech | JLG G15-44A Telehandler Parts Manual | Publication 31211076

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 13

FIGURE 1-1. FRAME WELDMENT 14
FIGURE 1-2. ENGINE POD INSTALLATION (ULS) 16
FIGURE 1-3. COUNTERWEIGHT WITHOUT PINTLE HITCH~COUNTERWEIGHT WITHOUT PINTLE HITCH 18
FIGURE 1-4. COUNTERWEIGHT WITH PINTLE HITCH 20
FIGURE 1-5. COVERS INSTALLATION 22
FIGURE 1-6. CONVEX MIRROR ASSEMBLY 24
FIGURE 1-7. ENGINE COVER ASSEMBLY 26

SECTION 2 - BOOM 29

FIGURE 2-1. BOOM INSTALLATION 30
FIGURE 2-2. BOOM ASSEMBLY 32
FIGURE 2-3. FLY BOOM INSTALLATION (SN 0160075857 to Present) 38
FIGURE 2-4. CHAIN INSTALLATION 40
FIGURE 2-5. CHAIN SHEAVE ASSEMBLY 42
FIGURE 2-6. QUICK COUPLER INSTALLATION, MANUAL 44
FIGURE 2-7. QUICK COUPLER ASSEMBLY 46
FIGURE 2-8. QUICK COUPLER INSTALLATION, HYDRAULIC 48
FIGURE 2-9. QUICK COUPLER VALVE 50
FIGURE 2-10. HYDRAULIC QUICK COUPLER ASSEMBLY 52
FIGURE 2-11. QUICK COUPLER CYLINDER ASSEMBLY 54
FIGURE 2-12. BOOM AUXILIARY HYDRAULICS ASSEMBLY 56

SECTION 3 - ATTACHMENTS 59

FIGURE 3-1. CARRIAGE ASSEMBLY (60 INCH) (Prior to SN 0160075857) 60
FIGURE 3-2. CARRIAGE ASSEMBLY (60 INCH) (SN 0160075857 to Present) 62
FIGURE 3-3. CARRIAGE ASSEMBLY (72 INCH) (Prior to SN 0160075857) 64
FIGURE 3-4. CARRIAGE ASSEMBLY (72 INCH) (SN 0160075857 to Present) 66
FIGURE 3-5. DUAL FORK POSITIONING CARRIAGE (50 INCH) 68
FIGURE 3-6. DUAL FORK POSITIONING CARRIAGE ASSEMBLY (50 INCH) 70
FIGURE 3-7. DUAL FORK CARRIAGE VALVE ASSEMBLY 72
FIGURE 3-8. SIDE TILT CARRIAGE ASSEMBLY (72 INCH) 74
FIGURE 3-9. SIDE SHIFT CARRIAGE ASSEMBLY (50 INCH) 76
FIGURE 3-10. SIDE TILT CARRIAGE ASSEMBLY (72 INCH) 78
FIGURE 3-11. DUAL FORK POSITIONING CARRIAGE ASSEMBLY (50 INCH) 80
FIGURE 3-12. DUAL FORK POSITIONING CARRIAGE (50 INCH) 82
FIGURE 3-13. 90 SWING CARRIAGE ASSEMBLY (72 INCH) 84
FIGURE 3-14. TRUSS BOOM (12 FOOT WITHOUT WINCH) 86
FIGURE 3-15. TRUSS BOOM (15 FOOT WITHOUT WINCH) 88
FIGURE 3-16. TRUSS BOOM (12 FOOT WITH WINCH) 90
FIGURE 3-17. BUCKET (72 INCH) 92
FIGURE 3-18. BUCKET (96 INCH) 94
FIGURE 3-19. BUCKET (102 INCH) 96
FIGURE 3-20. GRAPPLE BUCKET 98
FIGURE 3-21. PIPE HANDLER CARRIAGE 100
FIGURE 3-22. FORK MOUNTED PLATFORM (ASME) 104
FIGURE 3-23. FORK MOUNTED PLATFORM ASSEMBLY 106
FIGURE 3-24. FORK - PALLET 1.75X6X48 108
FIGURE 3-25. DUAL TAPER FORK (60X6X2.36) 110
FIGURE 3-26. FORK - DUAL TAPER 1.75X6X72 112
FIGURE 3-27. FORK EXTENSION (90 INCH) 114
FIGURE 3-28. PALLET FORK (48X5X2.36) 116
FIGURE 3-29. HOOK, FORK MOUNTED 118
FIGURE 3-30. COUPLER MOUNTED HOOK 120
FIGURE 3-31. FORK MOUNTED PLATFORM (FRENCH) 122

SECTION 4 - ENGINE AND ATTACHING PARTS 125

FIGURE 4-1. ENGINE ASSEMBLY INSTALLATION 126
FIGURE 4-2. ENGINE, 4.6L 128
FIGURE 4-3. TRANSMISSION 130
FIGURE 4-4. COOLER ASSEMBLY INSTALLATION 132
FIGURE 4-5. COOLER INSTALLATION 134

MidWestTech | JLG G15-44A Telehandler Parts Manual | Publication 31211076 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 4-6. RADIATOR PACKAGE 136
FIGURE 4-7. ENGINE POD EXHAUST INSTALLATION 138
FIGURE 4-8. EXHAUST INSTALLATION 140
FIGURE 4-9. HYDRAULIC PUMP INSTALLATION 142
FIGURE 4-10. AIR CLEANER INSTALLATION 144
FIGURE 4-11. AIR CLEANER FILTER 146
FIGURE 4-12. FUEL TANK 148
FIGURE 4-13. FUEL CAP, NON LOCKING 150
FIGURE 4-14. FUEL CAP, LOCKING 152

SECTION 5 - DRIVE TRAIN 155

FIGURE 5-1. DRIVETRAIN INSTALLATION 156
FIGURE 5-2. FRONT DRIVE SHAFT ASSEMBLY 158
FIGURE 5-3. REAR DRIVE SHAFT ASSEMBLY 160
FIGURE 5-4. REAR DRIVE SHAFT 162
FIGURE 5-5. FRONT AXLE ASSEMBLY 164
FIGURE 5-6. REAR AXLE ASSEMBLY 166
FIGURE 5-7. FRONT AXLE 168
FIGURE 5-8. FRONT AXLE, CENTRAL HOUSING 170
FIGURE 5-9. FRONT AXLE, DIFFERENTIAL 172
FIGURE 5-10. FRONT AXLE, HUB REDUCTION 174
FIGURE 5-11. FRONT AXLE, BRAKES 176
FIGURE 5-12. FRONT AXLE, STEERING 178
FIGURE 5-13. FRONT AXLE, TRUNION 180
FIGURE 5-14. FRONT AXLE, DIFFERENTIAL ASSEMBLY 182
FIGURE 5-15. FRONT AXLE, RING GEAR SUPPORT KIT 184
FIGURE 5-16. FRONT AXLE, PLANET GEAR CARRIER KIT 186
FIGURE 5-17. FRONT AXLE, SUPPORT ASSEMBLY 188
FIGURE 5-18. REAR AXLE 190
FIGURE 5-19. REAR AXLE, CENTRAL HOUSING 192
FIGURE 5-20. REAR AXLE, DIFFERENTIAL 194
FIGURE 5-21. REAR AXLE, HUB REDUCTION 196
FIGURE 5-22. REAR AXLE, BRAKES 198
FIGURE 5-23. REAR AXLE, STEERING 200
FIGURE 5-24. REAR AXLE, TRUNION 202
FIGURE 5-25. REAR AXLE, DIFFERENTIAL ASSEMBLY 204
FIGURE 5-26. REAR AXLE, RING GEAR SUPPORT KIT 206
FIGURE 5-27. REAR AXLE, PLANET GEAR CARRIER KIT 208
FIGURE 5-28. REAR AXLE, SUPPORT ASSEMBLY 210
FIGURE 5-29. FRONT AXLE, PIVOT SUPPORT ASSEMBLY 212
FIGURE 5-30. REAR AXLE, PIVOT SUPPORT ASSEMBLY 214
FIGURE 5-31. POWERSHIFT TRANSMISSION 216
FIGURE 5-32. TRANSMISION, ENGINE CONNECTION 220
FIGURE 5-33. TRANSMISSION, CONVERTER 222
FIGURE 5-34. TRANSMISSION, INPUT 224
FIGURE 5-35. TRANSMISSION, HOUSING GROUP 1 226
FIGURE 5-36. TRANSMISSION, HOUSING GROUP 2 228
FIGURE 5-37. TRANSMISSION, CLUTCH GROUP 1 230
FIGURE 5-38. TRANSMISSION, CLUTCH GROUP 2 232
FIGURE 5-39. TRANSMISSION, COUPLING GROUP 1 234
FIGURE 5-40. TRANSMISSION, COUPLING GROUP 2 236
FIGURE 5-41. TRANSMISSION, COUPLING GROUP 3 238
FIGURE 5-42. TRANSMISSION, COUPLING GROUP 4 240
FIGURE 5-43. TRANSMISSION, OUTPUT 242
FIGURE 5-44. TRANSMISSION, POWER TAKE-OFF 244
FIGURE 5-45. TRANSMISSION, CONTROL UNIT 246
FIGURE 5-46. TRANSMISSION, SHIFT SYSTEM 248
FIGURE 5-47. TRANSMISSION, PRESSURE REGULATOR 250
FIGURE 5-48. TRANSMISSION, PRESSURE OIL PUMP 252
FIGURE 5-49. TRANSMISSION, INDUCTIVE TRANSMITTER 254
FIGURE 5-50. TRANSMISSION, FILTER 256
FIGURE 5-51. TRANSMISSION, ACCESSORIES GROUP 1 258
FIGURE 5-52. TRANSMISSION, PERIPHERALS GROUP 1 260
FIGURE 5-53. TRANSMISSION, ACCESSORIES GROUP 2 262
FIGURE 5-54. TRANSMISSION, TRANSFER BOX 264
FIGURE 5-55. TRANSMISSION, TRANSFER BOX HOUSING 1 266

MidWestTech | JLG G15-44A Telehandler Parts Manual | Publication 31211076 Order the manual at mid-west-tech.com >

FIGURE 5-56. TRANSMISSION, TRANSFER BOX HOUSING 2 268
FIGURE 5-57. TRANSMISSION, TRANSFER BOX HOUSING INPUT 270
FIGURE 5-58. TRANSMISSION, TRANSFER BOX HOUSING OUTPUT 1 272
FIGURE 5-59. TRANMISSION, TRANSFER BOX HOUSING OUTPUT 2 274
FIGURE 5-60. FENDER INSTALLATION 276
FIGURE 5-61. TIRE SET - 17.5-25 PNEUMATIC 278
FIGURE 5-62. TIRE AND WHEEL ASSEMBLY (RIGHT) 280
FIGURE 5-63. TIRE AND WHEEL ASSEMBLY (LEFT) 282
FIGURE 5-64. TIRE SET - 17.5-25 FOAM L-2 284

SECTION 6 - CAB 287

FIGURE 6-1. CAB INSTALLATION 288
FIGURE 6-2. OPEN CAB ASSEMBLY 290
FIGURE 6-3. OPEN CAB 294
FIGURE 6-4. DASH INSTRUMENT PANEL 296
FIGURE 6-5. ELECTRICAL OPTIONS INSTALLATION 298
FIGURE 6-6. ENCLOSED CAB WITH HEATER 300
FIGURE 6-7. ENCLOSED CAB WITH HEATER/AC INSTALLATION 302
FIGURE 6-8. HEATER UNIT, 3 SPEED 306
FIGURE 6-9. ENCLOSED CAB 308
FIGURE 6-10. LOWER DOOR ASSEMBLY 314
FIGURE 6-11. ENCLOSED CAB 316
FIGURE 6-12. UPPER DOOR ASSEMBLY 320
FIGURE 6-13. OVERHEAD AC CONDENSER 322
FIGURE 6-14. AC/HEATER MOTOR, 3 SPEED 324
FIGURE 6-15. CAB CONTROLS INSTALLATION 326
FIGURE 6-16. FRONT WIPER 328
FIGURE 6-17. SKYLIGHT WIPER 330
FIGURE 6-18. SKYLIGHT WIPER MOTOR ASSEMBLY 332
FIGURE 6-19. SKYLIGHT WINDOW INSTALLATION 334
FIGURE 6-20. OPEN CAB HEATER INSTALLATION 336
FIGURE 6-21. RESISTOR POTENTIOMETER ASSEMBLY 338
FIGURE 6-22. SEAT (Prior to SN 0160077332) 340
FIGURE 6-23. SEAT (SN 0160077332 to Present) 342
FIGURE 6-24. SEAT BELT INSTALLATION (CALIFORNIA) (Prior to SN 0160077332) 344
FIGURE 6-25. SEAT BELT INSTALLATION (CALIFORNIA) (SN 0160077332 to Present) 346
FIGURE 6-26. REAR WINDOW EXIT INSTALLATION 348
FIGURE 6-27. CAB MIRROR INSTALLATION, LH 350
FIGURE 6-28. CAB FENDER 352
FIGURE 6-29. TOP BRICK GUARD INSTALLATION 354
FIGURE 6-30. FRONT BRICK GUARD INSTALLATION 356

SECTION 7 - CONTROLS 359

FIGURE 7-1. ACCELERATOR PEDAL 360
FIGURE 7-2. BRAKE PEDAL ASSEMBLY 362
FIGURE 7-3. STEERING CONTROL ASSEMBLY 364
FIGURE 7-4. TILT ON JOYSTICK ASSEMBLY 366
FIGURE 7-5. RHEOSTAT TILT 368
FIGURE 7-6. HYDRAULIC CONTROLLER 370
FIGURE 7-7. FRAME LEVEL HYDRAULIC CONTROLLER 372
FIGURE 7-8. CONTROLLER, AUX HYDRAULIC 374

SECTION 8 - HYDRAULIC CIRCUITS 377

FIGURE 8-1. MAIN HYDRAULIC INSTALLATION 378
FIGURE 8-2. MAIN CONTROL VALVE WITH FITTINGS 382
FIGURE 8-3. HYDRAULIC DRIVETRAIN INSTALLATION 384
FIGURE 8-4. CAB HYDRAULIC INSTALLATION 386
FIGURE 8-5. DECOMPRESSION VALVE ASSEMBLY 390
FIGURE 8-6. HYDRAULIC PUMP ASSEMBLY 392
FIGURE 8-7. PRESSURE REDUCER AND BRAKE VALVE ASSEMBLY 394
FIGURE 8-8. TILT RECIRCULATION INSTALLATION 396
FIGURE 8-9. VALVE ASSEMBLY 398

SECTION 9 - HYDRAUIC COMPONENTS 401

MidWestTech | JLG G15-44A Telehandler Parts Manual | Publication 31211076 Order the manual at mid-west-tech.com >

FIGURE 4-5. COOLER INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001130286	Ref	Cooler Installation	K
1	1001134453	2	Support, Cooler	
2	1001114803	2	Isolator, Mount	
3	1001197054	1	Radiator Package, (See RADIATOR PACKAGE for Breakdown)	
4	4740274	4	Washer	
5	88521208	2	Nut, Lock 1/2-13	
6	3300246	2	Nut, Push	
8	1001118092	1	Gasket	
9	4711600	5	Washer	
10	0641607	3	Bolt, 3/8-16X7/8	
11	1001121404	2	Bracket	
12	1001122566	1	Shroud	
13	0791508	2	Screw, 5/16-18X1	
14	0811606	2	Screw, 3/8-16X3/4 Grade 8	
15	2220767	1	Fitting, Barbed	
16	2170516	1	Fitting, Tee ORFS	
18	2172416	1	Fitting, ORFS	
19	1001159129	1	Valve	
20	2170716	1	Fitting, Tee ORFS	
21	2131616	2	Fitting, 90 ORFS	
22	90206194	9 in	Trim	
23	1001130046	1	Plate	
24	0791504	5	Screw, 5/16-18X1/2	
25	1001130079	1	Gasket	
26	2170212	2	Fitting, 90 ORFS	
27	1001133877	5	Seal	
28	1001121962	1	Gasket	
29	0641605	2	Bolt, 3/8-16X5/8	
30	77143006	4	Nut, Lock 5/16-18	
31	1001134456	1	Mount	
32	1001134458	1	Plate	
33	1001134516	1	Radiator, Fuel	
34	1001138258	1	Plate	
35	1001138313	1	Plate	
36	1001120639	99 in	Seal	
37	1001147450	1	Gasket	
38	1001149227	3	Bolt, 5/16-18X1	
39	1001149756	1	Gasket	

MidWestTech | JLG G15-44A Telehandler Parts Manual | Publication 31211076 Order the manual at mid-west-tech.com >

FIGURE 6-10. LOWER DOOR ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	91474481	Ref	Lower Door Assembly	
1	8035461	2	Bolt, 1/4-20X1-1/4	
2	91404316	1	Handle, Grab	
3	80264066	3	Bolt, M6X1X12	
4	91404311	1	Cover, Door	
5	80384191	6	Screw, Whiz-Lock 10-24x1/2	
6	80384192	1	Handle, LH Inside	
7	91404315	1	Lever, Release	
8	91404317	1	Screw, Socket M32X1.12 GR8	
9	91404318	1	Nut, Lock M8-32	
10	91404313	6	Nut, Lock M10-24	
11	91404320	1	Stiffener, Latch	
12	91404319	1	Latch, LH	
13	8866334	2	Rivnut, 1/4-20X0.469	
14	91404321	1	Bar, Lower Door Drive	
15	80384189	4	Bolt, 1/4-20X3/4	
16	1001081241	1	Handle, Cab Door	
17	80364001	8 ft	Seal, Bulb	
18	80364079	1	Latch, RH	
19	91404309	1	Rod, Exterior Release Door	
20	80384187	3	Clip, Rod End Retainer	
21	91404310	1	Rod, Interior Release Door	
22	91404312	1	Foam, Lower Door	
23	80964051	1	Key, Door	
24	N.S.S.	1	Weldment, Door	

MidWestTech | JLG G15-44A Telehandler Parts Manual | Publication 31211076 Order the manual at mid-west-tech.com >

FIGURE 10-6. ELECTRICAL INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001187113	Ref	Electrical Installation	B
1	0641408	2	Bolt, 1/4-20X1	
2	4711400	2	Washer, 1/4	
3	8305624	2	Nut, Lock	
4	8881800	5	Tie Strap	
5	10713707	1	Horn	
6	1001116274	1	Resistor	
7	1001127386	1	Harness, Chassis (See CHASSIS HARNESS for Breakdown)	
8	8270621	1	Alarm, Backup	
9	91365037	1	Sensor, Stabilizer Proximity	
10	0641504	1	Bolt, 5/16-18X1/2	

MidWestTech | JLG G15-44A Telehandler Parts Manual | Publication 31211076 Order the manual at mid-west-tech.com >