Illustrated Parts Manual

Models

3006H
30.6

31211226

April 16, 2018 - Rev F

An Oshkosh Corporation Company

MidWestTech | JLG 30.6, 3006H Telehandler Parts Manual | Publication 31211226

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 17

FIGURE 1-1. FRAME INSTALLATION (20IN WHEEL) 18
FIGURE 1-2. FRAME INSTALLATION (24IN WHEEL) 20
FIGURE 1-3. ENGINE ENCLOSURE INSTALLATION (JLG) 22
FIGURE 1-4. ENGINE ENCLOSURE COVER INSTALLATION 24
FIGURE 1-5. HOOD INSTALLATION (JLG) 26
FIGURE 1-6. COVER PLATES INSTALLATION (ULS) 28
FIGURE 1-7. COVER PLATES INSTALLATION (LS) 32
FIGURE 1-8. REAR COVER PLATES INSTALLATION 36
FIGURE 1-9. COUNTERWEIGHT INSTALLATION 38
FIGURE 1-10. TANKS INSTALLATION 40
FIGURE 1-11. FUEL TANK INSTALLATION 42
FIGURE 1-12. HYDRAULIC TANK INSTALLATION 44
FIGURE 1-13. FUEL TANK ASSEMBLY 46
FIGURE 1-14. HYDRAULIC TANK ASSEMBLY 48
FIGURE 1-15. FUEL AND HYDRAULIC CAP INSTALLATION 50
FIGURE 1-16. DEF TANK BRACKET INSTALLATION (NO TRAILER BRAKE) 52
FIGURE 1-17. DEF TANK BRACKET INSTALLATION (TRAILER BRAKE) 54
FIGURE 1-18. HITCH RETRIEVAL INSTALLATION 56
FIGURE 1-19. HITCH INSTALLATION (EEC AUTO) 58
FIGURE 1-20. HITCH INSTALLATION (PITON) 60
FIGURE 1-21. HITCH ASSEMBLY (EEC AUTO) 62
FIGURE 1-22. SLIDING HITCH ASSEMBLY (PITON) 64
FIGURE 1-23. HITCH INSTALLATION (EEC MANUAL) 66
FIGURE 1-24. HITCH ASSEMBLY (EEC MANUAL) 68
FIGURE 1-25. HITCH INSTALLATION (CUNA CATEGORY C) 70
FIGURE 1-26. HITCH ASSEMBLY (CUNA CATEGORY C) 72
FIGURE 1-27. HITCH INSTALLATION (CUNA CATEGORY D2) 74
FIGURE 1-28. HITCH ASSEMBLY (CUNA CATEGORY D2) 76
FIGURE 1-29. HITCH INSTALLATION (FIXED) 78
FIGURE 1-30. HITCH ASSEMBLY (FIXED) 80
FIGURE 1-31. CAB PLUG INSTALLATION (NON HYDRAULIC HITCH) 82
FIGURE 1-32. HITCH INSTALLATION (HYDRAULIC) 84
FIGURE 1-33. HITCH ASSEMBLY (HYDRAULIC) 86
FIGURE 1-34. FRONT RETRIEVAL HITCH PIN 88

SECTION 2 - BOOM 91

FIGURE 2-1. BOOM INSTALLATION (JLG) 92
FIGURE 2-2. BOOM ASSEMBLY (JLG) (Prior to SN 1160008371) 94
FIGURE 2-3. BOOM ASSEMBLY (JLG) (SN 1160008371 to Present) 96
FIGURE 2-4. BOOM ASSEMBLY (DEUTZ-FAHR) (SN 1160008371 to Present) 98
FIGURE 2-5. FIRST BOOM SECTION ASSEMBLY (JLG) 100
FIGURE 2-6. SECOND BOOM SECTION ASSEMBLY 102
FIGURE 2-7. LINK ASSEMBLY 104
FIGURE 2-8. LEVER ASSEMBLY 106
FIGURE 2-9. MANUAL QUICK COUPLER INSTALLATION (20IN WHEEL) 108
FIGURE 2-10. MANUAL QUICK COUPLER INSTALLATION (24IN WHEEL) 110
FIGURE 2-11. HYDRAULIC QUICK COUPLER INSTALLATION (20IN WHEEL) 112
FIGURE 2-12. HYDRAULIC QUICK COUPLER INSTALLATION (24IN WHEEL) 114
FIGURE 2-13. BOOM ANGLE INDICATOR INSTALLATION 116
FIGURE 2-14. BOOM PROP INSTALLATION 118
FIGURE 2-15. BOOM BRUSHES INSTALLATION 120
FIGURE 2-16. BOOM REMOTE GREASING INSTALLATION 122

SECTION 3 - ATTACHMENTS 125

FIGURE 3-1. PALLET FORK (50X100X1220) 126
FIGURE 3-2. PALLET FORK (50X120X1200) 128
FIGURE 3-3. PALLET FORK (60X100X1220) 130
FIGURE 3-4. PALLET FORK (50X100X1070) 132
FIGURE 3-5. PALLET FORK (2.36X4X48) 134
FIGURE 3-6. PALLET FORK (2.36X5X48) 136
FIGURE 3-7. PALLET FORK (50X100X1525) 138
FIGURE 3-8. BLOCKING FORK (50X50X1220) 140

MidWestTech | JLG 30.6, 3006H Telehandler Parts Manual | Publication 31211226 **Order the manual at mid-west-tech.com >**

TABLE OF CONTENTS

FIGURE 3-9. BLOCKING FORK (50X50X1220) 142
FIGURE 3-10. CARRIAGE ASSEMBLY (1200MM) (CE AND AUS) 144
FIGURE 3-11. CARRIAGE ASSEMBLY (1270MM) 146
FIGURE 3-12. SIDE TILTING CARRIAGE (4.5 TON - 1225 MM) 148
FIGURE 3-13. SIDE TILTING CARRIAGE (4.5 TON - 1270 MM) 150
FIGURE 3-14. SIDE SHIFT CARRIAGE (4.0 TON - 1225 MM) 152
FIGURE 3-15. SIDE SHIFT CARRIAGE (5.5 TON - 1270 MM) 154
FIGURE 3-16. FORK POSITIONING CARRIAGE WITH FORKS (4.5 TON) 156
FIGURE 3-17. DUAL FORK CARRIAGE ASSEMBLY 158
FIGURE 3-18. DUAL FORK CARRIAGE VALVE ASSEMBLY 160
FIGURE 3-19. DUAL TINE BAILING FORK CARRIAGE 162
FIGURE 3-20. BUCKET 1.0 YD³ (ANSI - JLG) 164
FIGURE 3-21. BUCKET 1.0 M³ (CE AND AUS) 166
FIGURE 3-22. BUCKET 1.5 M³ (CE AND AUS) 168
FIGURE 3-23. BUCKET 2.0 M³ (CE AND AUS) 170
FIGURE 3-24. FORK MOUNTED BUCKET (1.0 M³) 172
FIGURE 3-25. 4 IN 1 BUCKET 0.6 M³ 174
FIGURE 3-26. DIG BUCKET 1.0 M³ (CE AND AUS) 176
FIGURE 3-27. MANURE GRAPPLE BUCKET (CE & AUS) 178
FIGURE 3-28. MULTI-PURPOSE GRAPPLE BUCKET (1850MM) (ANSI - JLG) 180
FIGURE 3-29. MULTI-PURPOSE GRAPPLE (WIDE GRIP - 1850MM) (CE & AUS) 182
FIGURE 3-30. MULTI-PURPOSE GRAPPLE BUCKET (2100MM) (CE & AUS) 184
FIGURE 3-31. MUCK FORK AND GRAB (CE & AUS) 186
FIGURE 3-32. CUTTING EDGE (2100MM BUCKET) 188
FIGURE 3-33. TRUSS BOOM (4 TON - 2.1M) 190
FIGURE 3-34. TRUSS BOOM (1 TON - 3.4M) 192
FIGURE 3-35. TRUSS BOOM (0.9 TON - 3.7M) 194
FIGURE 3-36. TRUSS BOOM (1.8 TON - 1M FT WITH WINCH) 196
FIGURE 3-37. TRUSS BOOM (3 FT WITH WINCH) 198
FIGURE 3-38. TRUSS BOOM (0.9 TON - 3.7M WITH WINCH) 200
FIGURE 3-39. TRUSS BOOM (1.8 TON - 3 FT WITH WINCH) 202
FIGURE 3-40. TRUSS BOOM (0.9 TON - 12 FT WITH WINCH) 204
FIGURE 3-41. CRANE HOOK (CE AND AUS) 206
FIGURE 3-42. CRANE HOOK 208
FIGURE 3-43. FORK MOUNTED HOOK (4 TON) 210
FIGURE 3-44. FORK MOUNTED BASKET 212
FIGURE 3-45. FORK MOUNTED PLATFORM 214
FIGURE 3-46. FORK MOUNTED TRASH HOPPER 216
FIGURE 3-47. CONCRETE BUCKET 218
FIGURE 3-48. SWEEPER 222
FIGURE 3-49. SWEEPER 224
FIGURE 3-50. AUGER (COUPLER MOUNTED) 226
FIGURE 3-51. FORK POSITIONING CARRIAGE WITH FORKS (4.0 TON) 228
FIGURE 3-52. FORK ROTATING CARRIAGE (4.5 TON - 1270 MM) 230
FIGURE 3-53. FORK ROTATING CARRIAGE (2.05 TON - 990 MM) 234
FIGURE 3-54. DRIVE GROUP MOTOR 238
FIGURE 3-55. DRIVE MOTOR 240
FIGURE 3-56. FEM CARRIAGE AND FORKS 242
FIGURE 3-57. BUCKET GUARD 244
FIGURE 3-58. BALE HANDLER (TUBE CLAMP) 246
FIGURE 3-59. BALE HANDLER (SPIKE CLAMP) 248
FIGURE 3-60. BALE HANDLER KIT (SPIKES) 250
FIGURE 3-61. BALE HANDLER KIT (SPIKES TO TUBE) 252
FIGURE 3-62. FORK EXTENSION (50X100X1910) 254
FIGURE 3-63. FORK EXTENSION (60X100X1920) 256
FIGURE 3-64. TRANSPORT LATCHES 258
FIGURE 3-65. MANITOU HYDRAULIC COUPLING 260
FIGURE 3-66. MANITOU HYDRAULIC COUPLING 262
FIGURE 3-67. JCB HYDRAULIC COUPLING INSTALLATION 264
FIGURE 3-68. JCB HYDRAULIC COUPLING 266
FIGURE 3-69. MERLO HYDRAULIC COUPLING INSTALLATION 268
FIGURE 3-70. MERLO HYDRAULIC COUPLING 270

SECTION 4 - ENGINE AND ATTACHING PARTS 273

FIGURE 4-1. ENGINE INSTALLATION (74.4KW - ULS) 274
FIGURE 4-2. ENGINE INSTALLATION (74.4KW - LS) 276

MidWestTech | JLG 30.6, 3006H Telehandler Parts Manual | Publication 31211226 Order the manual at mid-west-tech.com >


FIGURE 4-3. ENGINE INSTALLATION (85KW - ULS) 278
FIGURE 4-4. ENGINE INSTALLATION (85KW - LS) 280
FIGURE 4-5. ENGINE MOUNTING INSTALLATION 282
FIGURE 4-6. DIPSTICK INSTALLATION 284
FIGURE 4-7. 3.6L ENGINE (85KW - ULS) 286
FIGURE 4-8. 3.6L ENGINE (74.4KW - ULS) 288
FIGURE 4-9. 3.6L ENGINE (85KW - LS) 290
FIGURE 4-10. 3.6L ENGINE (74.4KW - LS) 292
FIGURE 4-11. FUEL LINES INSTALLATION (ULS) 294
FIGURE 4-12. FUEL LINES INSTALLATION (LS) 296
FIGURE 4-13. EXHAUST INSTALLATION (ULS) 298
FIGURE 4-14. EXHAUST INSTALLATION (LS) (Prior to SN 0160079089, Excluding 0160079084, 0160079085 and 0160079086) 300
FIGURE 4-15. EXHAUST INSTALLATION (LS) (SN 0160079089 to Present, Including 0160079084, 0160079085 and 0160079086) 302
FIGURE 4-16. ENGINE PARTS INSTALLATION (NO A/C) 304
FIGURE 4-17. COOLING PACKAGE INSTALLATION (ULS) 306
FIGURE 4-18. COOLING PACKAGE INSTALLATION (LS) 308
FIGURE 4-19. RADIATOR COOLING PACKAGE INSTALLATION 310
FIGURE 4-20. RADIATOR 312
FIGURE 4-21. FAN INSTALLATION 314
FIGURE 4-22. FAN LINES INSTALLATION 316
FIGURE 4-23. FAN VALVE INSTALLATION 318
FIGURE 4-24. PRIMARY FUEL FILTER INSTALLATION (ULS) 320
FIGURE 4-25. PRIMARY FUEL FILTER INSTALLATION (LS) 322
FIGURE 4-26. AIR CLEANER INSTALLATION (ULS) 324
FIGURE 4-27. AIR CLEANER INSTALLATION (LS) 326
FIGURE 4-28. AIR CLEANER FILTER 328
FIGURE 4-29. COOLANT LINES INSTALLATION 330
FIGURE 4-30. COOLER LINES INSTALLATION (Prior to SN 1160008371) 332
FIGURE 4-31. COOLER LINES INSTALLATION (SN 1160008371 to Present) 334
FIGURE 4-32. CAC LINES INSTALLATION (ULS) 336
FIGURE 4-33. CAC LINES INSTALLATION (LS) 338
FIGURE 4-34. SURGE TANK INSTALLATION 340
FIGURE 4-35. BULKHEAD INSTALLATION 342
FIGURE 4-36. DEF PUMP AND CONTROL INSTALLATION 344
FIGURE 4-37. DEF TANK INSTALLATION 346
FIGURE 4-38. DEF PUMP LINES INSTALLATION 348
FIGURE 4-39. TRANSMISSION HYDROSTATIC ADAPTER INSTALLATION 350
FIGURE 4-40. TRANSMISSION HYDROSTATIC DRIVE PUMP INSTALLATION 352
FIGURE 4-41. IMPLEMENT PUMP INSTALLATION 354
FIGURE 4-42. IMPLEMENT PUMP ASSEMBLY 356
FIGURE 4-43. PULLEY COVER INSTALLATION 358
FIGURE 4-44. HYDRAULIC FAN PUMP INSTALLATION 360
FIGURE 4-45. HEATER LINES INSTALLATION (ULS) 362
FIGURE 4-46. HEATER LINES INSTALLATION (LS) 364
FIGURE 4-47. BLOCK HEATER INSTALLATION (230V) 366
FIGURE 4-48. BLOCK HEATER INSTALLATION (120V) 368
FIGURE 4-49. BLOCK HEATER (ULS) 370
FIGURE 4-50. BLOCK HEATER (LS) 372
FIGURE 4-51. A/C PUMP INSTALLATION 374
FIGURE 4-52. A/C LINES INSTALLATION 376
FIGURE 4-53. HYDROSTATIC PUMP INSTALLATION 378

SECTION 5 - DRIVE TRAIN 381

FIGURE 5-1. AXLES INSTALLATION (20IN WHEEL) 382
FIGURE 5-2. AXLES INSTALLATION (24IN WHEEL) 384
FIGURE 5-3. HYDROSTATIC MOTOR INSTALLATION 386
FIGURE 5-4. HYDROSTATIC DRIVE MOTOR 388
FIGURE 5-5. FRONT AXLE (20IN WHEEL) 390
FIGURE 5-6. FRONT AXLE, CENTRAL HOUSING (20IN WHEEL) 392
FIGURE 5-7. FRONT AXLE, DIFFERENTIAL (20IN WHEEL) 394
FIGURE 5-8. FRONT AXLE, HUB REDUCTION (20IN WHEEL) 396
FIGURE 5-9. FRONT AXLE, BRAKES (20IN WHEEL) 398
FIGURE 5-10. FRONT AXLE, STEERING (20IN WHEEL) 400
FIGURE 5-11. FRONT AXLE, GEAR BOX (20IN WHEEL) 402

MidWestTech | JLG 30.6, 3006H Telehandler Parts Manual | Publication 31211226 Order the manual at mid-west-tech.com >

FIGURE 4-15. EXHAUST INSTALLATION (LS) (SN 0160079089 to Present, Including 0160079084, 0160079085 and 0160079086)



MidWestTech | JLG 30.6, 3006H Telehandler Parts Manual | Publication 31211226 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
206	1001116723	12	Terminal	
207	1001117081	1	Connector	
208	1001118384	1	Terminal	
209	1001116723	6	Terminal	
210	1001117081	1	Connector	
211	1001118384	1	Terminal	
212	1001116723	6	Terminal	
213	1001117081	1	Connector	
214	1001118384	1	Terminal	
215	1001116723	6	Terminal	
216	1001214686	1	Connector	
217	1001116753	1	Terminal	
218	1001214687	1	Connector	
219	1001116753	3	Terminal	
220	4460891	1	Connector	
221	4460465	2	Terminal	
222	4460434	1	Connector	
223	4460268	15	Terminal	
224	4460884	1	Connector	
225	4460942	1	Terminal	
226	4460466	2	Plug	
227	4460994	1	Connector	
228	1001118384	2	Terminal	
229	4461118	1	Connector	
230	1001107854	2	Terminal	
231	1001104498	2	Seal	
232	1001116812	1	Connector	
233	4460944	2	Terminal	
234	4460466	1	Plug	
235	1001144296	1	Cap	
236	4460418	1	Connector	
237	4460419	2	Terminal	
238	4460945	1	Connector, 3 Way	

MidWestTech | JLG 30.6, 3006H Telehandler Parts Manual | Publication 31211226 Order the manual at mid-west-tech.com >