Illustrated Parts Manual

Models

4008PS

31211269

October 24, 2016

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 17

FIGURE 1-1. FRAME INSTALLATION 18
FIGURE 1-2. ENGINE ENCLOSURE INSTALLATION (NO RHOC) 20
FIGURE 1-3. ENGINE ENCLOSURE INSTALLATION (RHOC) 22
FIGURE 1-4. ENGINE ENCLOSURE COVER INSTALLATION (NO RHOC) 24
FIGURE 1-5. ENGINE ENCLOSURE COVER INSTALLATION (RHOC) 26
FIGURE 1-6. AIR INTAKE SEAL INSTALLATION 28
FIGURE 1-7. HOOD INSTALLATION 30
FIGURE 1-8. COVER PLATES INSTALLATION (NO OUTRIGGERS - ULS) 32
FIGURE 1-9. COVER PLATES INSTALLATION (NO OUTRIGGERS - LS) 34
FIGURE 1-10. COVER PLATE INSTALLATION (NO TRAILER BRAKES) 36
FIGURE 1-11. COVER PLATE INSTALLATION (TRAILER BRAKES) 38
FIGURE 1-12. COVER PLATE INSTALLATION (NO REAR AUX) 40
FIGURE 1-13. COVER PLATE INSTALLATION (REAR AUX) 42
FIGURE 1-14. COVER PLATE INSTALLATION (HYDRAULIC HITCH AND REAR AUX) 44
FIGURE 1-15. REAR COVER PLATE INSTALLATION (NO HYDRAULIC HITCH) 46
FIGURE 1-16. REAR COVER PLATE INSTALLATION (HYDRAULIC HITCH) 48
FIGURE 1-17. COUNTERWEIGHT INSTALLATION 50
FIGURE 1-18. TANKS INSTALLATION 52
FIGURE 1-19. FUEL TANK INSTALLATION 54
FIGURE 1-20. HYDRAULIC TANK INSTALLATION 56
FIGURE 1-21. FUEL TANK ASSEMBLY 58
FIGURE 1-22. HYDRAULIC TANK ASSEMBLY 60
FIGURE 1-23. FUEL AND HYDRAULIC CAP INSTALLATION 62
FIGURE 1-24. HITCH RETRIEVAL INSTALLATION 64
FIGURE 1-25. HITCH INSTALLATION (EEC AUTO) 66
FIGURE 1-26. HITCH INSTALLATION (PITON) 68
FIGURE 1-27. HITCH ASSEMBLY (EEC AUTO) 70
FIGURE 1-28. SLIDING HITCH ASSEMBLY (PITON) 72
FIGURE 1-29. HITCH INSTALLATION (EEC MANUAL) 74
FIGURE 1-30. HITCH ASSEMBLY (EEC MANUAL) 76
FIGURE 1-31. HITCH INSTALLATION (CUNA CATEGORY C) 78
FIGURE 1-32. HITCH ASSEMBLY (CUNA CATEGORY C) 80
FIGURE 1-33. HITCH INSTALLATION (CUNA CATEGORY D2) 82
FIGURE 1-34. HITCH ASSEMBLY (CUNA CATEGORY D2) 84
FIGURE 1-35. HITCH INSTALLATION (FIXED) 86
FIGURE 1-36. HITCH ASSEMBLY (FIXED) 88
FIGURE 1-37. HITCH INSTALLATION (HYDRAULIC) 90
FIGURE 1-38. TOOLBOX INSTALLATION 92

SECTION 2 - BOOM 95

FIGURE 2-1. BOOM INSTALLATION 96
FIGURE 2-2. BOOM ASSEMBLY 98
FIGURE 2-3. FIRST BOOM SECTION 100
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 102
FIGURE 2-5. LINK ASSEMBLY 104
FIGURE 2-6. LEVER ASSEMBLY 106
FIGURE 2-7. MANUAL QUICK COUPLER INSTALLATION 108
FIGURE 2-8. HYDRAULIC QUICK COUPLER INSTALLATION 110
FIGURE 2-9. BOOM ANGLE INDICATOR INSTALLATION 112
FIGURE 2-10. BOOM PROP INSTALLATION 114
FIGURE 2-11. BOOM BRUSHES INSTALLATION 116

SECTION 3 - ATTACHMENTS 119

FIGURE 3-1. CARRIAGE ASSEMBLY (1524MM) (CE & AUS) 120
FIGURE 3-2. CARRIAGE ASSEMBLY (1829MM) (CE & AUS) 122
FIGURE 3-3. CARRIAGE ASSEMBLY (1225MM) (CE & AUS) 124
FIGURE 3-4. CARRIAGE ASSEMBLY (1270MM) (ANSI) 126
FIGURE 3-5. CARRIAGE ASSEMBLY (1524 MM) (ANSI) 128
FIGURE 3-6. CARRIAGE ASSEMBLY (1829 MM) (ANSI) 130
FIGURE 3-7. SIDE TILTING CARRIAGE (4.5 TON - 1225 MM) (CE & AUS) 132
FIGURE 3-8. SIDE TILTING CARRIAGE (4.5 TON - 1270 MM) (ANSI) 134
FIGURE 3-9. SIDE TILTING CARRIAGE (4.5 TON - 1575 MM) (ANSI) 136

MidWestTech | JLG 4008PS Telehandler Parts Manual | Publication 31211269 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-10. SIDE TILTING CARRIAGE (4.0 TON - 1575 MM) (CE & AUS) 138
FIGURE 3-11. SIDE TILTING CARRIAGE (4.5 TON - 1829 MM) (ANSI) 140
FIGURE 3-12. SIDE TILTING CARRIAGE (4.0 TON - 1829 MM) (CE & AUS) 142
FIGURE 3-13. SIDE SHIFT CARRIAGE (4.0 TON - 1225 MM) (CE & AUS) 144
FIGURE 3-14. SIDE SHIFT CARRIAGE (5.5 TON - 1270 MM) (ANSI) 146
FIGURE 3-15. FORK POSITIONING CARRIAGE WITH FORKS (4.0 TON) (CE & AUS) 148
FIGURE 3-16. FORK POSITIONING CARRIAGE WITH FORKS (4.5 TON) (ANSI) 150
FIGURE 3-17. DUAL FORK CARRIAGE ASSEMBLY 152
FIGURE 3-18. DUAL FORK CARRIAGE VALVE ASSEMBLY 154
FIGURE 3-19. FORK ROTATING CARRIAGE (4.5 TON - 1270 MM) (AUS) 156
FIGURE 3-20. CARRIAGE ASSEMBLY (JOHN DEERE FIT) (CE) 160
FIGURE 3-21. CARRIAGE ASSEMBLY (MANITOU FIT) (CE) 162
FIGURE 3-22. FORK ASSEMBLY (JCB FIT) (CE) 164
FIGURE 3-23. DUAL TINE BAILING FORK CARRIAGE (CE & AUS) 166
FIGURE 3-24. FEM CARRIAGE AND FORKS (CE & AUS) 168
FIGURE 3-25. PALLET FORK (50X100X1070) (CE) 170
FIGURE 3-26. PALLET FORK (50X100X1200) (CE) 172
FIGURE 3-27. PALLET FORK (50X120X1200) (CE) 174
FIGURE 3-28. PALLET FORK (50X120X1200) (CE & AUS - IF EQUIPPED WITH SIDE SHIFT CARRIAGE (4.0 TON - 1225MM) 176
FIGURE 3-29. PALLET FORK (2.36X4X48) (ANSI) 178
FIGURE 3-30. PALLET FORK (2.36X5X48) (ANSI) 180
FIGURE 3-31. PALLET FORK (2.00X6X72) (ANSI) 182
FIGURE 3-32. BLOCKING FORK (50X50X1220) (CE & AUS) 184
FIGURE 3-33. BLOCKING FORK (50X50X1220) (ANSI) 186
FIGURE 3-34. LUMBER FORK (40X150X1540) (ANSI) 188
FIGURE 3-35. LUMBER FORK (50X180X1540) (ANSI) 190
FIGURE 3-36. LUMBER FORK (60X150X1524) (ANSI) 192
FIGURE 3-37. BUCKET (1.15 M³) (ANSI) 194
FIGURE 3-38. BUCKET (1 M³) (CE & AUS) 196
FIGURE 3-39. BUCKET (1.5 M³) (CE & AUS) 198
FIGURE 3-40. BUCKET (2 M³) (CE & AUS) 200
FIGURE 3-41. BUCKET (2.5 M³) (CE & AUS) 202
FIGURE 3-42. BUCKET (3 M³) (CE & AUS) 204
FIGURE 3-43. BOLT-ON EDGE (2450 MM) 206
FIGURE 3-44. FORK MOUNTED BUCKET (1.0 M³) (ANSI) 208
FIGURE 3-45. DIRT BUCKET (1.0 M³) (CE & AUS) 210
FIGURE 3-46. 4 IN 1 BUCKET (0.6 M³) (CE & AUS) 212
FIGURE 3-47. 4 IN 1 BUCKET (1.0 M³) (CE & AUS) 214
FIGURE 3-48. MULTI-PURPOSE GRAPPLE BUCKET (2450 MM) (ANSI) 216
FIGURE 3-49. MULTI-PURPOSE GRAPPLE BUCKET (WIDE GRIP - 2450 MM) (CE & AUS) 218
FIGURE 3-50. MANURE GRAPPLE BUCKET (CE & AUS) 220
FIGURE 3-51. BUCKET GUARD 222
FIGURE 3-52. BUCKET TEETH KIT 224
FIGURE 3-53. BALE HANDLER KIT (SPIKES) (CE AND AUS) 226
FIGURE 3-54. BALE HANDLER KIT (SPIKES TO TUBE) (CE & AUS) 228
FIGURE 3-55. BALE HANDLER (TUBE CLAMP) (CE & AUS) 230
FIGURE 3-56. BALE HANDLER (SPIKE CLAMP) (CE & AUS) 232
FIGURE 3-57. TRUSS BOOM (4 TON - 2.1M) (CE AND AUS) 234
FIGURE 3-58. TRUSS BOOM (1 TON - 3.4M) (CE AND AUS) 236
FIGURE 3-59. TRUSS BOOM (0.9 TON - 3.7M) (ANSI) 238
FIGURE 3-60. TRUSS BOOM (1.8 TON - 3 FT WITH WINCH) (CE) 240
FIGURE 3-61. TRUSS BOOM (1.8 TON - 3 FT WITH WINCH) (ANSI) 242
FIGURE 3-62. TRUSS BOOM (3 FT WITH WINCH) 244
FIGURE 3-63. TRUSS BOOM (0.9 TON - 12 FT WITH WINCH) (CE) 246
FIGURE 3-64. TRUSS BOOM (0.9 TON - 3.7M WITH WINCH) (ANSI) 248
FIGURE 3-65. CRANE HOOK (CE AND AUS) 250
FIGURE 3-66. CRANE HOOK (ANSI) 252
FIGURE 3-67. FORK MOUNTED HOOK (4 TON) (ANSI) 254
FIGURE 3-68. FORK MOUNTED HOOK (4 TON) (CE) 256
FIGURE 3-69. MUCK FORK AND GRAB (CE & AUS) 258
FIGURE 3-70. FORK MOUNTED BASKET (DOMESTIC) (ANSI) 260
FIGURE 3-71. FORK MOUNTED BASKET (ISO) (ANSI) 262
FIGURE 3-72. FORK MOUNTED BASKET (FRENCH) (ANSI) 264
FIGURE 3-73. FORK MOUNTED PLATFORM 266
FIGURE 3-74. FORK MOUNTED TRASH HOPPER 268
FIGURE 3-75. CONCRETE BUCKET (CE) 270

MidWestTech | JLG 4008PS Telehandler Parts Manual | Publication 31211269 Order the manual at mid-west-tech.com >

FIGURE 3-76. SWEEPER (CE & AUS) 272
FIGURE 3-77. SWEEPER (ANSI) 274
FIGURE 3-78. AUGER (CE & AUS) 276
FIGURE 3-79. AUGER BIT, (6INX4IN) (CE & AUS) 278
FIGURE 3-80. AUGER BIT, (9INX4IN) (CE & AUS) 280
FIGURE 3-81. AUGER BIT, (12INX4IN) (CE & AUS) 282
FIGURE 3-82. AUGER BIT, (15INX4IN) (CE & AUS) 284
FIGURE 3-83. AUGER BIT, (18INX4IN) (CE & AUS) 286
FIGURE 3-84. AUGER BIT, (24INX4IN) (CE & AUS) 288
FIGURE 3-85. AUGER BIT, (36INX4IN) (CE & AUS) 290
FIGURE 3-86. FORK EXTENSIONS (62X163X2286) (ANSI) 292
FIGURE 3-87. FORK EXTENSION (50X100X1910) (CE) 294
FIGURE 3-88. FORK EXTENSIONS (60X100X1920) (AUS) 296
FIGURE 3-89. FORK TRANSPORT LATCHES INSTALLATION 298

SECTION 4 - ENGINE AND ATTACHING PARTS 301

FIGURE 4-1. ENGINE INSTALLATION (74.4KW - ULS - PISTON PUMP) 302
FIGURE 4-2. ENGINE INSTALLATION (90KW - ULS - PISTON PUMP) 304
FIGURE 4-3. ENGINE INSTALLATION (100KW - ULS - PISTON PUMP) 306
FIGURE 4-4. ENGINE INSTALLATION (74.4KW - LS - PISTON PUMP) 308
FIGURE 4-5. ENGINE INSTALLATION (90KW - LS - PISTON PUMP) 310
FIGURE 4-6. ENGINE MOUNTING INSTALLATION (74.4KW) 312
FIGURE 4-7. ENGINE MOUNTING INSTALLATION (90KW/100KW) 314
FIGURE 4-8. 3.6L ENGINE (74.4KW - ULS - PISTON PUMP) 316
FIGURE 4-9. 3.6L ENGINE (90KW - ULS - PISTON PUMP) 318
FIGURE 4-10. 3.6L ENGINE (100KW - ULS - PISTON PUMP) 320
FIGURE 4-11. 3.6L ENGINE (74.4KW - LS - PISTON PUMP) 322
FIGURE 4-12. 3.6L ENGINE (90KW - LS - PISTON PUMP) 324
FIGURE 4-13. ENGINE ECU INSTALLATION (ULS) 326
FIGURE 4-14. ENGINE ECU INSTALLATION (LS) 328
FIGURE 4-15. BRACKET GUARD INSTALLATION 330
FIGURE 4-16. FUEL LINES INSTALLATION (ULS) 332
FIGURE 4-17. FUEL LINES INSTALLATION (ULS - RHOC) 334
FIGURE 4-18. FUEL LINES INSTALLATION (LS) 336
FIGURE 4-19. FUEL LINES INSTALLATION (LS - RHOC) 338
FIGURE 4-20. EXHAUST INSTALLATION (ULS) 340
FIGURE 4-21. EXHAUST INSTALLATION (LS) 342
FIGURE 4-22. COOLING PACKAGE INSTALLATION (74.4KW - ULS) 344
FIGURE 4-23. COOLING PACKAGE INSTALLATION (74.4KW - LS) 346
FIGURE 4-24. COOLING PACKAGE INSTALLATION (90KW - ULS) 348
FIGURE 4-25. COOLING PACKAGE INSTALLATION (90KW - LS) 350
FIGURE 4-26. COOLING FAN INSTALLATION 352
FIGURE 4-27. FAN LINES INSTALLATION (74.4KW) 354
FIGURE 4-28. FAN LINES INSTALLATION (90KW) 356
FIGURE 4-29. FAN DRIVE MOTOR 358
FIGURE 4-30. FAN DRIVE MOTOR (RHOC) 360
FIGURE 4-31. PRIMARY FUEL FILTER INSTALLATION (74.4KW - ULS) 362
FIGURE 4-32. FUEL FILTER INSTALLATION (90/100KW - ULS) 364
FIGURE 4-33. PRIMARY FUEL FILTER INSTALLATION (90KW - LS) 366
FIGURE 4-34. AIR CLEANER INSTALLATION (74.4KW - ULS) 368
FIGURE 4-35. AIR CLEANER INSTALLATION (90/100KW) 370
FIGURE 4-36. AIR CLEANER INSTALLATION (74.4KW - LS) 372
FIGURE 4-37. AIR CLEANER ASSEMBLY (74.4KW) 374
FIGURE 4-38. AIR CLEANER ASSEMBLY (90/100KW) 376
FIGURE 4-39. AIR INTAKE LINES INSTALLATION (74.4KW - ULS) 378
FIGURE 4-40. AIR INTAKE LINES INSTALLATION (90/100KW - ULS) 380
FIGURE 4-41. AIR INTAKE LINES INSTALLATION (74.4KW - LS) 382
FIGURE 4-42. AIR INTAKE LINES INSTALLATION (90KW - LS) 384
FIGURE 4-43. COOLER INSTALLATION (74.4KW) 386
FIGURE 4-44. COOLER INSTALLATION (90KW) 388
FIGURE 4-45. RADIATOR COOLING PACKAGE (74.4KW) 390
FIGURE 4-46. RADIATOR COOLING PACKAGE (90KW) 392
FIGURE 4-47. REMOTE HOC INSTALLATION 394
FIGURE 4-48. COOLANT LINES INSTALLATION (ULS) 396
FIGURE 4-49. COOLANT LINES INSTALLATION (LS) 398
FIGURE 4-50. COOLER LINES INSTALLATION (74.4KW) 400

MidWestTech | JLG 4008PS Telehandler Parts Manual | Publication 31211269 Order the manual at mid-west-tech.com >

FIGURE 3-19. FORK ROTATING CARRIAGE (4.5 TON - 1270 MM) (AUS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001132959	1	Fork Rotating Carriage (4.5 ton - 1270 MM) (CE & AUS)	C
1	70024538	1	Decal, Pinch Point	
2	70024787	1	Decal, No Step	
3	70024788	1	Decal, Capacity	
4	N.S.S.	Ref	Plate, Serial Number	
101	70024676	1	Baseplate	
102	70024677	1	Faceplate	
103	70024678	1	Bearing	
104	70024679	1	Fitting, Grease	
105	70024680	13	Bolt, M12X40	
106	70024681	11	Bolt, M12X45	
107	70024682	15	Washer, Lock M12	
108	70024683	4	Bolt, M12X30	
109	70024684	24	Bolt, M12X40	
110	70024685	1	Plug	
111	70024686	1	Seal	
112	70024687	1	Bolt, M12X20	
113	70024688	1	Plate	
201	70024690	6	Bolt, M12X25	
202	70024691	1	Cover	
203	70024692	1	Fitting	
204	Kit	AR	Shim, 0.10	
205	Kit	AR	Shim, 0.15	
206	Kit	1	Shim, 0.20	
207	70024696	2	Bearing	
208	70024697	1	Key	
209	70024698	1	Pinion	
210	70024699	1	Housing	
211	Kit	1	Gasket	
212	70024701	1	Worm	
213	70024702	2	O-Ring	
214	70024703	4	Bolt, M8X40	
217	70024731	1	Assembly, Check Valve (includes items 301 thru 303)	
218	70024744	1	Motor, Drive (includes item 401)	
220	70024706	1	Seal	
221	70024713	1	Bearing	
222	70024707	1	Gear, Worm	
223	70024708	1	Bearing	
224	70024709	1	Ring, Snap	
225	Kit	1	O-Ring	
226	70024711	1	Cover	
227	70024712	1	Seal	
228	70024714	1	Bolt, M10X16	
229	70024715	4	Bolt, M8X20	
230	70024716	1	Fitting	
234	70024720	4	Washer, M8	
235	70024721	4	Washer, M8	
237	Kit	1	Sealant	
238	70024724	1	Kit, Shim Service	
301	N.S.S.	Ref	Valve, Body	

MidWestTech | JLG 4008PS Telehandler Parts Manual | Publication 31211269 Order the manual at mid-west-tech.com >

FIGURE 10-60. ENGINE HARNESS (ULS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001183615	Ref	Engine Harness (ULS)	C
1	1001167688	1	Connector	
2	1001167634	2	Terminal	
3	1001126485	2	Seal	
4	4461118	1	Connector	
5	1001107854	2	Terminal	
6	1001126487	1	Connector	
7	1001167634	2	Terminal	
8	1001126485	2	Seal	
9	1001167616	1	Box, Fuse	
10	8220097	21	Terminal	
11	8220098	16	Terminal	
12	1001116725	3	Terminal	
13	1001175265	5	Seal	
14	4460458	16	Seal	
15	80963067	2	Seal	
16	4460748	5	Plug	
17	8229242	5	Fuse, 5A	
18	8229244	1	Fuse, 15A	
19	8229247	1	Fuse, 25A	
20	8229245	1	Fuse, 30A	
21	1001205172	5	Fuse, 35A	
22	1001177597	1	Fuse, 6A	
23	1001197719	1	Resistor	
24	1001190921	1	Seal, Fuse Box	
25	2902443	1	Kit, Receptacle	
26	4461071	8	Terminal	
27	4461072	1	Housing, Flange Mount Receptacle Inner	
28	4461073	1	Cap, Dust	
29	4461074	1	Housing, Receptacle Outer	
30	1001118282	1	Connector	
31	1001116734	2	Terminal	
32	1001116732	2	Terminal	
33	1001128128	1	Plug	
34	8220108	1	Terminal, Blade	
35	8220108	1	Terminal, Blade	
36	8220115	1	Terminal, Ring	
37	1001167633	1	Connector	
38	1001133715	3	Terminal	
39	1001135650	3	Seal	
40	1001126487	1	Connector	
41	1001167635	2	Terminal	
42	1001126485	2	Seal	
43	4460539	1	Connector	
44	77363244	1	Lock, Connector	
45	4460465	3	Terminal	
46	1001167631	1	Connector	
47	1001167630	4	Terminal	
48	1001126485	4	Seal	
49	1001126362	1	Connector	

MidWestTech | JLG 4008PS Telehandler Parts Manual | Publication 31211269 Order the manual at mid-west-tech.com >

FIGURE 11-8. DECALS INSTALLATION (AUS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001201867	Ref	Decals Installation (LS)	D
1	1701640	1	Decal, Manual	
3	1706098	1	Decal, Warning Ether Start	
4	1706281	1	Decal, Battery Warning	
5	1706282	1	Decal, Carry Personnel	
6	1706284	1	Decal, Electrocution Hazard	
7	1706285	1	Decal, Moving Parts (ISO)	
8	1706288	1	Decal, Tip Over Warning	
9	1706292	2	Decal, Pinch Point Boom Holes	
10	1001100957	4	Decal, Lift/Tie Down Point	
11	8005671	2	Decal, Cylinder Lock Warning	
12	8005675	2	Decal, Watch for Raised Boom Warning	
13	8006612	2	Decal, Stay Clear of Swing Area	
14	8008657	4	Decal, Set Brake Lever Warning	
15	1001094708	1	Decal, Hydraulic Oil	
16	8466306	1	Gage, Tilt Angle	
17	1001009178	8	Tack, Metal	
18	1001092877	1	Decal, Crush Hazard Warning	
19	1001092878	1	Decal, No Riders	
20	1001101895	1	Decal, Cab Warning	
22	1001130323	1	Decal, Oil Level	
23	1001155231	1	Decal, Nameplate Serial Number AUS	
26	1001217423	1	Decal, Boom Extend	
27	1001172035	1	Decal, No Weld Or Drill	
30	1001214206	1	Decal, Park Brake	
31	1001184632	1	Decal, Battery Positive	
32	1001189154	2	Decal, Read Operators Manual Instruction	
33	1001191229	1	Decal, Fuse Panel	
34	1001191487	1	Decal, Fuse Panel	
35	1001195855	1	Decal, Battery Disconnect	
37	AU2105	1	Decal, No Karcher	
38	8005616	2	Decal, Lifting Point	
39	8005870	1	Decal, Emergency Exit	
40	1001008540	1	Plate, Battery	
42	4109801	2	Decal, Tie Down Point	
43	1001155230	1	Decal, Cab AUS Safety	
44	1001138051	1	Plate, Homologation	
45	1001109053	1	Decal, Coolant Fill	

MidWestTech | JLG 4008PS Telehandler Parts Manual | Publication 31211269 Order the manual at mid-west-tech.com >