Illustrated Parts Manual

Models

8010H

SN 0160000001 to SN 0160078381

P/N
31211278

May 28, 2020 - Rev B

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. FRAME WELDMENT 16
FIGURE 1-2. FRAME WELDMENT (TUV) 18
FIGURE 1-3. GROMMETS INSTALLATION 20
FIGURE 1-4. TANK INSTALLATION 22
FIGURE 1-5. TANK INSTALLATION (TUV) 24
FIGURE 1-6. FUEL TANK INSTALLATION 26
FIGURE 1-7. FUEL TANK INSTALLATION (TUV) 28
FIGURE 1-8. HYDRAULIC TANK INSTALLATION 30
FIGURE 1-9. TANK SUPPORT INSTALLATION 32
FIGURE 1-10. FUEL TANK ASSEMBLY 34
FIGURE 1-11. LOCKING FUEL CAP 36
FIGURE 1-12. HYDRAULIC TANK ASSEMBLY 38
FIGURE 1-13. COUNTERWEIGHT INSTALLATION 40
FIGURE 1-14. ENGINE ENCLOSURE INSTALLATION 42
FIGURE 1-15. ENGINE ENCLOSURE ASSEMBLY 44
FIGURE 1-16. ENGINE HOOD ASSEMBLY 46
FIGURE 1-17. ENGINE HOOD INSULATION INSTALLATION 48
FIGURE 1-18. COVER INSTALLATION (ULS) 50
FIGURE 1-19. COVER INSTALLATION (LS) 52
FIGURE 1-20. FRAME COVER INSTALLATION 54
FIGURE 1-21. FRONT LOWER COVER INSTALLATION 56
FIGURE 1-22. PAD LOCK 58
FIGURE 1-23. REFLECTORS INSTALLATION 60
FIGURE 1-24. MIRROR INSTALLATION 62
FIGURE 1-25. MIRROR INSTALLATION 64
FIGURE 1-26. WHEEL CHOCK INSTALLATION 66

SECTION 2 - BOOM 69

FIGURE 2-1. BOOM INSTALLATION 70
FIGURE 2-2. BOOM INSTALLATION 72
FIGURE 2-3. BOOM ASSEMBLY 74
FIGURE 2-4. BOOM ASSEMBLY 76
FIGURE 2-5. FIRST BOOM SECTION ASSEMBLY 78
FIGURE 2-6. FIRST BOOM SECTION ASSEMBLY 80
FIGURE 2-7. SECOND BOOM SECTION ASSEMBLY 82
FIGURE 2-8. SECOND BOOM SECTION ASSEMBLY 84
FIGURE 2-9. THIRD BOOM SECTION ASSEMBLY 86
FIGURE 2-10. COUPLER INSTALLATION (MANUAL) 88
FIGURE 2-11. COUPLER INSTALLATION (HYDRAULIC) 90
FIGURE 2-12. COUPLER LOCKING CYLINDER ASSEMBLY 92
FIGURE 2-13. BOOM ANGLE INDICATOR INSTALLATION 94
FIGURE 2-14. BOOM PROP INSTALLATION 96
FIGURE 2-15. BOOM PROP BRACKET ASSEMBLY 98
FIGURE 2-16. MANUAL COUPLER PIN HOLDER INSTALLATION 100
FIGURE 2-17. BOOM BRUSHES INSTALLATION 102

SECTION 3 - ATTACHMENTS 105

FIGURE 3-1. ATTACHMENT RECOGNITION INSTALLATION 106
FIGURE 3-2. COMPONENTS ATTACHMENT RECOGNITION INSTALLATION 108
FIGURE 3-3. CARRIAGE ASSEMBLY, (60IN/1524MM) 110
FIGURE 3-4. CARRIAGE ASSEMBLY, (72IN/1829MM) 112
FIGURE 3-5. CARRIAGE ASSEMBLY, (87IN/2290MM) 114
FIGURE 3-6. DUAL FORK POSITIONING SIDE SHIFT CARRIAGE, (75IN/1899MM) 116
FIGURE 3-7. DUAL FORK POSITIONING CARRIAGE, (72IN/1829MM) 118
FIGURE 3-8. BUCKET (2.6 YD³/2.0M³) 120
FIGURE 3-9. BUCKET (5.23 YD3) 122
FIGURE 3-10. 4 IN 1 BUCKET (2.6 YD³/2.0M³) 124
FIGURE 3-11. 4 IN 1 BUCKET (1.3 YD³/1.0M³) 126
FIGURE 3-12. GRAPPLE BUCKET (1.7 YD³/1.3M³) 128
FIGURE 3-13. GRAPPLE BUCKET (2.6 YD³/2.0M³) 130
FIGURE 3-14. TRUSS BOOM (7.6 TON) 132
FIGURE 3-15. CRANE HOOK (7.6 TON) 134

MidWestTech | JLG 8010H Boom Lift Parts Manual | Publication 31211278 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-16. COUPLER MOUNTED WINCH 136
FIGURE 3-17. BALE HANDLER (ROUND) 138
FIGURE 3-18. BALE HANDLER (SQUARE) 142
FIGURE 3-19. PIPE HANDLER CARRIAGE 144
FIGURE 3-20. TIRE HANDLER CARRIAGE 148
FIGURE 3-21. LOG HANDLER CARRIAGE 150
FIGURE 3-22. STEEL COIL HANDLER CARRIAGE 154
FIGURE 3-23. PALLET FORK (2.25X6X48) 156
FIGURE 3-24. PALLET FORK (2.25X6X60) 158
FIGURE 3-25. PALLET FORK (2.25X6X72) 160
FIGURE 3-26. PALLET FORK (2.25X6X96) 162
FIGURE 3-27. FORK RETENTION INSTALLATION 164

SECTION 4 - ENGINE AND ATTACHING PARTS 167

FIGURE 4-1. ENGINE POD COMPONENT INSTALLATION (ULS) 168
FIGURE 4-2. ENGINE POD COMPONENT INSTALLATION (LS) 170
FIGURE 4-3. ENGINE INSTALLATION (LS) 172
FIGURE 4-4. ENGINE POD COMPONENT INSTALLATION (MINING) (ULS) 174
FIGURE 4-5. ENGINE POD COMPONENT INSTALLATION (MINING) (LS) 176
FIGURE 4-6. ENGINE POD INSTALLATION (MINING) (LS - HIGH AMBIENT) 178
FIGURE 4-7. ENGINE INSTALLATION (ULS) 180
FIGURE 4-8. ENGINE (100KW - ULS) 182
FIGURE 4-9. ENGINE (100KW - LS) 186
FIGURE 4-10. ENGINE MOUNT INSTALLATION 188
FIGURE 4-11. AIR INTAKE INSTALLATION (ULS) 190
FIGURE 4-12. AIR INTAKE INSTALLATION (LS) 192
FIGURE 4-13. AIR CLEANER INSTALLATION 194
FIGURE 4-14. AIR INTAKE DUCT INSTALLATION 196
FIGURE 4-15. PRIMARY FUEL FILTER INSTALLATION (ULS) 198
FIGURE 4-16. PRIMARY FUEL FILTER INSTALLATION (LS) 200
FIGURE 4-17. REMOTE FUEL PUMP INSTALLATION 202
FIGURE 4-18. FUEL LINES INSTALLATION 204
FIGURE 4-19. FUEL LINES INSTALLATION 206
FIGURE 4-20. FUEL LINES INSTALLATION 208
FIGURE 4-21. HYDROSTATIC ADAPTOR INSTALLATION 210
FIGURE 4-22. DUAL DRIVE SUPPORT ASSEMBLY 212
FIGURE 4-23. HYDROSTATIC DRIVE PUMP INSTALLATION 214
FIGURE 4-24. HYDROSTATIC DRIVE PUMP ASSEMBLY 216
FIGURE 4-25. IMPLEMENT PUMP INSTALLATION 218
FIGURE 4-26. IMPLEMENT PUMP ASSEMBLY 220
FIGURE 4-27. DEF COOLANT LINES INSTALLATION (ULS) 222
FIGURE 4-28. COOLING PACKAGE INSTALLATION 224
FIGURE 4-29. COOLING PACKAGE INSTALLATION (LS) 226
FIGURE 4-30. COOLING PACKAGE INSTALLATION (TUV) 228
FIGURE 4-31. COOLING PACKAGE INSTALLATION 230
FIGURE 4-32. RADIATOR, COOLING PACKAGE 234
FIGURE 4-33. COOLANT LINES INSTALLATION 236
FIGURE 4-34. RADIATOR LINES INSTALLATION 238
FIGURE 4-35. CAC LINES INSTALLATION 240
FIGURE 4-36. SURGE TANK INSTALLATION 242
FIGURE 4-37. TRANSMISION OIL COOLER LINES INSTALLATION 244
FIGURE 4-38. TRANSMISION OIL COOLER LINES INSTALLATION (TUV) 246
FIGURE 4-39. FAN GUARD INSTALLATION 248
FIGURE 4-40. FAN GUARD (REVERSING) INSTALLATION 250
FIGURE 4-41. COOLING FAN INSTALLATION 252
FIGURE 4-42. REVERSE COOLING FAN INSTALLATION 254
FIGURE 4-43. COOLING FAN INSTALLATION 256
FIGURE 4-44. COMPRESSOR COVER INSTALLATION 258
FIGURE 4-45. EXHAUST INSTALLATION (ULS) 260
FIGURE 4-46. EXHAUST INSTALLATION (LS) 262
FIGURE 4-47. DEF CONTROL MODULE INSTALLATION 264
FIGURE 4-48. DEF LINES INSTALLATION 266
FIGURE 4-49. DEF TANK INSTALLATION 268
FIGURE 4-50. DEF TANK ASSEMBLY 270
FIGURE 4-51. MUFFLER INSTALLATION (LS) 272
FIGURE 4-52. MUFFLER INSTALLATION (LS) 274

MidWestTech | JLG 8010H Boom Lift Parts Manual | Publication 31211278 Order the manual at mid-west-tech.com >

FIGURE 4-53. HEATER LINES INSTALLATION (ULS) 276
FIGURE 4-54. HEATER LINES INSTALLATION (LS) 278
FIGURE 4-55. A/C PUMP INSTALLATION 280
FIGURE 4-56. A/C LINES INSTALLATION 282
FIGURE 4-57. BLOCK HEATER INSTALLATION (230V) (ULS) 284
FIGURE 4-58. BLOCK HEATER INSTALLATION (115V) (ULS) 286
FIGURE 4-59. BLOCK HEATER INSTALLATION (230V) (LS) 288
FIGURE 4-60. BLOCK HEATER INSTALLATION (115V) (LS) 290
FIGURE 4-61. AIR SHUT OFF VALVE 292
FIGURE 4-62. ASO VALVE 294
FIGURE 4-63. AIR CLEANER FILTER ASSEMBLY 296

SECTION 5 - DRIVETRAIN 299

FIGURE 5-1. DRIVETRAIN INSTALLATION 300
FIGURE 5-2. FRONT AXLE INSTALLATION 302
FIGURE 5-3. FRONT AXLE MOUNTING INSTALLATION 304
FIGURE 5-4. FRONT AXLE LINES INSTALLATION 306
FIGURE 5-5. REAR AXLE INSTALLATION 308
FIGURE 5-6. REAR AXLE MOUNTING INSTALLATION 310
FIGURE 5-7. REAR AXLE LINES INSTALLATION 312
FIGURE 5-8. FRONT AXLE 314
FIGURE 5-9. FRONT AXLE, CENTRAL HOUSING 316
FIGURE 5-10. FRONT AXLE, DIFFERENTIAL 318
FIGURE 5-11. FRONT AXLE, HUB REDUCTION 320
FIGURE 5-12. FRONT AXLE, BRAKES 322
FIGURE 5-13. FRONT AXLE, STEERING 324
FIGURE 5-14. FRONT AXLE, TRUNION 326
FIGURE 5-15. REAR AXLE 328
FIGURE 5-16. REAR AXLE, CENTRAL HOUSING 330
FIGURE 5-17. REAR AXLE, DIFFERENTIAL 332
FIGURE 5-18. REAR AXLE, HUB REDUCTION 334
FIGURE 5-19. REAR AXLE, BRAKES 336
FIGURE 5-20. REAR AXLE, STEERING 338
FIGURE 5-21. REAR AXLE, TRUNION 340
FIGURE 5-22. DIFFERENTIAL KIT 342
FIGURE 5-23. DIFFERENTIAL KIT 344
FIGURE 5-24. STEERING CASE KIT (RF, LR) 346
FIGURE 5-25. STEERING CASE KIT (LF, RR) 348
FIGURE 5-26. TRUNION KIT 350
FIGURE 5-27. RING GEAR SUPPORT KIT 352
FIGURE 5-28. REDUCTION BUSHING KIT 354
FIGURE 5-29. PLANET GEAR CARRIER KIT 356
FIGURE 5-30. GEARBOX INSTALLATION 358
FIGURE 5-31. GEAR BOX 360
FIGURE 5-32. HYDROSTATIC MOTOR INSTALLATION 364
FIGURE 5-33. HYDROSTATIC MOTOR ASSEMBLY 366
FIGURE 5-34. DRIVE SHAFT INSTALLATION 368
FIGURE 5-35. TIRE/WHEEL SET (AIR 17.5-25 - 20 PLY) 370
FIGURE 5-36. RIGHT TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - 20 PLY) 372
FIGURE 5-37. LEFT TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - 20 PLY) 374
FIGURE 5-38. TIRE/WHEEL SET (FOAM 17.5-25 - 20 PLY) 376
FIGURE 5-39. TIRE/WHEEL SET (AIR 17.5 R25 - RADIAL) 378
FIGURE 5-40. RIGHT TIRE/WHEEL ASSEMBLY (AIR 17.5 R25 - RADIAL) 380
FIGURE 5-41. LEFT TIRE/WHEEL ASSEMBLY (AIR 17.5 R25 - RADIAL) 382
FIGURE 5-42. TIRE/WHEEL SET (AIR 17.5-25 - 22 PLY) 384
FIGURE 5-43. TIRE/WHEEL ASSEMBLY (AIR 17.5-25 - PLY) 386
FIGURE 5-44. FENDER INSTALLATION 388
FIGURE 5-45. RH FENDER ASSEMBLY 390
FIGURE 5-46. LH FENDER ASSEMBLY 392

SECTION 6 - CAB 395

FIGURE 6-1. CAB MOUNTING INSTALLATION 396
FIGURE 6-2. FRONT CAB MOUNT BRACKET INSTALLATION 398
FIGURE 6-3. CAB MOUNTS INSTALLATION 400
FIGURE 6-4. CAB STEP INSTALLATION 402

MidWestTech | JLG 8010H Boom Lift Parts Manual | Publication 31211278 Order the manual at mid-west-tech.com >

FIGURE 2-2. BOOM INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001192352	Ref	Boom Installation	C
1	0701230	1	Bolt, M12X130	
2	0711635	1	Bolt, M16X180 Grade 10.9	
3	0760810	2	Bolt, M8X20	
4	3291205	1	Nut, Lock M12X1.75 Grade 8	
5	3291605	1	Nut, Lock M16X2 Grade 8	
6	4811900	2	Washer, M8	
7	4812100	2	Washer, M12	
8	4812300	2	Washer, M16	
9	1001174103	1	Assembly, Boom Section (See Separate Breakdown in this Section)	
10	1001190254	1	Pin	
12	1001190256	1	Pin	
13	1001190257	1	Plate	
15	1001190260	1	Pin	
16	1001219953	4	Shim	
17	4032010	4	Bolt, M10X30	
18	4812000	4	Washer, M10	
19	1001195655	2	Pad, M44X50X160	
20	1001219905	AR	Shim	

MidWestTech | JLG 8010H Boom Lift Parts Manual | Publication 31211278 Order the manual at mid-west-tech.com >

FIGURE 7-3. BRAKE PEDAL INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001192737	Ref	Brake Pedal Installation	E
2	0760605	4	Bolt, M6X10	
3	0760608	1	Bolt, M6X16	
4	0760810	3	Bolt, M8X20	
5	3290601	3	Nut, M6X1	
6	3760348	1	Ring, Retaining	
10	4811700	4	Washer, M6	
11	4811702	4	Washer, M6	
12	4811900	3	Washer, M8	
14	4831900	3	Washer, Lock M8	
15	8405009	2	Clamp	
16	1001214220	1	Reservoir, Brake	
18	1001162920	1	Seal	
19	1001162922	1	Plate	
20	1001170231	3	Clip	
21	1001171874	1	Fitting, Straight	
22	1001172088	1	Bracket	
23	1001172094	1	Hose	
26	1001213265	1	Assembly, Brake Pedal (See Separate Breakdown in this Section)	
32	1001197139	1	Plate, Brake Pedal	
33	1001205061	Ref	Installation, Brake Sensor (See Separate Breakdown in this Section)	
34	80233218	1	Fitting, Straight ORFS	
35	80333151	1	Fitting, 90 ORFS	
36	1001168054	1	Fitting, 90 ORFS	

MidWestTech | JLG 8010H Boom Lift Parts Manual | Publication 31211278 Order the manual at mid-west-tech.com >

FIGURE 10-34. DRIVING LIGHT INSTALLATION (LED) (LH DIP)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001203082	Ref	Driving Light Installation (LED) (LH Dip)	G
1	0701014	6	Bolt, M10X30	
2	0761010	8	Bolt, M10X20	
4	3290607	4	Nut, Lock M6X1	
5	3291001	2	Nut, M10X1.5	
6	4811700	4	Washer, M6	
7	4812000	16	Washer, M10	
8	1001091715	1	Lamp, Rear (LH)	
	70021341	1	Bulb, 5W	
	70021340	1	Bulb, 21W	
	7029971	1	Bulb, 21W	
9	1001091716	1	Lamp, Rear (RH)	
	70021341	1	Bulb, 5W	
	70021340	1	Bulb, 21W	
	7029971	1	Bulb, 21W	
10	1001159734	1	Switch, Hazard	
11	1001215693	1	Harness, Headlights (See Seperate Breakdown in this Section)	
12	1001183112	2	Assembly, Rear Light Bracket (See Seperate Breakdown in this Section)	
15	1001203368	2	Bracket	
16	1001206100	1	Bracket	
17	1001209692	1	Light, Driving, (RH - LED) (LH Dip)	
18	1001209693	1	Light, Driving, (LH - LED) (LH Dip)	
19	1001209697	1	Cap	
21	1001146588	1	Strap, Cable Tie	
22	1001159737	1	Switch, Fog Lights	
23	1001008559	4	Strap, Cable	

MidWestTech | JLG 8010H Boom Lift Parts Manual | Publication 31211278 Order the manual at mid-west-tech.com >