2017

Parts Manual



JLG 615G

U2017JCT1PUSL

31211297


Order the manual at mid-west-tech.com >

Contents

ACCELERATOR ASSEMBLY [302290] 1
AIR INTAKE ASSEMBLY [302326] 2
BATTERY AND STARTER MOTOR ASSEMBLY [302331] 4
CAM CHAIN ASSEMBLY [302305] 5
CARGO BOX AND TAILGATE ASSEMBLY [302320] 6
CASE/BELT COOLING ASSEMBLY [302328] 8
CLUTCH/V-BELT/MAGNETO COVER ASSEMBLY [302308] 9
COOLING ASSEMBLY [302327] 11
CRANK BALANCER ASSEMBLY [302310] 13
CRANKCASE ASSEMBLY [302306] 14
CRANKSHAFT AND PISTON ASSEMBLY [302307] 16
CYLINDER ASSEMBLY [302303] 17
CYLINDER HEAD AND CAMSHAFT/VALVE ASSEMBLY [302304] 18
DASH ASSEMBLY [302283] 20
DRIVE TRAIN ASSEMBLY [302329] 22
ENGINE AND EXHAUST [302294] 24
FLOOR PANEL ASSEMBLY [302318] 26
FRAME AND RELATED PARTS [302319] 28
FRONT AND REAR BRAKE ASSEMBLY [302324] 30
FRONT DRIVE GEARCASE ASSEMBLY [302298] 32
FRONT SUSPENSION ASSEMBLY [302285] 34
GAS TANK ASSEMBLY [302291] 36
GEAR SHIFTING ASSEMBLY [302315] 38
GRILL AND HEADLIGHT ASSEMBLY [302275] 40
HOOD/FRONT STORAGE AND SIDE PANEL ASSEMBLY [302276] 42
MAGNETO ASSEMBLY [302333] 44
OIL FILTER/PUMP ASSEMBLY [302311] 45
REAR DRIVE GEARCASE ASSEMBLY [302299] 46
REAR SUSPENSION ASSEMBLY [302286] 48
ROPS AND TAILLIGHT ASSEMBLY [302322] 50
SEAT ASSEMBLY [302321] 52
SECONDARY DRIVE ASSEMBLY [302316] 54
SECONDARY TRANSMISSION ASSEMBLY [302314] 56
SHIFTER ASSEMBLY [302325] 58
STARTER CLUTCH ASSEMBLY [302309] 59
STEERING ASSEMBLY [302284] 60
SWAY BAR ASSEMBLY [302287] 62
THROTTLE BODY ASSEMBLY [302302] 63
TILT FRAME ASSEMBLY [302280] 65
TRANSMISSION ASSEMBLY [302313] 67
WATER PUMP ASSEMBLY [302312] 69
WHEEL AND TIRE ASSEMBLY [302323] 70
WIRING HARNESS ASSEMBLY [302330] 71

Order the manual at mid-west-tech.com >


SECONDARY TRANSMISSION ASSEMBLY [302314]



Item	Part No.	New Part	Qty	Name	Context	Footnote
1	1001240404		1	Countershaft Assembly	(inc. 2-10)	
2	1001240538		2	Ring, Retaining		
3	1001240400		1	Gear Select, Reverse		
4	1001240401		4	Shim		
5	1001240399		1	Gear, Reverse Driven		
6	1001240554		3	Bearing		
7	1001240398		1	Gear, Driven - Low		
8	1001240397		1	Countershaft		
9	1001240405		1	Gear Select, Sliding		
10	1001240406		1	Gear, Driven - High		
11	1001240402		1	Gear, Drive		
12	1001240466		1	Washer, Thrust		
13	1001240464		1	Washer		
14	1001240536		1	Ring, Retaining		
15	1001240394		1	Trigger, Speedometer Sensor		
16	1001240482		1	Washer, Thrust		
17	1001240535		1	Ring, Retaining		
18	1001240517		1	Gasket		
19	1001240494		2	Pin, Dowel		
20	1001240393		1	Housing, Speedometer Sensor		

MidWestTech | JLG 615G UTV Parts Manual | Publication 31211297 Order the manual at mid-west-tech.com >


TILT FRAME ASSEMBLY [302280]



Item	Part No.	New Part	Qty	Name	Context	Footnote
1	1001240743		1	Frame,Tilt - Assembly		
2	1001240688		4	Decal, Reflector - Red		
3	1001240811		2	Decal, Warning - Pinch Point		
4	1001240059		4	Bumper		
5	1001240608		2	Bumper		
6	1001240693		1	Endcap, Front - Right		
6	1001240694		1	Endcap, Front - Left		
7	1001240691		1	Endcap, Rear - Right		
7	1001240692		1	Endcap, Rear - Left		
8	1001240600		4	Screw, Cap		
9	1001240901		4	Nut		
10	1001240045		2	Block, Mounting	Upper	
11	1001240044		2	Block, Mounting	Lower	
12	1001240046		2	Cap, Housing		
13	1001240147		4	Screw, Shoulder		
14	1001240272		4	Nut		
15	1001240739		2	Support, Lift		
16	1001240133		4	Screw, Shoulder		
17	1001240744		1	Rod, Latch - Tilt Frame		
18	1001240596		2	Grip, Latch Rod		

MidWestTech | JLG 615G UTV Parts Manual | Publication 31211297 Order the manual at mid-west-tech.com >

WIRING HARNESS ASSEMBLY [302330]



Item	Part No.	New Part	Qty	Name	Context	Footnote
1	1001241174		1	Harness, Main	(inc. 2-10)	
2	1001240218		1	Tether, Accessory Connector		
3	1001240184		1	Cover, Fuse Block		
4	1001240187		1	Breaker, Circuit 15 Amp		
5	1001240175		1	Holder, Fuse		
6	1001240178		6	Relay (4-pin) 20 amp		
7	1001240189		1	Cover, Diagnostics Connector		
8	1001240174		8	Fuse - 10 Amp		
8	1001240186		2	Fuse - 20 Amp		
8	1001240173		4	Fuse - 30 Amp		
9	1001240850		1	Decal, Fuse Block		
10	1001240185		1	Seal		
11	1001240911		2	Nut, Lock		
12	1001240427		1	Coil, Ignition - Assembly	(inc. 13)	
13	1001240426		1	Cap, Spark Plug		
14	1001240934		4	Screw, Machine		
15	1001240271		4	Nut w/Washer		
16	1001241239		1	ECM		
17	1001240935		2	Screw, Machine		
18	1001240904		2	Nut		

MidWestTech | JLG 615G UTV Parts Manual | Publication 31211297 Order the manual at mid-west-tech.com >