Illustrated Parts Manual

Models
943

SN 0160084858 to SN 0160101057
including 0160083719, 0160083720 & 0160084650

P/N

31211314

May 20, 2020 - Rev E

An Oshkosh Corporation Company

MidWestTech | JLG 943 Telehandler Parts Manual | Publication 31211314

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. FRAME (NO OUTRIGGERS) 16
FIGURE 1-2. ENGINE ENCLOSURE INSTALLATION 18
FIGURE 1-3. ENGINE ENCLOSURE COVER INSTALLATION 20
FIGURE 1-4. HOOD ASSEMBLY 22
FIGURE 1-5. HOOD ASSEMBLY 24
FIGURE 1-6. COVER INSTALLATION (NO OUTRIGGERS) (ULS) 26
FIGURE 1-7. COVER INSTALLATION (NO OUTRIGGERS) (LS) 28
FIGURE 1-8. COUNTERWEIGHT INSTALLATION 30
FIGURE 1-9. TANK INSTALLATION 32
FIGURE 1-10. FUEL TANK INSTALLATION 34
FIGURE 1-11. HYDRAULIC TANK INSTALLATION 36
FIGURE 1-12. FUEL CAP ASSEMBLY 38
FIGURE 1-13. MIRROR INSTALLATION 40

SECTION 2 - BOOM 43

FIGURE 2-1. BOOM ASSEMBLY 44
FIGURE 2-2. FIRST BOOM SECTION ASSEMBLY 46
FIGURE 2-3. SECOND BOOM SECTION ASSEMBLY 48
FIGURE 2-4. THIRD BOOM SECTION ASSEMBLY 50
FIGURE 2-5. RETRACT CHAIN INSTALLATION 52
FIGURE 2-6. EXTEND CHAIN INSTALLATION 54
FIGURE 2-7. PINS INSTALLATION 56
FIGURE 2-8. RETRACT CHAIN SHEAVE 58
FIGURE 2-9. EXTEND CHAIN ROLLER 60
FIGURE 2-10. HOSE BRACKET INSTALLATION 62
FIGURE 2-11. BOOM PINNING INSTALLATION 64
FIGURE 2-12. LIFT CYLINDER PINS INSTALLATION 66
FIGURE 2-13. COMPENSATION CYLINDER PINS INSTALLATION 68
FIGURE 2-14. BOOM PIVOT PIN INSTALLATION 70
FIGURE 2-15. MANUAL QUICK COUPLER INSTALLATION 72
FIGURE 2-16. HYDRAULIC QUICK COUPLER INSTALLATION 74
FIGURE 2-17. BOOM PIN INSTALLATION 76
FIGURE 2-18. TILT CYLINDER PIN INSTALLATION 78
FIGURE 2-19. BOOM ANGLE INDICATOR INSTALLATION 80
FIGURE 2-20. BOOM PROP INSTALLATION 82
FIGURE 2-21. BOOM PROP INSTALLATION 84
FIGURE 2-22. BOOM BRUSHES INSTALLATION 86
FIGURE 2-23. QUICK COUPLER ASSEMBLY 88
FIGURE 2-24. BOOM PROP BRACKET 90

SECTION 3 - ATTACHMENTS 93

FIGURE 3-1. CARRIAGE ASSEMBLY (1270MM) 94
FIGURE 3-2. CARRIAGE ASSEMBLY (1524 MM) 96
FIGURE 3-3. CARRIAGE ASSEMBLY (1829 MM) 98
FIGURE 3-4. SIDE TILT CARRIAGE ASSEMBLY (50 INCH) 100
FIGURE 3-5. SIDE TILT CARRIAGE ASSEMBLY (60 INCH) 102
FIGURE 3-6. SIDE TILT CARRIAGE ASSEMBLY (72 INCH) 104
FIGURE 3-7. 90 SWING CARRIAGE ASSEMBLY (72 INCH) 106
FIGURE 3-8. SIDE SHIFT CARRIAGE (5.5 TON - 1270 MM) 108
FIGURE 3-9. FORK POSITIONING CARRIAGE WITH FORKS (4.5 TON) 110
FIGURE 3-10. DUAL FORK CARRIAGE VALVE ASSEMBLY 112
FIGURE 3-11. PALLET FORK (2.36X4X48) 114
FIGURE 3-12. PALLET FORK (2.36X5X48) 116
FIGURE 3-13. PALLET FORK (2.36X4X48) 118
FIGURE 3-14. PALLET FORK (2.36X5X72) 120
FIGURE 3-15. FORK - PALLET (2.4X4X60) 122
FIGURE 3-16. LUMBER FORK (40X150X1540) 124
FIGURE 3-17. LUMBER FORK (50X180X1540) 126
FIGURE 3-18. LUMBER FORK (60X150X1524) 128
FIGURE 3-19. PALLET FORK (2.00X6X72) 130
FIGURE 3-20. BLOCKING FORK (50X50X1220) 132
FIGURE 3-21. FORK CLAMPS INSTALL 134

MidWestTech | JLG 943 Telehandler Parts Manual | Publication 31211314 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-22. FORK EXTENSIONS (62X163X2286) 136
FIGURE 3-23. FORK MOUNTED BUCKET (1.0 M³) 138
FIGURE 3-24. BUCKET 1.0 YD³ (ANSI - JLG) 140
FIGURE 3-25. BUCKET (1.15 M³) 142
FIGURE 3-26. BUCKET (102 INCH) 144
FIGURE 3-27. MULTI-PURPOSE GRAPPLE BUCKET (2450 MM) 146
FIGURE 3-28. TRUSS BOOM (0.9 TON - 3.7M) 148
FIGURE 3-29. TRUSS BOOM (15 FOOT) 150
FIGURE 3-30. ADJUSTABLE TRUSS BOOM 152
FIGURE 3-31. ADJUSTABLE TRUSS BOOM INSTALLATION (FORK MOUNTED) 154
FIGURE 3-32. TRUSS BOOM (1.8 TON - 1M FT WITH WINCH) 156
FIGURE 3-33. TRUSS BOOM (0.9 TON - 3.7M WITH WINCH) 158
FIGURE 3-34. FORK MOUNTED HOOK (4 TON) 160
FIGURE 3-35. CRANE HOOK 162
FIGURE 3-36. MAST (8 FOOT) 164
FIGURE 3-37. SIDE TILT ELECTRIC MAST (8 FOOT) 168
FIGURE 3-38. FORK MOUNTED BASKET 172
FIGURE 3-39. FORK MOUNTED BASKET 174
FIGURE 3-40. FORK MOUNTED BASKET 176
FIGURE 3-41. FORK MOUNTED PLATFORM 178
FIGURE 3-42. SWEEPER - HOPPER ASSEMBLY 180
FIGURE 3-43. FORK MOUNTED TRASH HOPPER 182
FIGURE 3-44. PO CHECK VALVE 184
FIGURE 3-45. MAIN LIFT CYLINDER 186
FIGURE 3-46. KIT DECAL 188
FIGURE 3-47. DRYWALL SWING CARRIAGE INSTALLATION 190
FIGURE 3-48. ROTATING DRYWALL CARRIAGE 192
FIGURE 3-49. DRYWALL BOARD HANDLER 194
FIGURE 3-50. PIVOT FRAME GROUP 196
FIGURE 3-51. DRYWALL CYLINDER 198
FIGURE 3-52. DRYWALL HYDRAULIC GROUP 200
FIGURE 3-53. DRYWALL VALVE ASSEMBLY 202
FIGURE 3-54. DRYWALL CYLINDER 204
FIGURE 3-55. DRYWALL FORK GROUP 206

SECTION 4 - ENGINE AND ATTACHING PARTS 209

FIGURE 4-1. ENGINE INSTALLATION (ULS) 210
FIGURE 4-2. ENGINE INSTALLATION, 74HP (ULS) 212
FIGURE 4-3. ENGINE INSTALLATION (LS) 214
FIGURE 4-4. ENGINE MOUNTING INSTALLATION 216
FIGURE 4-5. 3.8L ENGINE (ULS) 218
FIGURE 4-6. ENGINE, 74HP 220
FIGURE 4-7. 3.8L ENGINE (LS) 222
FIGURE 4-8. FAN INSTALLATION 224
FIGURE 4-9. PRIMARY FUEL FILTER INSTALLATION (ULS) 226
FIGURE 4-10. PRIMARY FUEL FILTER INSTALLATION (LS) 228
FIGURE 4-11. FAN INSTALLATION, 74HP (ULS) 230
FIGURE 4-12. AIR CLEANER LINES INSTALLATION (ULS) 232
FIGURE 4-13. AIR CLEANER LINES INSTALLATION (LS) 234
FIGURE 4-14. AIR CLEANER INSTALLATION (ULS) 236
FIGURE 4-15. AIR CLEANER INSTALLATION (LS) 238
FIGURE 4-16. AIR CLEANER ASSEMBLY (74.4KW) 240
FIGURE 4-17. AIR CLEANER ASSEMBLY (90/100KW) 242
FIGURE 4-18. AIR INTAKE DUCT INSTALLATION 244
FIGURE 4-19. AIR INTAKE SHUT OFF VALVE INSTALLATION 246
FIGURE 4-20. DEF LINES INSTALLATION 248
FIGURE 4-21. FUEL LINES INSTALLATION (ULS) 250
FIGURE 4-22. FUEL LINES INSTALLATION (LS) 254
FIGURE 4-23. COOLING PACKAGE INSTALLATION (ULS) 258
FIGURE 4-24. COOLING PACKAGE INSTALLATION (LS) 260
FIGURE 4-25. RADIATOR COOLING PACKAGE 262
FIGURE 4-26. HOC LINES INSTALLATION 264
FIGURE 4-27. COOLANT LINES INSTALLATION (ULS) 266
FIGURE 4-28. COOLANT LINES INSTALLATION (LS) 268
FIGURE 4-29. CAC LINES INSTALLATION (ULS) 270
FIGURE 4-30. CAC LINES INSTALLATION (LS) 272

MidWestTech | JLG 943 Telehandler Parts Manual | Publication 31211314 Order the manual at mid-west-tech.com >

FIGURE 4-31. TOC LINES INSTALLATION 274
FIGURE 4-32. SURGE TANK INSTALLATION 276
FIGURE 4-33. FAN GUARD INSTALLATION 278
FIGURE 4-34. EXHAUST INSTALLATION (ULS) 280
FIGURE 4-35. EXHAUST INSTALLATION 282
FIGURE 4-36. EXHAUST INSTALLATION (LS) 284
FIGURE 4-37. ENGINE PARTS INSTALLATION (NO HEATER) 286
FIGURE 4-38. ENGINE PARTS INSTALLATION (HEATER) 288
FIGURE 4-39. A/C PUMP INSTALLATION (ULS) 290
FIGURE 4-40. A/C PUMP INSTALLATION (LS) 292
FIGURE 4-41. FUEL TANK ASSEMBLY 294
FIGURE 4-42. DEF TANK INSTALLATION 296
FIGURE 4-43. DEF TANK ASSEMBLY (SN 0160084858 through 0160089430) 298
FIGURE 4-44. DEF TANK ASSEMBLY (SN 0160089431 through 0160101057) 300
FIGURE 4-45. DEF PUMP AND CONTROL INSTALLATION 302
FIGURE 4-46. DEF PUMP LINES INSTALLATION 304
FIGURE 4-47. MUFFLER INSTALLATION (LS) 306
FIGURE 4-48. A/C LINES INSTALLATION 308
FIGURE 4-49. UREA PUMP 310
FIGURE 4-50. HEATER BREATHER - 110 HP 312
FIGURE 4-51. HEATER BREATHER - 74 HP 314
FIGURE 4-52. DEF BREATHER VALVE 316

SECTION 5 - DRIVETRAIN 319

FIGURE 5-1. DRIVETRAIN INSTALLATION, 74HP 320
FIGURE 5-2. DRIVETRAIN INSTALLATION 322
FIGURE 5-3. FRONT AXLE INSTALLATION, 74HP 324
FIGURE 5-4. FRONT AXLE INSTALLATION 326
FIGURE 5-5. REAR AXLE INSTALLATION, 74HP 328
FIGURE 5-6. REAR AXLE INSTALLATION 330
FIGURE 5-7. DRIVE SHAFTS INSTALLATION 332
FIGURE 5-8. FRONT AXLE MOUNTING INSTALLATION, 74HP 334
FIGURE 5-9. FRONT AXLE MOUNTING INSTALLATION 336
FIGURE 5-10. FRONT AXLE LINES INSTALLATION 338
FIGURE 5-11. REAR AXLE MOUNTING INSTALLATION, 74HP 340
FIGURE 5-12. REAR AXLE MOUNTING INSTALLATION 342
FIGURE 5-13. REAR AXLE LINES INSTALLATION 344
FIGURE 5-14. FRONT DRIVE SHAFT INSTALLATION 346
FIGURE 5-15. REAR DRIVE SHAFT INSTALLATION 348
FIGURE 5-16. FRONT AXLE, 74HP 350
FIGURE 5-17. FRONT AXLE, CENTRAL HOUSING 74HP 352
FIGURE 5-18. FRONT AXLE, DIFFERENTIAL 74HP 354
FIGURE 5-19. FRONT AXLE, HUB REDUCTION 74HP 356
FIGURE 5-20. FRONT AXLE, BRAKES 74HP 360
FIGURE 5-21. FRONT AXLE, STEERING 74HP 362
FIGURE 5-22. FRONT AXLE, TRUNION 74HP 364
FIGURE 5-23. FRONT AXLE 366
FIGURE 5-24. FRONT AXLE, BRAKES 368
FIGURE 5-25. FRONT AXLE, CENTRAL HOUSING 370
FIGURE 5-26. FRONT AXLE, DIFFERENTIAL 372
FIGURE 5-27. FRONT AXLE, HUB REDUCTION 374
FIGURE 5-28. FRONT AXLE, STEERING 376
FIGURE 5-29. FRONT AXLE, TRUNION 378
FIGURE 5-30. FRONT AXLE, DIFFERENTIAL KIT 380
FIGURE 5-31. FRONT AXLE, PLANET GEAR CARRIER 382
FIGURE 5-32. FRONT AXLE, RING GEAR SUPPORT 384
FIGURE 5-33. FRONT AXLE, PLANET GEAR CARRIER 386
FIGURE 5-34. FRONT AXLE, SUPPORT 388
FIGURE 5-35. FRONT AXLE, SUPPORT 390
FIGURE 5-36. REAR AXLE, 74HP 392
FIGURE 5-37. REAR AXLE, CENTRAL HOUSING 74HP 394
FIGURE 5-38. REAR AXLE, DIFFERENTIAL 74HP 396
FIGURE 5-39. REAR AXLE, HUB REDUCTION 74HP 398
FIGURE 5-40. REAR AXLE, BRAKES 74HP 402
FIGURE 5-41. REAR AXLE, STEERING 74HP 404
FIGURE 5-42. REAR AXLE, TRUNION 74HP 406

MidWestTech | JLG 943 Telehandler Parts Manual | Publication 31211314 Order the manual at mid-west-tech.com >

FIGURE 3-43. FORK MOUNTED TRASH HOPPER

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001195082	Ref	Fork Mounted Trash Hopper	J
1	0700614	4	Bolt, M6X30	
2	3290601	4	Nut, M6X1 Grade 8	
3	3391410	6	Pin	
4	4811700	8	Washer, M6	
5	5242400	4	Washer, M24	
6	1001192711	1	Door Assembly	
7	1001192720	1	Hook Assembly	
8	N.S.S.	1	Weldment, Trash Hopper	
9	1001192875	1	Tray Assembly	
10	1001192876	2	Arm, Swing	
11	1001192877	1	Rod, Swing	
12	1001193525	1	Bar	
13	1001193540	2	Pin	
14	1001193729	2	Plate	
15	1001198355	2	Spacer	
16	1001102813	2	Pin	
17	N.S.S.	1	S/N Plate	
18	1001203503	1	Decal, Trash Hopper Operation	
19	1706302	2	Decal, Pinch Point	
20	0641510	2	Bolt, 5/16-18 x 1-1/4	
21	3311502	2	Nut, 5/16-18	

MidWestTech | JLG 943 Telehandler Parts Manual | Publication 31211314 Order the manual at mid-west-tech.com >

FIGURE 10-2. MAIN ELECTRICAL INSTALLATION (ULS) (74 HP)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001225986	Ref	Main Electrical Installation (ULS) (74 HP)	B
1	1001167051	Ref	Installation, Electrical Frame (See Separate Breakdown in this Section)	
2	1001173765	Ref	Installation, Engine Bay Electrical (See Separate Breakdown in this Section)	
3	1001225987	Ref	Installation, Wiring Frame (See Separate Breakdown in this Section)	
4	1001227963	Ref	Installation, Engine Bay Wiring (See Separate Breakdown in this Section)	

MidWestTech | JLG 943 Telehandler Parts Manual | Publication 31211314 Order the manual at mid-west-tech.com >

FIGURE 10-90. ENGINE AIR SHUT OFF VALVE HARNESS

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001231483	Ref	Air Shut Off Valve Harness (Engine)	D
1	1001187079	1	Terminal, Ring	
2	1001231397	1	Connector	
3	8229235	1	Fuse, 20amp	
4	1001231401	2	Terminal	
5	1001230402	2	Seal	
10	1001187078	1	Terminal, Ring	
11	1001231397	1	Connector	
12	8229261	1	Fuse, 20amp	
13	1001231400	2	Terminal	
14	1001230403	2	Seal	
15	1001116812	1	Connector	
16	4460465	2	Terminal	
17	4460466	1	Plug	
18	4460884	1	Connector	
19	4460465	4	Terminal	
20	1001187079	1	Terminal, Ring	
21	1001144147	1	Connector	
22	4460464	2	Terminal	
23	4460466	1	Plug	
24	1001116812	1	Connector	
25	4460465	2	Terminal	
26	4460466	1	Plug	
27	1001116812	1	Connector	
28	4460465	2	Terminal	
29	4460466	1	Plug	
30	4460539	1	Connector	
31	4460465	2	Terminal	
32	4460466	1	Plug	
33	1001116815	1	Connector, 3 Pin	
34	4460945	1	Terminal, 3 Way "T" Receptacle	
35	4460891	1	Connector	
36	1001157890	2	Terminal	
37	4460742	1	Connector	
38	4460475	2	Terminal	
39	4460458	2	Plug	
40	1001116774	1	Connector	
41	4460518	8	Plug	
42	1001126008	4	Terminal	
43	1001116808	1	Connector	
44	1001126008	9	Terminal	
45	4460518	3	Plug	
46	4460761	1	Connector	
47	4460321	1	Terminal	
48	1001118378	4	Terminal	
49	4460809	4	Plug	
50	1001143551	1	Seal	
51	1001218358	1	Lanyard Rope	
52	1001231398	1	Connector	
53	1001231400	4	Terminal	

MidWestTech | JLG 943 Telehandler Parts Manual | Publication 31211314 Order the manual at mid-west-tech.com >