Illustrated Parts Manual

Models
1055
1255

PVC
1911
2005

P/N
31211373

July 1, 2020 - Rev B

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 17

FIGURE 1-1. FRAME COVER INSTALLATION (ULS) 18
FIGURE 1-2. FRAME COVER INSTALLATION (LS) 20
FIGURE 1-3. ENGINE MOUNTING INSTALLATION 22
FIGURE 1-4. ENGINE ENCLOSURE INSTALLATION 24
FIGURE 1-5. ENGINE ENCLOSURE COVER INSTALLATION 26
FIGURE 1-6. HOOD ASSEMBLY 28
FIGURE 1-7. TANK INSTALLATION 30
FIGURE 1-8. FUEL TANK INSTALLATION 32
FIGURE 1-9. HYDRAULIC TANK INSTALLATION 34
FIGURE 1-10. OUTRIGGERS INSTALLATION 36
FIGURE 1-11. COUNTERWEIGHT INSTALLATION - 1055 38
FIGURE 1-12. COUNTERWEIGHT INSTALLATION - 1255 40
FIGURE 1-13. MIRROR INSTALLATION 42

SECTION 2 - BOOM 45

FIGURE 2-1. BOOM ASSEMBLY - 1055 46
FIGURE 2-2. BOOM ASSEMBLY - 1255 50
FIGURE 2-3. FIRST BOOM ASSEMBLY - 1055 54
FIGURE 2-4. FIRST BOOM ASSEMBLY - 1255 56
FIGURE 2-5. SECOND BOOM ASSEMBLY - 1055 58
FIGURE 2-6. SECOND BOOM ASSEMBLY - 1255 60
FIGURE 2-7. THIRD BOOM ASSEMBLY - 1055 62
FIGURE 2-8. THIRD BOOM ASSEMBLY - 1255 64
FIGURE 2-9. FOURTH BOOM ASSEMBLY - 1055 66
FIGURE 2-10. FOURTH BOOM ASSEMBLY - 1255 68
FIGURE 2-11. EXTEND CYLINDER PINS INSTALLATION 70
FIGURE 2-12. SECOND BOOM SECTION EXTEND CHAIN INSTALLATION - 1055 72
FIGURE 2-13. SECOND BOOM SECTION EXTEND CHAIN INSTALLATION - 1255 74
FIGURE 2-14. THIRD BOOM SECTION EXTEND CHAIN INSTALLATION 76
FIGURE 2-15. SECOND BOOM SECTION RETRACT CHAIN INSTALLATION - 1055 78
FIGURE 2-16. SECOND BOOM SECTION RETRACT CHAIN INSTALLATION - 1255 80
FIGURE 2-17. THIRD BOOM SECTION RETRACT CHAIN INSTALLATION - 1055 82
FIGURE 2-18. THIRD BOOM SECTION RETRACT CHAIN INSTALLATION - 1255 84
FIGURE 2-19. CHAIN SHEAVE ASSEMBLY 86
FIGURE 2-20. CHAIN SHEAVE ASSEMBLY 88
FIGURE 2-21. CHAIN SHEAVE ASSEMBLY 90
FIGURE 2-22. CHAIN SHEAVE ASSEMBLY 92
FIGURE 2-23. BOOM PINNING INSTALLATION 94
FIGURE 2-24. BOOM PIVOT INSTALLATION 96
FIGURE 2-25. LIFT CYLINDER INSTALLATION 98
FIGURE 2-26. COMPENSATION CYLINDER INSTALLATION 100
FIGURE 2-27. BOOM BRUSHES INSTALLATION 102
FIGURE 2-28. BOOM ANGLE INDICATOR INSTALLATION 104
FIGURE 2-29. MANUAL QUICK COUPLER INSTALLATION 106
FIGURE 2-30. HYDRAULIC QUICK COUPLER INSTALLATION 108
FIGURE 2-31. BOOM PIN INSTALLATION 110
FIGURE 2-32. TILT CYLINDER PIN INSTALLATION 112
FIGURE 2-33. QUICK COUPLER ASSEMBLY 114
FIGURE 2-34. BOOM PROP INSTALLATION (ANSI) 116
FIGURE 2-35. BOOM PROP INSTALLATION (CANADA) 118
FIGURE 2-36. BOOM PROP BRACKET 120

SECTION 3 - ATTACHMENTS 123

FIGURE 3-1. CARRIAGE ASSEMBLY (50 INCH) (PVC 1911) 124
FIGURE 3-2. CARRIAGE ASSEMBLY (50 INCH) (PVC 2005) 126
FIGURE 3-3. CARRIAGE ASSEMBLY (1524 MM) (PVC 1911) 128
FIGURE 3-4. CARRIAGE ASSEMBLY (1524 MM) (PVC 2005) 130
FIGURE 3-5. CARRIAGE ASSEMBLY (72 INCH) (PVC 1911) 132
FIGURE 3-6. CARRIAGE ASSEMBLY (72 INCH) (PVC 2005) 134
FIGURE 3-7. SIDE TILT CARRIAGE ASSEMBLY (50 INCH) (PVC 1911) 136
FIGURE 3-8. SIDE TILT CARRIAGE ASSEMBLY (50 INCH) (PVC 2005) 138
FIGURE 3-9. SIDE TILT CARRIAGE ASSEMBLY (60 INCH) (PVC 1911) 140

MidWestTech | JLG 1055, 1255 Telehandler Parts Manual | Publication 31211373 **Order the manual at mid-west-tech.com >**

TABLE OF CONTENTS

FIGURE 3-10. SIDE TILT CARRIAGE ASSEMBLY (60 INCH) (PVC 2005) 142
FIGURE 3-11. SIDE TILT CARRIAGE ASSEMBLY (72 INCH) (PVC 1911) 144
FIGURE 3-12. SIDE TILT CARRIAGE ASSEMBLY (72 INCH) (PVC 2005) 146
FIGURE 3-13. CARRIAGE ASSEMBLY - 48IN/12000# CAPICITY SIDE SHIFT (PVC 2005) 148
FIGURE 3-14. 90 SWING CARRIAGE ASSEMBLY (72 INCH) (PVC 1911) 150
FIGURE 3-15. 90 SWING CARRIAGE ASSEMBLY (72 INCH) (PVC 2005) 152
FIGURE 3-16. FORK POSITIONING CARRIAGE WITH FORKS (4.5 TON) (PVC 1911) 154
FIGURE 3-17. FORK POSITIONING CARRIAGE WITH FORKS (4.5 TON) (PVC 2005) 156
FIGURE 3-18. DUAL FORK CARRIAGE ASSEMBLY 158
FIGURE 3-19. DUAL FORK CARRIAGE VALVE ASSEMBLY 160
FIGURE 3-20. DUAL FORK POSITIONING CARRIAGE ASSEMBLY (50 INCH) - 1255 162
FIGURE 3-21. BOOM - 3FT WITH WINCH (PVC 1911) 164
FIGURE 3-22. BOOM - 3FT WITH WINCH (PVC 2005) 166
FIGURE 3-23. TRUSS BOOM (0.9 TON - 3.7M WITH WINCH) 168
FIGURE 3-24. TRUSS BOOM (0.9 TON - 3.7M) (PVC 1911) 170
FIGURE 3-25. TRUSS BOOM (0.9 TON - 3.7M) (PVC 2005) 172
FIGURE 3-26. TRUSS BOOM (15 FOOT) (PVC 1911) 174
FIGURE 3-27. TRUSS BOOM (15 FOOT) (PVC 2005) 176
FIGURE 3-28. ADJUSTABLE TRUSS BOOM (PVC 1911) 178
FIGURE 3-29. ADJUSTABLE TRUSS BOOM (PVC 2005) 180
FIGURE 3-30. MAST (8 FOOT) 182
FIGURE 3-31. SIDE TILT ELECTRIC MAST (8 FOOT) 186
FIGURE 3-32. KIT DECAL 190
FIGURE 3-33. MAIN LIFT CYLINDER 192
FIGURE 3-34. FORK MOUNTED BUCKET (1.0 M^3) 194
FIGURE 3-35. BUCKET 1.0 YD^3 (ANSI - JLG) (PVC 1911) 196
FIGURE 3-36. BUCKET 1.0 YD^3 (ANSI - JLG) (PVC 2005) 198
FIGURE 3-37. BUCKET (1.15 M^3) (PVC 1911) 200
FIGURE 3-38. BUCKET (1.15 M^3) (PVC 2005) 202
FIGURE 3-39. BUCKET (102 INCH) 204
FIGURE 3-40. FORK MOUNTED BASKET 206
FIGURE 3-41. FORK MOUNTED BASKET 208
FIGURE 3-42. FORK MOUNTED BASKET 210
FIGURE 3-43. FORK MOUNTED PLATFORM 212
FIGURE 3-44. PIPE HANDLER CARRIAGE 214
FIGURE 3-45. FORK MOUNTED HOOK (4 TON) 218
FIGURE 3-46. COUPLER MOUNTED HOOK (PVC 1911) 220
FIGURE 3-47. COUPLER MOUNTED HOOK (PVC 2005) 222
FIGURE 3-48. FORK CLAMPS INSTALL 224
FIGURE 3-49. BLOCKING FORK (50X50X1220) 226
FIGURE 3-50. LUMBER FORK (40X150X1540) 228
FIGURE 3-51. LUMBER FORK (50X180X1540) 230
FIGURE 3-52. PALLET FORK (2.36X4X48) 232
FIGURE 3-53. PALLET FORK (2.36X5X48) 234
FIGURE 3-54. FORK - PALLET (2.4X4X60) 236
FIGURE 3-55. PALLET FORK (60X125X1524) 238
FIGURE 3-56. PALLET FORK (2.36X4X48) 240
FIGURE 3-57. PALLET FORK (2.36X5X72) 242
FIGURE 3-58. LUMBER FORK (60X150X1524) 244
FIGURE 3-59. PALLET FORK (2.00X6X72) (PVC 1911) 246
FIGURE 3-60. PALLET FORK (2.00X6X72) (PVC 2005) 248
FIGURE 3-61. PALLET FORK (2.00X6X48) 250
FIGURE 3-62. FORK EXTENSIONS (62X163X2286) 252
FIGURE 3-63. FORK MOUNTED TRASH HOPPER 254
FIGURE 3-64. ADJUSTABLE TRUSS BOOM INSTALLATION (FORK MOUNTED) 256
FIGURE 3-65. SWEEPER ASSEMBLY 258
FIGURE 3-66. SWEEPER - HOPPER ASSEMBLY 260
FIGURE 3-67. SWEEPER - BODY ASSEMBLY 262
FIGURE 3-68. SWEEPER - MOTOR ASSEMBLY 264
FIGURE 3-69. SWEEPER - IDLER ASSEMBLY 266
FIGURE 3-70. SWEEPER - CORE ASSEMBLY 268
FIGURE 3-71. SWEEPER - HYDRAULIC SINGLE MOTOR ASSEMBLY 270
FIGURE 3-72. SWING CARRIAGE 180 (PVC 1911) 272
FIGURE 3-73. SWING CARRIAGE 180 (PVC 2005) 278
FIGURE 3-74. DRYWALL SWING CARRIAGE INSTALLATION (PVC 1911) 284
FIGURE 3-75. DRYWALL SWING CARRIAGE INSTALLATION (PVC 2005) 286
FIGURE 3-76. ROTATING DRYWALL CARRIAGE 288

MidWestTech | JLG 1055, 1255 Telehandler Parts Manual | Publication 31211373 Order the manual at mid-west-tech.com >

FIGURE 3-77. DRYWALL BOARD HANDLER 290
FIGURE 3-78. PIVOT FRAME GROUP 292
FIGURE 3-79. DRYWALL CYLINDER 294
FIGURE 3-80. DRYWALL HYDRAULIC GROUP 296
FIGURE 3-81. DRYWALL VALVE ASSEMBLY 298
FIGURE 3-82. DRYWALL CYLINDER 300
FIGURE 3-83. DRYWALL FORK GROUP 302
FIGURE 3-84. MULTI-PURPOSE GRAPPLE BUCKET (2450 MM) 304
FIGURE 3-85. SIDE TILT CARRIAGE ASSEMBLY (60 INCH) (PVC 2005) 306

SECTION 4 - ENGINE AND ATTACHING PARTS 309

FIGURE 4-1. ENGINE INSTALLATION (ULS) 310
FIGURE 4-2. ENGINE INSTALLATION (LS) 312
FIGURE 4-3. 3.8L ENGINE (ULS) (PVC 1911) 314
FIGURE 4-4. 3.8L ENGINE (ULS) (PVC 2005) 316
FIGURE 4-5. 3.8L ENGINE (LS) 318
FIGURE 4-6. FUEL LINES INSTALLATION (ULS) 320
FIGURE 4-7. FUEL LINES INSTALLATION (LS) 324
FIGURE 4-8. PRIMARY FUEL FILTER INSTALLATION (ULS) 328
FIGURE 4-9. PRIMARY FUEL FILTER INSTALLATION (LS) 330
FIGURE 4-10. FUEL TANK ASSEMBLY 332
FIGURE 4-11. COOLING PACKAGE INSTALLATION (ULS) 334
FIGURE 4-12. COOLING PACKAGE INSTALLATION (LS) 336
FIGURE 4-13. RADIATOR COOLING PACKAGE 338
FIGURE 4-14. HOC LINES INSTALLATION 340
FIGURE 4-15. COOLANT LINES INSTALLATION (ULS) 342
FIGURE 4-16. COOLANT LINES INSTALLATION (LS) 344
FIGURE 4-17. CAC LINES INSTALLATION (ULS) 346
FIGURE 4-18. CAC LINES INSTALLATION (LS) 348
FIGURE 4-19. TOC LINES INSTALLATION 350
FIGURE 4-20. SURGE TANK INSTALLATION 352
FIGURE 4-21. FAN INSTALLATION 354
FIGURE 4-22. FAN GUARD INSTALLATION 356
FIGURE 4-23. AIR INTAKE LINES INSTALLATION (ULS) 358
FIGURE 4-24. AIR CLEANER LINES INSTALLATION (LS) 360
FIGURE 4-25. AIR CLEANER INSTALLATION (ULS) 362
FIGURE 4-26. AIR CLEANER INSTALLATION (LS) 364
FIGURE 4-27. AIR CLEANER ASSEMBLY (90/100KW) 366
FIGURE 4-28. AIR INTAKE DUCT INSTALLATION 368
FIGURE 4-29. EXHAUST INSTALLATION (ULS) 370
FIGURE 4-30. EXHAUST INSTALLATION (LS) 372
FIGURE 4-31. MUFFLER INSTALLATION (LS) 374
FIGURE 4-32. DEF LINES INSTALLATION 376
FIGURE 4-33. DEF PUMP LINES INSTALLATION 378
FIGURE 4-34. DEF TANK INSTALLATION 380
FIGURE 4-35. DEF PUMP AND CONTROL INSTALLATION 382
FIGURE 4-36. UREA PUMP 384
FIGURE 4-37. DEF TANK ASSEMBLY 386
FIGURE 4-38. DEF BREATHER VALVE 388
FIGURE 4-39. ENGINE PARTS INSTALLATION (NO HEATER) 390
FIGURE 4-40. ENGINE PARTS INSTALLATION (HEATER) 392
FIGURE 4-41. A/C PUMP INSTALLATION (ULS) 394
FIGURE 4-42. A/C PUMP INSTALLATION (LS) 396
FIGURE 4-43. A/C LINES INSTALLATION 398
FIGURE 4-44. FUEL CAP ASSEMBLY 400
FIGURE 4-45. HEATER BREATHER 402
FIGURE 4-46. AIR INTAKE SHUT OFF VALVE INSTALLATION 404

SECTION 5 - DRIVE TRAIN 407

FIGURE 5-1. DRIVE TRAIN INSTALLATION 408
FIGURE 5-2. FRONT AXLE INSTALLATION 410
FIGURE 5-3. FRONT AXLE MOUNTING INSTALLATION 412
FIGURE 5-4. FRONT AXLE 414
FIGURE 5-5. FRONT AXLE, CENTRAL HOUSING 416
FIGURE 5-6. FRONT AXLE, DIFFERENTIAL 418

MidWestTech | JLG 1055, 1255 Telehandler Parts Manual | Publication 31211373 Order the manual at mid-west-tech.com >

FIGURE 5-4. FRONT AXLE

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001160802	Ref	FRONT AXLE	G
1		Ref	Front Axle, Central Housing (See Separate Breakdown in this Section)	
2		Ref	Front Axle, Differential (See Separate Breakdown in this Section)	
3		Ref	Front Axle, Hub Reduction (See Separate Breakdown in this Section)	
4		Ref	Front Axle, Brakes (See Separate Breakdown in this Section)	
5		Ref	Front Axle, Steering (See Separate Breakdown in this Section)	
6		Ref	Front Axle, Trunion (See Separate Breakdown in this Section)	

MidWestTech | JLG 1055, 1255 Telehandler Parts Manual | Publication 31211373 Order the manual at mid-west-tech.com >

FIGURE 6-10. EROPS CAB INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001173419	Ref	EROPS CAB INSTALLATION	K
3	1001160508	Ref	Installation, Mirror (See Separate Breakdown in this Section)	
4	1001161499	Ref	Installation, Accelerator Pedal (See Separate Breakdown in Controls Section)	
5	1001155447	Ref	Installation, Front Wiper (See Separate Breakdown in this Section)	
6	1001162789	Ref	Installation, Washer Tank (See Separate Breakdown in this Section)	
7	1001170366	Ref	Installation, Front Cover (See Separate Breakdown in this Section)	
8	1001172401	Ref	Installation, Level Indicator (See Separate Breakdown in this Section)	
9	1001204598	1	Decal, Emergency Exit	
10	1001214326	Ref	Cab (See Separate Breakdown in this Section)	
11	1001214332	Ref	Installation, Enclosed Cab (See Separate Breakdown in this Section)	

MidWestTech | JLG 1055, 1255 Telehandler Parts Manual | Publication 31211373 Order the manual at mid-west-tech.com >

FIGURE 9-1. CYLINDER GROUP INSTALLATION - 1055

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001160721	Ref	Cylinder Group Installation - 1055	H
1	1001208766	Ref	Installation, Lift Cylinder (See Separate Breakdown in HYDRAULIC CIRCUITS Section)	
2	1001196455	Ref	Cylinder, Tilt - 1055 (See Separate Breakdown in this Section)	
3	1001184452	Ref	Cylinder, Compensation - 1055 (See Separate Breakdown in this Section)	
4	1001162076	Ref	Installation, Frame Level Cylinder (See Separate Breakdown in HYDRAULIC CIRCUITS Section)	
5	1001213065	Ref	Cylinder, Outrigger (See Separate Breakdown in this Section)	
6	1001164036	Ref	Installation, Rear Axle Stabilizer Cylinder (See Separate Breakdown in HYDRAULIC CIRCUITS Section)	
7	1001171330	Ref	Installation, Extend/Retract Cylinder (See Separate Breakdown in HYDRAULIC CIRCUITS Section)	

MidWestTech | JLG 1055, 1255 Telehandler Parts Manual | Publication 31211373 Order the manual at mid-west-tech.com >