Illustrated Parts Manual

Model
1732

PVC
1911
2005

P/N
31211381

June 15, 2020 - Rev B

An Oshkosh Corporation Company

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211381

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME AND ATTACHING PARTS 15

FIGURE 1-1. GROMMETS INSTALLATION 16
FIGURE 1-2. TANKS INSTALLATION 18
FIGURE 1-3. HYDRAULIC TANK INSTALLATION 20
FIGURE 1-4. HYDRAULIC TANK ASSEMBLY 22
FIGURE 1-5. FUEL TANK INSTALLATION 24
FIGURE 1-6. FUEL TANK ASSEMBLY 26
FIGURE 1-7. TANK SUPPORT INSTALLATION 28
FIGURE 1-8. LOCKING FUEL CAP 30
FIGURE 1-9. PAD LOCK 32
FIGURE 1-10. ENGINE ENCLOSURE & HOOD INSTALLATION 34
FIGURE 1-11. HOOD ASSEMBLY 36
FIGURE 1-12. ENGINE ENCLOSURE ASSEMBLY 38
FIGURE 1-13. COVER INSTALLATION (ULS) 40
FIGURE 1-14. FRAME COVER INSTALLATION 42
FIGURE 1-15. FRONT LOWER COVER INSTALLATION 44
FIGURE 1-16. MIRROR INSTALLATION 46
FIGURE 1-17. WHEEL CHOCK INSTALLATION 48

SECTION 2 - BOOM 51

FIGURE 2-1. BOOM INSTALLATION 52
FIGURE 2-2. BOOM ASSEMBLY 54
FIGURE 2-3. FIRST BOOM SECTION ASSEMBLY 56
FIGURE 2-4. SECOND BOOM SECTION ASSEMBLY 58
FIGURE 2-5. COUPLER INSTALLATION (MANUAL) 60
FIGURE 2-6. COUPLER INSTALLATION (HYDRAULIC) 62
FIGURE 2-7. COUPLER LOCKING CYLINDER ASSEMBLY 64
FIGURE 2-8. MANUAL COUPLER PIN HOLDER INSTALLATION 66
FIGURE 2-9. BOOM BRUSHES INSTALLATION 68
FIGURE 2-10. BOOM PROP INSTALLATION 70
FIGURE 2-11. BOOM PROP BRACKET ASSEMBLY 72

SECTION 3 - ATTACHMENTS 75

FIGURE 3-1. ATTACHMENT RECOGNITION INSTALLATION - COMPLETE 76
FIGURE 3-2. ATTACHMENT RECOGNITION INSTALLATION 78
FIGURE 3-3. ATTACHMENT RECOGNITION RECEIVER 80
FIGURE 3-4. ATTACHMENT RECOGNITION ANTENNA 82
FIGURE 3-5. BALE HANDLER (ROUND BALES) 84
FIGURE 3-6. BALE HANDLER (SQUARE BALES) 88
FIGURE 3-7. BASKET, PERSONNEL (1.2MX2.4M) (DOMESTIC) 90
FIGURE 3-8. BASKET, PERSONNEL (1.2MX2.4M) (ISO) 92
FIGURE 3-9. BASKET, PERSONNEL (1.2MX2.4M) (FRENCH LANGUAGE) 94
FIGURE 3-10. BASKET ASSEMBLY - FORK MOUNTED 96
FIGURE 3-11. BASKET DOCKING STATION 98
FIGURE 3-12. BOOM - TRUSS (3.6TON FORK MOUNTED) 100
FIGURE 3-13. BOOM - TRUSS (7.6 TON) 102
FIGURE 3-14. BUCKET (2.6 YD^3/2.0M^3) 104
FIGURE 3-15. BUCKET (5.23 YD^3) 106
FIGURE 3-16. BUCKET - 4 IN 1 (2.6 YD^3/2.0M^3) 108
FIGURE 3-17. BUCKET - 4 IN 1 (1.3 YD^3/1.0M^3) 110
FIGURE 3-18. BUCKET - GRAPPLE (1.7 YD^3/1.3M^3) 112
FIGURE 3-19. BUCKET - GRAPPLE (2.6 YD^3/2.0M^3) 114
FIGURE 3-20. BUCKET - FORK MOUNTED (1.0M^3) 116
FIGURE 3-21. CARRIAGE ASSEMBLY (60IN/1524MM) 118
FIGURE 3-22. CARRIAGE ASSEMBLY (72IN/1829MM) 120
FIGURE 3-23. CARRIAGE ASSEMBLY (87IN/2290MM) 122
FIGURE 3-24. CARRIAGE ASSEMBLY - DUAL FORK POSITIONING CARRIAGE (72IN/1829MM) 124
FIGURE 3-25. CARRIAGE ASSEMBLY - DUAL FORK POSITIONING SIDE SHIFT CARRIAGE (75IN/1899MM) 126
FIGURE 3-26. CARRIAGE ASSEMBLY - LOG HANDLER CARRIAGE 128
FIGURE 3-27. CARRIAGE ASSEMBLY - PIPE HANDLER CARRIAGE 132
FIGURE 3-28. CARRIAGE ASSEMBLY - STEEL COIL HANDLER CARRIAGE 136
FIGURE 3-29. CARRIAGE ASSEMBLY - TIRE HANDLER CARRIAGE (PVC1911) 138
FIGURE 3-30. CARRIAGE ASSEMBLY - TIRE HANDLER (PVC 2005) 140

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211381 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-31. FORK - PALLET (2.25X6X48) 144
FIGURE 3-32. FORK - PALLET (2.25X6X60) 146
FIGURE 3-33. FORK - PALLET (2.25X6X72) 148
FIGURE 3-34. FORK - PALLET (2.25X6X96) 150
FIGURE 3-35. FORK RETENTION INSTALLATION 152
FIGURE 3-36. HOOK - CRANK (7.6 TON) 154
FIGURE 3-37. HOOK ATTACH - FORK MOUNTED 156
FIGURE 3-38. HOPPER - TRASH 158
FIGURE 3-39. WINCH - COUPLER MOUNTED 160

SECTION 4 - ENGINE AND ATTACHING PARTS 163

FIGURE 4-1. ENGINE POD COMPONENT INSTALLATION (ULS) 164
FIGURE 4-2. ENGINE POD COMPONENT INSTALLATION (MINING) (ULS) 166
FIGURE 4-3. ENGINE INSTALLATION (ULS) 168
FIGURE 4-4. ENGINE ASSEMBLY (ULS) 170
FIGURE 4-5. ENGINE MOUNT INSTALLATION 174
FIGURE 4-6. AIR INTAKE INSTALLATION (ULS) 176
FIGURE 4-7. AIR CLEANER INSTALLATION 178
FIGURE 4-8. AIR CLEANER ASSEMBLY 180
FIGURE 4-9. AIR INTAKE DUCT INSTALLATION 182
FIGURE 4-10. PRIMARY FUEL FILTER INSTALLATION (ULS) 184
FIGURE 4-11. REMOTE FUEL PUMP INSTALLATION 186
FIGURE 4-12. FUEL LINES INSTALLATION (ULS) 188
FIGURE 4-13. HYDROSTATIC ADAPTOR INSTALLATION 190
FIGURE 4-14. DUAL DRIVE SUPPORT ASSEMBLY 192
FIGURE 4-15. HYDROSTATIC DRIVE PUMP INSTALLATION 194
FIGURE 4-16. HYDROSTATIC DRIVE PUMP ASSEMBLY 196
FIGURE 4-17. IMPLEMENT PUMP INSTALLATION 198
FIGURE 4-18. IMPLEMENT PUMP ASSEMBLY 200
FIGURE 4-19. DEF COOLANT LINES INSTALLATION (ULS) 202
FIGURE 4-20. COOLING PACKAGE INSTALLATION (ULS & NO HIGH AMBIENT) 204
FIGURE 4-21. COOLING PACKAGE INSTALLATION (ULS ASOV) 206
FIGURE 4-22. RADIATOR - COOLING PACKAGE 210
FIGURE 4-23. RADIATOR LINES INSTALLATION (ALL EXCEPT ULS & LS ASOV) 212
FIGURE 4-24. RADIATOR LINES INSTALLATION (ULS & LS ASOV) 214
FIGURE 4-25. COOLANT LINES INSTALLATION 216
FIGURE 4-26. SURGE TANK INSTALLATION 218
FIGURE 4-27. TRANSMISION OIL COOLER LINES INSTALLATION 220
FIGURE 4-28. FAN GUARD INSTALLATION 222
FIGURE 4-29. FAN GUARD (REVERSING) INSTALLATION 224
FIGURE 4-30. COOLING FAN INSTALLATION 226
FIGURE 4-31. COOLING FAN (REVERSING) INSTALLATION 228
FIGURE 4-32. COOLING FAN COVER (REVERSING) INSTALLATION 230
FIGURE 4-33. EXHAUST INSTALLATION (ULS) 232
FIGURE 4-34. DEF TANK INSTALLATION 234
FIGURE 4-35. DEF TANK ASSEMBLY 236
FIGURE 4-36. DEF LINES INSTALLATION 238
FIGURE 4-37. DEF CONTROL MODULE INSTALLATION 240
FIGURE 4-38. HEATER LINES INSTALLATION (ULS) 242
FIGURE 4-39. A/C PUMP INSTALLATION 244
FIGURE 4-40. A/C LINES INSTALLATION 246
FIGURE 4-41. BLOCK HEATER INSTALLATION (115V) (ULS) 248
FIGURE 4-42. HEATED BREATHER TUBE INSTALLATION 250

SECTION 5 - DRIVE TRAIN 253

FIGURE 5-1. DRIVETRAIN INSTALLATION 254
FIGURE 5-2. HYDROSTATIC MOTOR INSTALLATION 256
FIGURE 5-3. HYDROSTATIC MOTOR ASSEMBLY 258
FIGURE 5-4. GEARBOX INSTALLATION 260
FIGURE 5-5. GEAR BOX 262
FIGURE 5-6. DRIVE SHAFT INSTALLATION 266
FIGURE 5-7. FRONT AXLE INSTALLATION 268
FIGURE 5-8. FRONT AXLE MOUNTING INSTALLATION 270
FIGURE 5-9. FRONT AXLE 272
FIGURE 5-10. FRONT AXLE, CENTRAL HOUSING 274

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211381 Order the manual at mid-west-tech.com >

FIGURE 5-11. FRONT AXLE, DIFFERENTIAL 276
FIGURE 5-12. DIFFERENTIAL KIT 278
FIGURE 5-13. FRONT AXLE, HUB REDUCTION 280
FIGURE 5-14. FRONT AXLE, BRAKES 282
FIGURE 5-15. FRONT AXLE, STEERING 284
FIGURE 5-16. FRONT AXLE, TRUNION 286
FIGURE 5-17. FRONT AXLE LINES INSTALLATION 288
FIGURE 5-18. REAR AXLE INSTALLATION 290
FIGURE 5-19. REAR AXLE MOUNTING INSTALLATION 292
FIGURE 5-20. REAR AXLE, BRAKES 294
FIGURE 5-21. REAR AXLE, STEERING 296
FIGURE 5-22. REAR AXLE 298
FIGURE 5-23. REAR AXLE, CENTRAL HOUSING 300
FIGURE 5-24. REAR AXLE, DIFFERENTIAL 302
FIGURE 5-25. DIFFERENTIAL KIT 304
FIGURE 5-26. REAR AXLE, HUB REDUCTION 306
FIGURE 5-27. STEERING CASE KIT (RF, LR) 308
FIGURE 5-28. STEERING CASE KIT (LF, RR) 310
FIGURE 5-29. REAR AXLE, TRUNION 312
FIGURE 5-30. TRUNION KIT 314
FIGURE 5-31. RING GEAR SUPPORT KIT 316
FIGURE 5-32. REDUCTION BUSHING KIT 318
FIGURE 5-33. PLANET GEAR CARRIER KIT 320
FIGURE 5-34. REAR AXLE LINES INSTALLATION 322
FIGURE 5-35. TIRE/WHEEL SET (AIR 17.5-25 - 20 PLY) 324
FIGURE 5-36. TIRE/WHEEL SET (FOAM 17.5-25 - 20 PLY) 326
FIGURE 5-37. TIRE/WHEEL SET (AIR 17.5 R25 - RADIAL) 328
FIGURE 5-38. FENDER INSTALLATION 330
FIGURE 5-39. RH FENDER ASSEMBLY 332
FIGURE 5-40. LH FENDER ASSEMBLY 334

SECTION 6 - CAB 337

FIGURE 6-1. CAB MOUNTING INSTALLATION 338
FIGURE 6-2. FRONT CAB MOUNT BRACKET INSTALLATION 340
FIGURE 6-3. CAB MOUNTS INSTALLATION 342
FIGURE 6-4. CAB COMPONENTS INSTALLATION 344
FIGURE 6-5. CAB INSTALLATION 346
FIGURE 6-6. CAB ASSEMBLY (PVC 1911) 348
FIGURE 6-7. CAB ASSEMBLY (PVC 2005) 350
FIGURE 6-8. DOOR INSTALLATION 352
FIGURE 6-9. DOOR ASSEMBLY 354
FIGURE 6-10. CAB DOOR 356
FIGURE 6-11. DOOR UPPER GLASS ASSEMBLY 358
FIGURE 6-12. CAB LATCH ASSEMBLY 360
FIGURE 6-13. CAB DOOR TRIGGER ASSEMBLY 362
FIGURE 6-14. DOOR STRAP INSTALLATION 364
FIGURE 6-15. CAB PLUG GROUP 366
FIGURE 6-16. REAR WINDOW INSTALLATION 368
FIGURE 6-17. REAR WINDOW GROUP 370
FIGURE 6-18. REAR WIPER INSTALLATION 372
FIGURE 6-19. REAR WINDOW RELEASE INSTALLATION (ANSI - ENGLISH) 374
FIGURE 6-20. REAR WINDOW RELEASE INSTALLATION (ENGLISH/FREMCH) 376
FIGURE 6-21. FRONT WIPER INSTALLATION 378
FIGURE 6-22. WASHER TANK INSTALLATION 380
FIGURE 6-23. WASHER BOTTLE 382
FIGURE 6-24. FRONT COVER INSTALLATION 384
FIGURE 6-25. FRONT DUCT COVER 386
FIGURE 6-26. FILTER TRAY PANEL 388
FIGURE 6-27. LEVEL INDICATOR INSTALLATION 390
FIGURE 6-28. BASIC MIRROR INSTALLATION 392
FIGURE 6-29. MULTIFUNCTION DISPLAY INSTALLATION 394
FIGURE 6-30. SEAT INSTALLATION (CLOTH) 396
FIGURE 6-31. SEAT ASSEMBLY 398
FIGURE 6-32. SEAT INSTALLATION (AIR SUSPENSION - STANDARD) 400
FIGURE 6-33. SEAT ASSEMBLY (AIR SUSPENSION - STANDARD) 402
FIGURE 6-34. UPPER SEAT ASSEMBLY 404

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211381 Order the manual at mid-west-tech.com >

FIGURE 4-21. COOLING PACKAGE INSTALLATION (ULS ASOV)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001223874	Ref	Cooling Package Installation	C
1	0701018	2	Bolt, M10X50	
2	0701020	1	Bolt, M10X60	
3	0760812	4	Bolt,M8X25	
4	0761210	1	Bolt, M12X20	
5	0761215	2	Bolt, M12X35	
6	0761218	2	Bolt, M12X50	
7	2200223	1	Plug	
8	3290505	2	Nut, M5X0.8	
9	3290801	4	Nut, M8X1.25	
10	3291001	2	Nut, M10X1.5	
11	3291005	1	Nut, Lock M10X1.5	
12	3740080	2	Relay	
13	4740274	4	Washer	
14	4740550	1	Washer, M12	
15	4811600	2	Washer, M5	
16	4811900	8	Washer, M8	
17	4812002	5	Washer, M10	
18	4812102	3	Washer, M12	
19	4832100	5	Washer, Lock M12	
20	7169541	AR	Tape	
21	8278020	1	Mount	
22	1001003305	1	Clip	
23	1001008559	4	Strap, Cable	
24	1001114803	2	Mount	
25	1001146588	2	Strap, Cable	
26	1001155540	2	Washer	
27	1001173452	1	Seal, Foam Gasket	
28	1001173457	1	Seal	
29	1001196191	1	Bracket, Air Baffle	
30	1001200498	1	Bracket, Radiator	
31	1001200499	1	Bracket, Frame	
32	1001200631	1	Lamp, LED Indicator	
33	1001201301	1	Radiator, (See Separate Breakdown in this Section)	
34	1001201302	Ref	Installation, Coolant Lines (See Separate Breakdown in this Section)	
35	1001201304	Ref	Installation, Surge Tank (See Separate Breakdown in this Section)	
36	1001201305	Ref	Installation, Transmission Oil Cooler Lines (See Separate Breakdown in this Section)	
37	1001203181	1	Accessory, Control	
38	1001203947	1	Panel, Air Dam	
39	1001203948	1	Plate, Air Dam	
41	1001215941	1	Switch	
42	1001219082	1	Bracket	
43	1001223869	1	Installation, Radiator Lines (See Separate Breakdown in this Section)	
44	1001227077	1	Decal, Air Shut Off	
45	1001227964	1	Decal, ASOV Test	
46	1001228643	1	Decal, ASOV Equipped	
47	1001231407	1	Harness, POSI Air Shutoff (See Separate Breakdown in Electrical	

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211381 Order the manual at mid-west-tech.com >

FIGURE 6-40. HEATER INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001160043	Ref	Heater Installation	K
1	0760810	2	Bolt, M8X20	
2	3290401	2	Nut, M4X0.7	
3	4811400	2	Washer, M4	
4	4811902	2	Washer, M8	
5	4831400	2	Washer, Lock M4	
6	4831900	2	Washer, M8	
9	1001161858	1	Assembly, Heater (See Separate Breakdown in this Section)	
10	1001159925	1	Switch, HVAC Recycle	
14	1001218996	1	Filter, HVAC Air	
15	1001172553	1	Filter, HVAC Recirculation Air	
16	1001172547	1	Switch, HVAC Rotary 3 Speed	
17	1001172550	2	Knob, HVAC Control	
18	1001218529	1	Cable, HVAC	
19	1001188590	2	Grommet	
20	1001218542	2	Shim	
21	1001221059	1	Valve, Water	
22	1001221295	1	House	
23	8410009	2	Clamp	

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211381 Order the manual at mid-west-tech.com >

FIGURE 10-70. LIGHTS - DRIVING LIGHT INSTALLATION (RH DIP)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001186853	Ref	Driving Light Installation (RH Dip)	I
2	3290607	4	Nut, Lock M6X1	
3	4811700	4	Washer, M6	
4	4812000	16	Washer, M10	
5	2920208	1	Light, Driving (RH) (RH Dip)	
	7029969	1	Bulb, 4W	
	7029970	1	Bulb, 55W	
	7029971	1	Bulb, 21W	
6	2920207	1	Light, Driving (LH) (RH Dip)	
	7029969	1	Bulb, 4W	
	7029970	1	Bulb, 55W	
	7029971	1	Bulb, 21W	
7	1001091715	1	Light, Rear (LH)	
	70021341	1	Bulb, 5W	
	70021340	1	Bulb, 21W	
	7029971	1	Bulb, 21W	
8	1001091716	1	Light, Rear (RH)	
	70021341	1	Bulb, 5W	
	70021340	1	Bulb, 21W	
	7029971	1	Bulb, 21W	
9	1001209697	1	Cap	
10	1001159734	1	Switch, Hazard	
12	1001183112	2	Assembly, Rear Light Bracket (See Separate Breakdown in this Section)	
13	1001206100	1	Bracket	
16	0761010	8	Bolt, M10X20	
17	0701014	6	Bolt, M10X30	
18	3291001	2	Nut, M10X1.5	
19	1001203368	2	Bracket	
20	1001146588	1	Strap, Tie	
21	1001215693	1	Harness, Headlight (See Separate Breakdown in this Section)	
22	1001159737	1	Switch, Fog Lights	
23	1001008559	4	Strap, Cable	

MidWestTech | JLG 1732 Telehandler Parts Manual | Publication 31211381 Order the manual at mid-west-tech.com >