Illustrated Parts Manual

Models

800A
800AJ

SN 0300069000
through 0300140000

P/N
3121176

August 31, 2018 - Rev AJ

ANSI

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 11

FIGURE 1-1. AXLE AND STEERING INSTALLATION 12
FIGURE 1-2. TIRE AND WHEEL INSTALLATIONS 18
FIGURE 1-3. DRIVE HUB ASSEMBLIES (SN 0300069000 through 0300083331) 22
FIGURE 1-4. DRIVE HUB ASSEMBLY (SN 0300083332 through 0300140000) 26
FIGURE 1-5. DRIVE MOTOR ASSEMBLY (SN 0300069000 through 0300083331) 30
FIGURE 1-6. DRIVE MOTOR ASSEMBLY (ORIGINAL EQUIPMENT) (4 BOLT ASSEMBLY) (SN 0300083332 through 0300140000) 32
FIGURE 1-7. DRIVE MOTOR ASSEMBLY (SERVICE REPLACEMENT) (5 BOLT ASSEMBLY) (SN 0300083332 through 0300140000) 36
FIGURE 1-8. DRIVE VALVES AND SHIELDS INSTALLATIONS (SN 0300069000 through 0300083331) 40
FIGURE 1-9. DRIVE VALVES AND SHIELDS INSTALLATIONS (SN 0300083332 through 0300140000) 42
FIGURE 1-10. TOW PACKAGE INSTALLATION (2WS ONLY) 44

SECTION 2 - TURNTABLE 47

FIGURE 2-1. CONTROL VALVES AND HORN INSTALLATIONS 48
FIGURE 2-2. MAIN CONTROL VALVE ASSEMBLY 52
FIGURE 2-3. ACCESSORY VALVE ASSEMBLY 56
FIGURE 2-4. AUXILIARY PUMP ASSEMBLY 58
FIGURE 2-5. TURNTABLE BEARING AND SWING DRIVE INSTALLATION 62
FIGURE 2-6. SWING MOTOR/HUB ASSEMBLY (SN 0300069000 through 0300134352) 64
FIGURE 2-7. SWING MOTOR/HUB ASSEMBLY (SN 0300134353 through 0300140000) 70
FIGURE 2-8. CATERPILLAR ENGINE INSTALLATION (SN 0300069000 through 0300139399) 74
FIGURE 2-9. CATERPILLAR ENGINE INSTALLATION (SN 0300139400 through 0300140000) 84
FIGURE 2-10. DEUTZ ENGINE INSTALLATION (SN 0300069000 through 0300077499) 92
FIGURE 2-11. DEUTZ ENGINE INSTALLATION (SN 0300077500 through 0300140000) 98
FIGURE 2-12. FORD ENGINE INSTALLATION - NON-UL SPEC MACHINES (SN 0300069000 through 0300077499) 110
FIGURE 2-13. FORD ENGINE INSTALLATION - UL MACHINES (SN 0300069000 through 0300077499) 116
FIGURE 2-14. FORD ENGINE INSTALLATION (SN 0300077500 through 0300140000) 122
FIGURE 2-15. DUAL FUEL INSTALLATION (GAS MACHINES OPTIONS) 128
FIGURE 2-16. GM ENGINE INSTALLATION (SN 0300069000 through 0300140000) 132
FIGURE 2-17. PISTON PUMP ASSEMBLY 140
FIGURE 2-18. TANK INSTALLATIONS 144
FIGURE 2-19. ROTARY COUPLING INSTALLATION (SN 0300069000 through 0300083331) 148
FIGURE 2-20. ROTARY COUPLING INSTALLATION (SN 0300083332 through 0300137974) 150
FIGURE 2-21. ROTARY COUPLING INSTALLATION (SN 0300137975 through 0300140000) 154
FIGURE 2-22. GROUND CONTROL BOX ASSEMBLY (WITHOUT UGM) 158
FIGURE 2-23. GROUND CONTROL BOX ASSEMBLY (WITH UGM) 164
FIGURE 2-24. ELECTRICAL OPTIONS INSTALLATION (TURNTABLE MOUNTED) 168
FIGURE 2-25. HOODS INSTALLATION (SN 0300069000 through 0300089981) 172
FIGURE 2-26. HOODS INSTALLATION (SN 0300089982 through 0300140000) 176
FIGURE 2-27. ENGINE TRAY JACK INSTALLATION (OPTIONAL) 182
FIGURE 2-28. 2500W GENERATOR INSTALLATION - CATERPILLAR MACHINES (OPTIONAL) 184
FIGURE 2-29. 2500W GENERATOR INSTALLATION - DEUTZ MACHINES (OPTIONAL) 188
FIGURE 2-30. 2500W GENERATOR INSTALLATION - FORD MACHINES (OPTIONAL) (SN 0300069000 through 0300077499) 192
FIGURE 2-31. 2500W GENERATOR INSTALLATION - FORD MACHINES (OPTIONAL) (SN 0300077500 through 0300140000) 196
FIGURE 2-32. 2500W GENERATOR INSTALLATION - GM MACHINES (OPTIONAL) 200
FIGURE 2-33. 7500W SKYPOWER GENERATOR INSTALLATION - CATERPILLAR AND DEUTZ MACHINES (ANSI AND CSA SPECS) 204
FIGURE 2-34. 7500W SKYPOWER GENERATOR INSTALLATION - FORD MACHINES (ANSI AND CSA SPECS) 210
FIGURE 2-35. 7500W SKYPOWER GENERATOR INSTALLATION - GM MACHINES (ANSI AND CSA SPECS) 214

SECTION 3 - BOOM 219

FIGURE 3-1. BOOM AND CYLINDER INSTALLATION - 800A 220
FIGURE 3-2. BOOM AND CYLINDER INSTALLATION - 800AJ 224
FIGURE 3-3. TOWER BOOM ASSEMBLY 228
FIGURE 3-4. MAIN BOOM ASSEMBLIES 232
FIGURE 3-5. ROTATOR ASSEMBLY (FRONT ENTRY PLATFORM) 236
FIGURE 3-6. ROTATOR ASSEMBLY (SIDE ENTRY PLATFORM) 240
FIGURE 3-7. VALVE AND LIMIT SWITCH INSTALLATIONS (BOOM MOUNTED) 242

MidWestTech | JLG 800A, 800AJ Boom Lift Parts Manual | Publication 3121176 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 4 - PLATFORM 245

FIGURE 4-1. PLATFORM COMPONENTS INSTALLATION (FRONT ENTRY PLATFORM) 246
FIGURE 4-2. PLATFORM COMPONENTS INSTALLATION (SIDE ENTRY PLATFORM) 250
FIGURE 4-3. PLATFORM COMPONENTS INSTALLATION (FALL ARREST PLATFORM) 254
FIGURE 4-4. PLATFORM CONSOLE ASSEMBLY (SN 0300069000 through 0300137974) 256
FIGURE 4-5. PLATFORM CONSOLE ASSEMBLY (SN 0300137975 through 0300140000) 262
FIGURE 4-6. CONTROLLER ASSEMBLY (LIFT AND SWING) 266
FIGURE 4-7. CONTROLLER ASSEMBLY (LIFT AND SWING) 268
FIGURE 4-8. CONTROLLER ASSEMBLY (LIFT AND SWING) 270
FIGURE 4-9. CONTROLLER ASSEMBLY (DRIVE AND STEER) 274
FIGURE 4-10. CONTROLLER ASSEMBLY (DRIVE AND STEER) 276
FIGURE 4-11. CONTROLLER ASSEMBLY (DRIVE AND STEER) 278
FIGURE 4-12. SOFT TOUCH SYSTEM INSTALLATION (OPTIONAL) 280

SECTION 5 - CYLINDER 283

FIGURE 5-1. AXLE LOCKOUT CYLINDER ASSEMBLY 284
FIGURE 5-2. LEVEL CYLINDER ASSEMBLY - PLATFORM SLAVE 286
FIGURE 5-3. LEVEL CYLINDER ASSEMBLY - PLATFORM SLAVE (800A ONLY) (SERVICE REPLACEMENT) 290
FIGURE 5-4. LEVEL CYLINDER ASSEMBLY - PLATFORM SLAVE (800AJ ONLY) (SERVICE REPLACEMENT) 292
FIGURE 5-5. LEVEL CYLINDER ASSEMBLY - UPRIGHT 294
FIGURE 5-6. LEVEL CYLINDER ASSEMBLY - UPRIGHT (SERVICE REPLACEMENT) 296
FIGURE 5-7. LIFT CYLINDER ASSEMBLY - JIB (800AJ ONLY) (ORIGINAL EQUIPMENT) 298
FIGURE 5-8. LIFT CYLINDER ASSEMBLY - JIB (800AJ ONLY) (USAGE MAY VARY) (SERVICE REPLACEMENT) 300
FIGURE 5-9. LIFT CYLINDER ASSEMBLY - JIB (800AJ ONLY) (USAGE MAY VARY) (SERVICE REPLACEMENT) 302
FIGURE 5-10. LIFT CYLINDER ASSEMBLY - MAIN BOOM (ORIGINAL EQUIPMENT) 304
FIGURE 5-11. LIFT CYLINDER ASSEMBLY - MAIN BOOM (SERVICE REPLACEMENT) 306
FIGURE 5-12. LIFT CYLINDER ASSEMBLY - TOWER BOOM (ORIGINAL EQUIPMENT) 308
FIGURE 5-13. LIFT CYLINDER ASSEMBLY - TOWER BOOM (SERVICE REPLACEMENT) 310
FIGURE 5-14. MASTER CYLINDER ASSEMBLY - 800A (ORIGINAL EQUIPMENT) 312
FIGURE 5-15. MASTER CYLINDER ASSEMBLY - 800A (SERVICE REPLACEMENT) 314
FIGURE 5-16. MASTER CYLINDER ASSEMBLY - 800AJ (ORIGINAL EQUIPMENT) 316
FIGURE 5-17. MASTER CYLINDER ASSEMBLY - 800AJ (SERVICE REPLACEMENT) 318
FIGURE 5-18. STEER CYLINDER ASSEMBLY 320
FIGURE 5-19. TELESCOPE CYLINDER ASSEMBLY - MAIN BOOM 322
FIGURE 5-20. TELESCOPE CYLINDER ASSEMBLY - MAIN BOOM (800A) (SERVICE REPLACEMENT) 324
FIGURE 5-21. TELESCOPE CYLINDER ASSEMBLY - MAIN BOOM (800AJ) (SERVICE REPLACEMENT) 326
FIGURE 5-22. TELESCOPE CYLINDER ASSEMBLY - TOWER BOOM 328
FIGURE 5-23. TELESCOPE CYLINDER ASSEMBLY - TOWER BOOM (SERVICE REPLACEMENT) 330

SECTION 6 - HYDRAULIC 333

FIGURE 6-1. AXLE LOCKOUT HYDRAULIC DIAGRAM 334
FIGURE 6-2. DRIVE HYDRAULIC DIAGRAM - 2WD (SN 0300069000 through 0300083331) 336
FIGURE 6-3. DRIVE HYDRAULIC DIAGRAM - 2WD (SN 0300083332 through 0300140000) 340
FIGURE 6-4. DRIVE HYDRAULIC DIAGRAM - 4WD/2WS (SN 0300069000 through 0300083331) 346
FIGURE 6-5. DRIVE HYDRAULIC DIAGRAM - 4WD/2WS (SN 0300083332 through 0300140000) 350
FIGURE 6-6. STANDARD HYDRAULIC DIAGRAM (WITH FENNER AND HALDEX BRAND AUXILIARY PUMP) 356
FIGURE 6-7. STANDARD HYDRAULIC DIAGRAM (WITH BUCHER BRAND AUXILIARY PUMP) 360
FIGURE 6-8. HYDRAULIC DIAGRAM LIST 364

SECTION 7 - ELECTRICAL 367

FIGURE 7-1. ELECTRICAL DIAGRAM LIST 368
FIGURE 7-2. HARNESS COMPONENTS INSTALLATION WITHOUT UGM 370
FIGURE 7-3. HARNESS COMPONENTS INSTALLATION WITH UGM 390

SECTION 8 - DECALS 405

FIGURE 8-1. DECAL INSTALLATION (ANSI SPEC) (SN 0300069000 through 0300089981) 406
FIGURE 8-2. DECAL INSTALLATION (ANSI SPEC) (SN 0300089982 through 0300140000) 410
FIGURE 8-3. DECAL INSTALLATION (COUNTRY SPEC) (SN 0300069000 through 0300089981) 414
FIGURE 8-4. DECAL INSTALLATION (COUNTRY SPEC) (SN 0300089982 through 0300140000) 420

SECTION 9 - RECOMMENDED SERVICE PARTS STOCK 427

MidWestTech | JLG 800A, 800AJ Boom Lift Parts Manual | Publication 3121176 Order the manual at mid-west-tech.com >

FIGURE 9-1. MODEL 800A/800AJ STANDARD PARTS 428
FIGURE 9-2. MODEL 800A/800AJ VARIABLE PARTS 430

SECTION 10 - SPECIAL OPTIONS 431

FIGURE 10-1. SPECIAL OPTIONS 432

PART NUMBER INDEX 439

MidWestTech | JLG 800A, 800AJ Boom Lift Parts Manual | Publication 3121176 Order the manual at mid-west-tech.com >

FIGURE 2-5. TURNTABLE BEARING AND SWING DRIVE INSTALLATION

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
		Ref	**TURNTABLE WELDMENT**	
	4620135	Ref	Standard Machines	
		Ref	**SWING DRIVE INSTALLATION**	
	0272189	Ref	**Swing Drive Installation (SN 0300069000 through 0300134352)**	D
	1001094889	Ref	**Swing Drive Installation (SN 0300134353 through 0300140000)**	B
1	0100011	AR	Compound, Locking **(SN 0300069000 through 0300074382)**	
2	0100019	AR	Compound, Locking	
3	0682216	4	Bolt 3/4in - 10NC x 2in (Grade 8)	
4		Ref	Motor, Swing Assembly Options:	
4	3160286	1	Motor, Swing Assembly (See SWING MOTOR/HUB ASSEMBLY for Breakdown) **(SN 0300069000 through 0300074382)**	
4	3160294	NLA	Motor, Swing Assembly (Use p/n 1001101060) (See SWING MOTOR/HUB ASSEMBLY for Breakdown) **(SN 0300074383 through 0300134352)**	
4	1001101060	1	Motor, Swing Assembly (See SWING MOTOR/HUB ASSEMBLY for Breakdown) **(SN 0300134353 through 0300140000)**	
5	3312002	1	Nut Jam 5/8in - 11NC	
6	3900293	1	Screw, Shoulder	
7	3932224	4	Screw 3/4in - 10NC x 1-1/2in **(SN 0300069000 through 0300074382)**	
8	3952020	1	Setscrew 5/8in x 2in	
9	4071009	1	Shim	
10	4740057	4	Hardened, Washer	
11	4846430	1	Plate, Swing Drive **(SN 0300069000 through 0300074382)**	
	0271002	Ref	**TURNTABLE BEARING INSTALLATION**	E
101	0100019	AR	Compound, Locking	
102	0440244	1	Bearing, Turntable	
103	0682023	24	Bolt 5/8in - 11NC X 2-7/8in (Grade 8)	
104	0682032	24	Bolt 5/8in - 11NC x 4in (Grade 8)	
105	4892000	48	Flatwasher, Hardened	
150	2915094	1	**TURNTABLE BEARING KIT**	
	0259147	Ref	**TURNTABLE LOCK INSTALLATION**	B
201	4844958	1	Weldment, Pin	
202	3421565	1	Pin, Snap	
203	3760170	2	Ring, Quick Release	
204	1260017	9 in/23cm	Chain	
	0255316	Ref	**REMOTE BEARING LUBE INSTALLATION**	3
301	2751095	1	Hose, Grease **(SN 0300069000 through 0300070975)**	
302	2180344	2	Fitting, Bulkhead	
303	2160003	2	Fitting, Grease Elbow	
304	2220063	2	Fitting, Elbow	
305	2751032	1	Hose, Grease	

MidWestTech | JLG 800A, 800AJ Boom Lift Parts Manual | Publication 3121176 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
		Ref	**SOFT TOUCH SYSTEM INSTALLATION (OPTIONAL)**	
	0273824	Ref	**6ft/1.8m Platforms**	B
	0272427	Ref	**8ft/2.4m Platforms**	D
		Ref	**6ft/1.8m Platforms with Fall Arrest**	
	0274927	Ref	**6ft/1.8m Platforms with Fall Arrest (SN 0300069000 through 0300136487)**	A
	1001108256	Ref	**6ft/1.8m Platforms with Fall Arrest (SN 0300136488 through 0300140000)**	A
	0273706	Ref	**8ft/2.4m Platforms with Fall Arrest**	B
401	4360387	1	Switch, Pushbutton	
402	1702938	1	Decal - Soft Touch Override	
403	4460425	1	Connector, Strain Relief	
404	2920028	1	Lamp, Indicator **(SN 0300136488 through 0300140000)**	
405	2920029	1	Bulb **(SN 0300136488 through 0300140000)**	
		Ref	**PLATFORM WORKLIGHT INSTALLATION (OPTIONAL)**	
	0270814	Ref	**Non-UL Spec 800A & 800AJ (SN 0300069000 through 0300074426)**	3-E
	0273484	Ref	**Non-UL Spec 800A (SN 0300074427 through 0300140000)**	D
	0273485	Ref	**Non-UL Spec 800AJ (SN 0300074427 through 0300140000)**	D
	0272742	Ref	**UL Machines**	1-A
		Ref	Non-UL Spec Machines - Use Items 501-505	
501	4360232	1	Breaker, Circuit - 15Amp **(SN 0300069000 through 0300074426)**	
502	0721003	2	Bolt #10-24NC x 3/8in **(SN 0300069000 through 0300074426)**	
503	4761000	4	Lockwasher #10 **(SN 0300069000 through 0300074426)**	
504	3311001	2	Nut #10-24NC **(SN 0300069000 through 0300074426)**	
505		Ref	Connector, Strain Relief Options:	
505	4460598	1	ANSI Spec Machines **(SN 0300069000 through 0300074426)**	
505	4460426	1	ANSI Spec Machines **(SN 0300074427 through 0300140000)**	
		Ref	UL Spec Machines - Use Items 506-513	
506	4460598	1	Connector, Strain Relief	
507	2400067	1	Holder, Fuse	
508	2400068	1	Fuse, 10 Amp	
509	3910608	2	Screw	
510	4750600	3	Flatwasher	
511	4760600	2	Lockwasher	
512	3310601	2	Nut	
513	4740455	2	Flatwasher, Nylon Shoulder	
	0271340	Ref	**JIB SWITCH INSTALLATION (OPTIONAL)**	1
601	4360328	1	Switch, Toggle	
601	3790012	1	O-Ring	
	0258945	Ref	**STEER SWITCH (4WS) INSTALLATION (OPTIONAL)**	1
701	4360331	1	Switch, Toggle	
701	3790012	1	O-Ring	
	0271941	Ref	**CONSOLE BOX INSTALLATION**	B
805	1702676	1	Decal - Horn	
809	4360331	1	Switch, Toggle (4WD)	
809	3790012	1	O-Ring	
	0275804	Ref	**LIGHT PANEL DECAL INSTALLATION**	B
901	1707111	1	Decal - Light Panel Display	

MidWestTech | JLG 800A, 800AJ Boom Lift Parts Manual | Publication 3121176 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
			0300089982 through 0300140000)	
	2902303	Ref	Decal Kit - Master **(SN 0300089982 through 0300140000)**	
	1001108720	Ref	Decal Kit - Platform (800A)	
	1001108721	Ref	Decal Kit - Platform (800AJ)	
	2910872	Ref	Decal Kit - Platform Console **(SN 0300069000 through 0300137974)**	
	1001119563	Ref	Decal Kit - Platform Console **(SN 0300137975 through 0300140000)**	
	2902353	Ref	Decal Kit - Tire Load	
	2300040	Ref	**Diesel Fuel - Anti-Gel**	
	2902396	Ref	**Drive/Steer Cutout Kit**	
	0274619	Ref	**Dual AC 110V GFI Installation**	
		Ref	**Electrical Connector Kits**	
	1001148902	Ref	Amp/Tyco Electrical Connector Kit	
	1001148903	Ref	Deutsch DT Electrical Connector Kit	
	1001148904	Ref	Deutsch HD Electrical Connector Kit	
	1001148905	Ref	Packard Electrical Connector Kit	
	1001148906	Ref	Various Electrical Connectors Kit	
		Ref	**Engine Block Heater Installations:**	
	0258696	Ref	**Ford Engine Machines**	
	0275261	Ref	**GM Engine Machines**	
	0257157	Ref	**Ether Start Installation (Deutz Engine Machines SN 0300069000 through SN 0300085331 Only)**	
		Ref	**Exhaust Rain Cap Installation**	
	0274598		Exhaust Rain Cap Installation **(SN 0300069000 through 0300136458)**	
	1001108962		Exhaust Rain Cap Installation **(SN 0300136459 through 0300140000)**	
		Ref	**Filter Kits:**	
		Ref	**Combined Filter Kit Options (Hydraulic/Air and Fuel/Engine Oil):**	
		Ref	**Deutz Engine Machines**	
	2910467	1	Deutz Engine Machines **(SN 0300069000 through 0300077499)**	
	1001110996	1	Deutz Engine Machines **(SN 0300077500 through 0300087265)**	
	1001111014	1	Deutz Engine Machines **(SN 0300087266 through 0300140000)**	
		Ref	**Caterpillar Engine Machines**	
	2915139	1	Caterpillar Engine Machines **(SN 0300069000 through 0300087265)**	
	1001111015	1	Caterpillar Engine Machines **(SN 0300087266 through 0300140000)**	
		Ref	**Ford LRG-425 Non-UL Engine Machines**	
	1001114116	1	Ford LRG-425 Non-UL Engine Machines **(SN 0300069000 through 0300087265)**	
	1001114115	1	Ford LRG-425 Non-UL Engine Machines **(SN 0300087266 through 0300140000)**	
		Ref	**GM Engine Machines**	
	1001114056	1	GM Engine Machines **(SN 0300069000 through 0300140000)**	
		Ref	**Hydraulic/Air Filter Options:**	
		Ref	**Deutz Engine Machines**	
	1001109693	1	Deutz Engine Machines **(SN 0300069000 through 0300087265)**	

MidWestTech | JLG 800A, 800AJ Boom Lift Parts Manual | Publication 3121176 Order the manual at mid-west-tech.com >