Illustrated Parts Manual

Models
E300AJ
E300AJP

PVC
2001

31215002

November 1, 2019 - Rev A

ANSI

CE

AS/NZS

An Oshkosh Corporation Company

MidWestTech | JLG E300AJ, E300AJP Boom Lift Parts Manual | Publication 31215002

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 11

FIGURE 1-1. STEER INSTALLATION 12
FIGURE 1-2. HUB AND SPINDLE ASSEMBLY - LH 14
FIGURE 1-3. HUB AND SPINDLE ASSEMBLY - RH 16
FIGURE 1-4. WHEEL DRIVE INSTALLATION (ALL SPECS EXCEPT UL SPEC) 18
FIGURE 1-5. WHEEL DRIVE INSTALLATION (UL SPECS) 20
FIGURE 1-6. DRIVE MOTOR ASSEMBLY 24
FIGURE 1-7. DRIVE HUB ASSEMBLY 26
FIGURE 1-8. TIRE AND WHEEL INSTALLATION 30
FIGURE 1-9. BATTERY INSTALLATION - 305AH BATTERIES 32
FIGURE 1-10. BATTERY INSTALLATION - 305AH BATTERIES (UL SPECS) 34
FIGURE 1-11. BATTERY INSTALLATION - 305AH AGM BATTERIES 36
FIGURE 1-12. BATTERY INSTALLATION - 375AH/706HD BATTERIES 38
FIGURE 1-13. INVERTER INSTALLATION - OPTIONAL 40
FIGURE 1-14. FRAME COVERS INSTALLATION 42

SECTION 2 - TURNTABLE 45

FIGURE 2-1. VALVES, TANK AND MOTOR INSTALLATION - E300AJ 46
FIGURE 2-2. VALVES, TANK AND MOTOR INSTALLATION - E300AJP 48
FIGURE 2-3. MAIN VALVE ASSEMBLY 50
FIGURE 2-4. BOOM VALVE ASSEMBLY - E300AJ 52
FIGURE 2-5. BOOM VALVE ASSEMBLY - E300AJP 54
FIGURE 2-6. TURNTABLE BEARING AND SWING DRIVE INSTALLATION 56
FIGURE 2-7. TURNTABLE BEARING ASSEMBLY 58
FIGURE 2-8. SWING MOTOR ASSEMBLY 60
FIGURE 2-9. DRIVE ORIENTATION INSTALLATION 62
FIGURE 2-10. ELECTRICAL COMPONENTS INSTALLATION - E300AJ (ALL SPECS EXCEPT CE & UL SPECS) 64
FIGURE 2-11. ELECTRICAL COMPONENTS INSTALLATION - E300AJ (CE SPECS) 66
FIGURE 2-12. ELECTRICAL COMPONENTS INSTALLATION - E300AJ (UL SPECS) 68
FIGURE 2-13. ELECTRICAL COMPONENTS INSTALLATION - E300AJP (ALL SPECS EXCEPT CE & UL SPECS) 70
FIGURE 2-14. ELECTRICAL COMPONENTS INSTALLATION - E300AJP (CE SPECS) 72
FIGURE 2-15. ELECTRICAL COMPONENTS INSTALLATION - E300AJP (UL SPECS) 74
FIGURE 2-16. GROUND CONTROL BOX ASSEMBLY - E300AJ (ALL SPECS EXCEPT CE SPECS) 76
FIGURE 2-17. GROUND CONTROL BOX ASSEMBLY - E300AJ (CE SPECS) 78
FIGURE 2-18. GROUND CONTROL BOX ASSEMBLY - E300AJP (ALL SPECS EXCEPT CE SPECS) 80
FIGURE 2-19. GROUND CONTROL BOX ASSEMBLY - E300AJP (CE SPECS) 82
FIGURE 2-20. BATTERY CHARGER INSTALLATION - WITH PLUG (ALL SPECS EXCEPT CE SPECS) 84
FIGURE 2-21. BATTERY CHARGER INSTALLATION - WITH PLUG (CE SPECS) 86
FIGURE 2-22. BATTERY CHARGER INSTALLATION - WITHOUT PLUG 88
FIGURE 2-23. BATTERY CHARGER ASSEMBLY 90
FIGURE 2-24. STROBE LIGHT INSTALLATION - AMBER 92
FIGURE 2-25. STROBE LIGHT INSTALLATION - BLUE 94
FIGURE 2-26. STROBE LIGHT INSTALLATION - RED 96
FIGURE 2-27. ALARM INSTALLATION 98
FIGURE 2-28. WHITE NOISE ALARM INSTALLATION 100
FIGURE 2-29. HOODS INSTALLATION 102

SECTION 3 - BOOM 105

FIGURE 3-1. BOOM AND CYLINDERS INSTALLATION - E300AJ 106
FIGURE 3-2. BOOM AND CYLINDERS INSTALLATION - E300AJP 108
FIGURE 3-3. MAIN BOOM ASSEMBLY - E300AJ 110
FIGURE 3-4. MAIN BOOM ASSEMBLY - E300AJP 112
FIGURE 3-5. TOWER BOOM ASSEMBLY - E300AJ 114
FIGURE 3-6. TOWER BOOM ASSEMBLY - E300AJP 116
FIGURE 3-7. JIB ASSEMBLY - E300AJ 118
FIGURE 3-8. JIB ASSEMBLY - E300AJP 120
FIGURE 3-9. ROTATOR ASSEMBLY - PLATFORM 122
FIGURE 3-10. ROTATOR ASSEMBLY - JIB SWING 124
FIGURE 3-11. POWER TRACK INSTALLATION 126
FIGURE 3-12. PLATFORM SUPPORT INSTALLATION 128

SECTION 4 - PLATFORM 131

MidWestTech | JLG E300AJ, E300AJP Boom Lift Parts Manual | Publication 31215002 **Order the manual at mid-west-tech.com >**

TABLE OF CONTENTS

FIGURE 4-1. PLATFORM ASSEMBLY - 4FT/1.22M - SIDE GATE ENTRY 132
FIGURE 4-2. PLATFORM ASSEMBLY - 4FT/1.22M - DROP BAR ENTRY 134
FIGURE 4-3. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - E300AJ (ALL SPECS EXCEPT UL SPECS) 136
FIGURE 4-4. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - E300AJ (UL SPECS) 138
FIGURE 4-5. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - E300AJP (ALL SPECS EXCEPT UL SPECS) 140
FIGURE 4-6. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - E300AJP (UL SPECS) 142
FIGURE 4-7. CONSOLE BOX ASSEMBLY - E300AJ (ALL SPECS EXCEPT UL SPECS) 144
FIGURE 4-8. CONSOLE BOX ASSEMBLY - E300AJ (UL SPECS) 148
FIGURE 4-9. CONSOLE BOX ASSEMBLY - E300AJP (ALL SPECS EXCEPT UL SPECS) 152
FIGURE 4-10. CONSOLE BOX ASSEMBLY - E300AJP (UL SPECS) 156
FIGURE 4-11. CONTROLLER ASSEMBLY (DRIVE AND STEER) 160
FIGURE 4-12. CONTROLLER ASSEMBLY (LIFT AND SWING) 162
FIGURE 4-13. FOOTSWITCH ASSEMBLY 166
FIGURE 4-14. LIGHT PANEL INSTALLATION 168
FIGURE 4-15. TRAY ASSEMBLY 170
FIGURE 4-16. SKYGUARD BAR INSTALLATION 172
FIGURE 4-17. SKYEYE INSTALLATION 174
FIGURE 4-18. SKYLINE INSTALLATION 176

SECTION 5 - CYLINDER 179

FIGURE 5-1. LEVEL (PLATFORM SLAVE) CYLINDER ASSEMBLY 180
FIGURE 5-2. LIFT CYLINDER ASSEMBLY - JIB 182
FIGURE 5-3. LIFT CYLINDER ASSEMBLY - MAIN BOOM 184
FIGURE 5-4. LIFT CYLINDER ASSEMBLY - TOWER BOOM 186
FIGURE 5-5. MASTER CYLINDER ASSEMBLY 188
FIGURE 5-6. STEER CYLINDER ASSEMBLY 190
FIGURE 5-7. TELESCOPE CYLINDER ASSEMBLY - E300AJ 192
FIGURE 5-8. TELESCOPE CYLINDER ASSEMBLY - E300AJP 194

SECTION 6 - HYDRAULIC 197

FIGURE 6-1. HYDRAULIC DIAGRAM - E300AJ 198
FIGURE 6-2. HYDRAULIC DIAGRAM - E300AJP 202

SECTION 7 - ELECTRICAL 205

FIGURE 7-1. AC BOX AT PLATFORM INSTALLATION - LOCALLY SUPPLIED COMPONENTS (ANSI EXPORT, AUSTRALIAN AND CE SPECS) 206
FIGURE 7-2. AC BOX AT PLATFORM INSTALLATION - 110V (ANSI, ANSI EXPORT, CSA, JAPANESE AND UL SPECS) 208
FIGURE 7-3. AC BOX AT PLATFORM INSTALLATION - ANSI AND CSA SPECS 210
FIGURE 7-4. AC BOX AT PLATFORM INSTALLATION - 110V IEC YELLOW (CE SPECS) 212
FIGURE 7-5. AC BOX AT PLATFORM INSTALLATION - 220V IEC BLUE (CE SPECS) 214
FIGURE 7-6. AC BOX AT PLATFORM INSTALLATION - 220V AFSINT107 KEYED GROUND (CE SPECS) 216
FIGURE 7-7. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 POST GROUND (CE SPECS) 218
FIGURE 7-8. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 SIDE GROUND (CE SPECS) 220
FIGURE 7-9. BATTERY CABLE KIT - 305AH BATTERIES 222
FIGURE 7-10. BATTERY CABLE KIT - 305AH BATTERIES (UL SPECS) 224
FIGURE 7-11. BATTERY CABLE KIT - 305AH AGM BATTERIES 226
FIGURE 7-12. BATTERY CABLE KIT - 375AH/706HD BATTERIES 228
FIGURE 7-13. BOOM CABLES AND CLAMPS INSTALLATION - E300AJ 230
FIGURE 7-14. BOOM CABLES AND CLAMPS INSTALLATION - E300AJP 234
FIGURE 7-15. BOOM HARNESS - MAIN BOOM 238
FIGURE 7-16. BOOM HARNESS - TOWER BOOM 240
FIGURE 7-17. BOOM VALVE AND LIMIT SWITCH HARNESS 242
FIGURE 7-18. BREAKER BOX KIT - CE SPECS 244
FIGURE 7-19. CHARGER CORD PLUG INSTALLATION - 110V - IEC 60309 - YELLOW (CE SPECS) 246
FIGURE 7-20. CHARGER CORD PLUG INSTALLATION - 220V - IEC 60309 - BLUE (CE SPECS) 248
FIGURE 7-21. CHARGER CORD PLUG INSTALLATION - 220V - AFSINT107 KEYED GROUND (CE SPECS) 250
FIGURE 7-22. CHARGER CORD PLUG INSTALLATION - 220V - CEE7 POST GROUND (CE SPECS) 252
FIGURE 7-23. CHARGER CORD PLUG INSTALLATION - 220V - CEE7 SIDE GROUND (CE SPECS) 254
FIGURE 7-24. DRIVE CABLE KIT (ALL SPECS EXCEPT UL SPEC) 256
FIGURE 7-25. DRIVE CABLE KIT (UL SPECS) 258
FIGURE 7-26. INVERTER HARNESS 260
FIGURE 7-27. PLATFORM BOX HARNESS 262
FIGURE 7-28. RECEPTACLE BOX KIT - 110V IEC YELLOW (CE SPECS) 264
FIGURE 7-29. RECEPTACLE BOX KIT - 220V IEC BLUE (CE SPECS) 266

MidWestTech | JLG E300AJ, E300AJP Boom Lift Parts Manual | Publication 31215002 Order the manual at mid-west-tech.com >

FIGURE 7-30. RECEPTACLE BOX KIT - 220V AFSINT107 KEYED GROUND (CE SPECS) 268
FIGURE 7-31. RECEPTACLE BOX KIT - 220V CEE7 POST GROUND (CE SPECS) 270
FIGURE 7-32. RECEPTACLE BOX KIT - 220V CEE7 SIDE GROUND (CE SPECS) 272
FIGURE 7-33. SKYGUARD INTERFACE HARNESS 274
FIGURE 7-34. SKYEYE EMITTER HARNESS 276
FIGURE 7-35. SKYEYE INTERMEDIATE HARNESS 278
FIGURE 7-36. SKYEYE RECEIVER HARNESS 280
FIGURE 7-37. SKYLINE HARNESS 282
FIGURE 7-38. STEER SENSOR HARNESS 284
FIGURE 7-39. TRACTION MODULE TO DRIVE HARNESS 286
FIGURE 7-40. TRACTION MODULE TO TURNTABLE HARNESS 288
FIGURE 7-41. TURNTABLE HARNESS 292
FIGURE 7-42. WHITE NOISE ALARM HARNESS 296

SECTION 8 - DECALS 299

FIGURE 8-1. DECAL INSTALLATION (ANSI SPEC) 300
FIGURE 8-2. DECAL INSTALLATION (BRAZIL SPEC) 304
FIGURE 8-3. DECAL INSTALLATION (CHINESE SPEC) 308
FIGURE 8-4. DECAL INSTALLATION (CSA SPEC) 312
FIGURE 8-5. DECAL INSTALLATION (JAPANESE SPEC) 316
FIGURE 8-6. DECAL INSTALLATION (KOREAN SPEC) 320
FIGURE 8-7. DECAL INSTALLATION (LATIN AMERICAN SPEC) 324
FIGURE 8-8. DECAL INSTALLATION - OPTIONS 328

SECTION 9 - RECOMMENDED SERVICE PARTS STOCK 331

FIGURE 9-1. RECOMMENDED SERVICE PARTS STOCK 332

SECTION 10 - SPECIAL OPTIONS 335

FIGURE 10-1. SPECIAL OPTIONS 336

PART NUMBER INDEX 339

MidWestTech | JLG E300AJ, E300AJP Boom Lift Parts Manual | Publication 31215002 Order the manual at mid-west-tech.com >

FIGURE 4-11. CONTROLLER ASSEMBLY (DRIVE AND STEER)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001166538	Ref	CONTROLLER ASSEMBLY (DRIVE AND STEER)	G
		Ref	Note: Original Equipment Controller May Have Been Replaced with Service Replacement Controller. Visually Identify Controller Before Ordering Parts.	
		Ref	Note : Use p/n 1001212415 Kit as Replacement.	
7	70004738	2	Washer	
10	70004739	1	Roller	
11	70004740	1	Boot, Switch	
14	70004741	2	Half, Handle	
17	70004742	1	Enclosure	
18	70004743	4	Nut	
19	70004744	NLA	Boot, Controller (Note: Use Item 200)	
20	70004745	NLA	Tube, Locking (Note: Use Item 200)	
21	70004746	NLA	Disc, Locking (Note: Use Item 200)	
25	70004747	2	Seal, Rope	
26	70004748	1	Screw M3 x 6	
28	70004749	2	Screw M5 x 20	
29	70004750	1	Pin, Dowel	
30	70004751	4	Screw M3 x 16	
101	4460265	1	Connector - 9 Position	
101	4460226	7	Socket, Female	
200	70005230	1	Boot Kit (Includes Items 19-21)	

MidWestTech | JLG E300AJ, E300AJP Boom Lift Parts Manual | Publication 31215002 Order the manual at mid-west-tech.com >

FIGURE 5-6. STEER CYLINDER ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001108310	Ref	STEER CYLINDER ASSEMBLY	C
1	70002384	1	Barrel Weldment	
2	70002383	1	Rod Weldment	
3	70002382	1	Head	
4	See Note	NSS	Wiper (Note: Use Item 100)	
5	70002373	1	Ring, Retaining	
6	See Note	NSS	Seal, Rod (Note: Use Item 100)	
7	See Note	NSS	Ring, Back-up (Note: Use Item 100)	
8	70022586	1	Ring, Wear	
9	See Note	NSS	O-Ring (Note: Use Item 100)	
10	See Note	NSS	Ring, Back-up (Note: Use Item 100)	
11	See Note	NSS	O-Ring (Note: Use Item 100)	
12	70002381	1	Piston	
13	See Note	NSS	Seal, Piston (Note: Use Item 100)	
14	See Note	NSS	O-Ring (Note: Use Item 100)	
15	70002335	1	Nut	
15	0100071	AR	Compound, Locking	
16	70002363	2	Bearing	
17	70002380	2	Bearing	
100	70002379	1	Seal Kit (Includes Items 4, 6, 7, 9, 10, 11, 13 & 14)	

MidWestTech | JLG E300AJ, E300AJP Boom Lift Parts Manual | Publication 31215002 Order the manual at mid-west-tech.com >

FIGURE 8-7. DECAL INSTALLATION (LATIN AMERICAN SPEC)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001248658	Ref	DECAL INSTALLATION (LATIN AMERICAN SPECS)	B
1	0641406	4	Bolt 1/4 x 3/4	
2	0860520	1	Box, Manual Storage	
3	1701500	4	Decal - Lift	
4	1701504	1	Decal - Hydraulic Oil	
5	1701509	1	Decal - Manual	
6	1701529	3	Decal - Arrow	
7	1701642	1	Decal - Arrow	
8	1701644	1	Decal - Battery Charger	
9	1702155	2	Decal - Battery Disconnect	
10	1702300	4	Decal - Tie Down	
11	See Note	NSS	Decal - Bar Code (Note: Not Available for Purchase)	
12	1703923	1	Decal - Warning/Danger	
13	1703929	1	Decal - Warning/Danger	
14	1703935	3	Decal - Danger Electrocution	
15	1703947	4	Decal - Crushing	
16	1703983	1	Decal - Footswitch	
17	1704001	2	Decal - No Hands	
18	1704277	2	Decal - Lanyard Attach Graphic	
19	1704339	3	Decal - Battery Ventilation	
20	1704412	1	Decal - Hydraulic Oil	
21	1705910	1	Decal - Drive/Steer Instruction	
22	1706126	4	Decal - Tire Load	
23	3251813	1	Decal - USA	
24	3311405	4	Nut 1/4	
25	3820001	2	Rivet	
26	4751400	4	Washer 1/4	
27	1001110196	1	Decal - Manual Descent	
28	1001112461	1	Decal - Lift Diagram	
29	1001113171	1	Decal - Hand Crushing	
30	1001253930	1	Decal - Warning/Single Capacity	
31	1001253931	1	Decal - Warning/Single Capacity	
32	1001212200	1	Decal - Manual Descent	
33	1001224049	1	Decal - Yearly Inspection	

MidWestTech | JLG E300AJ, E300AJP Boom Lift Parts Manual | Publication 31215002 Order the manual at mid-west-tech.com >