Illustrated Parts Manual

Models
E450A
E450AJ
M450AJ

PVC
2001
2007

P/N
31215014

June 15, 2020 - Rev B

ANSI

AS/NZS

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

SECTION 1 - FRAME 11

FIGURE 1-1. STEERING INSTALLATION - E450AJ (CHINA BUILT MACHINES) 12
FIGURE 1-2. STEERING INSTALLATION (USA BUILT MACHINES) 14
FIGURE 1-3. HUB - SPINDLE ASSEMBLY - RH 16
FIGURE 1-4. HUB - SPINDLE ASSEMBLY - LH 18
FIGURE 1-5. DRIVE INSTALLATION - E450A AND E450AJ (NON-UL SPECS) 20
FIGURE 1-6. DRIVE INSTALLATION - E450A AND E450AJ (UL SPECS) 24
FIGURE 1-7. DRIVE HUB ASSEMBLY 28
FIGURE 1-8. DRIVE MOTOR ASSEMBLY 32
FIGURE 1-9. ELECTRICAL PLATE ASSEMBLY - LH (NON-UL SPECS) 34
FIGURE 1-10. ELECTRICAL PLATE ASSEMBLY - LH (UL SPECS) 36
FIGURE 1-11. ELECTRICAL PLATE ASSEMBLY - RH (NON-UL SPECS) 38
FIGURE 1-12. ELECTRICAL PLATE ASSEMBLY - RH (UL SPECS) 40
FIGURE 1-13. TIRE/WHEEL - IN240/55 - 17.5 FOAM FILLED 42
FIGURE 1-14. TIRE/WHEEL - IN240/55-17.5 FOAM FILLED NON MARKING 44
FIGURE 1-15. TIRE/WHEEL - 26 X 7 X 20 - SOLID NON MARKING 46
FIGURE 1-16. MOTOR/PUMP/TANK INSTALLATION - E450A/E450AJ NON-UL SPECS 48
FIGURE 1-17. MOTOR/PUMP/TANK INSTALLATION - E450A/E450AJ UL SPECS 50
FIGURE 1-18. MOTOR/PUMP ASSEMBLY 52
FIGURE 1-19. HYDRAULIC TANK ASSEMBLY - E450A/E450AJ 54
FIGURE 1-20. HYDRAULIC TANK ASSEMBLY - M450AJ 56
FIGURE 1-21. VALVE INSTALLATION - FRAME MOUNTED - E450AJ 58
FIGURE 1-22. VALVE INSTALLATION - FRAME MOUNTED - M450AJ 60
FIGURE 1-23. BRAKE/STEER VALVE ASSEMBLY 62
FIGURE 1-24. BATTERY BOX INSTALLATION - STANDARD (ALL SPECS EXCEPT AUSTRALIAN, CE AND CHINA SPECS) 64
FIGURE 1-25. BATTERY BOX INSTALLATION - STANDARD (AUSTRALIAN, CE AND CHINA SPECS) 66
FIGURE 1-26. BATTERY BOX INSTALLATION - AGM BATTERIES (ALL SPECS EXCEPT AUSTRALIAN, CE AND CHINA SPECS) 68
FIGURE 1-27. BATTERY BOX INSTALLATION - AGM BATTERIES (AUSTRALIAN, CE AND CHINA SPECS) 70
FIGURE 1-28. BATTERY CHARGER INSTALLATION - E450A/E450AJ (ANSI, ANSI EXPORT, CSA, JAPANESE AND UL SPECS) (PVC 2001) 72
FIGURE 1-29. BATTERY CHARGER INSTALLATION (ALL SPECS EXCEPT AUSTRALIAN & CE SPECS) (PVC 2007) 74
FIGURE 1-30. BATTERY CHARGER INSTALLATION - E450A/E450AJ (AUSTRALIAN SPEC) (PVC 2001) 76
FIGURE 1-31. BATTERY CHARGER INSTALLATION - E400AJPN (AUSTRALIAN SPEC) (PVC 2007) 78
FIGURE 1-32. BATTERY CHARGER INSTALLATION - E450A/E450AJ (ANSI EXPORT AND CE SPECS) (PVC 2001) 80
FIGURE 1-33. BATTERY CHARGER INSTALLATION (ANSI EXPORT, CE AND CHINA SPECS) (PVC 2007) 82
FIGURE 1-34. BATTERY CHARGER INSTALLATION - E450AJ (ANSI EXPORT AND CHINA SPECS) 84
FIGURE 1-35. BATTERY CHARGER ASSEMBLY 86
FIGURE 1-36. INVERTER INSTALLATION - E450A/E450AJ 88
FIGURE 1-37. VOLTAGE GUARD ASSEMBLY AND INSTALLATION (ANSI EXPORT AND CHINA SPECS) 90
FIGURE 1-38. FRAME COVER INSTALLATION - E450A/E450AJ 92

SECTION 2 - TURNTABLE 95

FIGURE 2-1. VALVE INSTALLATION- TURNTABLE MOUNTED - E450A 96
FIGURE 2-2. VALVE INSTALLATION - TURNTABLE MOUNTED - E450AJ 98
FIGURE 2-3. VALVE INSTALLATION - TURNTABLE MOUNTED - M450AJ 100
FIGURE 2-4. MAIN CONTROL VALVE ASSEMBLY 102
FIGURE 2-5. RELEVELING VALVE ASSEMBLY 104
FIGURE 2-6. JIB VALVE ASSEMBLY 106
FIGURE 2-7. MOTION ALARM INSTALLATION 108
FIGURE 2-8. TURNTABLE BEARING AND SWING DRIVE INSTALLATION 110
FIGURE 2-9. SWING MOTOR ASSEMBLY 112
FIGURE 2-10. SWING BEARING ASSEMBLY 114
FIGURE 2-11. REMOTE BEARING LUBE INSTALLATION - OPTIONAL 116
FIGURE 2-12. DRIVE ORIENTATION INSTALLATION 118
FIGURE 2-13. GROUND CONTROL BOX INSTALLATION - E450AJ/M450AJ (ALL SPECS EXCEPT CE AND CHINA SPECS) 120
FIGURE 2-14. GROUND CONTROL BOX INSTALLATION - E450AJ/M450AJ (CE AND CHINA SPECS) 122
FIGURE 2-15. GROUND CONTROL BOX ELECTRICAL ASSEMBLY - E450A (ALL SPECS EXCEPT CE SPECS) 124
FIGURE 2-16. GROUND CONTROL BOX ELECTRICAL ASSEMBLY - E450A (CE SPECS) 126
FIGURE 2-17. GROUND CONTROL BOX ELECTRICAL ASSEMBLY - E450AJ/M450AJ (ALL SPECS EXCEPT CE AND CHINA SPECS) 128
FIGURE 2-18. GROUND CONTROL BOX ELECTRICAL ASSEMBLY - E450AJ/M450AJ (CE AND CHINA SPECS) 130
FIGURE 2-19. STROBE LIGHT INSTALLATION - AMBER (OPTIONAL) 132

MidWestTech | JLG E450AJ Boom Lift Parts Manual | Publication 31215014_Rev_B Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 2-20. STROBE LIGHT ASSEMBLY - AMBER 134
FIGURE 2-21. BEACON LIGHT INSTALLATION - BLUE 136
FIGURE 2-22. BEACON LIGHT INSTALLATION - RED 138

SECTION 3 - ENGINE 141

FIGURE 3-1. KUBOTA MOTOR/GENERATOR ASSEMBLY - M450AJ 142
FIGURE 3-2. KUBOTA ENGINE COMPONENTS 144

SECTION 4 - BOOM 147

FIGURE 4-1. BOOM AND CYLINDERS INSTALLATION - E450AJ/M450AJ (USA BUILT MACHINES) 148
FIGURE 4-2. BOOM AND CYLINDERS INSTALLATION - E450AJ (CHINA BUILT MACHINES) 152
FIGURE 4-3. MAIN BOOM ASSEMBLY - E450A 156
FIGURE 4-4. MAIN BOOM ASSEMBLY - E450AJ/M450AJ 158
FIGURE 4-5. JIB INSTALLATION 160
FIGURE 4-6. ROTATOR ASSEMBLY - E450A 162
FIGURE 4-7. ROTATOR ASSEMBLY - E450AJ/M450AJ 164
FIGURE 4-8. PLATFORM SUPPORT INSTALLATION - E450AJ/M450AJ 166
FIGURE 4-9. BOOM LIMIT SWITCHES INSTALLATION 168

SECTION 5 - PLATFORM 171

FIGURE 5-1. PLATFORM ASSEMBLY - 4FT/1.22M - SIDE GATE ENTRY 172
FIGURE 5-2. PLATFORM ASSEMBLY - 5FT/1.52M - SIDE GATE ENTRY 174
FIGURE 5-3. PLATFORM ASSEMBLY - 4FT/1.22M - DROP BAR ENTRY 176
FIGURE 5-4. PLATFORM ASSEMBLY - 5FT/1.52M - DROP BAR ENTRY 178
FIGURE 5-5. PLATFORM ASSEMBLY - 30IN X 3FT (76CM X .91M) - DROP BAR ENTRY 180
FIGURE 5-6. PLATFORM ASSEMBLY - 6FT/1.83M - DROP BAR ENTRY 182
FIGURE 5-7. PLATFORM ASSEMBLY - 5FT/1.52M - FALL ARREST 184
FIGURE 5-8. PLATFORM ASSEMBLY - 6FT/1.83M - FALL ARREST 186
FIGURE 5-9. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - WITH 1 CELL LSS AND WITH SKYGUARD (NON-UL SPECS) 188
FIGURE 5-10. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - WITH 1 CELL LSS AND WITH SKYGUARD (UL SPECS) 190
FIGURE 5-11. PLATFORM CONSOLE ASSEMBLY - WITH 1 CELL LSS AND WITH SKYGUARD (NON-UL SPECS) 192
FIGURE 5-12. PLATFORM CONSOLE ASSEMBLY - WITH 1 CELL LSS AND WITH SKYGUARD (UL SPECS) 196
FIGURE 5-13. LIGHT PANEL INSTALLATION 200
FIGURE 5-14. JIB SWITCH INSTALLATION - E450AJ/M450AJ 202
FIGURE 5-15. CONTROLLER ASSEMBLY - DRIVE AND STEER 204
FIGURE 5-16. CONTROLLER ASSEMBLY - LIFT AND SWING 206
FIGURE 5-17. FOOTSWITCH ASSEMBLY 210
FIGURE 5-18. MOTOR CONTROLS INSTALLATION - M450AJ 212
FIGURE 5-19. TRAY ASSEMBLY 214
FIGURE 5-20. SKYEYE INSTALLATION 216
FIGURE 5-21. SKYGUARD BAR INSTALLATION 218
FIGURE 5-22. SKYLINE INSTALLATION 220
FIGURE 5-23. PIPE RACK INSTALLATION 222

SECTION 6 - CYLINDER 225

FIGURE 6-1. LEVEL (PLATFORM SLAVE) CYLINDER ASSEMBLY - E450A 226
FIGURE 6-2. LEVEL (PLATFORM SLAVE) CYLINDER ASSEMBLY - E450AJ/M450AJ (USA BUILT MACHINES) 228
FIGURE 6-3. LEVEL (PLATFORM SLAVE) CYLINDER ASSEMBLY - E450AJ (CHINA BUILT MACHINES) 230
FIGURE 6-4. LIFT CYLINDER ASSEMBLY - JIB - E450AJ/M450AJ 232
FIGURE 6-5. LIFT CYLINDER ASSEMBLY - LOWER - E450A 234
FIGURE 6-6. LIFT CYLINDER ASSEMBLY - LOWER - E450AJ/M450AJ (USA BUILT MACHINES) 236
FIGURE 6-7. LIFT CYLINDER ASSEMBLY - LOWER - E450AJ (CHINA BUILT MACHINES) 238
FIGURE 6-8. LIFT CYLINDER ASSEMBLY - MID - E450A/E450AJ/M450AJ (USA BUILT MACHINES) 240
FIGURE 6-9. LIFT CYLINDER ASSEMBLY - MID - E450AJ (CHINA BUILT MACHINES) 242
FIGURE 6-10. LIFT CYLINDER ASSEMBLY - UPPER - E450A (PRIOR TO PVC 2001) 244
FIGURE 6-11. LIFT CYLINDER ASSEMBLY - UPPER - E450A (PVC 2001) 246
FIGURE 6-12. LIFT CYLINDER ASSEMBLY - UPPER - E450AJ/M450AJ (USA BUILT MACHINES) (PRIOR TO PVC 2001) 248
FIGURE 6-13. LIFT CYLINDER - UPPER - E400AJPN (PVC 2001) 250
FIGURE 6-14. TELESCOPE CYLINDER ASSEMBLY - E450A (PRIOR TO PVC 2001) 252
FIGURE 6-15. TELESCOPE CYLINDER ASSEMBLY - E400AJPN (PVC 2001) 254
FIGURE 6-16. LIFT CYLINDER ASSEMBLY - UPPER - E450AJ (CHINA BUILT MACHINES) 256

MidWestTech | JLG E450AJ Boom Lift Parts Manual | Publication 31215014_Rev_B Order the manual at mid-west-tech.com >

FIGURE 6-17. MASTER CYLINDER ASSEMBLY - E450A 258
FIGURE 6-18. MASTER CYLINDER ASSEMBLY - E450AJ/M450AJ (USA BUILT MACHINES) 260
FIGURE 6-19. MASTER CYLINDER ASSEMBLY - E450AJ (CHINA BUILT MACHINES) 262
FIGURE 6-20. STEER CYLINDER ASSEMBLY (USA BUILT MACHINES) 264
FIGURE 6-21. STEER CYLINDER ASSEMBLY (CHINA BUILT MACHINES) 266
FIGURE 6-22. TELESCOPE CYLINDER ASSEMBLY - E450AJ/M450AJ 268
FIGURE 6-23. COUNTERBALANCE VALVE ASSEMBLY 270

SECTION 7 - HYDRAULIC 273

FIGURE 7-1. HYDRAULIC DIAGRAM - E450AJ 274
FIGURE 7-2. HYDRAULIC DIAGRAM LIST 278

SECTION 8 - ELECTRICAL 279

FIGURE 8-1. ELECTRICAL DIAGRAM LIST 280
FIGURE 8-2. AC PLUGS AND SOCKETS INSTALLATION - AFSINT 107-2-01 KEYED GROUND - 2 X 4 BOX (CE SPEC) 282
FIGURE 8-3. AC PLUGS AND SOCKETS INSTALLATION - CEE7 POST GROUND (CE SPEC) 284
FIGURE 8-4. AC PLUGS AND SOCKETS INSTALLATION - CEE 7 SIDE GROUND (CE SPEC) 286
FIGURE 8-5. AC PLUGS AND SOCKETS INSTALLATION - CEE7 POST GROUND - 2 X 4 BOX (CE SPEC) 288
FIGURE 8-6. AC PLUGS AND SOCKETS INSTALLATION - CEE7 SIDE GROUND - 2 X 4 BOX (CE SPEC) 290
FIGURE 8-7. AC PLUGS AND SOCKETS INSTALLATION - IEC 60309 BLUE (CE SPEC) 292
FIGURE 8-8. AC PLUGS AND SOCKETS INSTALLATION - IEC 60309 YELLOW (CE SPEC) 294
FIGURE 8-9. BATTERY CABLE KIT - E450A AND E450AJ (NON-UL SPECS) 296
FIGURE 8-10. BATTERY CABLE KIT - E450A AND E450AJ (UL SPECS) 298
FIGURE 8-11. BATTERY CABLE KIT - M450AJ (NON-UL SPECS) 300
FIGURE 8-12. BOOM CABLE - LOWER - E450A/E450AJ/M450AJ 302
FIGURE 8-13. BOOM CABLE - UPPER - E450A 304
FIGURE 8-14. BOOM CABLE - UPPER - E450AJ/M450AJ 306
FIGURE 8-15. BOOM LIMIT SWITCH HARNESS - LOWER 308
FIGURE 8-16. BOOM LIMIT SWITCH HARNESS - UPPER 310
FIGURE 8-17. BREAKER BOX KIT WITH ONE BREAKERS - CE SPEC 312
FIGURE 8-18. BREAKER BOX KIT WITH TWO BREAKERS - CE SPEC 314
FIGURE 8-19. CABLES AND CLAMPS INSTALLATION - E450AJ/M450AJ 316
FIGURE 8-20. CHARGER CORD PLUG INSTALLATION - 110V - IEC 60309 - YELLOW (CE SPEC) 318
FIGURE 8-21. CHARGER CORD PLUG INSTALLATION - 220V - AFSINT 107 KEYED GROUND (CE SPEC) 320
FIGURE 8-22. CHARGER CORD PLUG INSTALLATION - 220V - CEE7 POST GROUND (CE SPEC) 322
FIGURE 8-23. CHARGER CORD PLUG INSTALLATION - 220V - CEE7 SIDE GROUND (CE SPEC) 324
FIGURE 8-24. CHARGER CORD PLUG INSTALLATION - 220V - IEC 60309 - BLUE (CE SPEC) 326
FIGURE 8-25. CHASSIS TO TURNTABLE HARNESS 328
FIGURE 8-26. GENERATOR HARNESS 330
FIGURE 8-27. GROUND CONTROL PANEL HARNESS 332
FIGURE 8-28. INVERTER HARNESS 334
FIGURE 8-29. INVERTER IGNITION HARNESS 336
FIGURE 8-30. LOWER BOOM 110V HARNESS ASSEMBLY 338
FIGURE 8-31. LOWER BOOM 220V HARNESS ASSEMBLY 340
FIGURE 8-32. PLATFORM CONSOLE HARNESS - WITH 1 CELL LSS 342
FIGURE 8-33. PLUG AND RECEPTACLE INSTALLATION - SUPPLIED LOCALLY 344
FIGURE 8-34. PLUG AND RECEPTACLE INSTALLATION - 110V 346
FIGURE 8-35. PLUG AND RECEPTACLE INSTALLATION - 220V 348
FIGURE 8-36. PLUG AND RECEPTACLE 110V INSTALLATION - IEC 60309 - YELLOW (CE SPEC) 350
FIGURE 8-37. PLUG AND RECEPTACLE 220V INSTALLATION - AFSINT 107 KEYED GROUND - 2 X 4 BOX (CE SPEC) 352
FIGURE 8-38. PLUG AND RECEPTACLE 220V INSTALLATION - CEE7 POST GROUND - 2 X 4 BOX (CE SPEC) 354
FIGURE 8-39. PLUG AND RECEPTACLE 220V INSTALLATION - CEE7 POST GROUND - 70MM X 70MM BOX (CE SPEC) 356
FIGURE 8-40. PLUG AND RECEPTACLE 220 INSTALLATION - CEE7 SIDE GROUND - 2 X 4 BOX (CE SPEC) 358
FIGURE 8-41. PLUG AND RECEPTACLE 220V INSTALLATION - CEE7 SIDE GROUND - 70MM X 70MM BOX (CE SPEC) . 360
FIGURE 8-42. PLUG AND RECEPTACLE 220V INSTALLATION - IEC 60309 - BLUE (CE SPEC) 362
FIGURE 8-43. SKYEYE INTERMEDIATE HARNESS 364
FIGURE 8-44. SKYEYE RECEIVER HARNESS 366
FIGURE 8-45. SKYEYE EMITTER HARNESS 368
FIGURE 8-46. SKYGUARD HARNESS - WITH 1 CELL LSS 370
FIGURE 8-47. SKYLINE HARNESS 372
FIGURE 8-48. STEER/BRAKE HARNESS 374
FIGURE 8-49. TRACTION HARNESS 376
FIGURE 8-50. TURNTABLE HARNESS 378
FIGURE 8-51. UPPER BOOM 110V HARNESS ASSEMBLY 382
FIGURE 8-52. UPPER BOOM 220V HARNESS ASSEMBLY 384

MidWestTech | JLG E450AJ Boom Lift Parts Manual | Publication 31215014_Rev_B Order the manual at mid-west-tech.com >

SECTION 1 - FRAME

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
44B	70005415	2	O-Ring Between Brake and Motor (1 Per Assembly) (Not Shown)	
44C	4031707	8	Capscrew M6 x 16	
44D	1001109892	8	Washer M6	
45	1001188528	1	Steer/Brake Harness (See Separate Breakdown in ELECTRICAL SECTION)	
46	1001212456	1	Electrical Plate Assembly - RH (See Separate Breakdown in this Section)	
47	1001213626	1	Decal - 400 Amp Fuse	
48	1001214668	1	Electrical Plate Assembly - LH (See Separate Breakdown in this Section)	
49	4240175	1	Tie-Strap Clamp	
50	0100020	AR	Sealant	
100	1001212454	1	Battery Cable Kit (See Separate Breakdown in ELECTRICAL SECTION)	

MidWestTech | JLG E450AJ Boom Lift Parts Manual | Publication 31215014_Rev_B Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
27	70000325	1	Sensor, Oil Temperature (Not Shown - Located on Opposite Side of Engine Base)	
28	70000326	1	Module, Engine Control	
29	70000327	1	Alternator	
29	70000382	1	Stator, Alternator	
29	70004394	1	Lead, Field Terminal Block Diode	
30	70000328	1	Harness, Generator	
31	70000329	1	Fuse 15Amp (Not Shown)	
32	70000330	1	Fuse 20Amp (Not Shown)	
33	70002543	1	Engine, Kubota (without Generator)	
34	70000289	1	Regulator, Voltage (Not Shown - Located on Opposite Side of Engine)	

MidWestTech | JLG E450AJ Boom Lift Parts Manual | Publication 31215014_Rev_B Order the manual at mid-west-tech.com >

FIGURE 7-2. HYDRAULIC DIAGRAM LIST

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
		Ref	Note: Diagrams are available from JLG Service/Parts Department. See Service and Maintenance Manual for schematics.	
	1001218114	Ref	Hydraulic, Schematic	

MidWestTech | JLG E450AJ Boom Lift Parts Manual | Publication 31215014_Rev_B Order the manual at mid-west-tech.com >