Illustrated Parts Manual

Models

400S
460SJ

PVC
2001
2007

P/N
31215017

February 7, 2020 - Rev B

ANSI

AS/NZS

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 13

FIGURE 1-1. AXLE INSTALLATION 14
FIGURE 1-2. STEER INSTALLATION WITHOUT TOW PACKAGE 16
FIGURE 1-3. STEER INSTALLATION WITH TOW PACKAGE 18
FIGURE 1-4. WHEEL DRIVE INSTALLATION (2WD) 20
FIGURE 1-5. WHEEL DRIVE INSTALLATION (4WD) 22
FIGURE 1-6. DRIVE HUB AND BRAKE ASSEMBLY - REAR 24
FIGURE 1-7. DRIVE HUB ASSEMBLY - FRONT 28
FIGURE 1-8. HUB - SPINDLE ASSEMBLY (2WD) 30
FIGURE 1-9. DRIVE MOTOR ASSEMBLY (2WD) 32
FIGURE 1-10. DRIVE MOTOR ASSEMBLY (4WD) 34
FIGURE 1-11. TRACTION VALVE ASSEMBLY (2WD) 36
FIGURE 1-12. TRACTION VALVE ASSEMBLY (4WD) 38
FIGURE 1-13. TIRE AND WHEEL INSTALLATION - 12 X 16.5 FOAM FILLED (AVAILABLE ON ALL SPECS) 40
FIGURE 1-14. TIRE AND WHEEL INSTALLATION - 12 X 16.5 FF NON-MARKING (AVAILABLE ON ALL SPECS) 42
FIGURE 1-15. TIRE AND WHEEL INSTALLATION - 14 X 17.5 FOAM FILLED (AVAILABLE ON ALL SPECS) 44
FIGURE 1-16. FRAME SHIELD INSTALLATION - WITHOUT TOW BAR 46
FIGURE 1-17. FRAME SHIELD INSTALLATION - WITH TOW BAR 48
FIGURE 1-18. TOW BAR INSTALLATION 50
FIGURE 1-19. TOW BAR ASSEMBLY 52
FIGURE 1-20. LP TANK BRACKETS INSTALLATION 54

SECTION 2 - TURNTABLE 57

FIGURE 2-1. CONTROL VALVES INSTALLATION - 400S 58
FIGURE 2-2. CONTROL VALVES INSTALLATION - 460SJ 60
FIGURE 2-3. MAIN VALVE ASSEMBLY - 400S 62
FIGURE 2-4. MAIN VALVE ASSEMBLY - 460SJ 66
FIGURE 2-5. AXLE VALVE ASSEMBLY 70
FIGURE 2-6. SWING DRIVE INSTALLATION 72
FIGURE 2-7. SWING HUB/MOTOR ASSEMBLY 74
FIGURE 2-8. TURNTABLE BEARING INSTALLATION 78
FIGURE 2-9. BEARING LUBE INSTALLATION 80
FIGURE 2-10. TURNTABLE LOCK INSTALLATION 82
FIGURE 2-11. ROTARY COUPLING INSTALLATION 84
FIGURE 2-12. TANKS INSTALLATION - DIESEL MACHINES 86
FIGURE 2-13. TANKS INSTALLATION - GAS MACHINES 88
FIGURE 2-14. HYDRAULIC TANK ASSEMBLY 90
FIGURE 2-15. AUXILIARY PUMP AND BATTERY INSTALLATION 92
FIGURE 2-16. AUXILIARY PUMP AND BATTERY WITH DISCONNECT SWITCH INSTALLATION 94
FIGURE 2-17. AUXILIARY PUMP ASSEMBLY 96
FIGURE 2-18. ELECTRICAL INSTALLATION - 400S 98
FIGURE 2-19. ELECTRICAL INSTALLATION - 460SJ 100
FIGURE 2-20. ELECTRICAL INSTALLATION – 460SJ WITH DEUTZ (STAGE V) 102
FIGURE 2-21. ELECTRICAL PANEL ASSEMBLY 104
FIGURE 2-22. WHITE NOISE ALARM INSTALLATION 106
FIGURE 2-23. GROUND CONTROL ASSEMBLY – 400S 108
FIGURE 2-24. GROUND CONTROL ASSEMBLY – 460SJ 110
FIGURE 2-25. GROUND CONTROL ASSEMBLY - DEUTZ (STAGE V) (460SJ) (CE SPECS) 112
FIGURE 2-26. GROUND CONTROL DECAL AND KEYSWITCH INSTALLATION - 400S (ALL SPECS EXCEPT AUSTRALIAN AND CE SPECS) 114
FIGURE 2-27. GROUND CONTROL DECAL AND KEYSWITCH INSTALLATION - 400S (ANSI EXPORT SPECS) (PVC 2001) 116
FIGURE 2-28. GROUND CONTROL DECAL AND KEYSWITCH INSTALLATION - 460SJ (ALL SPECS EXCEPT CE SPEC) 118
FIGURE 2-29. GROUND CONTROL DECAL AND KEYSWITCH INSTALLATION - 460SJ (CE SPEC) (PVC 2001) 120
FIGURE 2-30. GROUND CONTROL DECAL AND KEYSWITCH INSTALLATION - 460SJ (STAGE V) (CE SPECS) 122
FIGURE 2-31. GROUND CONTROL MOUNTING - 400S 124
FIGURE 2-32. GROUND CONTROL MOUNTING - 460SJ 126
FIGURE 2-33. GROUND CONTROL MOUNTING - DEUTZ (STAGE V) (460SJ) (CE SPECS) 128
FIGURE 2-34. LIGHT PANEL INSTALLATION - 400S 130
FIGURE 2-35. LIGHT PANEL INSTALLATION - 460SJ 132
FIGURE 2-36. BEACON LIGHT INSTALLATION - AMBER 134
FIGURE 2-37. BEACON LIGHT INSTALLATION - BLUE 136
FIGURE 2-38. BEACON LIGHT INSTALLATION - RED 138
FIGURE 2-39. HOOD INSTALLATION - ABS (DEUTZ & GM ENGINES) 140

MidWestTech | JLG 400S, 460SJ Boom Lift Parts Manual | Publication 31215017 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 2-40. HOOD INSTALLATION - ABS (KUBOTA ENGINES) 144
FIGURE 2-41. HOOD INSTALLATION - ABS (KUBOTA ENGINES) (CE SPECS) 148
FIGURE 2-42. ABS HOOD ASSEMBLY - ENGINE SIDE 152
FIGURE 2-43. ABS HOOD ASSEMBLY - ENGINE SIDE (CE SPEC) 154
FIGURE 2-44. ABS HOOD ASSEMBLY - TANK SIDE 156
FIGURE 2-45. ABS HOOD ASSEMBLY - TANK SIDE (CE SPEC) 158
FIGURE 2-46. HOOD INSTALLATION - STEEL 160
FIGURE 2-47. STEEL HOOD ASSEMBLY - ENGINE SIDE 164
FIGURE 2-48. STEEL HOOD ASSEMBLY - TANK SIDE 166
FIGURE 2-49. SOUND REDUCTION INSTALLATION - KUBOTA ENGINE MACHINES WITH STEEL HOODS 168
FIGURE 2-50. TURNTABLE COVERS INSTALLATION 170

SECTION 3 - ENGINE 173

FIGURE 3-1. ENGINE INSTALLATION - DEUTZ D2011 ENGINE (WITHOUT ARCTIC PACKAGE) (AUSTRALIAN AND CHINA SPECS) 174
FIGURE 3-2. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2011 (WITHOUT ARCTIC PACKAGE) (AUSTRALIAN AND CHINA SPECS) 180
FIGURE 3-3. ENGINE ASSEMBLY - DEUTZ D2011 ENGINE (WITHOUT ARCTIC PACKAGE) (AUSTRALIAN AND CHINA SPECS) 182
FIGURE 3-4. ENGINE INSTALLATION - DEUTZ D2011 ENGINE (WITH ARCTIC PACKAGE) (ANSI EXPORT AND CHINA SPECS) 186
FIGURE 3-5. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2011 (WITH ARCTIC PACKAGE) (ANSI EXPORT AND CHINA SPECS) 192
FIGURE 3-6. ENGINE ASSEMBLY - DEUTZ D2011 ENGINE (WITH ARCTIC PACKAGE) (ANSI EXPORT AND CHINA SPECS) 194
FIGURE 3-7. ENGINE COMPONENTS - DEUTZ D2011 198
FIGURE 3-8. ENGINE INSTALLATION - DEUTZ D2011 ENGINE (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) 202
FIGURE 3-9. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2011 (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) 206
FIGURE 3-10. ENGINE ASSEMBLY - DEUTZ D2011 ENGINE (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) 208
FIGURE 3-11. ENGINE COMPONENTS - DEUTZ D2011 (STAGE V) 212
FIGURE 3-12. ENGINE INSTALLATION - DEUTZ D2.9L4 ENGINE (WITHOUT ARCTIC PACKAGE) (ANSI, ANSI EXPORT AND CSA SPECS) 216
FIGURE 3-13. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2.9L4 (WITHOUT ARCTIC PACKAGE) (ANSI, ANSI EXPORT AND CSA SPECS) 222
FIGURE 3-14. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITHOUT ARCTIC PACKAGE) (ANSI, ANSI EXPORT AND CSA SPECS) (PVC 2001) 224
FIGURE 3-15. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITHOUT ARCTIC PACKAGE) (ANSI, ANSI EXPORT AND CSA SPECS) (PVC 2007) 230
FIGURE 3-16. ENGINE INSTALLATION - DEUTZ D2.9L4 ENGINE (WITH ARCTIC PACKAGE) (ANSI, ANSI EXPORT AND CSA SPECS) 236
FIGURE 3-17. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2.9L4 (WITH ARCTIC PACKAGE) (ANSI, ANSI EXPORT AND CSA SPECS) 242
FIGURE 3-18. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITH ARCTIC PACKAGE) (ANSI, ANSI EXPORT AND CSA SPECS) (PVC 2001) 244
FIGURE 3-19. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITH ARCTIC PACKAGE) (ANSI, ANSI EXPORT AND CSA SPECS) (PVC 2007) 250
FIGURE 3-20. ENGINE INSTALLATION - DEUTZ D2.9L4 ENGINE (STAGE V) (CE SPECS) 256
FIGURE 3-21. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2.9L4 ENGINE (STAGE V) (CE SPECS) 262
FIGURE 3-22. ENGINE ASSEMBLY – DEUTZ D2.9L4 ENGINE (STAGE V) (CE SPECS) 264
FIGURE 3-23. BREATHER HEATER INSTALLATION - DEUTZ D2.9L4 ENGINE WITH ARCTIC PACKAGE 270
FIGURE 3-24. BRACKET ASSEMBLY - FUEL PUMP AND FILTER (DEUTZ D2.9L4 ENGINE) 272
FIGURE 3-25. BRACKET ASSEMBLY - FUEL PUMP AND FILTER (DEUTZ D2.9L4 ENGINE) (STAGE V) 274
FIGURE 3-26. PUMP COUPLING KIT (DEUTZ ENGINES) 276
FIGURE 3-27. ENGINE INSTALLATION - KUBOTA ENGINE (WITHOUT ARCTIC PACKAGE) 278
FIGURE 3-28. ENGINE AND PUMP SUB-ASSEMBLY - KUBOTA ENGINE (WITHOUT ARCTIC PACKAGE) 284
FIGURE 3-29. ENGINE ASSEMBLY - KUBOTA ENGINE (WITHOUT ARCTIC PACKAGE) 286
FIGURE 3-30. ENGINE INSTALLATION - KUBOTA ENGINE (WITH ARCTIC PACKAGE) 292
FIGURE 3-31. ENGINE AND PUMP SUB-ASSEMBLY - KUBOTA ENGINE (WITH ARCTIC PACKAGE) 298
FIGURE 3-32. ENGINE ASSEMBLY - KUBOTA ENGINE (WITH ARCTIC PACKAGE) 300
FIGURE 3-33. ENGINE COMPONENTS - KUBOTA 306
FIGURE 3-34. PUMP COUPLING KIT - KUBOTA ENGINE 310
FIGURE 3-35. PISTON PUMP ASSEMBLY 312
FIGURE 3-36. SPARK ARRESTOR INSTALLATION - DEUTZ D2011 ENGINE 316
FIGURE 3-37. ENGINE BAFFLE INSTALLATION - ABS HOODS (DEUTZ & GM ENGINES) 318
FIGURE 3-38. ENGINE BAFFLE INSTALLATION - ABS HOODS (KUBOTA ENGINES) 320

MidWestTech | JLG 400S, 460SJ Boom Lift Parts Manual | Publication 31215017 Order the manual at mid-west-tech.com >

FIGURE 3-39. ENGINE BAFFLE INSTALLATION - STEEL HOODS 322
FIGURE 3-40. ENGINE TRAY JACK (USA BUILT MACHINES) 324
FIGURE 3-41. ENGINE TRAY JACK (ROMANIAN BUILT MACHINES) 326
FIGURE 3-42. GENERATOR INSTALLATION - 2500W/60HZ (DEUTZ D2011 ENGINE) 328
FIGURE 3-43. GENERATOR INSTALLATION - 2500W/60HZ (DEUTZ D2.9L4 ENGINE) 332
FIGURE 3-44. GENERATOR INSTALLATION - 2500W/60HZ (KUBOTA ENGINE) 336
FIGURE 3-45. GENERATOR INSTALLATION - 4000W/50HZ (DEUTZ D2011 ENGINES) 340
FIGURE 3-46. GENERATOR INSTALLATION - 4000W/60HZ (DEUTZ D2011 ENGINE) 344
FIGURE 3-47. GENERATOR INSTALLATION - 4000W/60HZ (DEUTZ D2.9L4 ENGINE) 348
FIGURE 3-48. GENERATOR INSTALLATION - 4000W/50HZ (DEUTZ STAGE V ENGINE) 352
FIGURE 3-49. GENERATOR INSTALLATION - 7500W/50HZ (DEUTZ D2011 ENGINE) (PVC 2001) 356
FIGURE 3-50. GENERATOR INSTALLATION - 7500W/50HZ (DEUTZ D2011 ENGINE) (PVC 2007) 360
FIGURE 3-51. GENERATOR INSTALLATION - 7500W/60HZ (DEUTZ D2011 ENGINE) 364
FIGURE 3-52. GENERATOR INSTALLATION - 7500W/60HZ (DEUTZ D2.9L4 ENGINE) 368
FIGURE 3-53. GENERATOR INSTALLATION - 7500W/60HZ (KUBOTA ENGINE) 372
FIGURE 3-54. GENERATOR INSTALLATION - 7500W/50HZ (DEUTZ STAGE V ENGINE) 376

SECTION 4 - BOOM 379

FIGURE 4-1. BOOM AND CYLINDERS INSTALLATION - 400S 380
FIGURE 4-2. BOOM AND CYLINDERS INSTALLATION - 460SJ (USA BUILT MACHINES) 382
FIGURE 4-3. BOOM AND CYLINDERS INSTALLATION - 460SJ (ROMANIAN BUILT MACHINES) 384
FIGURE 4-4. MAIN BOOM ASSEMBLY - 400S 386
FIGURE 4-5. MAIN BOOM ASSEMBLY - 460SJ (USA BUILT MACHINES) 388
FIGURE 4-6. MAIN BOOM ASSEMBLY - 460SJ (ROMANIAN BUILT MACHINES) 390
FIGURE 4-7. JIB BOOM ASSEMBLY - 460SJ (USA BUILT MACHINES) 392
FIGURE 4-8. JIB BOOM ASSEMBLY - 460SJ (ROMANIAN BUILT MACHINES) 394
FIGURE 4-9. ROTATOR ASSEMBLY - 400S 396
FIGURE 4-10. ROTATOR ASSEMBLY - 460SJ 398
FIGURE 4-11. POWER TRACK INSTALLATION 400
FIGURE 4-12. POWER TRACK INSTALLATION 402
FIGURE 4-13. CAPACITY SWITCH INSTALLATION 404
FIGURE 4-14. TRANSPORT SWITCHES INSTALLATION 406
FIGURE 4-15. PLATFORM SUPPORT INSTALLATION - WITH 1 CELL LSS 408

SECTION 5 - PLATFORM 411

FIGURE 5-1. PLATFORM ASSEMBLY - 30IN X 5FT (76.2CM X 1.52M) WITH SWING GATE (USA BUILT MACHINES) 412
FIGURE 5-2. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH SWING GATE (USA BUILT MACHINES) 414
FIGURE 5-3. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH SWING GATE (USA BUILT MACHINES) 416
FIGURE 5-4. PLATFORM ASSEMBLY - 30IN X 5FT (76.2CM X 1.52M) WITH DROP BAR (USA BUILT MACHINES) 418
FIGURE 5-5. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH DROP BAR (USA BUILT MACHINES) 420
FIGURE 5-6. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH DROP BAR (USA BUILT MACHINES) 422
FIGURE 5-7. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH FALL ARREST (ANSI, ANSI EXPORT AND CHINA SPECS) (USA BUILT MACHINES) 424
FIGURE 5-8. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M) WITH SWING GATE (ROMANIAN BUILT MACHINES) 426
FIGURE 5-9. PLATFORM ASSEMBLY - 36IN X 6FT (92CM X 1.83M) WITH SWING GATE (ROMANIAN BUILT MACHINES) 428
FIGURE 5-10. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH SWING GATE (ROMANIAN BUILT MACHINES) 430
FIGURE 5-11. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH DROP BAR (ROMANIAN BUILT MACHINES) 432
FIGURE 5-12. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M) WITH DROP BAR (ROMANIAN BUILT MACHINES) .. 434
FIGURE 5-13. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH DROP BAR (ROMANIAN BUILT MACHINES) 436
FIGURE 5-14. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) TRI-ENTRY WITH GATE 438
FIGURE 5-15. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) TRI-ENTRY WITH DROPBAR 440
FIGURE 5-16. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH TRI-ENTRY (1 GATE/2 DROP BARS) 442
FIGURE 5-17. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH TRI-ENTRY (3 DROP BARS) 444
FIGURE 5-18. PLATFORM ASSEMBLY - 30IN X 3FT (76CM X .91M) - DROP BAR ENTRY 446
FIGURE 5-19. PLATFORM CONSOLE BOX INSTALLATION 448
FIGURE 5-20. PLATFORM CONSOLE BOX ASSEMBLY 450
FIGURE 5-21. CONTROLLER ASSEMBLY (DRIVE AND STEER) 454
FIGURE 5-22. CONTROLLER ASSEMBLY (LIFT AND SWING) 456
FIGURE 5-23. FOOTSWITCH ASSEMBLY 460
FIGURE 5-24. LIGHT PANEL INSTALLATION - 400S 462
FIGURE 5-25. LIGHT PANEL INSTALLATION - 460SJ 464
FIGURE 5-26. TRAY INSTALLATION 466
FIGURE 5-27. SOFT TOUCH INSTALLATION - 6FT (1.83M) FALL ARREST PLATFORM (OPTIONAL) 468
FIGURE 5-28. SOFT TOUCH INSTALLATION - 8FT (2.4M) PLATFORM (OPTIONAL) 470

MidWestTech | JLG 400S, 460SJ Boom Lift Parts Manual | Publication 31215017 Order the manual at mid-west-tech.com >

FIGURE 1-9. DRIVE MOTOR ASSEMBLY (2WD)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	3160351	Ref	DRIVE MOTOR ASSEMBLY (2WD)	D
1	7022302	2	Bearing, Journal	
2	7007446	1	Pin	
3	7007438	2	Ring, Retaining	
4	7022305	1	Swashplate	
5	See Note	2	Pin (Note: Not Available for Purchase)	
6	7022328	1	Gasket	
7	7023907	1	Cylinder Block Kit (Includes Items 7A & 9-17)	
7A	7023907	1	Block, Cylinder	
8	7023908	1	Plate, Valve	
9	7021277	1	Guide, Slipper Retainer	
10	7021275	3	Pin, Slipper Hold Down	
11	7023907	9	Piston Assembly	
12	7021276	1	Retainer, Hold Down Pin	
13	7023907	1	Retainer, Slipper	
14	7022311	1	Ring, Retaining	
15	7022312	1	Spring	
16	7024868	1	Washer	
17	7022314	1	Retainer, Spring	
18	7023910	1	Shaft	
19	7007439	1	Ring, Retaining	
20	70000797	1	Cap, End - Axial	
21	7022368	5	Screw	
22	7021249	1	Bearing, Needle	
23	2220886	1	Plug (Includes Item 24)	
24	7022328	1	O-Ring	
25	2220883	1	Plug (Includes Item 26)	
26	7022328	1	O-Ring	
27	7027419	2	Plug (Includes Item 28)	
28	7022328	2	O-Ring	
29	7024853	1	Seat, Spring	
30	3160351	1	Housing	
31	2220883	2	Plug (Includes Item 32)	
32	7022328	2	O-Ring	
33	2220886	1	Plug (Includes Item 34)	
34	7022328	1	O-Ring	
35	7022328	1	O-Ring	
36	7022328	1	Ring, Seal	
37	7024854	1	Piston, Servo (Includes Items 35 & 36)	
38	7007437	1	Bearing	
39	7022326	1	Spring	
40	7022328	1	Seal, Lip	
41	7022371	1	Washer, Support	
50	7022328	1	Seal Kit (Includes Items 6, 24, 26, 28, 32, 34, 35, 36 & 40)	

MidWestTech | JLG 400S, 460SJ Boom Lift Parts Manual | Publication 31215017 Order the manual at mid-west-tech.com >

FIGURE 8-37. ENGINE HARNESS - DEUTZ D2.9L4 (PVC 2007)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001167108	Ref	ENGINE HARNESS - DEUTZ D2.9L4	K
1	1001133956	1	Connector, 94 Position	
1	1001182361	6	Terminal	
1	1001126351	2	Terminal	
1	1001230934	17	Terminal	
1	1001230935	63	Plug, Terminal	
1	1001256507	4	Terminal	
1	1001230936	2	Plug, Terminal	
1	1001182365	6	Seal	
2	1001133957	1	Connector - 60 Position	
2	1001230936	11	Plug, Terminal	
2	1001126351	13	Terminal	
2	1001230935	19	Plug, Terminal	
2	1001230934	11	Terminal	
2	1001252527	4	Terminal	
2	1001256507	2	Terminal	
3	4461095	3	Plug, Male - 3 Position	
3	4460944	6	Socket, Female	
3	4460466	3	Plug, Terminal	
3	4461070	3	Connector, Female with Resistor 3 Position	
4	8220115	1	Terminal, Ring	
5	2902443	1	Receptacle Kit	
5	4461071	8	Socket, Female	
5	4461072	1	Receptacle with Flange - 8 Position	
5	4461073	1	Cap, Dust	
5	4461074	1	Shell, Black	
6	80484084	1	Connector - 8 Position	
6	4460746	3	Terminal	
6	1001234800	1	Terminal	
6	4460748	4	Plug, Terminal	
6	4460458	4	Seal	
6	8229242	1	Fuse - 5Amp	
6	80983191	1	Fuse - 10Amp	
6	1001147264	1	Cap	
7	1001116952	1	Plug, Male - 2 Position	
7	4460465	2	Socket, Female	
8	1001117106	1	Terminal, Ring	
9	4460043	1	Terminal, Ring	
10	4460247	2	Terminal, Ring	
11	4460703	1	Terminal, Ring	
12	8220164	1	Terminal, Ring	
13	1001117107	2	Terminal, Ring	
14	1001126362	1	Connector - 62 Position	
14	1001126363	25	Terminal	
14	1001126391	21	Seal, Terminal	
14	1001126392	10	Terminal	
14	4461008	4	Seal, Terminal	
14	1001126365	2	Terminal	
14	1001223459	10	Seal, Terminal	
14	1001126364	23	Seal, Terminal	

MidWestTech | JLG 400S, 460SJ Boom Lift Parts Manual | Publication 31215017 Order the manual at mid-west-tech.com >

FIGURE 9-5. DECAL INSTALLATION - CE SPEC (460SJ)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001217488	Ref	DECAL INSTALLATION - REFERENCE CHART (TURNTABLE)	B
	1001171368	Ref	DECAL INSTALLATION - CE SPEC (460SJ)	J
1	1705921	1	Decal - Tipping/Electrocution (Platform)	
2	1705822	1	Decal - Electrocution/Safety Manual	
3	1705961	3	Decal - Electrocution	
4	1701518	3	Decal - Warning Crushing	
8	1001159323	1	Decal - JLG 8 in Black	
10	1702773	1	Decal - JLG 5	
13	1001171339	1	Decal - Capacity (Platform)	
14	1001171339	1	Decal - Capacity (Ground Control)	
15	1001204510	1	Decal - Sound Power Level	
16	1701504	1	Decal - Hydraulic Oil	
17	See Note	NSS	Decal - Bar Code (Note: Not Available for Purchase)	
20	1701509	1	Decal - Manual	
21	1702300	8	Decal - Tie Down	
22	1701500	4	Decal - Lift	
23	1701529	4	Decal - Arrow	
25	0860520	1	Box, Manual Storage	
26	4751400	4	Washer, 1/4	
27	3311405	4	Nut, Lock 1/4	
28	3820001	2	Rivet	
29	1705828	1	Decal - Footswitch	
38	1701499	6	Decal - No Lift	
40	1704412	1	Decal - Hydraulic Oil Chart	
43	0641406	4	Bolt, 1/4 x 3/4	
46	1001189882	1	Decal - MSSO	
54	1701518	2	Decal - Warning Crushing	
100	1001232066	1	Decal - Platform Lanyard Kit (Not Shown)	
101	1704277	3	Decal - Attach Lanyard Here	

MidWestTech | JLG 400S, 460SJ Boom Lift Parts Manual | Publication 31215017 Order the manual at mid-west-tech.com >