Illustrated Parts Manual

Models
450A
450AJ

PVC
2001
2007

P/N
31215023

February 7, 2020 - Rev B

ANSI

AS/NZS

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 13

FIGURE 1-1. AXLE INSTALLATION 14
FIGURE 1-2. STEER INSTALLATION WITHOUT TOW PACKAGE 16
FIGURE 1-3. STEER INSTALLATION WITH TOW PACKAGE 18
FIGURE 1-4. WHEEL DRIVE INSTALLATION (2WD) 20
FIGURE 1-5. WHEEL DRIVE INSTALLATION (4WD) 22
FIGURE 1-6. HUB - SPINDLE ASSEMBLY 24
FIGURE 1-7. DRIVE HUB AND BRAKE ASSEMBLY - REAR 26
FIGURE 1-8. DRIVE HUB ASSEMBLY - FRONT 30
FIGURE 1-9. DRIVE MOTOR ASSEMBLY (2WD) 32
FIGURE 1-10. DRIVE MOTOR ASSEMBLY (4WD) 34
FIGURE 1-11. FRAME SHIELD INSTALLATION 36
FIGURE 1-12. TIRE AND WHEEL INSTALLATION - 12 X 16.5 FOAM FILLED (AVAILABLE ON ANSI, ANSI EXPORT, CSA AND JAPANESE SPECS) 38
FIGURE 1-13. TIRE AND WHEEL INSTALLATION - 12 X 16.5 FOAM FILLED NON MARKING (AVAILABLE ON ANSI, ANSI EXPORT, CSA AND JAPANESE SPECS) 40
FIGURE 1-14. TIRE AND WHEEL INSTALLATION - 33 X 12-20 SOLID NON-MARKING (AVAILABLE ON AUSTRALIAN AND CE SPECS) 42
FIGURE 1-15. TIRE AND WHEEL INSTALLATION - 33/1550 X 16.5 FOAM-FILLED (AVAILABLE ON ALL SPECS) 44
FIGURE 1-16. TIRE AND WHEEL INSTALLATION - 315/55 D20 FOAM FILLED (AVAILABLE ON AUSTRALIAN, CE AND CHINA SPECS) 46
FIGURE 1-17. TIRE AND WHEEL INSTALLATION - 315/55 D20 FOAM FILLED NON-MARKING (AVAILABLE ON AUSTRALIAN, CE AND CHINA SPECS) 48
FIGURE 1-18. 2WD VALVES INSTALLATION - 450A FRAME MOUNTED 50
FIGURE 1-19. 2WD VALVES INSTALLATION - 450AJ FRAME MOUNTED 52
FIGURE 1-20. 4WD VALVES INSTALLATION - 450A FRAME MOUNTED 54
FIGURE 1-21. 4WD VALVES INSTALLATION - 450AJ FRAME MOUNTED 56
FIGURE 1-22. TRACTION VALVE ASSEMBLY - 2WD 58
FIGURE 1-23. TRACTION VALVE ASSEMBLY - 4WD 60
FIGURE 1-24. TOW PACKAGE INSTALLATION (OPTIONAL) 62
FIGURE 1-25. TOW BAR ASSEMBLY 64

SECTION 2 - TURNTABLE 67

FIGURE 2-1. 2WD VALVES INSTALLATION - 450A TURNTABLE MOUNTED 68
FIGURE 2-2. 2WD VALVES INSTALLATION - 450AJ TURNTABLE MOUNTED 70
FIGURE 2-3. 4WD VALVES INSTALLATION - 450A TURNTABLE MOUNTED 72
FIGURE 2-4. 4WD VALVES INSTALLATION - 450AJ TURNTABLE MOUNTED 74
FIGURE 2-5. MAIN VALVE ASSEMBLY 76
FIGURE 2-6. AUXILIARY PUMP ASSEMBLY 78
FIGURE 2-7. SWING DRIVE AND TURNTABLE BEARING INSTALLATION 80
FIGURE 2-8. SWING MOTOR ASSEMBLY 82
FIGURE 2-9. TURNTABLE BEARING ASSEMBLY 84
FIGURE 2-10. TURNTABLE COVERS INSTALLATION 86
FIGURE 2-11. TURNTABLE LOCK INSTALLATION 88
FIGURE 2-12. TANKS INSTALLATION - DIESEL MACHINES 90
FIGURE 2-13. TANKS INSTALLATION - GAS MACHINES 92
FIGURE 2-14. DRIVE ORIENTATION INSTALLATION 94
FIGURE 2-15. GROUND CONTROL ASSEMBLY - 450A WITH DEUTZ ENGINES (ANSI SPECS) 96
FIGURE 2-16. GROUND CONTROL ASSEMBLY - 450AJ WITH DEUTZ ENGINES (ALL SPECS EXCEPT CE AND CHINA SPECS) 98
FIGURE 2-17. GROUND CONTROL ASSEMBLY - 450AJ WITH DEUTZ ENGINE (CHINA SPECS) 100
FIGURE 2-18. GROUND CONTROL ASSEMBLY - 450AJ WITH DEUTZ D2.9L4 ENGINE (STAGE V) (CE SPECS) 102
FIGURE 2-19. GROUND CONTROL ASSEMBLY - 450A WITH KUBOTA ENGINE (ANSI AND CSA SPECS) 104
FIGURE 2-20. GROUND CONTROL ASSEMBLY - 450AJ WITH KUBOTA ENGINE (ANSI SPECS) 106
FIGURE 2-21. LIGHT PANEL INSTALLATION – GROUND CONTROL (USA & CHINA BUILT MACHINES) 108
FIGURE 2-22. LIGHT PANEL INSTALLATION – GROUND CONTROL (ROMANIAN BUILT MACHINES) 110
FIGURE 2-23. ELECTRICAL SYSTEM INSTALLATION 112
FIGURE 2-24. WHITE NOISE ALARM INSTALLATION 116
FIGURE 2-25. BEACON LIGHT INSTALLATION - AMBER 118
FIGURE 2-26. BEACON LIGHT INSTALLATION - BLUE 120
FIGURE 2-27. BEACON LIGHT INSTALLATION - RED 122
FIGURE 2-28. BATTERY AND CABLE INSTALLATION - USA AND CHINA BUILT MACHINES (PVC 2001) 124
FIGURE 2-29. BATTERY AND CABLE INSTALLATION - USA AND CHINA BUILT MACHINES (PVC 2007) 126
FIGURE 2-30. BATTERY AND CABLE INSTALLATION - ROMANIAN BUILT MACHINES (PVC 2001) 128

MidWestTech | JLG 450A, 450AJ Boom Lift Parts Manual | Publication 31215023 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 2-31. BATTERY AND CABLE INSTALLATION - ROMANIAN BUILT MACHINES (PVC 2007) 130
FIGURE 2-32. HOODS INSTALLATION - 450A WITH DEUTZ ENGINES 132
FIGURE 2-33. HOODS INSTALLATION - 450A WITH KUBOTA ENGINE 136
FIGURE 2-34. HOODS INSTALLATION - 450AJ WITH DEUTZ ENGINES (USA & CHINA BUILT MACHINES) 140
FIGURE 2-35. HOODS INSTALLATION - 450AJ WITH DEUTZ ENGINE (ROMANIAN BUILT MACHINES) 144
FIGURE 2-36. HOODS INSTALLATION - 450AJ WITH KUBOTA ENGINE 148
FIGURE 2-37. HOOD ASSEMBLY - TANK SIDE (USA & CHINA BUILT MACHINES) 152
FIGURE 2-38. HOOD ASSEMBLY - TANK SIDE (ROMANIAN BUILT MACHINES) 154
FIGURE 2-39. HOOD ASSEMBLY - ENGINE SIDE (USA & CHINA BUILT MACHINES) 156
FIGURE 2-40. HOOD ASSEMBLY - ENGINE SIDE (ROMANIAN BUILT MACHINES) 158

SECTION 3 - ENGINE 161

FIGURE 3-1. ENGINE INSTALLATION - DEUTZ D2.9L4 ENGINE (WITHOUT ARCTIC PACKAGE) (ANSI, ANSI EXPORT, CSA AND JAPANESE SPECS) 162
FIGURE 3-2. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2.9L4 (WITHOUT ARCTIC PACKAGE) (ANSI, ANSI EXPORT, CSA AND JAPANESE SPECS) 166
FIGURE 3-3. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITHOUT ARCTIC PACKAGE) (ANSI, ANSI EXPORT, CSA AND JAPANESE SPECS) (PVC 2001) 168
FIGURE 3-4. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITHOUT ARCTIC PACKAGE) (ANSI, ANSI EXPORT, CSA AND JAPANESE SPECS) (PVC 2007) 174
FIGURE 3-5. ENGINE INSTALLATION - DEUTZ D2.9L4 ENGINE (WITH ARCTIC PACKAGE) (ANSI AND CSA SPECS) 180
FIGURE 3-6. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2.9L4 (WITH ARCTIC PACKAGE) (ANSI AND CSA SPECS) 186
FIGURE 3-7. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITH ARCTIC PACKAGE) (ANSI AND CSA SPECS) (PVC 2001) 188
FIGURE 3-8. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITH ARCTIC PACKAGE) (ANSI AND CSA SPECS) (PVC 2007) 194
FIGURE 3-9. ENGINE INSTALLATION - DEUTZ D2.9L4 ENGINE (STAGE V) (CE SPECS) 200
FIGURE 3-10. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2.9L4 ENGINE (STAGE V) (CE SPECS) 206
FIGURE 3-11. ENGINE ASSEMBLY – DEUTZ D2.9L4 ENGINE (STAGE V) (CE SPECS) 208
FIGURE 3-12. BRACKET ASSEMBLY - FUEL PUMP AND FILTER (DEUTZ D2.9L4 ENGINE) 214
FIGURE 3-13. BRACKET ASSEMBLY - FUEL PUMP AND FILTER (DEUTZ D2.9L4 ENGINE) (STAGE V) 216
FIGURE 3-14. BREATHER HEATER INSTALLATION - DEUTZ D2.9L4 ENGINE WITH ARCTIC PACKAGE 218
FIGURE 3-15. ENGINE INSTALLATION - DEUTZ D2011 ENGINE (WITHOUT ARCTIC PACKAGE) (ANSI EXPORT, AUSTRALIAN, CE (LRC) AND CHINA SPECS) 220
FIGURE 3-16. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2011 (WITHOUT ARCTIC PACKAGE) (ANSI EXPORT, AUSTRALIAN AND CHINA SPECS) 224
FIGURE 3-17. ENGINE ASSEMBLY - DEUTZ D2011 ENGINE (WITHOUT ARCTIC PACKAGE) (ANSI EXPORT, AUSTRALIAN AND CHINA SPECS) 226
FIGURE 3-18. ENGINE INSTALLATION - DEUTZ D2011 ENGINE (WITH ARCTIC PACKAGE) (ANSI EXPORT AND CHINA SPECS) 230
FIGURE 3-19. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2011 (WITH ARCTIC PACKAGE) (ANSI EXPORT AND CHINA SPECS) 234
FIGURE 3-20. ENGINE ASSEMBLY - DEUTZ D2011 ENGINE (WITH ARCTIC PACKAGE) (ANSI EXPORT AND CHINA SPECS) 236
FIGURE 3-21. ENGINE COMPONENTS - DEUTZ D2011 240
FIGURE 3-22. ENGINE INSTALLATION - DEUTZ D2011 ENGINE (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) (PVC 2001) 244
FIGURE 3-23. ENGINE AND PUMP SUB-ASSEMBLY - DEUTZ D2011 (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) (PVC 2001) 248
FIGURE 3-24. ENGINE ASSEMBLY - DEUTZ D2011 ENGINE (STAGE V) (WITHOUT ARCTIC PACKAGE) (CE SPECS) (PVC 2001) 250
FIGURE 3-25. PUMP COUPLING KIT – DEUTZ ENGINES 254
FIGURE 3-26. ENGINE INSTALLATION - KUBOTA ENGINE (WITHOUT ARCTIC PACKAGE) 256
FIGURE 3-27. ENGINE AND PUMP SUB-ASSEMBLY - KUBOTA ENGINE (WITHOUT ARCTIC PACKAGE) 262
FIGURE 3-28. ENGINE ASSEMBLY - KUBOTA ENGINE (WITHOUT ARCTIC PACKAGE) 264
FIGURE 3-29. ENGINE INSTALLATION - KUBOTA ENGINE (WITH ARCTIC PACKAGE) 270
FIGURE 3-30. ENGINE AND PUMP SUB-ASSEMBLY - KUBOTA ENGINE (WITH ARCTIC PACKAGE) 276
FIGURE 3-31. ENGINE ASSEMBLY - KUBOTA ENGINE (WITH ARCTIC PACKAGE) 278
FIGURE 3-32. ENGINE COMPONENTS - KUBOTA 284
FIGURE 3-33. PUMP COUPLING KIT - KUBOTA ENGINE 288
FIGURE 3-34. PISTON PUMP ASSEMBLY 290
FIGURE 3-35. SPARK ARRESTOR INSTALLATION - DEUTZ D2011 ENGINE 294
FIGURE 3-36. ENGINE BAFFLE INSTALLATION - WITH DEUTZ ENGINES 296
FIGURE 3-37. ENGINE BAFFLE INSTALLATION – WITH KUBOTA ENGINE 298
FIGURE 3-38. GENERATOR INSTALLATION - 2500W/50HZ (DEUTZ D2011 ENGINE) 300
FIGURE 3-39. GENERATOR INSTALLATION - 2500W/60HZ (DEUTZ D2011 ENGINE) 304

MidWestTech | JLG 450A, 450AJ Boom Lift Parts Manual | Publication 31215023 Order the manual at mid-west-tech.com >

FIGURE 3-40. GENERATOR INSTALLATION - 2500W/60HZ (DEUTZ D2.9L4 ENGINE) 308
FIGURE 3-41. GENERATOR INSTALLATION - 2500W/60HZ (KUBOTA ENGINE) 312
FIGURE 3-42. GENERATOR INSTALLATION - 4000W/50HZ (DEUTZ D2011 ENGINE) 316
FIGURE 3-43. GENERATOR INSTALLATION - 4000W/60HZ (DEUTZ D2011 ENGINE) 320
FIGURE 3-44. GENERATOR INSTALLATION - 4000W/60HZ (DEUTZ D2.9L4 ENGINE) 324
FIGURE 3-45. GENERATOR INSTALLATION - 4000W/50HZ (DEUTZ ENGINE) (STAGE V) 328
FIGURE 3-46. GENERATOR INSTALLATION - 7500W/50HZ (DEUTZ D2011 ENGINE) (PVC 2001) 332
FIGURE 3-47. GENERATOR INSTALLATION - 7500W/50HZ (DEUTZ D2011 ENGINE) (PVC 2007) 336
FIGURE 3-48. GENERATOR INSTALLATION - 7500W/60HZ (DEUTZ D2011 ENGINE) 340
FIGURE 3-49. GENERATOR INSTALLATION - 7500W/60HZ (DEUTZ D2.9L4 ENGINE) 344
FIGURE 3-50. GENERATOR INSTALLATION - 7500W/50HZ (DEUTZ ENGINE) (STAGE V) 348
FIGURE 3-51. GENERATOR INSTALLATION - 7500W/60HZ (KUBOTA ENGINE) 352

SECTION 4 - BOOM 357

FIGURE 4-1. CYLINDERS INSTALLATION - 450A 358
FIGURE 4-2. CYLINDERS INSTALLATION - 450AJ (USA AND CHINA BUILT MACHINES) 360
FIGURE 4-3. CYLINDERS INSTALLATION - 450AJ (ROMANIAN BUILT MACHINES) 362
FIGURE 4-4. BOOM INSTALLATION - 450A 364
FIGURE 4-5. BOOM INSTALLATION WITH AIRLINE - 450A 366
FIGURE 4-6. BOOM INSTALLATION WITH SKYPOWER AND AIRLINE - 450A 368
FIGURE 4-7. BOOM INSTALLATION WITH SKYPOWER - 450A 370
FIGURE 4-8. BOOM INSTALLATION KIT - 450A 372
FIGURE 4-9. BOOM INSTALLATION - 450AJ USA AND CHINA BUILT MACHINES 374
FIGURE 4-10. BOOM INSTALLATION - 450AJ ROMANIAN BUILT MACHINES 376
FIGURE 4-11. JIB INSTALLATION - USA AND CHINA BUILT MACHINES 378
FIGURE 4-12. JIB INSTALLATION - ROMANIAN BUILT MACHINES 380
FIGURE 4-13. MAIN BOOM ASSEMBLY - 450A 382
FIGURE 4-14. MAIN BOOM ASSEMBLY - 450AJ 384
FIGURE 4-15. TOWER BOOM ASSEMBLY - 450A 386
FIGURE 4-16. TOWER BOOM ASSEMBLY - 450AJ USA AND CHINA BUILT MACHINES 388
FIGURE 4-17. TOWER BOOM ASSEMBLY - 450AJ ROMANIAN BUILT MACHINES 390
FIGURE 4-18. ROTATOR ASSEMBLY 392
FIGURE 4-19. PLATFORM SUPPORT INSTALLATION 394
FIGURE 4-20. 2WD VALVES INSTALLATION - 450A BOOM MOUNTED 396
FIGURE 4-21. 2WD VALVES INSTALLATION - 450AJ BOOM MOUNTED 398
FIGURE 4-22. 4WD VALVES INSTALLATION - 450A BOOM MOUNTED 400
FIGURE 4-23. 4WD VALVES INSTALLATION - 450AJ BOOM MOUNTED 402
FIGURE 4-24. UPRIGHT VALVE ASSEMBLY 404
FIGURE 4-25. BOOM VALVE ASSEMBLY - 450A 406
FIGURE 4-26. BOOM VALVE ASSEMBLY - 450AJ 408

SECTION 5 - PLATFORM 411

FIGURE 5-1. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) - SIDE GATE ENTRY (USA BUILT MACHINES) 412
FIGURE 5-2. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M) - SIDE GATE ENTRY (USA AND CHINA BUILT MACHINES) 414
FIGURE 5-3. PLATFORM ASSEMBLY - 30IN X 6FT (76CM X 1.83M) - SIDE GATE ENTRY (USA AND CHINA BUILT MACHINES) 416
FIGURE 5-4. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) - SIDE GATE ENTRY (ROMANIAN BUILT MACHINES) 418
FIGURE 5-5. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M) - SIDE GATE ENTRY (ROMANIAN BUILT MACHINES) 420
FIGURE 5-6. PLATFORM ASSEMBLY - 30IN X 6FT (76CM X 1.83M) - SIDE GATE ENTRY (ROMANIAN BUILT MACHINES) 422
FIGURE 5-7. PLATFORM ASSEMBLY - 30IN X 3FT (76CM X .91M) - DROP BAR ENTRY (USA AND ROMANIAN BUILT MACHINES) 424
FIGURE 5-8. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) - WITH DROP BAR (USA BUILT MACHINES) 426
FIGURE 5-9. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M) - WITH DROP BAR (USA AND CHINA BUILT MACHINES) 428
FIGURE 5-10. PLATFORM ASSEMBLY - 30IN X 6FT (76CM X 1.83M) - WITH DROP BAR (USA AND CHINA BUILT MACHINES) 430
FIGURE 5-11. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) - WITH DROP BAR (ROMANIAN BUILT MACHINES) 432
FIGURE 5-12. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M) - WITH DROP BAR (ROMANIAN BUILT MACHINES) 434
FIGURE 5-13. PLATFORM ASSEMBLY - 30IN X 6FT (76CM X 1.83M) - WITH DROP BAR (ROMANIAN BUILT MACHINES) 436
FIGURE 5-14. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M - FALL ARREST (ANSI, ANSI EXPORT AND CSA SPECS) 438
FIGURE 5-15. CONSOLE BOX INSTALLATION - 450A 440
FIGURE 5-16. CONSOLE BOX INSTALLATION - 450AJ 442
FIGURE 5-17. PLATFORM CONSOLE BOX ASSEMBLY - 450A 444

MidWestTech | JLG 450A, 450AJ Boom Lift Parts Manual | Publication 31215023 Order the manual at mid-west-tech.com >

FIGURE 3-7. ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITH ARCTIC PACKAGE) (ANSI AND CSA SPECS) (PVC 2001)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001174777	Ref	ENGINE ASSEMBLY - DEUTZ D2.9L4 ENGINE (WITH ARCTIC PACKAGE)	S
1	0100011	AR	Compound, Locking	
2	0100020	AR	Sealant, Pipe	
3	0100081	AR	Adhesive	
7	0711214	1	Bolt M12 x 30	
8	0711224	4	Bolt M12 x 80	
9	0741606	2	Screw 3/8 x 3/4	
10	0760610	6	Bolt M6 x 20	
11	0760808	1	Bolt M8 x 16	
12	0760812	1	Bolt M8 x 25	
13	0760814	8	Bolt M8 x 30	
14	0761014	2	Bolt M10 x 30	
15	0761015	7	Bolt M10 x 35	
16	0761016	4	Bolt M10 x 40	
17	0761210	1	Bolt M12 x 20	
18	0761212	2	Bolt M12 x 25	
19	0771414	9	Bolt M14 x 30 Grade 10.9	
21	0961951	2	Bushing	
22	1321716	2	Clamp	
23	1703162	2	Decal - Caution Fan	
24	2220315	1	Fitting, Barbed	
26	2720015	2 ft/0.61m	Hose	
27	2720340	8 in /0.2m	Hose	
28	2902065	1	Pump Coupling Kit (See Separate Breakdown in this Section)	
29	3290605	7	Nut M6	
30	3290805	11	Nut M8	
31	3291001	4	Nut M10	
32	3291005	9	Nut M10	
33	3310401	3	Nut #4	
34	3331215	4	Nut M12 x 1.75	
35	3910408	3	Screw #4- x 1/2	
36	3931512	4	Capscrew 5/16 x 3/4	
37	4031914	4	Bolt M8 x 50	
38	4060805	2.25 ft/ 0.69m	Flex-Trim	
39	4240099	AR	Tie-Strap	
40	4640751	1	Valve, Oil Drain	
41	4710400	3	Washer #4	
42	4711500	4	Washer 5/16	
43	4811700	4	Washer M6	
44	4811900	35	Washer M8	
45	4812000	22	Washer M10	
46	4812100	4	Washer M12	
47	4812200	9	Washer M14	
48	5241200	4	Washer M12	
49	8305401	2	Nut Jam	
50	8307109	2	Washer, .250	
51	8310548	2	Screw 1/4 x 1/2	

MidWestTech | JLG 450A, 450AJ Boom Lift Parts Manual | Publication 31215023 Order the manual at mid-west-tech.com >

FIGURE 3-20. ENGINE ASSEMBLY - DEUTZ D2011 ENGINE (WITH ARCTIC PACKAGE) (ANSI EXPORT AND CHINA SPECS)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001174783	Ref	ENGINE ASSEMBLY - DEUTZ D2011 ENGINE (WITH ARCTIC PACKAGE)	L
1	0080231	1	Spacer, Fan	
2	0100011	AR	Compound, Locking	
3	0100020	AR	Sealant, Pipe	
4	0100081	AR	Adhesive	
7	0711224	4	Bolt M12 x 80 Grade 10.9	
8	0760610	6	Bolt M6 x 20	
9	0760814	8	Bolt M8 x 30	
10	0760815	9	Bolt M8 x 35	
11	0761015	11	Bolt M10 x 35	
12	0771414	8	Bolt M14 x 30 Grade 10.9	
13	0961951	2	Bushing	
14	1320016	2	Clamp	
15	1703162	2	Decal - Caution Fan	
16	2060025	1	Fan	
17	2220315	1	Fitting, Barbed	
18	2220451	2	Fitting, Straight JIC/ORB	
19	2580062	1	Heater, Engine Block	
21	3290605	6	Nut M6	
22	3290805	13	Nut M8	
23	3291005	11	Nut M10	
24	3331215	4	Nut M12	
25	3520054	2	Plug	
26	3740067	2	Relay Assembly	
26	3300220	2	Nut	
26	3321001	1	Nut #10	
26	3740140	1	Relay	
26	4761000	1	Washer #10	
26	1001111424	2	Washer	
27	3960407	1	Gasket	
28	4240099	AR	Tie-Strap (Not Shown)	
29	4811700	15	Washer M6	
30	4811900	20	Washer M8	
31	4812000	22	Washer M10	
32	4812200	8	Washer M14	
33	4923451	1	Harness, Glow Plugs	
34	5241200	4	Washer M12	
35	8305401	2	Nut, Jam	
36	8307109	2	Washer	
37	8310548	2	Screw 1/4 x 1/2	
38	1001132195	1	Bracket, Engine Mount	
39	1001132196	1	Bracket, Engine Mount	
40	1001138173	1	Support, Service Indicator	
41	1001138175	1	Bracket, Service Indicator	
42	1001139819	1	Adapter, Air Intake	
43	1001141694	1	Clamp, Air Cleaner	
44	1001141995	1	Fitting, Barbed	
45	1001143390	1	Indicator	

MidWestTech | JLG 450A, 450AJ Boom Lift Parts Manual | Publication 31215023 Order the manual at mid-west-tech.com >

FIGURE 10-1. RECOMMENDED SERVICE PARTS STOCK

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
		Ref	Note: The following list will service one machine (built to current production per date on the front cover) with emergency repair parts which can be installed in the field. Parts from the list should be replaced when inventory is depleted to keep service parts stock supplied. For further information, contact your JLG dealer or the JLG Industries Parts Department.	
		Ref	STANDARD PARTS	
	7024885	1	Coil	
	70002386	1	Coil	
	70003788	1	Coil	
	70005219	1	Coil	
	70004897	1	Coil	
	70004871	1	Coil	
	7027628	1	Coil	
	1001212415	1	Controller Assembly (Drive and Steer)	
	1001129555	1	Controller Assembly (Lift and Swing)	
	70010383	1	Element, Filter Charge Pump (Includes O-Ring)	
	70002838	1	Fill Cap Assembly (Includes Cap, Chain and Fill Basket)	
	70003614	1	Filter Kit (Includes Hydraulic Element, Breather Element and Gasket)	
	1001095704	2	Fuse - 3Amp	
	1001196635	2	Fuse - 3Amp	
	8229242	2	Fuse - 5Amp	
	8229244	2	Fuse - 15Amp	
	1001129285	2	Fuse with Diode – 1Amp	
	3740067	1	Relay	
	3740140	1	Relay	
	3740086	1	Relay	
	1001095704	1	Relay	
	1001117308	1	Relay	
	2860030	1	Key, Replacement	
	4360328	1	Switch, Toggle	
	4360387	1	Switch, Push Button	
	4360475	1	Switch, Emergency Stop	
	4360476	1	Switch, Contact Block	
	4360407	1	Switch, Potentiometer	
	1001155045	1	Switch, Toggle	
	1001159256	1	Switch, Toggle	
	1001161709	1	Switch, Toggle	
		Ref	VARIABLE PARTS	
	1001181045	1	Breaker, 30mA/16Amp (CE Spec with 2 Breaker Box)	
	1001152479	1	Breaker, Circuit 16A Double (CE Specs Machines with 3 Breaker Box)	
	1001152482	1	Breaker, Circuit 30mA (CE Specs Machines with 3 Breaker Box)	
	70003783	12	Element, Air Cleaner (Deutz 2.9L4, Deutz D2011 Engines and Deutz D2.9L4 Engines (Stage V))	
	7016331	12	Filter, Oil (Deutz Engines)	
	70006023	12	Filter, Oil (Kubota Engines)	
	70025153	12	Filter, Fuel (Deutz 2.9L4 Engines)	
	70025161	12	Filter, Fuel (Deutz 2.9L4 Engines)	

MidWestTech | JLG 450A, 450AJ Boom Lift Parts Manual | Publication 31215023 Order the manual at mid-west-tech.com >