Illustrated Parts Manual

Model

H800AJ

PVC
2001
2007

P/N
31215044

August 1, 2020 – Rev C

ANSI

AS/NZS

An Oshkosh Corporation Company

MidWestTech | JLG H800AJ Boom Lift Parts Manual | Publication 31215044

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 11

FIGURE 1-1. AXLE INSTALLATION - WITHOUT TOW PACKAGE 12
FIGURE 1-2. AXLE INSTALLATION - WITH TOW PACKAGE 14
FIGURE 1-3. STEER INSTALLATION - WITHOUT TOW PACKAGE 16
FIGURE 1-4. STEER INSTALLATION - WITH TOW PACKAGE 18
FIGURE 1-5. WHEEL DRIVE AND FRAME VALVES INSTALLATION 20
FIGURE 1-6. DRIVE HUB/BRAKE ASSEMBLY 22
FIGURE 1-7. DRIVE MOTOR ASSEMBLY 24
FIGURE 1-8. TIRE & WHEEL INSTALLATION - 15-625 NHS FOAM-FILLED 26
FIGURE 1-9. TIRE AND WHEEL INSTALLATION - 18-625 NHS FOAM-FILLED 28
FIGURE 1-10. TIRE AND WHEEL INSTALLATION - 18-625 NHS FOAM-FILLED NON-MARKING 30
FIGURE 1-11. FRAME SHIELDS INSTALLATION 32
FIGURE 1-12. TOW PACKAGE INSTALLATION (OPTIONAL) (ANSI. SPECS) 34
FIGURE 1-13. TOW BAR ASSEMBLY 36

SECTION 2 - TURNTABLE 39

FIGURE 2-1. VALVES INSTALLATION 40
FIGURE 2-2. MAIN VALVE ASSEMBLY 42
FIGURE 2-3. BRAKE/2 SPEED VALVE ASSEMBLY 46
FIGURE 2-4. SWING DRIVE INSTALLATION 48
FIGURE 2-5. SWING MOTOR/HUB ASSEMBLY 50
FIGURE 2-6. TURNTABLE BEARING AND LUBE INSTALLATION 54
FIGURE 2-7. TURNTABLE LOCK INSTALLATION 56
FIGURE 2-8. ROTARY COUPLING INSTALLATION 58
FIGURE 2-9. TANKS INSTALLATION 60
FIGURE 2-10. HYDRAULIC TANK ASSEMBLY 62
FIGURE 2-11. FUEL TANK ASSEMBLY 64
FIGURE 2-12. OIL COOLER INSTALLATION 66
FIGURE 2-13. BATTERY BOXES INSTALLATION 68
FIGURE 2-14. BATTERY CHARGERS INSTALLATION (FACTORY SUPPLIED 220V PLUG) 72
FIGURE 2-15. BATTERY CHARGERS INSTALLATION (CUSTOMER SUPPLIED PLUG) 74
FIGURE 2-16. ELECTRICAL SYSTEM INSTALLATION 76
FIGURE 2-17. IMG CONTROL BOX ASSEMBLY 78
FIGURE 2-18. ELECTRICAL ASSEMBLY - 12V FUSE BOX 82
FIGURE 2-19. GROUND CONTROL BOX ASSEMBLY 84
FIGURE 2-20. LIGHT PANEL INSTALLATION - GROUND CONTROL 86
FIGURE 2-21. GROUND CONTROL PANEL DECAL INSTALLATION (WITHOUT MSSO) 88
FIGURE 2-22. GROUND CONTROL PANEL DECAL INSTALLATION (WITH MSSO) 90
FIGURE 2-23. ALARM INSTALLATION 92
FIGURE 2-24. WHITE NOISE ALARM INSTALLATION - ADJUSTABLE AMBIENT 94
FIGURE 2-25. WHITE NOISE MOTION ALARM INSTALLATION - AMBIENT 96
FIGURE 2-26. STROBE LIGHT INSTALLATION - AMBER (OPTIONAL) 98
FIGURE 2-27. STROBE LIGHT INSTALLATION - BLUE (OPTIONAL) 100
FIGURE 2-28. STROBE LIGHT INSTALLATION - RED (OPTIONAL) 102
FIGURE 2-29. HEAT SHIELD AND ACCESS PANELS INSTALLATION 104
FIGURE 2-30. HOODS INSTALLATION 106
FIGURE 2-31. HOOD ASSEMBLY - TANK SIDE 110
FIGURE 2-32. HOOD ASSEMBLY - ENGINE SIDE 112

SECTION 3 - ENGINE 115

FIGURE 3-1. ENGINE INSTALLATION 116
FIGURE 3-2. ENGINE AND PUMPS SUB-ASSEMBLY 120
FIGURE 3-3. ENGINE AND TRAY ASSEMBLY 122
FIGURE 3-4. ENGINE AND GENERATOR ASSEMBLY 126
FIGURE 3-5. ENGINE AND CLUTCH ASSEMBLY 128
FIGURE 3-6. ENGINE FAN MOUNTING ASSEMBLY 130
FIGURE 3-7. KUBOTA ENGINE COMPONENTS 132
FIGURE 3-8. GENERATOR ASSEMBLY 136
FIGURE 3-9. VARIABLE PUMP ASSEMBLY 138
FIGURE 3-10. HYDROSTATIC PUMP ASSEMBLY 142
FIGURE 3-11. FUEL/WATER SEPARATOR ASSEMBLY 144
FIGURE 3-12. ENGINE HOOD BAFFLES INSTALLATION 146
FIGURE 3-13. TRAY JACK INSTALLATION 148

MidWestTech | JLG H800AJ Boom Lift Parts Manual | Publication 31215044 **Order the manual at mid-west-tech.com >**

TABLE OF CONTENTS

FIGURE 3-14. 4000W GENERATOR INSTALLATION - 220V/50HZ (OPTIONAL) 150
FIGURE 3-15. 7500W SKYPOWER GENERATOR INSTALLATION - 220V/50HZ (OPTIONAL) 154
FIGURE 3-16. 7500W SKYPOWER GENERATOR INSTALLATION - 110V/60HZ (OPTIONAL) 158

SECTION 4 - BOOM 161

FIGURE 4-1. BOOM AND CYLINDER INSTALLATION 162
FIGURE 4-2. MAIN BOOM ASSEMBLY 164
FIGURE 4-3. MAIN BOOM ASSEMBLY 166
FIGURE 4-4. TOWER BOOM ASSEMBLY 168
FIGURE 4-5. JIB ASSEMBLY 170
FIGURE 4-6. ROTATOR ASSEMBLY 172
FIGURE 4-7. POWER TRACK INSTALLATION - MAIN BOOM 174
FIGURE 4-8. POWER TRACK INSTALLATION - TOWER BOOM 176
FIGURE 4-9. BOOM VALVES INSTALLATION 178
FIGURE 4-10. BOOM VALVE ASSEMBLY 180
FIGURE 4-11. BOOM VALVE AND LIMIT SWITCHES INSTALLATION 182
FIGURE 4-12. TILT SENSOR INSTALLATION 184
FIGURE 4-13. TRANSPORT POSITION SWITCH INSTALLATION (CE SPECS) 186
FIGURE 4-14. PLATFORM SUPPORT INSTALLATION 188

SECTION 5 - PLATFORM 191

FIGURE 5-1. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) WITH SWING GATE 192
FIGURE 5-2. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) WITH DROP BAR 194
FIGURE 5-3. PLATFORM ASSEMBLY - 30IN X 6FT (76CM X 1.83M) WITH SWING GATE 196
FIGURE 5-4. PLATFORM ASSEMBLY - 30IN X 6FT (76CM X 1.83M) WITH DROP BAR 198
FIGURE 5-5. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH SWING GATE 200
FIGURE 5-6. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH DROP BAR 202
FIGURE 5-7. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH FALL ARREST (ANSI, ANSI EXPORT, CHINA & CSA SPECS) 204
FIGURE 5-8. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH SWING GATE 206
FIGURE 5-9. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH DROP BAR 208
FIGURE 5-10. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH FALL ARREST 210
FIGURE 5-11. TRAY ASSEMBLY 212
FIGURE 5-12. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION 214
FIGURE 5-13. PLATFORM CONSOLE BOX ASSEMBLY 216
FIGURE 5-14. LIGHT PANEL INSTALLATION 220
FIGURE 5-15. JIB SWITCH INSTALLATION 222
FIGURE 5-16. CONTROLLER ASSEMBLY (DRIVE AND STEER) 224
FIGURE 5-17. CONTROLLER ASSEMBLY (LIFT AND SWING) 226
FIGURE 5-18. FOOTSWITCH ASSEMBLY 230
FIGURE 5-19. SOFT TOUCH INSTALLATION - 6FT (1.83M) PLATFORM (OPTIONAL) 232
FIGURE 5-20. SOFT TOUCH INSTALLATION - 6FT (1.83M) FALL ARREST PLATFORM (OPTIONAL) 234
FIGURE 5-21. SOFT TOUCH INSTALLATION - 8FT (2.4M) PLATFORM (OPTIONAL) 236
FIGURE 5-22. SOFT TOUCH INSTALLATION - 8FT (2.4M) FALL ARREST PLATFORM (OPTIONAL) 238
FIGURE 5-23. SKYEYE INSTALLATION 240
FIGURE 5-24. SKYGUARD BAR INSTALLATION 242
FIGURE 5-25. SKYLINE INSTALLATION 244
FIGURE 5-26. SKYGLAZIER INSTALLATION (ANSI, ANSI EXPORT, AUSTRALIAN & CSA SPECS) 246
FIGURE 5-27. SKYWELDER INSTALLATION (50HZ) 248
FIGURE 5-28. SKYWELDER INSTALLATION (60HZ) 250
FIGURE 5-29. SKYWELDER PREP PACKAGE (60HZ) 252
FIGURE 5-30. WELDER ASSEMBLY 254
FIGURE 5-31. PIPE RACK INSTALLATION (ANSI AND CSA SPECS ONLY) 256
FIGURE 5-32. FALL ARREST INSTALLATION (BOLT-ON) 30IN X 4FT (76CM X 1.22M) PLATFORM 258
FIGURE 5-33. FALL ARREST INSTALLATION (BOLT-ON) 36IN X 6FT (91.2CM X 1.82M) PLATFORM 260
FIGURE 5-34. FALL ARREST INSTALLATION (BOLT-ON) 30IN X 6FT (76CM X 1.83M) PLATFORM 262
FIGURE 5-35. FALL ARREST INSTALLATION (BOLT-ON) 36IN X 8FT (91.5CM X 2.4M) PLATFORM 264

SECTION 6 - CYLINDER 267

FIGURE 6-1. AXLE LOCKOUT CYLINDER ASSMBLY 268
FIGURE 6-2. LEVEL (SLAVE) CYLINDER ASSEMBLY - JIB 270
FIGURE 6-3. LEVEL (SLAVE) CYLINDER ASSEMBLY - UPRIGHT 272
FIGURE 6-4. LIFT CYLINDER ASSEMBLY - JIB 274
FIGURE 6-5. LIFT CYLINDER ASSEMBLY - MAIN BOOM 276

MidWestTech | JLG H800AJ Boom Lift Parts Manual | Publication 31215044 Order the manual at mid-west-tech.com >

FIGURE 6-6. LIFT CYLINDER ASSEMBLY - TOWER BOOM 278
FIGURE 6-7. MASTER CYLINDER ASSEMBLY 280
FIGURE 6-8. STEER CYLINDER ASSEMBLY 282
FIGURE 6-9. TELESCOPE CYLINDER ASSEMBLY - MAIN BOOM 284
FIGURE 6-10. TELESCOPE CYLINDER ASSEMBLY - TOWER BOOM 286

SECTION 7 - HYDRAULIC 289

FIGURE 7-1. AXLE LOCKOUT HYDRAULIC DIAGRAM 290
FIGURE 7-2. DRIVE HYDRAULIC DIAGRAM 292
FIGURE 7-3. STANDARD HYDRAULIC DIAGRAM 298
FIGURE 7-4. TOW HYDRAULIC DIAGRAM 302

SECTION 8 - ELECTRICAL 305

FIGURE 8-1. AC BOX AT PLATFORM INSTALLATION - 110V GFI RECEPTACLE (ALL SPECS EXCEPT AUSTRALIAN & CE SPECS) 306
FIGURE 8-2. AC BOX AT PLATFORM INSTALLATION - 110V IEC YELLOW (CE SPECS) (MACHINES WITHOUT 4000W GENERATOR) 308
FIGURE 8-3. AC BOX AT PLATFORM INSTALLATION - 110V IEC YELLOW (CE SPECS) (MACHINES WITH 4000W GENERATOR) 310
FIGURE 8-4. AC BOX AT PLATFORM INSTALLATION - 220V (ANSI, CSA & JAPANESE SPECS) 312
FIGURE 8-5. AC BOX AT PLATFORM INSTALLATION - 220V IEC BLUE (CE SPECS) (MACHINES WITHOUT 4000W GENERATOR) 314
FIGURE 8-6. AC BOX AT PLATFORM INSTALLATION - 220V IEC BLUE (CE SPECS) (MACHINES WITH 4000W GENERATOR) 316
FIGURE 8-7. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 2X4 POST GROUND (CE SPECS) (MACHINES WITHOUT 4000W GENERATOR) 318
FIGURE 8-8. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 2X4 POST GROUND (CE SPECS) (MACHINES WITH 4000W GENERATOR) 320
FIGURE 8-9. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 2X4 SIDE GROUND (CE SPECS) (MACHINES WITHOUT 4000W GENERATOR) 322
FIGURE 8-10. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 2X4 SIDE GROUND (CE SPECS) (MACHINES WITH 4000W GENERATOR) 324
FIGURE 8-11. AC BOX AT PLATFORM INSTALLATION - 220V AFSINT 107 (CE SPECS) (MACHINES WITHOUT 4000W GENERATOR) 326
FIGURE 8-12. AC BOX AT PLATFORM INSTALLATION - 220V AFSINT 107 (CE SPECS) (MACHINES WITH 4000W GENERATOR) 328
FIGURE 8-13. AC BOX AT PLATFORM INSTALLATION - BOX WITH COVER (ANSI EXPORT, AUSTRALIAN, CHINA & JAPANESE SPECS) 330
FIGURE 8-14. AC BOX AT PLATFORM INSTALLATION - 240V RECEPTACLE (WITH 4000W GENERATOR) (ALL SPECS EXCEPT ANSI & CSA SPECS) 332
FIGURE 8-15. AC BOX AT PLATFORM INSTALLATION - 240V RECEPTACLE (WITH 7500W SKYPOWER GENERATOR) (ANSI & CSA SPECS) 334
FIGURE 8-16. AC BOX AT PLATFORM MID-BOOM PLUG INSTALLATION (WITHOUT 7500W SKYPOWER GENERATOR) (ALL SPECS EXCEPT ANSI & CSA SPECS) 336
FIGURE 8-17. AC BOX AT PLATFORM MID-BOOM PLUG INSTALLATION (WITH 7500W SKYPOWER GENERATOR) 338
FIGURE 8-18. AC BREAKER BOX INSTALLATION - WITH 2 BREAKERS (CE SPECS WITH 4000W GENERATOR) 340
FIGURE 8-19. AC BREAKER BOX INSTALLATION - WITH 2 BREAKERS (BRAZIL SPECS) 342
FIGURE 8-20. AC BREAKER BOX INSTALLATION - WITH 3 BREAKERS (CE SPECS WITH 4000W GENERATOR) 344
FIGURE 8-21. BATTERY CABLES INSTALLATION 346
FIGURE 8-22. BATTERY STACK HARNESS (LH) 348
FIGURE 8-23. BATTERY STACK HARNESS (RH) 350
FIGURE 8-24. BOOM VALVE HARNESS 352
FIGURE 8-25. BOOM CABLES INSTALLATION (MACHINES WITHOUT GENERATOR) 354
FIGURE 8-26. BOOM CABLES INSTALLATION (AUSTRALIAN SPECS WITH 4000W GENERATOR) 356
FIGURE 8-27. BOOM CABLES INSTALLATION (CE SPECS WITH 4000W GENERATOR) 358
FIGURE 8-28. BOOM CABLES INSTALLATION (ANSI, ANSI EXPORT, CHINA, CSA & JAPANESE SPECS WITH 7500W GENERATOR) 360
FIGURE 8-29. BOOM CABLES INSTALLATION (AUSTRALIAN & CE SPECS WITH 7500W GENERATOR) 362
FIGURE 8-30. BOOM CABLE - MAIN BOOM 364
FIGURE 8-31. BOOM CABLE - TOWER BOOM 366
FIGURE 8-32. BREAKER BOX KIT - WITH 2 BREAKERS (CE SPECS WITHOUT 4000W GENERATOR & BRAZIL SPECS) 368
FIGURE 8-33. BREAKER BOX KIT - WITH 2 BREAKERS (CE SPECS WITH 4000W GENERATOR) 370
FIGURE 8-34. BREAKER BOX KIT - WITH 3 BREAKERS (CE SPECS WITH 4000W GENERATOR) 372
FIGURE 8-35. CHARGER HARNESS 374
FIGURE 8-36. CONTROL HARNESS 376

MidWestTech | JLG H800AJ Boom Lift Parts Manual | Publication 31215044 Order the manual at mid-west-tech.com >

FIGURE 5-16. CONTROLLER ASSEMBLY (DRIVE AND STEER)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001166538	Ref	CONTROLLER ASSEMBLY (DRIVE AND STEER)	G
		Ref	Note: Original Equipment Controller May Have Been Replaced with Service Replacement Controller. Visually Identify Controller Before Ordering Parts.	
		Ref	Note: Use p/n 1001212415 Kit as Replacement.	
7	70004738	2	Washer	
10	70004739	1	Roller	
11	70004740	1	Boot, Switch	
14	70004741	2	Half, Handle	
17	70004742	1	Enclosure	
18	70004743	4	Nut	
19	70004744	NLA	Boot, Controller (Note: Use Item 200)	
20	70004745	NLA	Tube, Locking (Note: Use Item 200)	
21	70004746	NLA	Disc, Locking (Note: Use Item 200)	
25	70004747	2	Seal, Rope	
26	70004748	1	Screw M3 x 6	
28	70004749	2	Screw M5 x 20	
29	70004750	1	Pin, Dowel	
30	70004751	4	Screw M3 x 16	
101	4460265	1	Connector - 9 Position	
101	4460226	7	Socket, Female	
200	70005230	1	Boot Kit (Includes Items 19-21)	

MidWestTech | JLG H800AJ Boom Lift Parts Manual | Publication 31215044 Order the manual at mid-west-tech.com >

FIGURE 6-7. MASTER CYLINDER ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001228050	Ref	MASTER CYLINDER ASSEMBLY	A
		Ref	Note: Original Cylinder may have been replaced with Service Replacement. Identify PN Stamped on Cylinder Before Ordering Parts.	
1	See Note	NSS	Barrel (Note: Not Available for Purchase)	
2	70006668	1	Rod	
3	70006643	1	Head	
4	See Note	NSS	Wiper (Note: Use Item 30)	
5	See Note	NSS	Seal, Rod (Note: Use Item 30)	
6	See Note	NSS	Ring, Wear (Note: Use Item 30)	
7	See Note	NSS	O-Ring (Note: Use Item 30)	
8	See Note	NSS	Ring, Back-up (Note: Use Item 30)	
9	70006644	1	Piston	
10	See Note	NSS	Ring, Wear (Note: Use Item 30)	
11	See Note	NSS	Ring, Lock (Note: Use Item 30)	
12	See Note	NSS	O-Ring (Note: Use Item 30)	
13	See Note	NSS	Ring, Back-up (Note: Use Item 30)	
14	70006651	1	Spacer, Tube	
15	0961894	1	Bushing, Tapered	
16	0630535	3	Capscrew 1/4 x 1-1/8	
17	3931620	8	Capscrew 3/8 x 1-1/4	
18	0962155	1	Bushing	
19	0961951	2	Bushing	
20	2220885	2	Plug, O-Ring	
30	1001138796	1	Seal Kit (Machines with Arctic Package) (Includes Items 4-8 & 10-13)	

MidWestTech | JLG H800AJ Boom Lift Parts Manual | Publication 31215044 Order the manual at mid-west-tech.com >

FIGURE 11-1. SPECIAL OPTIONS

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
		Ref	Note: This list is to accommodate machines ordered with special equipment. Options may not be applicable to all models. For more specific parts information contact JLG Parts Department.	
		Ref	MISCELLANEOUS SPECIAL OPTIONS	
	0258805	Ref	Airline to Platform Installation - 1/2in	
	1001092092	Ref	Airline to Platform Installation - 1/2in (With Arctic Package)	
	1001152965	Ref	Beacon/Strobe Light (Amber) (Platform Mounted) Installation	
	1001228656	Ref	Beacon/Strobe Light (Amber) (Dual Ground & Platform Mounted) Installation	
	0258737	Ref	Bellows Installation - Boom	
	1001158259	Ref	Bellows Installation - Chassis	
	2910887	Ref	Boom Wear Pad Kit	
	0258654	Ref	Boom Wipers Installation	
	1001172045	Ref	Cable/Ladder Carrier Installation (800AJ Only)	
		Ref	ClearSky Telematics Add-on Kits (Dealer Installed)	
	1001230187	Ref	ClearSky Telematics Add-on Kits - Canbus Connection (Dealer Installed) (ANSI & CSA Specs)	
	1001234099	Ref	ClearSky Telematics Add-on Kits - Canbus Connection (Dealer Installed) (CE Specs)	
	1001246142	Ref	ClearSky Telematics Add-on Kit (Dealer Installed) (Australian Specs)	
	1001230504	Ref	ClearSky Telematics Add-on Kits - 3 Wire Connection (Dealer Installed) (ANSI & CSA Specs)	
	1001234102	Ref	ClearSky Telematics Installation - 3 Wire Connection (Dealer Installed) (CE Specs)	
	1001242192	Ref	ClearSky Access Control Add-on Kit	
	1001243183	Ref	ClearSky Telematics Access Control Add-on Kit - Canbus (ANSI & CSA Specs)	
	1001243184	Ref	ClearSky Telematics Access Control Add-on Kit - Canbus (ANSI Export & CE Specs)	
		Ref	ClearSky Telematics Installation (Factory Installed)	
	1001227448	Ref	ClearSky Telematics Installation - Canbus Connection (Factory Installed) (ANSI & CSA Specs)	
	1001246473	Ref	ClearSky Telematics Installation - Canbus Connection (Factory Installed) (Australian Specs)	
	1001228949	Ref	ClearSky Telematics Installation - Canbus Connection (Factory Installed) (ANSI Export & CE Specs)	
	1001246474	Ref	ClearSky Telematics Installation - Canbus Connection (Factory Installed) (China Specs)	
	1001229107	Ref	ClearSky Telematics Installation - 3 Wire Connection (Factory Installed) (ANSI & CSA Specs)	
	1001233237	Ref	ClearSky Telematics Installation - 3 Wire Connection (Factory Installed) (ANSI Export & CE Specs)	
	1001238307	Ref	Charging Kit – 120V (Dual Plug)	
	1001235269	Ref	Clutch Actuator Installation Kit	
	1001227904	Ref	Cold Weather Package Installation - 120V (All Specs except Australian, CE and China Specs)	
	1001232214	Ref	Cold Weather Package Installation - 240V (CE Specs Only)	
	1001115918	Ref	Cribbing Installation	
		Ref	Decal Kit Options:	
	1001220864	Ref	Boom Transport Decal Kit	
	1001108721	Ref	Platform Decal Kit (ANSI Specs)	

MidWestTech | JLG H800AJ Boom Lift Parts Manual | Publication 31215044 Order the manual at mid-west-tech.com >