Illustrated Parts Manual

Model
1850SJ

PVC
2001
2007

P/N
31215068

June 15, 2020 - Rev B

ANSI

CE

AS/NZS

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 13

FIGURE 1-1. AXLES INSTALLATION 14
FIGURE 1-2. STEERING INSTALLATION 16
FIGURE 1-3. WHEEL DRIVE INSTALLATION 18
FIGURE 1-4. DRIVE MOTOR ASSEMBLY 20
FIGURE 1-5. DRIVE HUB ASSEMBLY 22
FIGURE 1-6. TIRE/WHEEL INSTALLATION - IN445/50D710 FOAM-FILLED 26
FIGURE 1-7. VALVES INSTALLATION - FRAME (WITH LSS) 28
FIGURE 1-8. TRACTION VALVE ASSEMBLY 30
FIGURE 1-9. STEER/AXLE EXTEND VALVE ASSEMBLY 32
FIGURE 1-10. COVERS INSTALLATION - FRAME 34
FIGURE 1-11. ELECTRICAL COMPONENTS INSTALLATION – FRAME (ANSI EXPORT (LRC), AUSTRALIAN AND CHINA SPECS) 36
FIGURE 1-12. ELECTRICAL COMPONENTS INSTALLATION - FRAME (ANSI, ANSI EXPORT (HRC), CSA AND JAPANESE SPECS) 38
FIGURE 1-13. ELECTRICAL COMPONENTS INSTALLATION - FRAME (CE SPECS) (LRC) 40
FIGURE 1-14. ELECTRICAL COMPONENTS INSTALLATION - FRAME (CE SPECS) 42

SECTION 2 - TURNTABLE 45

FIGURE 2-1. VALVES AND HYDRAULIC FILTERS INSTALLATION - TURNTABLE (WITH LSS) 46
FIGURE 2-2. MAIN VALVE ASSEMBLY 48
FIGURE 2-3. TURNTABLE BEARING INSTALLATION 52
FIGURE 2-4. TURNTABLE LOCK INSTALLATION 54
FIGURE 2-5. SWING DRIVE INSTALLATION 56
FIGURE 2-6. SWING HUB/BRAKE/ MOTOR ASSEMBLY 58
FIGURE 2-7. COUPLING/COLLECTOR RING INSTALLATION 62
FIGURE 2-8. TANKS INSTALLATION 64
FIGURE 2-9. TANKS INSTALLATION - WITH DIESEL EXHAUST FLUID TANK 66
FIGURE 2-10. HYDRAULIC TANK ASSEMBLY 68
FIGURE 2-11. AUXILIARY POWER/BATTERIES INSTALLATIONS 70
FIGURE 2-12. AUXILIARY PUMP AND MOTOR ASSEMBLY 72
FIGURE 2-13. TURNTABLE ELECTRICAL COMPONENTS INSTALLATION (ANSI EXPORT (LRC), AUSTRALIAN AND CHINA SPECS) 74
FIGURE 2-14. TURNTABLE ELECTRICAL COMPONENTS INSTALLATION (ANSI, ANSI EXPORT (HRC), CSA AND JAPANESE SPECS) 78
FIGURE 2-15. TURNTABLE ELECTRICAL COMPONENTS INSTALLATION (CE (LRC) SPECS) 82
FIGURE 2-16. TURNTABLE ELECTRICAL COMPONENTS INSTALLATION (CE SPECS) 86
FIGURE 2-17. GROUND CONTROL CONSOLE ASSEMBLY (ANSI EXPORT (LRC), AUSTRALIAN AND CHINA SPECS) 90
FIGURE 2-18. GROUND CONTROL CONSOLE ASSEMBLY (ANSI, ANSI EXPORT (HRC), CSA AND JAPANESE SPECS) 92
FIGURE 2-19. GROUND CONTROL CONSOLE ASSEMBLY (CE (LRC) SPECS) 94
FIGURE 2-20. GROUND CONTROL CONSOLE ASSEMBLY (CE SPECS) 96
FIGURE 2-21. KEY SWITCH 98
FIGURE 2-22. LIGHT PANEL 100
FIGURE 2-23. ELECTRICAL PANEL ASSEMBLY 102
FIGURE 2-24. ALARM INSTALLATION 104
FIGURE 2-25. BEACON LIGHT INSTALLATION - AMBER 106
FIGURE 2-26. STROBE LIGHT INSTALLATION - BLUE 108
FIGURE 2-27. STROBE LIGHT INSTALLATION - RED 110
FIGURE 2-28. HOOD INSTALLATION 112
FIGURE 2-29. VENTURI INSTALLATION (HRC) (ANSI, ANSI EXPORT (HRC), CE, CSA CE AND JAPANESE) 118
FIGURE 2-30. VENTURI INSTALLATION (LRC) (ANSI EXPORT (LRC), AUSTRALIAN, CE (LRC) AND CHINA) 120

SECTION 3 - ENGINE 123

FIGURE 3-1. DEUTZ LRC ENGINE INSTALLATION - WITHOUT COLD WEATHER PKG 124
FIGURE 3-2. DEUTZ LRC ENGINE/PUMP ASSEMBLY - WITHOUT COLD WEATHER PKG 128
FIGURE 3-3. DEUTZ LRC ENGINE ASSEMBLY - WITHOUT COLD WEATHER PKG 130
FIGURE 3-4. DEUTZ LRC ENGINE INSTALLATION - WITH COLD WEATHER PKG 136
FIGURE 3-5. DEUTZ LRC ENGINE/PUMP ASSEMBLY - WITH COLD WEATHER PKG 140
FIGURE 3-6. DEUTZ LRC ENGINE ASSEMBLY - WITH COLD WEATHER PKG 142
FIGURE 3-7. DEUTZ HRC ENGINE INSTALLATION - WITHOUT COLD WEATHER PKG 148
FIGURE 3-8. DEUTZ HRC ENGINE/PUMP ASSEMBLY - WITHOUT COLD WEATHER PKG 152
FIGURE 3-9. DEUTZ HRC ENGINE ASSEMBLY - WITHOUT COLD WEATHER PKG 154
FIGURE 3-10. DEUTZ HRC ENGINE INSTALLATION - WITH COLD WEATHER PKG 160

MidWestTech | JLG 1850SJ Boom Lift Parts Manual | Publication 31215068_Rev_B Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 3-11. DEUTZ HRC ENGINE/PUMP ASSEMBLY - WITH COLD WEATHER PKG 164
FIGURE 3-12. DEUTZ HRC ENGINE ASSEMBLY - WITH COLD WEATHER PKG 166
FIGURE 3-13. DEUTZ HRC (STAGE V) ENGINE INSTALLATION - WITHOUT COLD WEATHER PKG 172
FIGURE 3-14. DEUTZ HRC (STAGE V) ENGINE/PUMP ASSEMBLY - WITHOUT COLD WEATHER PKG 176
FIGURE 3-15. DEUTZ HRC (STAGE V) ENGINE ASSEMBLY - WITHOUT COLD WEATHER PKG 178
FIGURE 3-16. PUMP COUPLING KIT 184
FIGURE 3-17. TANDEM PUMP ASSEMBLY 186
FIGURE 3-18. PISTON PUMP ASSEMBLY 190
FIGURE 3-19. GEAR PUMP ASSEMBLY 194
FIGURE 3-20. FUEL FILTER/WATER SEPARATOR INSTALLATION 196
FIGURE 3-21. FUEL FILTER ASSEMBLY 198
FIGURE 3-22. SPARK ARRESTOR INSTALLATION - DEUTZ LRC (OPTIONAL) 200
FIGURE 3-23. SPARK ARRESTOR INSTALLATION - DEUTZ T4F (OPTIONAL) 202
FIGURE 3-24. 4000W GENERATOR INSTALLATION - 50HZ SPEC (OPTIONAL) 204
FIGURE 3-25. 7500W SKYPOWER GENERATOR INSTALLATION - 60HZ (OPTIONAL) 208
FIGURE 3-26. 7500W SKYPOWER GENERATOR INSTALLATION - 50HZ (OPTIONAL) 212

SECTION 4 - BOOM 215

FIGURE 4-1. BOOM INSTALLATION 216
FIGURE 4-2. BOOM ASSEMBLY 218
FIGURE 4-3. JIB INSTALLATION 226
FIGURE 4-4. JIB ASSEMBLY 230
FIGURE 4-5. PLATFORM ROTATOR ASSEMBLY 232
FIGURE 4-6. JIB ROTATOR ASSEMBLY 234
FIGURE 4-7. PLATFORM SUPPORT INSTALLATION 236
FIGURE 4-8. POWER TRACK INSTALLATION - BOOM 238
FIGURE 4-9. VALVES INSTALLATION - BOOM (WITH LSS) 242
FIGURE 4-10. JIB VALVE ASSEMBLY 244
FIGURE 4-11. PLATFORM VALVE ASSEMBLY 246
FIGURE 4-12. BOOM SENSORS AND SWITCHES INSTALLATION 248
FIGURE 4-13. BOOM CABLES - ANSI, ANSI EXPORT, CSA AND JAPANESE SPECS 254
FIGURE 4-14. BOOM CABLES (AUSTRALIAN, CE AND CHINA SPECS) 256
FIGURE 4-15. BOOM CABLES - SKYPOWER 258
FIGURE 4-16. BOOM CABLES INSTALLATION - 4000W 50HZ GENERATOR (ANSI EXPORT, AUSTRALIAN, CE, CHINA AND JAPANESE SPECS) 260
FIGURE 4-17. JIB ENCLOSURE BOX ASSEMBLY 262

SECTION 5 - PLATFORM 265

FIGURE 5-1. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH SWING GATE 266
FIGURE 5-2. PLATFORM ASSEMBLY - SIDE GATE ENTRY 268
FIGURE 5-3. PLATFORM ASSEMBLY - SIDE GATE/DROP BAR TRI-ENTRY 270
FIGURE 5-4. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH TRI-ENTRY (1 GATE/2 DROP BARS) 272
FIGURE 5-5. PLATFORM ASSEMBLY - DROP BAR ENTRY 274
FIGURE 5-6. PLATFORM ASSEMBLY - DROP BAR ENTRY 276
FIGURE 5-7. PLATFORM ASSEMBLY - DROP BAR TRI-ENTRY 278
FIGURE 5-8. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH TRI-ENTRY (3 DROP BARS) 280
FIGURE 5-9. PLATFORM ASSEMBLY - FALL ARREST - ANSI SPEC 282
FIGURE 5-10. TRAY INSTALLATION 284
FIGURE 5-11. LCD DISPLAY INSTALLATION 286
FIGURE 5-12. PLATFORM CONTROLS INSTALLATION - WITH SKYGUARD 288
FIGURE 5-13. PLATFORM CONSOLE ASSEMBLY - WITH SKYGUARD 290
FIGURE 5-14. DECAL AND LIGHT PANEL 294
FIGURE 5-15. CONTROLLER ASSEMBLY (LIFT AND SWING) 296
FIGURE 5-16. CONTROLLER ASSEMBLY (DRIVE AND STEER) 300
FIGURE 5-17. FOOTSWITCH ASSEMBLY 302
FIGURE 5-18. SKYGUARD BAR INSTALLATION 304
FIGURE 5-19. PIPE RACK INSTALLATION (ANSI AND CSA SPECS) 306
FIGURE 5-20. PIPE RACK INSTALLATION (AUSTRALIAN SPEC) 308
FIGURE 5-21. SKYCUTTER INSTALLATION (ANSI, ANSI EXPORT, CHINA, CSA AND JAPANESE SPECS) 310
FIGURE 5-22. SKYEYE INSTALLATION 312
FIGURE 5-23. SKYWELDER/SKYCUTTER COMBO INSTALLATION (60HZ) (ANSI, ANSI EXPORT, CHINA CSA AND JAPANESE SPECS) 314
FIGURE 5-24. SKYGLAZIER INSTALLATION (ANSI AND CSA SPECS) 318
FIGURE 5-25. SKYGLAZIER INSTALLATION (BRAZIL SPECS) 320
FIGURE 5-26. SKYGLAZIER INSTALLATION (DANISH SPECS) 322

MidWestTech | JLG 1850SJ Boom Lift Parts Manual | Publication 31215068_Rev_B Order the manual at mid-west-tech.com >

FIGURE 5-27. SKYGLAZIER INSTALLATION (LATIN AMERICAN SPECS) 324
FIGURE 5-28. SKYGLAZIER INSTALLATION (ENGLISH/FRENCH SPECS) 326
FIGURE 5-29. SKYGLAZIER INSTALLATION (GERMAN SPECS) 328
FIGURE 5-30. SKYGLAZIER INSTALLATION (ITALIAN SPECS) 330
FIGURE 5-31. SKYGLAZIER INSTALLATION (PORTUGUESE SPECS) 332
FIGURE 5-32. SKYGLAZIER INSTALLATION (SPANISH SPECS) 334
FIGURE 5-33. SKYGLAZIER INSTALLATION (SWEDISH SPECS) 336
FIGURE 5-34. SKYGLAZIER INSTALLATION (UK SPECS) 338
FIGURE 5-35. SKYLINE INSTALLATION 340
FIGURE 5-36. SKYWELDER INSTALLATION (50HZ) (ANSI EXPORT, AUSTRALIAN, CE, CHINA AND JAPANESE) 342
FIGURE 5-37. SKYWELDER INSTALLATION (60HZ) (ANSI, ANSI EXPORT, CSA AND JAPANESE) 344
FIGURE 5-38. SKYWELDER PREP PACKAGE (60HZ) (ANSI, ANSI EXPORT, CHINA AND CSA SPECS) 346
FIGURE 5-39. SOFT TOUCH INSTALLATION - 8FT (2.4M) PLATFORM (OPTIONAL) 348
FIGURE 5-40. SOFT TOUCH INSTALLATION - 8FT (2.4M) FALL ARREST PLATFORM (OPTIONAL) 350
FIGURE 5-41. PLASMA CUTTER ASSEMBLY 352
FIGURE 5-42. WELDER ASSEMBLY 354
FIGURE 5-43. FALL ARREST INSTALLATION (BOLT - ON) (6FT/1.82M PLATFORM) 356
FIGURE 5-44. FALL ARREST INSTALLATION (BOLT-ON) (6FT/1.82M TRI-ENTRY PLATFORM) 358
FIGURE 5-45. FALL ARREST INSTALLATION (BOLT - ON) (8FT/2.4M PLATFORM) 360

SECTION 6 - CYLINDER 363

FIGURE 6-1. AXLE EXTEND CYLINDER ASSEMBLY 364
FIGURE 6-2. LEVEL CYLINDER ASSEMBLY - JIB SLAVE 366
FIGURE 6-3. LEVEL CYLINDER ASSEMBLY - PLATFORM SLAVE 368
FIGURE 6-4. LIFT CYLINDER ASSEMBLY - BOOM 370
FIGURE 6-5. LIFT CYLINDER ASSEMBLY - JIB 372
FIGURE 6-6. LOCK CYLINDER ASSEMBLY - JIB 374
FIGURE 6-7. STEER CYLINDER ASSEMBLY 376
FIGURE 6-8. TELESCOPE CYLINDER ASSEMBLY - BOOM 378
FIGURE 6-9. TELESCOPE CYLINDER ASSEMBLY - JIB 380

SECTION 7 - HYDRAULIC 383

FIGURE 7-1. BOOM AND JIB HYDRAULIC DIAGRAM 384
FIGURE 7-2. CHASSIS HYDRAULIC DIAGRAM 386
FIGURE 7-3. TURNTABLE HYDRAULIC DIAGRAM 390
FIGURE 7-4. HYDRAULIC DIAGRAM LIST 394

SECTION 8 - ELECTRICAL 395

FIGURE 8-1. ELECTRICAL DIAGRAM LIST 396
FIGURE 8-2. AC BOX AT PLATFORM INSTALLATION - 110V IEC 60309 YELLOW WITHOUT 4000W GENERATOR (CE SPECS) 398
FIGURE 8-3. AC BOX AT PLATFORM INSTALLATION - 110V IEC 60309 YELLOW WITH 4000W GENERATOR (CE SPECS) 400
FIGURE 8-4. AC BOX AT PLATFORM INSTALLATION - 220V IEC 60309 BLUE WITHOUT 4000W GENERATOR (CE SPECS) 402
FIGURE 8-5. AC BOX AT PLATFORM INSTALLATION - 220V IEC 60309 BLUE WITH 4000W GENERATOR (CE SPECS) 404
FIGURE 8-6. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 POST GROUND (2X4 BOX) WITHOUT 4000W GENERATOR (CE SPECS) 406
FIGURE 8-7. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 POST GROUND (2X4 BOX) WITH 4000W GENERATOR (CE SPECS) 408
FIGURE 8-8. AC BOX AT PLATFORM INSTALLATION - 220V AFSINT 107 KEYED GROUND (2X4 BOX) WITHOUT 4000W GENERATOR (CE SPECS) 410
FIGURE 8-9. AC BOX AT PLATFORM INSTALLATION - 220V AFSINT 107 KEYED GROUND (2X4 BOX) WITH 4000W GENERATOR (CE SPECS) 412
FIGURE 8-10. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 SIDE GROUND (2X4 BOX) WITHOUT 4000W GENERATOR (CE SPECS) 414
FIGURE 8-11. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 SIDE GROUND (2X4 BOX) WITH 4000W GENERATOR (CE SPECS) 416
FIGURE 8-12. AC BOX AT PLATFORM INSTALLATION - BOX WITH COVER (2X4 BOX) WITH 4000W GENERATOR (ANSI EXPORT, AUSTRALIAN, CE, CHINA AND JAPANESE SPECS) 418
FIGURE 8-13. AC BOX AT PLATFORM INSTALLATION - 240V (WITH 7500W SKYPOWER GENERATOR) (ALL SPECS EXCEPT AUSTRALIAN & CE SPECS) 420
FIGURE 8-14. BATTERY CABLE KIT - DEUTZ LRC ENGINES 422
FIGURE 8-15. BATTERY CABLE KIT - DEUTZ HRC ENGINES 424

MidWestTech | JLG 1850SJ Boom Lift Parts Manual | Publication 31215068_Rev_B Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
44	70002604	4	Orifice	
45	70002605	1	Center Section Assembly (Includes Item 58)	
46	70002168	2	Gasket, End Cap	
47	70001958	2	Plug Assembly (Includes Item 48)	
48	7021256	2	O-Ring (Part of Item 47)	
49	70001958	2	Plug Assembly (Includes Item 50)	
50	7021256	2	O-Ring (Part of Item 49)	
51	70001958	2	Plug Assembly (Includes Item 52)	
52	7021256	2	O-Ring (Part of Item 51)	
53	70001958	2	Plug Assembly (Includes Item 54)	
54	7021256	2	O-Ring (Part of Item 53)	
55	70002606	4	Capscrew	
58	70002607	2	Bearing, Journal (Part of Item 45)	
59	70002608	1	Bracket, Lifting	
60	70002609	1	Screw	
61	See Note	1	Housing (Note: Not Available for Purchase)	
62	70002175	1	Shaft	
63	70002610	1	Ball Bearing Kit	
	7007439	1	Ring, Retaining	
65	70002174	1	Shaft Seal Kit (Includes Items 66-68) (Note: This is a universal kit and will contain extra pieces that are not used on this pump assembly)	
66	70002177	1	Seal, Lip	
67	70002178	1	O-Ring	
68	70002179	1	Ring, Retaining	
69	See Note	1	Housing (Note: Not Available for Purchase)	
71	70002612	1	Shaft	
72	70002610	1	Ball Bearing Kit	
74	70002621	1	High Pressure Relief Valve Cartridge Assembly (Includes Item 75)	
75	70002622	1	Seal Kit - 70002621 Valve (Part of Item 74)	
76	7007415	1	O-Ring (Part of Items 81, 84, 87 & 90)	
77	7021293	1	Ring, Back-up (Part of Items 81, 84, 87 & 90)	
78	7022300	1	O-Ring (Part of Items 81, 84, 87 & 90)	
79	70002616	1	SCR Valve Assembly	
80	7024800	1	Spring	
81	7021265	1	Plug Assembly (Includes Qty 1 of Items 76-78)	
82	70002616	1	SCR Valve Assembly	
83	7024800	1	Spring	
84	7021265	1	Plug Assembly (Includes Qty 1 of Item 76-78)	
85	70002616	1	SCR Valve Assembly	
86	7024800	1	Spring	
87	70002617	1	Plug Assembly (Includes Qty 1 of Item 76-78)	
88	70002616	1	SCR Valve Assembly	
89	7024800	1	Spring	
90	7021265	1	Plug Assembly (Includes Qty 1 of Items 76-78)	
91	70002623	1	Overhaul Seal Kit (Includes Items 3, 5, 22, 27, 30, 37, 38, 41, 46, 48, 50, 52, 54, 66, 67, 75, 76, 77 & 78)	

MidWestTech | JLG 1850SJ Boom Lift Parts Manual | Publication 31215068_Rev_B Order the manual at mid-west-tech.com >

FIGURE 6-3. LEVEL CYLINDER ASSEMBLY - PLATFORM SLAVE

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001228057	Ref	LEVEL (PLATFORM) CYLINDER ASSEMBLY	E
		Ref	Note: Original Cylinder May Have Been Replaced with Service Replacement. Identify PN Stamped on Cylinder Before Ordering Parts.	
1	See Note	NSS	Barrel Weldment (Note: Not Available for Purchase)	
2	70006519	1	Rod Weldment	
3	70006518	1	Head	
4	See Note	NSS	Wiper, Rod (Note: Use Item 100)	
5	See Note	NSS	Seal, Rod (Note: Use Item 100)	
6	See Note	NSS	Ring, Wear (Note: Use Item 100)	
7	See Note	NSS	O-Ring (Note: Use Item 100)	
8	See Note	NSS	Ring, Back-up (Note: Use Item 100)	
9	See Note	NSS	O-Ring (Note: Use Item 100)	
10	70006517	1	Piston	
11	See Note	NSS	Ring, Lock (Note: Use Item 100)	
12	See Note	NSS	Ring, Guide (Note: Use Item 100)	
13	See Note	NSS	O-Ring (Note: Use Item 100)	
14	See Note	NSS	Ring, Back-up (Note: Use Item 100)	
15	70006516	1	Spacer	
16	0961902	1	Bushing, Tapered	
17	0630535	3	Capscrew 1/4 x 1-1/8	
21	1001117990	1	Sensor, Cylinder Length	
22	70006464	1	Setscrew M5	
23	70006463	1	Cap, Retainer	
24	3931420	8	Capscrew 1/4 x 1-1/4	
25	4640489	1	Cartridge, Counterbalance Valve	
25	See Note	NSS	Seal Kit - 4640489 Cartridge Valve (1 Per Valve) (Note: Not Available for Purchase)	
26	4641260	1	Cartridge, Counterbalance Valve	
26	2900770	1	Seal Kit - 4641260 Cartridge Valve (1 Per Valve)	
27	1001117969	2	Bushing	
28	0962006	2	Bushing	
29	2220883	2	Plug, O-Ring	
30	2220883	3	Plug, O-Ring	
31	0100011	AR	Compound, Locking	
32	0100038	AR	Primer, Locking	
100	1001139995	1	Seal Kit (Includes Items 4-9 & 11-14)	
200	1001119105	1	Sensor Magnet Kit (Includes Items 201-203)	
201	1001117994	2	Sleeve, Spacer	
202	1001118066	1	Magnet, Sensor	
203	1001118069	1	Ring, Internal Retaining	

MidWestTech | JLG 1850SJ Boom Lift Parts Manual | Publication 31215068_Rev_B Order the manual at mid-west-tech.com >

FIGURE 9-10. DECAL INSTALLATION - OPTIONS

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001248556	Ref	DECAL INSTALLATION - REFERENCE CHART	A
	1001261850	Ref	Decal Installation - Options	
108	1001231801	1	Decal - Warning Prop 65 Diesel (ANSI Specs)	
120	4420051	20 ft /6m	Tape, Warning Stripes	
145	1001159981	Ref	Kit, Decal Model Designation	
145	1001159980	2	Decal, 1850SJ	
146	1001160443	Ref	Kit, Decal Max Tire Load	
146	1001159855	4	Decal, Max Tire Load	
151	1001159983	1	Decal, Lift Diagram	
173	1001125209	1	Decal, Daily Check List (Danish Language)	
173	1001125203	1	Decal, Daily Check List (Dutch Language)	
173	1001125198	1	Decal, Daily Check List (English and Chinese Languages)	
173	1001125196	1	Decal, Daily Check List (English Language)	
173	1001125201	1	Decal, Daily Check List (English and French Languages)	
173	1001125202	1	Decal, Daily Check List (English and Japanese Languages)	
173	1001125197	1	Decal, Daily Check List (English and Korean Languages)	
173	1001125199	1	Decal, Daily Check List (English and Spanish Languages)	
173	1001125207	1	Decal, Daily Check List (Finnish Languages)	
173	1001125204	1	Decal, Daily Check List (French Languages)	
173	1001125211	1	Decal, Daily Check List (German Languages)	
173	1001125205	1	Decal, Daily Check List (Italian Languages)	
173	1001125210	1	Decal, Daily Check List (Norwegian Languages)	
173	1001125212	1	Decal, Daily Check List (Polish Language)	
173	1001125200	1	Decal, Daily Check List (Portuguese Language)	
173	1001125206	1	Decal, Daily Check List (Spanish Languages)	
173	1001125208	1	Decal, Daily Check List (Swedish Languages)	
205	See Note	NSS	Nameplate, Serial Number (Note: Not Available for Purchase)	
210	1702868	2	Decal - No Hands (English Language)	
210	1001116846	2	Decal - No Hands (English and Chinese Languages)	
210	1704000	2	Decal - No Hands (English and French Languages)	
210	1705969	2	Decal - No Hands (English and Korean Languages)	
210	1705967	2	Decal - No Hands (English and Portuguese Languages)	
210	1704001	2	Decal - No Hands (English and Spanish Languages)	
215	1001116025	Ref	Kit, JLG Decal (Includes items 215A - 215E)	
215A	1702774	1	Decal, JLG Lift	
215B	1702773	3	Decal, JLG	
215C	1704885	1	Decal, WWW.JLG.COM	
215D	1705864	2	Decal, JLG	
215E	1705865	2	Decal, Ultra Boom	
238	1001125387	1	Decal, Ultra Low Sulfur Fuel (ANSI and CSA Specs)	
238	1001139654	1	Decal, Ultra Low Sulfur Fuel (ANSI Export, Australian, CE, China and Japanese Specs)	
245	1001160444	Ref	Decal - ClearSky	
245A	1001116208	2	Decal - ClearSky	
245B	1001120989	1	Decal - Radio Frequency	
253	1001143852	1	Decal, LRC EPA (ANSI Export, China and Australian Specs Only)	
262A	1001141300	1	Decal - SkyGuard Override	
262B	1001141302	1	Decal - SkyGuard Soft Touch Override	
263	1001197408	1	Decal - MSSO	

MidWestTech | JLG 1850SJ Boom Lift Parts Manual | Publication 31215068_Rev_B Order the manual at mid-west-tech.com >