Illustrated Parts Manual

Models

R1532i
R1932
R1932i

PVC
1910
2004

P/N
31215089

March 15, 2020 - Rev B

ANSI

CE

AS/NZS

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 11

FIGURE 1-1. STEER INSTALLATION 12
FIGURE 1-2. DRIVE/BRAKE INSTALLATION 14
FIGURE 1-3. DRIVE MOTOR ASSEMBLY 16
FIGURE 1-4. TIRE AND WHEEL INSTALLATION 18
FIGURE 1-5. POTHOLE PROTECTION SYSTEM INSTALLATION 20
FIGURE 1-6. TILT SENSOR INSTALLATION 22
FIGURE 1-7. BATTERY CHARGER INSTALLATION - DELTA-Q (WITHOUT COMMUNICATION PORT) (LOCALLY SUPPLIED PLUG) 24
FIGURE 1-8. BATTERY CHARGER INSTALLATION - DELTA-Q (WITH COMMUNICATION PORT) (LOCALLY SUPPLIED PLUG) 26
FIGURE 1-9. BATTERY CHARGER INSTALLATION - DELTA-Q (WITHOUT COMMUNICATION PORT) (110V PLUG) 28
FIGURE 1-10. BATTERY CHARGER INSTALLATION - DELTA-Q (WITH COMMUNICATION PORT) (110V PLUG) 30
FIGURE 1-11. BATTERY CHARGER INSTALLATION - DELTA-Q (WITHOUT COMMUNICATION PORT) (AUSTRALIAN PLUG) (R1932) 32
FIGURE 1-12. BATTERY CHARGER INSTALLATION - DELTA-Q (WITH COMMUNICATION PORT) (AUSTRALIAN PLUG) (R1932) 34
FIGURE 1-13. BATTERY CHARGER INSTALLATION - DELTA-Q (WITHOUT COMMUNICATION PORT) (KOREAN PLUG) 36
FIGURE 1-14. BATTERY CHARGER INSTALLATION - DELTA-Q (WITH COMMUNICATION PORT) (KOREAN PLUG) 38
FIGURE 1-15. BATTERY CHARGER INSTALLATION - GREEN POWER (CHINA PLUG) (CHINA BUILT MACHINES) 40
FIGURE 1-16. BATTERY CHARGER INSTALLATION - EAGLE PERFORMANCE (110V PLUG) (MEXICO BUILT MACHINES) 42
FIGURE 1-17. BATTERY CHARGER INSTALLATION - GREEN POWER (LOCALLY SUPPLIED PLUG) (CHINA BUILT MACHINES) 44
FIGURE 1-18. STROBE LIGHT INSTALLATION - SINGLE SANMAK BRAND (AMBER) (WITH GUARD) 46
FIGURE 1-19. STROBE LIGHT INSTALLATION - DAUL SANMAK BRAND (AMBER) (WITH GUARD) 48
FIGURE 1-20. ALARM INSTALLATION (AMBIENT/WHITE NOISE) (OPTIONAL) 50
FIGURE 1-21. LADDER INSTALLATION 52
FIGURE 1-22. FRAME COVERS INSTALLATION - FRONT AND REAR (R1532I/R1932I) 54
FIGURE 1-23. FRAME COVERS INSTALLATION - FRONT (R1932) 56

SECTION 2 - GROUND CONTROLS 59

FIGURE 2-1. HYDRAULIC COMPONENTS INSTALLATION 60
FIGURE 2-2. VALVE ASSEMBLY 62
FIGURE 2-3. ELECTRICAL COMPONENTS INSTALLATION 64
FIGURE 2-4. ELECTRICAL COMPONENTS INSTALLATION - #1 (EUROPEAN BUILT MACHINES) 66
FIGURE 2-5. ELECTRICAL COMPONENTS INSTALLATION - #2 (EUROPEAN BUILT MACHINES) 68
FIGURE 2-6. MDI INSTALLATION 70
FIGURE 2-7. BATTERIES INSTALLATION - STANDARD BATTERIES WITH DISCONNECT 72
FIGURE 2-8. BATTERIES INSTALLATION - AGM BATTERIES WITH DISCONNECT (MEXICO BUILT MACHINES) 74
FIGURE 2-9. BATTERIES INSTALLATION - AGM EVCG BATTERIES WITH DISCONNECT (CHINA BUILT MACHINES) 76
FIGURE 2-10. BATTERIES INSTALLATION - TROJAN BATTERIES WITH DISCONNECT (CHINA BUILT MACHINES) (PVC 1910) 78
FIGURE 2-11. BATTERIES INSTALLATION - TROJAN BATTERIES WITH DISCONNECT (CHINA BUILT MACHINES) (PVC 2004) 80
FIGURE 2-12. INVERTER INSTALLATION (OPTIONAL) (MEXICO BUILT MACHINES) 82
FIGURE 2-13. DOORS INSTALLATION 84

SECTION 3 - SCISSORS ARMS 87

FIGURE 3-1. SCISSORS ARMS INSTALLATION – R1532I (PVC 1910) 88
FIGURE 3-2. SCISSORS ARMS INSTALLATION – R1532I (PVC 2004) 92
FIGURE 3-3. SCISSORS ARMS INSTALLATION – R1932/R1932I (PVC 1910) 96
FIGURE 3-4. SCISSORS ARMS INSTALLATION – R1932/R1932I (PVC 2004) 100
FIGURE 3-5. SCISSORS ARMS KIT - R1532I 104
FIGURE 3-6. SCISSORS ARMS KIT - R1932/R1932I 106
FIGURE 3-7. ARM GUARD INSTALLATION 108

SECTION 4 - PLATFORM 111

FIGURE 4-1. PLATFORM INSTALLATION – R1532I 112
FIGURE 4-2. PLATFORM INSTALLATION - R1932/R1932I 114
FIGURE 4-3. PLATFORM EXTENSION INSTALLATION 116
FIGURE 4-4. RAILS INSTALLATION - FIXED RAILS/GATE ENTRY (INSIDE TUBE SLIDER) 118
FIGURE 4-5. RAIL KIT - FIXED RAILS (INSIDE TUBE SLIDER) 120

MidWestTech | JLG R1532i, R1932, R1932i Scissor Lift Parts Manual | Publication 31215089 **Order the manual at mid-west-tech.com >**

TABLE OF CONTENTS

FIGURE 4-6. RAILS INSTALLATION - FOLD-DOWN RAILS/GATE ENTRY (INSIDE TUBE SLIDER) 122
FIGURE 4-7. RAIL KIT - FOLD-DOWN RAILS (INSIDE TUBE SLIDER) 124
FIGURE 4-8. RAILS INSTALLATION - FOLD-DOWN RAILS/GATE ENTRY (QUIK FOLD) (INSIDE TUBE SLIDER) 126
FIGURE 4-9. RAILS INSTALLATION - FOLD-DOWN RAILS/GATE ENTRY (OUTSIDE TUBE SLIDER) 128
FIGURE 4-10. RAILS INSTALLATION – FOLD-DOWN RAILS/GATE ENTRY (NARROW ACCESS) 130
FIGURE 4-11. HANDLE EXTENSION INSTALLATION (OPTIONAL) 134
FIGURE 4-12. GATE LATCH INSTALLATION - OPTIONAL 136
FIGURE 4-13. PLATFORM CONTROL BOX INSTALLATION (R1532I/R1932I) 138
FIGURE 4-14. PLATFORM CONTROL BOX INSTALLATION (R1932) 140
FIGURE 4-15. DRIVE/STEER CONTROLLER ASSEMBLY 142
FIGURE 4-16. OVERHEAD PROTECTION INSTALLATION (KOREAN SPECS) 144
FIGURE 4-17. PANEL CARRIER INSTALLATION (R1932) 146
FIGURE 4-18. PIPE RACK INSTALLATION (R1932) 148

SECTION 5 - CYLINDER 151

FIGURE 5-1. LIFT CYLINDER ASSEMBLY 152
FIGURE 5-2. STEER CYLINDER ASSEMBLY 154

SECTION 6 - HYDRAULIC 157

FIGURE 6-1. HYDRAULIC DIAGRAM 158

SECTION 7 - ELECTRICAL 161

FIGURE 7-1. AC BOX AT PLATFORM INSTALLATION - 110V GFI (ANSI, ANSI EXPORT, CHINA, CSA, JAPANESE AND KOREA SPECS) 162
FIGURE 7-2. AC BOX AT PLATFORM INSTALLATION - 110V IEC YELLOW (CE SPECS) 164
FIGURE 7-3. AC BOX AT PLATFORM INSTALLATION - 220V IEC BLUE (CE SPECS) 166
FIGURE 7-4. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 POST GROUND (CE SPECS) 168
FIGURE 7-5. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 SIDE GROUND (CE SPECS) 170
FIGURE 7-6. AC BOX AT PLATFORM INSTALLATION - 220V AFSINT 107 (CE SPECS) 172
FIGURE 7-7. AC BOX AT PLATFORM INSTALLATION - 220V CHINA PLUG (CHINA SPECS) 174
FIGURE 7-8. AC BOX AT PLATFORM INSTALLATION - 220V LOCALLY SUPPLIED COMPONENTS (ALL SPECS) 176
FIGURE 7-9. BREAKER BOX KIT WITH 1 DOUBLE BREAKER 178
FIGURE 7-10. BREAKER BOX KIT WITH 3 BREAKERS 180
FIGURE 7-11. CAN SPLICE HARNESS 182
FIGURE 7-12. CHARGER HARNESS 184
FIGURE 7-13. CHASSIS HARNESS 186
FIGURE 7-14. GROUND TO PLATFORM CABLE INSTALLATION - R1532I WITHOUT PLATFORM COIL CABLE 190
FIGURE 7-15. GROUND TO PLATFORM CABLE INSTALLATION - R1532I WITH PLATFORM COIL CABLE 192
FIGURE 7-16. GROUND TO PLATFORM CABLE INSTALLATION - R1532I WITHOUT PLATFORM COIL CABLE AND WITH FOOTSWITCH 194
FIGURE 7-17. GROUND TO PLATFORM CABLE INSTALLATION - R1532I WITH PLATFORM COIL CABLE AND FOOTSWITCH 196
FIGURE 7-18. GROUND TO PLATFORM CABLE INSTALLATION – R1932I/R1932 WITHOUT PLATFORM COIL CABLE (ALL SPECS EXCEPT AUSTRALIAN AND KOREA SPECS) 198
FIGURE 7-19. GROUND TO PLATFORM CABLE INSTALLATION - R1932 WITHOUT PLATFORM COIL CABLE (AUSTRALIAN SPECS) 200
FIGURE 7-20. GROUND TO PLATFORM CABLE INSTALLATION - R1932I/R1932 WITH PLATFORM COIL CABLE (ALL SPECS EXCEPT AUSTRALIAN SPECS) 202
FIGURE 7-21. GROUND TO PLATFORM CABLE INSTALLATION - R1932 WITH PLATFORM COIL CABLE (AUSTRALIAN SPECS) 204
FIGURE 7-22. GROUND TO PLATFORM CABLE INSTALLATION - R1932I/R1932 WITHOUT PLATFORM COIL CABLE AND WITH FOOTSWITCH 206
FIGURE 7-23. GROUND TO PLATFORM CABLE INSTALLATION - R1932I/R1932 WITH PLATFORM COIL CABLE AND FOOTSWITCH 208
FIGURE 7-24. GROUND TO PLATFORM CABLE INSTALLATION - R1932 (EUROPEAN BUILT MACHINES) 210
FIGURE 7-25. GROUND TO PLATFORM CABLE INSTALLATION - R1932I/R1932 WITH PLATFORM STRAIGHT CABLE ONLY (EUROPEAN BUILT MACHINES) 212
FIGURE 7-26. GROUND TO PLATFORM CABLE INSTALLATION - R1932I/R1932 WITH PLATFORM COIL CABLE ONLY (EUROPEAN BUILT MACHINES) 214
FIGURE 7-27. LIFT DOWN HARNESS - WITH LSS 216
FIGURE 7-28. PLATFORM BOX HARNESS 218
FIGURE 7-29. RECEPTACLE BOX KIT - 110V GFI 220
FIGURE 7-30. RECEPTACLE BOX KIT - 110V IEC YELLOW (CE SPEC) 222
FIGURE 7-31. RECEPTACLE BOX KIT - 220V IEC BLUE (CE SPEC) 224

MidWestTech | JLG R1532i, R1932, R1932i Scissor Lift Parts Manual | Publication 31215089 Order the manual at mid-west-tech.com >

FIGURE 7-32. RECEPTACLE BOX KIT - 220V CEE7 POST GROUND (CE SPEC) 226
FIGURE 7-33. RECEPTACLE BOX KIT - 220V CEE7 SIDE GROUND (CE SPEC) 228
FIGURE 7-34. RECEPTACLE BOX KIT - 220V AFSINT 107 (CE SPEC) 230

SECTION 8 - DECALS 233

FIGURE 8-1. DECAL INSTALLATION (ANSI SPEC) 234
FIGURE 8-2. DECAL INSTALLATION (AUSTRALIAN SPECS) 236
FIGURE 8-3. DECAL INSTALLATION (BRAZIL SPECS) 238
FIGURE 8-4. DECAL INSTALLATION (CE SPECS) 240
FIGURE 8-5. DECAL INSTALLATION (CHINA SPECS) 242
FIGURE 8-6. DECAL INSTALLATION (CSA SPECS) 244
FIGURE 8-7. DECAL INSTALLATION (KOREAN SPECS) 246
FIGURE 8-8. DECAL INSTALLATION (LATIN AMERICAN SPECS) 248
FIGURE 8-9. DECAL INSTALLATION - OPTIONS 250

SECTION 9 - RECOMMENDED SERVICE PARTS STOCK 253

FIGURE 9-1. RECOMMENDED SERVICE PARTS STOCK 254

SECTION 10 - SPECIAL OPTIONS 255

FIGURE 10-1. SPECIAL OPTIONS 256

PART NUMBER INDEX 259

MidWestTech | JLG R1532i, R1932, R1932i Scissor Lift Parts Manual | Publication 31215089 Order the manual at mid-west-tech.com >

FIGURE 5-1. LIFT CYLINDER ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001198935	Ref	LIFT CYLINDER ASSEMBLY	C
1	70005790	1	Barrel	
2	70005791	1	Rod	
3	70005792	1	Head	
4	See Note	1	Wiper (Note: Use Item 23)	
5	70002410	1	Ring, Retaining	
6	See Note	1	Seal, Rod (Note: Use Item 23)	
7	See Note	1	Ring, Back-up (Note: Use Item 23)	
8	70005793	1	Spacer	
9	See Note	1	O-Ring (Note: Use Item 23)	
10	See Note	1	Ring, Back-up (Note: Use Item 23)	
11	See Note	1	O-Ring (Note: Use Item 23)	
12	70005794	1	Piston	
13	See Note	1	Seal, Piston (Note: Use Item 23)	
14	See Note	1	Ring, Wear (Note: Use Item 23)	
15	See Note	1	O-Ring (Note: Use Item 23)	
16	70005796	1	Nut	
17	0962292	4	Bearing	
18	70004233	1	Valve, Manual Descent	
19	70004232	1	Valve, Check	
20	70004231	1	Orifice	
21	70023370	4	Plug	
22	70005795	2	Fitting, Straight JIC	
23	70005797	1	Seal Kit - Cylinder (Includes Items 4, 6, 7, 9-11 & 13-15)	

MidWestTech | JLG R1532i, R1932, R1932i Scissor Lift Parts Manual | Publication 31215089 Order the manual at mid-west-tech.com >

FIGURE 7-17. GROUND TO PLATFORM CABLE INSTALLATION - R1532I WITH PLATFORM COIL CABLE AND FOOTSWITCH

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001225493	Ref	GROUND TO PLATFORM CABLE INSTALLATION	A
1	4240017	AR	Tie-Strap (Not Shown)	
2	1001223262	1	Platform Harness	
2	4460899	1	Receptacle, Female - 6 Position (To Item 3)	
2	4460464	4	Pin, Male	
2	4460943	2	Pin, Male	
2	4460754	1	Connector - 14 Position (To Console Box)	
2	4460465	8	Socket, Female	
2	4460944	2	Socket, Female	
2	4460466	4	Plug, Terminal	
2	4460891	1	Plug, Male - 2 Position (To Footswitch)	
2	4460465	2	Socket, Female	
2	4460897	1	Receptacle, Female - 2 Position (Footswitch Jumper)	
2	4460464	2	Pin, Male	
2	4460539	1	Plug, Male - 3 Position (To Overhead Switches)	
2	4460465	2	Socket, Female	
2	4460466	1	Plug, Terminal	
3	1001225377	1	Cable Assembly - Ground to Platform	
3	4460894	1	Plug, Male - 6 Position (To Platform Harness Item 2)	
3	4460465	4	Socket, Female	
3	4460944	2	Socket, Female	
3	4460899	1	Receptacle, Female - 6 Position (To Chassis Harness)	
3	4460464	4	Pin, Male	
3	4460943	2	Pin, Male	

MidWestTech | JLG R1532i, R1932, R1932i Scissor Lift Parts Manual | Publication 31215089 Order the manual at mid-west-tech.com >

FIGURE 7-23. GROUND TO PLATFORM CABLE INSTALLATION - R1932I/R1932 WITH PLATFORM COIL CABLE AND FOOTSWITCH

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001203631	Ref	GROUND TO PLATFORM CABLE INSTALLATION	F
		Ref	Note: Only Available on Japanese Specs.	
1	4240017	AR	Tie-Strap (Not Shown)	
3	1001200811	1	Cable Assembly - Ground to Platform	
3	4460894	1	Plug, Male - 6 Position (To Platform Harness Item 4)	
3	4460465	4	Socket, Female	
3	4460944	2	Socket, Female	
3	4460899	1	Receptacle, Female - 6 Position (To Chassis Harness)	
3	4460464	4	Pin, Male	
3	4460943	2	Pin, Male	
4	1001223262	1	Platform Harness	
4	4460899	1	Receptacle, Female - 6 Position (To Item 3)	
4	4460464	4	Pin, Male	
4	4460943	2	Pin, Male	
4	4460754	1	Connector - 14 Position (To Console Box)	
4	4460465	8	Socket, Female	
4	4460944	2	Socket, Female	
4	4460466	4	Plug, Terminal	
4	4460891	1	Plug, Male - 2 Position (To Footswitch)	
4	4460465	2	Socket, Female	
4	4460897	1	Receptacle, Female - 2 Position (Footswitch Jumper)	
4	4460464	2	Pin, Male	
4	4460539	1	Plug, Male - 3 Position (To Overhead Switches)	
4	4460465	2	Socket, Female	
4	4460466	1	Plug, Terminal	

MidWestTech | JLG R1532i, R1932, R1932i Scissor Lift Parts Manual | Publication 31215089 Order the manual at mid-west-tech.com >