Illustrated Parts Manual

Model

260MRT

PVC
1910
2004

P/N
31215867

March 15, 2020 - Rev B

ANSI

AS/NZS

An Oshkosh Corporation Company

MidWestTech | JLG 260MRT Scissor Lift Parts Manual | Publication 31215867

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 11

FIGURE 1-1. STEERING AND DRIVE INSTALLATION - 4WD (2WS) 12
FIGURE 1-2. MOTOR/BRAKE/HUB ASSEMBLY (REAR) 14
FIGURE 1-3. DRIVE MOTOR ASSEMBLY (FRONT) 16
FIGURE 1-4. TIRE AND WHEEL INSTALLATION - 26 X 12 FOAM FILLED 18
FIGURE 1-5. TIRE AND WHEEL INSTALLATION - 26 X 12 FOAM FILLED NON-MARKING 20
FIGURE 1-6. STATIC STRAP INSTALLATION 22
FIGURE 1-7. ELEVATION SWITCH INSTALLATION (STANDARD) 24
FIGURE 1-8. ELEVATION SWITCH INSTALLATION (AUTO LEVEL LEVELING JACKS) (ALL MACHINES EXCEPT MACHINES WITH LEVEL AT 6 DEGREE SLOPE) 26
FIGURE 1-9. ELEVATION SWITCH INSTALLATION (AUTO LEVEL LEVELING JACKS) (MACHINES WITH LEVEL AT 6 DEGREE SLOPE) (AUSTRALIAN SPECS) 28
FIGURE 1-10. HORN INSTALLATION 30
FIGURE 1-11. MOTION ALARM INSTALLATION 32
FIGURE 1-12. LADDER INSTALLATION (ALL MACHINES EXCEPT MACHINES WITH LEVEL AT 6 DEGREE SLOPE) 34
FIGURE 1-13. LADDER INSTALLATION (MACHINES WITH LEVEL AT 6 DEGREE SLOPE) (AUSTRALIAN SPECS) 36
FIGURE 1-14. LP TANK BRACKETS INSTALLATION 38
FIGURE 1-15. LEVELING JACKS AUTO LEVEL INSTALLATION (ALL MACHINES EXCEPT MACHINES WITH LEVEL AT 6 DEGREE SLOPE) 40
FIGURE 1-16. LEVELING JACKS AUTO LEVEL INSTALLATION (MACHINES WITH LEVEL AT 6 DEGREE SLOPE) (AUSTRALIAN SPECS) 42
FIGURE 1-17. LEVELING JACK ASSEMBLY (ALL MACHINES EXCEPT MACHINES WITH LEVEL AT 6 DEGREE SLOPE) 44
FIGURE 1-18. LEVELING JACK ASSEMBLY (MACHINES WITH LEVEL AT 6 DEGREE SLOPE) (AUSTRALIAN SPECS) 46
FIGURE 1-19. LEVELING JACK CONTROL VALVE ASSEMBLY 48

SECTION 2 - GROUND CONTROLS 51

FIGURE 2-1. CONTROL VALVES AND TANK INSTALLATION (DIESEL MACHINES) 52
FIGURE 2-2. CONTROL VALVES AND TANK INSTALLATION (DUAL FUEL MACHINES) 54
FIGURE 2-3. MAIN VALVE ASSEMBLY 56
FIGURE 2-4. FLOW DIVIDER ASSEMBLY 58
FIGURE 2-5. HYDRAULIC OIL TANK ASSEMBLY 60
FIGURE 2-6. FUEL TANK ASSEMBLY 62
FIGURE 2-7. GROUND CONTROLS INSTALLATION (DIESEL MACHINES WITHOUT LEVELING JACKS) (ALL SPECS EXCEPT CE SPECS) 64
FIGURE 2-8. GROUND CONTROLS INSTALLATION (DIESEL MACHINES WITHOUT LEVELING JACKS) (CE SPECS) 66
FIGURE 2-9. GROUND CONTROLS INSTALLATION (DUAL FUEL MACHINES WITHOUT LEVELING JACKS) (ALL SPECS EXCEPT AUSTRALIAN AND CE SPECS) 68
FIGURE 2-10. GROUND CONTROLS INSTALLATION (DIESEL MACHINES WITH LEVELING JACKS) (ALL SPECS EXCEPT CE SPECS) 70
FIGURE 2-11. GROUND CONTROLS INSTALLATION (DIESEL MACHINES WITH LEVELING JACKS) (CE SPECS) 72
FIGURE 2-12. GROUND CONTROLS INSTALLATION (DUAL FUEL MACHINES WITH LEVELING JACKS) (ALL SPECS EXCEPTAUSTRALIAN AND CE SPECS) 74
FIGURE 2-13. GROUND CONTROL BOX ASSEMBLY (DIESEL MACHINES) (ALL SPECS EXCEPT CE SPECS) 76
FIGURE 2-14. GROUND CONTROL BOX ASSEMBLY (DIESEL MACHINES) (CE SPECS) 78
FIGURE 2-15. GROUND CONTROL BOX ASSEMBLY (DUAL FUEL MACHINES) (ALL SPECS EXCEPT AUSTRALIAN AND CE SPECS) 80
FIGURE 2-16. BEACON LIGHT INSTALLATION 82
FIGURE 2-17. HOODS INSTALLATION 84
FIGURE 2-18. HOOD VENT INSTALLATION 86

SECTION 3 - ENGINE 89

FIGURE 3-1. KUBOTA ENGINE INSTALLATION (DUAL FUEL) 90
FIGURE 3-2. KUBOTA ENGINE POWERPLANT ASSEMBLY (DUAL FUEL) 92
FIGURE 3-3. KUBOTA ENGINE ASSEMBLY (DUAL FUEL) 94
FIGURE 3-4. ENGINE COMPONENTS - KUBOTA DUAL FUEL 96
FIGURE 3-5. KUBOTA ENGINE INSTALLATION (DIESEL) 98
FIGURE 3-6. KUBOTA ENGINE POWERPLANT ASSEMBLY (DIESEL) 100
FIGURE 3-7. KUBOTA ENGINE ASSEMBLY (DIESEL) 102
FIGURE 3-8. KUBOTA ENGINE THROTTLE INSTALLATION (DIESEL) 104
FIGURE 3-9. ENGINE COMPONENTS - KUBOTA DIESEL 106
FIGURE 3-10. VARIABLE DISPLACEMENT PUMP ASSEMBLY 110
FIGURE 3-11. GEAR PUMP ASSEMBLY 114
FIGURE 3-12. GENERATOR INSTALLATION 116

MidWestTech | JLG 260MRT Scissor Lift Parts Manual | Publication 31215867 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 4 - SCISSORS ARMS 119

FIGURE 4-1. SCISSOR ARMS INSTALLATION (ALL MACHINES EXCEPT MACHINES WITH LEVEL AT 6 DEGREE SLOPE) 120
FIGURE 4-2. SCISSOR ARMS INSTALLATION (MACHINES WITH LEVEL AT 6 DEGREE SLOPE) (AUSTRALIAN SPECS) 124
FIGURE 4-3. ARM GUARDS INSTALLATION 128
FIGURE 4-4. ARM GUARDS ATTACH 130

SECTION 5 - PLATFORM 133

FIGURE 5-1. PLATFORM AND EXTENSION INSTALLATION - WITHOUT D-RINGS 134
FIGURE 5-2. PLATFORM AND EXTENSION INSTALLATION - WITH D-RINGS 138
FIGURE 5-3. HANDRAIL INSTALLATION (SWING GATE) 142
FIGURE 5-4. CONSOLE BOX ASSEMBLY - DIESEL MACHINES (WITHOUT AUTO LEVELING JACKS) 144
FIGURE 5-5. CONSOLE BOX ASSEMBLY - DIESEL MACHINES (WITH AUTO LEVELING JACKS) 146
FIGURE 5-6. CONSOLE BOX ASSEMBLY – DIESEL MACHINES (WITHOUT AUTO LEVELING JACKS AND WITH GENERATOR) 148
FIGURE 5-7. CONSOLE BOX ASSEMBLY – DIESEL MACHINES (WITH AUTO LEVELING JACKS AND GENERATOR) 150
FIGURE 5-8. CONSOLE BOX ASSEMBLY - DUAL FUEL MACHINES (WITHOUT AUTO LEVELING JACKS) 152
FIGURE 5-9. CONSOLE BOX ASSEMBLY - DUAL FUEL MACHINES (WITH AUTO LEVELING JACKS) 154
FIGURE 5-10. CONSOLE BOX ASSEMBLY - DUAL FUEL MACHINES (WITHOUT AUTO LEVELING JACKS AND WITH GENERATOR) 156
FIGURE 5-11. CONSOLE BOX ASSEMBLY - DUAL FUEL MACHINES (WITH AUTO LEVELING JACKS AND GENERATOR) 158
FIGURE 5-12. DRIVE/STEER CONTROLLER ASSEMBLY 160
FIGURE 5-13. PLATFORM RAIL PADDING/DECK BUMPERS INSTALLATION 162

SECTION 6 - CYLINDER 165

FIGURE 6-1. LEVELING JACKS CYLINDER ASSEMBLY (ALL MACHINES EXCEPT MACHINES WITH LEVEL AT 6 DEGREE SLOPE) 166
FIGURE 6-2. LEVELING JACK CYLINDER ASSEMBLY (MACHINES WITH LEVEL AT 6 DEGREE SLOPE) (AUSTRALIAN SPECS) 168
FIGURE 6-3. LIFT CYLINDER COMPONENTS ASSEMBLY 170
FIGURE 6-4. STEER CYLINDER ASSEMBLY 172

SECTION 7 - HYDRAULIC 175

FIGURE 7-1. DRIVE HYDRAULIC DIAGRAM (STANDARD) 176
FIGURE 7-2. DRIVE HYDRAULIC DIAGRAM (AUTO LEVEL LEVELING JACKS) 180

SECTION 8 - ELECTRICAL 183

FIGURE 8-1. AC BOX AT PLATFORM INSTALLATION - 110V (ALL SPECS EXCEPT AUSTRALIAN AND CE SPECS) 184
FIGURE 8-2. AC BOX AT PLATFORM INSTALLATION - 110V GFI (ALL SPECS EXCEPT AUSTRALIAN AND CE SPECS) 186
FIGURE 8-3. AC BOX AT PLATFORM INSTALLATION - 110V IEC YELLOW (CE SPECS) 188
FIGURE 8-4. AC BOX AT PLATFORM INSTALLATION - 220V 190
FIGURE 8-5. AC BOX AT PLATFORM INSTALLATION - 220V IEC BLUE (CE SPECS) 192
FIGURE 8-6. AC BOX AT PLATFORM INSTALLATION - 220V AFSINT 107 KEYED GROUND 2 X 4 BOX (CE SPECS) 194
FIGURE 8-7. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 POST GROUND 2X4 BOX (CE SPECS) 196
FIGURE 8-8. AC BOX AT PLATFORM INSTALLATION - 220V CEE7 SIDE GROUND 2X4 BOX (CE SPECS) 198
FIGURE 8-9. AC CORD CABLE 200
FIGURE 8-10. ADAPTER - AUTO LEVEL HARNESS 202
FIGURE 8-11. BEACON LIGHT HARNESS 204
FIGURE 8-12. BREAKER BOX KIT - 110/220V 16AMP BREAKER 206
FIGURE 8-13. BREAKER BOX KIT WITH THREE BREAKERS 208
FIGURE 8-14. ELEVATION SWITCH HARNESS 210
FIGURE 8-15. ENGINE AND VALVE HARNESS 212
FIGURE 8-16. GENERATOR HARNESS 214
FIGURE 8-17. GROUND CONTROL BOX HARNESS (DUAL FUEL MACHINES) 216
FIGURE 8-18. GROUND CONTROL BOX HARNESS (DUAL FUEL MACHINES) 218
FIGURE 8-19. AUTO LEVELING JACK HARNESS 220
FIGURE 8-20. LOAD SENSE HARNESS 222
FIGURE 8-21. MODULE TO ANALYZER HARNESS 224
FIGURE 8-22. PLATFORM CABLE INSTALLATION 226
FIGURE 8-23. PLATFORM CABLE ASSEMBLY 228
FIGURE 8-24. PLATFORM CONTROL BOX HARNESS - DIESEL MACHINES (WITHOUT AUTO LEVELING JACKS) 230

MidWestTech | JLG 260MRT Scissor Lift Parts Manual | Publication 31215867 Order the manual at mid-west-tech.com >

FIGURE 8-25. PLATFORM CONTROL BOX HARNESS - DIESEL MACHINES (WITH AUTO LEVELING JACKS) 232
FIGURE 8-26. PLATFORM CONTROL BOX HARNESS - DIESEL MACHINES (WITHOUT AUTO LEVELING JACKS AND WITH GENERATOR) 234
FIGURE 8-27. PLATFORM CONTROL BOX HARNESS - DIESEL MACHINES (WITH AUTO LEVELING JACKS AND GENERATOR) 236
FIGURE 8-28. PLATFORM CONTROL BOX HARNESS – DUAL FUEL MACHINES (WITHOUT AUTO LEVELING JACKS) 238
FIGURE 8-29. PLATFORM CONTROL BOX HARNESS - DUAL FUEL MACHINES (WITH AUTO LEVELING JACKS) 240
FIGURE 8-30. PLATFORM CONTROL BOX HARNESS - DUAL FUEL MACHINES (WITHOUT AUTO LEVELING JACKS AND WITH GENERATOR) 242
FIGURE 8-31. PLATFORM CONTROL BOX HARNESS - DUAL FUEL MACHINES (WITH AUTO LEVELING JACKS AND GENERATOR) 244
FIGURE 8-32. RECEPTACLE BOX KIT - 110V IEC YELLOW (CE SPEC) 246
FIGURE 8-33. RECEPTACLE BOX KIT - 220V IEC BLUE (CE SPEC) 248
FIGURE 8-34. RECEPTACLE BOX KIT - 220V CEE7 POST GROUND 2IN X 4IN (CE SPEC) 250
FIGURE 8-35. RECEPTACLE BOX KIT - 220V CEE7 SIDE GROUND 2IN X 4IN (CE SPEC) 252
FIGURE 8-36. RECEPTACLE BOX KIT - 220V AFSINT 107 (CE SPEC) 254

SECTION 9 - DECALS 257

FIGURE 9-1. DECAL INSTALLATION - ANSI SPEC 258
FIGURE 9-2. DECAL INSTALLATION - BRAZIL SPECS (SPANISH/PORTUGUESE) 260
FIGURE 9-3. DECAL INSTALLATION - CE SPEC 262
FIGURE 9-4. DECAL INSTALLATION - CSA (ENGLISH/FRENCH) 264
FIGURE 9-5. DECAL INSTALLATION - LATIN AMERICAN SPECS (ENGLISH/SPANISH) 266
FIGURE 9-6. DECAL INSTALLATION - OPTIONS 268

SECTION 10 - RECOMMENDED SERVICE PARTS STOCK 271

FIGURE 10-1. MODEL 260MRT STANDARD PARTS 272
FIGURE 10-2. MODEL 260MRT VARIABLE PARTS 274

SECTION 11 - SPECIAL OPTIONS 275

FIGURE 11-1. SPECIAL OPTIONS 276

PART NUMBER INDEX 279

MidWestTech | JLG 260MRT Scissor Lift Parts Manual | Publication 31215867 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
44	4711500	16	Washer 5/16	
45	4711600	24	Washer 3/8	
46	4740333	4	Washer	
47	4740438	16	Washer	
48	4846024	1	Prop, Safety	
49	2902259	1	Kit, Arm Included Item 1 - 8) (Not Shown)	
50	3020022	AR	Grease, White Lithium (Not Shown)	
51	4420037	AR	Tape, Insulation (Not Shown)	
52	4922428	1	Lift Down Harness (Not Shown)	
52	4460499	1	Connector, DIN	
52	4460465	2	Socket, Female	
53	1001118681	1	Arm Sub-Assembly Kit (Not Shown - Includes Items 9-18, 20-27, 29, 30, 32-49, 51, 52 & 54-60)	
54	4922713	3	Cable, Electrical - 12/3	
55	2220371	1	Fitting, Straight	
56	2220473	1	Fitting, 90	
57	2752622	1	Hose	
58	2753398	1	Hose	
59	0259803	Ref	Platform Cable Installation (Not Shown - See Separate Breakdown in ELECTRICAL SECTION)	
60	4922915	1	LSS Harness (See Separate Breakdown in ELECTRICAL SECTION)	

MidWestTech | JLG 260MRT Scissor Lift Parts Manual | Publication 31215867 Order the manual at mid-west-tech.com >

FIGURE 7-1. DRIVE HYDRAULIC DIAGRAM (STANDARD)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	2792717	Ref	HYDRAULIC DIAGRAM	E
1	2752478	2	Hose	
2	2752613	2	Hose	
3	2753503	1	Hose	
4	2753504	1	Hose	
5	2753505	1	Hose	
7	2753388	2	Hose	
8	2752489	1	Hose	
9	2753389	2	Hose	
10	2752469	1	Hose	
11	2753394	1	Hose	
12	2753395	2	Hose	
15	2753397	1	Hose	
16	2752622	AR	Hose	
17	2753398	AR	Hose	
18	2753390	2	Hose	
20	2753392	2	Hose	
21	2753393	1	Hose	
22	2753375	1	Hose	
23	2753376	1	Hose	
24	2753377	1	Hose	
25	2753378	1	Hose	
26	2753379	1	Hose	
27	2753380	1	Hose	
28	2753381	1	Hose	
29	2753382	1	Hose	
30	1001093121	1	Hose	
31	2220490	1	Fitting, Tee FL/FL	
32	2230024	2	Fitting, Straight JIC/JIC	
33	2220603	1	Fitting, Straight JIC/ORB	
34	2220371	7	Fitting, Straight JIC/ORB	
35	2220372	1	Fitting, Straight JIC/ORB	
36	2220899	1	Fitting, Tee JIC/ORB/JIC	
38	2220473	2	Fitting, 90 JIC/ORB	
39	2220490	2	Fitting, Tee JIC/JIC/JIC	
40	2220622	1	Fitting, Reducer JIC/FSJIC	
41	2220472	2	Fitting, 90 JIC/ORB	
42	2220415	2	Fitting, Straight JIC/ORB	
43	2220578	2	Fitting, 90 JIC/ORB	
44	2220451	2	Fitting, Straight JIC/ORB	
45	2221025	1	Fitting, Straight JIC/ORB	
46	2220947	12	Fitting, Straight JIC/ORB	
47	2220906	1	Fitting, 90 JIC/ORB	
48	2220948	1	Fitting, Tee JIC/FSJIC/JIC	
49	2221049	1	Fitting, Tee JIC/ORB/JIC	
50	2221036	1	Fitting, 90 JIC/ORB	
51	2220738	1	Fitting, Tee JIC/ORB/JIC	
52	2220377	1	Fitting, Straight JIC/ORB	
53	2220998	2	Fitting, Straight JIC/ORB	
54	2220635	1	Fitting, Tee JIC/FSJIC/JIC	

MidWestTech | JLG 260MRT Scissor Lift Parts Manual | Publication 31215867 Order the manual at mid-west-tech.com >

FIGURE 10-2. MODEL 260MRT VARIABLE PARTS

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	Note	Ref	Note: The following list will service one machine (built to current production per date on the front cover) with emergency repair parts which can be installed in the field. Parts from the list should be replaced when inventory is depleted to keep service parts stock supplied. For further information, contact your JLG dealer or the JLG Industries Parts Department.	
		Ref	VARIABLE PARTS	
	4360548	1	Switch, Limit (Auto Leveling Jacks)	
	7024501	1	Coil (Auto Leveling Jacks)	
	3740049	1	Relay	
	7025479	1	Solenoid, Stop (Diesel)	
	70004395	12	Filter, Oil (Diesel)	
	7017901	1	Switch, Oil (Diesel)	
	7017950	4	Element, Fuel (Diesel)	
	7017938	4	Element, Breather (Diesel)	
	7017980	4	Filter, Oil (Dual Fuel)	
	7017992	4	Filter, Fuel (Dual Fuel)	
	4360469	1	Switch, Key	
	4360548	1	Switch, Limit	
	1001181045	1	Breaker 16Amp/30mAmp Combination (CE Spec with 2 Breaker Box)	
	1001189172	1	Breaker 16Amp (Box with 3 Breakers)	
	1001189171	1	Breaker 30mAmp (Box with 3 Breakers)	

MidWestTech | JLG 260MRT Scissor Lift Parts Manual | Publication 31215867 Order the manual at mid-west-tech.com >