Illustrated Parts Manual

Models
E450A/
E450AJ
M450AJ

SN 0300189898
through 0300208529
Includes SN 0300185900
and 0300186011

P/N
3121649

November 16, 2018 - Rev G

ANSI

CE

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

SECTION 1 - FRAME 13

FIGURE 1-1. STEERING INSTALLATION 14
FIGURE 1-2. HUB - SPINDLE ASSEMBLY - RH 16
FIGURE 1-3. HUB - SPINDLE ASSEMBLY - LH 18
FIGURE 1-4. WHEEL DRIVE - E450A/E450AJ 20
FIGURE 1-5. WHEEL DRIVE - E450A/E450AJ - UL LISTED 24
FIGURE 1-6. WHEEL DRIVE - M450AJ 28
FIGURE 1-7. HUB - DRIVE ASSEMBLY 32
FIGURE 1-8. DRIVE MOTOR ASSEMBLY 36
FIGURE 1-9. TIRE AND WHEEL - IN240/55-17.5 PNEUMATIC 38
FIGURE 1-10. TIRE AND WHEEL - IN240/55 - 17.5 FOAM FILL 40
FIGURE 1-11. TIRE AND WHEEL - IN240/55-17.5 PNEUMATIC NON MARKING 42
FIGURE 1-12. TIRE AND WHEEL - 26 X 7 X 20 - SOLID NON MARKING 44
FIGURE 1-13. TIRE AND WHEEL - IN240/55-17.5 FOAM FILL NON MARKING 46
FIGURE 1-14. TIRE AND WHEEL - IN240/55-17.5 PNEUMATIC NON MARKING TS 48
FIGURE 1-15. WHEEL COVER INSTALLATION - IN240/55-17.5 TIRES ONLY 50
FIGURE 1-16. MOTOR/PUMP/TANK INSTALLATION - E450A/E450AJ 52
FIGURE 1-17. MOTOR/PUMP/TANK INSTALLATION - E450A/E450AJ - UL LISTED 54
FIGURE 1-18. MOTOR/PUMP/TANK INSTALLATION - M450AJ 56
FIGURE 1-19. MOTOR/PUMP ASSEMBLY 58
FIGURE 1-20. HYDRAULIC TANK ASSEMBLY - E450A/E450AJ 60
FIGURE 1-21. HYDRAULIC TANK ASSEMBLY - M450AJ 62
FIGURE 1-22. VALVE INSTALLATION - FRAME MOUNTED - E450A 64
FIGURE 1-23. VALVE INSTALLATION - FRAME MOUNTED - E450AJ 66
FIGURE 1-24. VALVE INSTALLATION - FRAME MOUNTED - M450AJ 68
FIGURE 1-25. BRAKE/STEER VALVE ASSEMBLY 70
FIGURE 1-26. BATTERY BOX INSTALLATION (ALL SPECS EXCEPT CE AND AUSTRALIAN SPECS) 72
FIGURE 1-27. BATTERY BOX INSTALLATION - AGM BATTERIES (ALL SPECS EXCEPT CE AND AUSTRALIAN SPECS) 74
FIGURE 1-28. BATTERY BOX INSTALLATION - CE AND AUSTRALIAN SPECS 76
FIGURE 1-29. BATTERY BOX INSTALLATION - AGM BATTERIES (CE AND AUSTRALIAN SPECS) 78
FIGURE 1-30. BATTERY CHARGER INSTALLATION - E450A/E450AJ (ALL SPECS EXCEPED CE AND AUSTRALIAN SPECS) 80
FIGURE 1-31. BATTERY CHARGER INSTALLATION - E450A/E450AJ (AUSTRALIAN SPEC) 82
FIGURE 1-32. BATTERY CHARGER INSTALLATION - E450A/E450AJ (ANSI EXPORT AND CE SPECS) 84
FIGURE 1-33. BATTERY CHARGER INSTALLATION - M450AJ (ALL SPECS EXCEPTED CE, AUSTRALIAN AND UL SPECS) 86
FIGURE 1-34. BATTERY CHARGER INSTALLATION - M450AJ (AUSTRALIAN SPEC) 88
FIGURE 1-35. BATTERY CHARGER INSTALLATION - M450AJ (ANSI EXPORT AND CE SPECS) 90
FIGURE 1-36. INVERTER INSTALLATION - E450A/E450AJ 92
FIGURE 1-37. FRAME COVER INSTALLATION - M450AJ 94
FIGURE 1-38. FRAME COVER INSTALLATION - E450A/E450AJ 96

SECTION 2 - TURNTABLE 99

FIGURE 2-1. VALVE INSTALLATION - TURNTABLE MOUNTED - E450A 100
FIGURE 2-2. VALVE INSTALLATION - TURNTABLE MOUNTED - E450AJ 102
FIGURE 2-3. VALVE INSTALLATION - TURNTABLE MOUNTED - M450AJ 104
FIGURE 2-4. MAIN CONTROL VALVE ASSEMBLY 106
FIGURE 2-5. RELEVELING VALVE ASSEMBLY 110
FIGURE 2-6. JIB VALVE ASSEMBLY 112
FIGURE 2-7. MOTION ALARM INSTALLATION 114
FIGURE 2-8. TURNTABLE BEARING AND SWING DRIVE INSTALLATION 116
FIGURE 2-9. SWING MOTOR ASSEMBLY 118
FIGURE 2-10. SWING BEARING ASSEMBLY 120
FIGURE 2-11. REMOTE BEARING LUBE INSTALLATION - OPTIONAL 122
FIGURE 2-12. DRIVE ORIENTATION INSTALLATION 124
FIGURE 2-13. FUEL TANK AND BATTERY INSTALLATION - M450AJ 126
FIGURE 2-14. GROUND CONTROL BOX ASSEMBLY - E450A 128
FIGURE 2-15. GROUND CONTROL BOX ASSEMBLY - E450A - CE SPEC (SN 0300189898 through 0300200789) 130
FIGURE 2-16. GROUND CONTROL BOX ASSEMBLY - E450A - CE SPEC (SN 0300200790 through 0300208529) 132
FIGURE 2-17. GROUND CONTROL BOX ASSEMBLY - E450AJ/M450AJ 134
FIGURE 2-18. GROUND CONTROL BOX ASSEMBLY - E450AJ/M450AJ - CE SPEC (SN 0300189898 through 0300200789) 136
FIGURE 2-19. GROUND CONTROL BOX ASSEMBLY - E450AJ/M450AJ - CE SPEC (SN 0300200790 through 0300208529) 138
FIGURE 2-20. MOTOR CONTROLS INSTALLATION - M450AJ 140
FIGURE 2-21. STROBE LIGHT INSTALLATION (AMBER) - OPTIONAL 142

MidWestTech | JLG E450A, E450AJ, M450AJ Boom Lift Parts Manual | Publication 3121649 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 2-22. STROBE LIGHT INSTALLATION - UL LISTED - OPTIONAL 144
FIGURE 2-23. STROBE LIGHT ASSEMBLY 146
FIGURE 2-24. BEACON LIGHT INSTALLATION - BLUE (SN 0300189898 through 0300200789) 148
FIGURE 2-25. BEACON LIGHT INSTALLATION - BLUE (SN 0300200790 through 0300208529) 150
FIGURE 2-26. HOOD INSTALLATION - E450A/E450AJ 152
FIGURE 2-27. HOOD INSTALLATION - M450AJ 154

SECTION 3 - ENGINE 157

FIGURE 3-1. KUBOTA MOTOR/GENERATOR INSTALLATION - M450AJ 158
FIGURE 3-2. KUBOTA MOTOR/GENERATOR ASSEMBLY - M450AJ 160
FIGURE 3-3. KUBOTA MOTOR/GENERATOR COMPONENTS 162

SECTION 4 - BOOM 165

FIGURE 4-1. BOOM AND CYLINDERS INSTALLATION - E450A 166
FIGURE 4-2. BOOM AND CYLINDERS INSTALLATION - E450AJ/M450AJ 168
FIGURE 4-3. MAIN BOOM ASSEMBLY - E450A 172
FIGURE 4-4. MAIN BOOM ASSEMBLY - E450AJ/M450AJ 176
FIGURE 4-5. JIB INSTALLATION 178
FIGURE 4-6. ROTATOR ASSEMBLY - E450A 180
FIGURE 4-7. ROTATOR ASSEMBLY - E450AJ/M450AJ 182
FIGURE 4-8. PLATFORM SUPPORT WITHOUT LOAD SENSING 184
FIGURE 4-9. PLATFORM SUPPORT INSTALLATION - WITH LSS - E450AJ/M450AJ 186
FIGURE 4-10. PLATFORM SUPPORT INSTALLATION - WITH LSS - E450A 190
FIGURE 4-11. CABLES AND CLAMPS INSTALLATION - E450A 194
FIGURE 4-12. CABLES AND CLAMPS INSTALLATION - E450AJ/M450AJ 196
FIGURE 4-13. BOOM LIMIT SWITCHES INSTALLATION 198

SECTION 5 - PLATFORM 201

FIGURE 5-1. PLATFORM ASSEMBLY - 4FT/1.22M - SIDE GATE ENTRY (SN 0300189898 through 0300200789) 202
FIGURE 5-2. PLATFORM ASSEMBLY - 4FT/1.22M - SIDE GATE ENTRY (SN 0300200790 through 0300208529) 204
FIGURE 5-3. PLATFORM ASSEMBLY - 5FT/1.52M - SIDE GATE ENTRY (SN 0300189898 through 0300200789) 206
FIGURE 5-4. PLATFORM ASSEMBLY - 5FT/1.52M - SIDE GATE ENTRY (SN 0300200790 through 0300208529) 208
FIGURE 5-5. PLATFORM ASSEMBLY - 5FT/1.52M - SIDE GATE ENTRY - WITH STOP (SN 0300189898 through 0300195136) 210
FIGURE 5-6. PLATFORM ASSEMBLY - 6FT/1.83M - SIDE GATE ENTRY (SN 0300195137 through 0300200789) 212
FIGURE 5-7. PLATFORM ASSEMBLY - 6FT/1.83M - SIDE GATE ENTRY (SN 0300200790 through 0300208529) 214
FIGURE 5-8. PLATFORM ASSEMBLY - 4FT/1.22M - DROP BAR ENTRY (SN 0300189898 through 0300200789) 216
FIGURE 5-9. PLATFORM ASSEMBLY - 4FT/1.22M - DROP BAR ENTRY (SN 0300200790 through 0300208529) 218
FIGURE 5-10. PLATFORM ASSEMBLY - 5FT/1.52M - DROP BAR ENTRY (SN 0300189898 through 0300200789) 220
FIGURE 5-11. PLATFORM ASSEMBLY - 5FT/1.52M - DROP BAR ENTRY (SN 0300200790 through 0300208529) 222
FIGURE 5-12. PLATFORM ASSEMBLY - 6FT/1.83M - DROP BAR ENTRY (SN 0300189898 through 0300200789) 224
FIGURE 5-13. PLATFORM ASSEMBLY - 6FT/1.83M - DROP BAR ENTRY (SN 0300200790 through 0300208529) 226
FIGURE 5-14. PLATFORM ASSEMBLY - 5FT/1.52M - FALL ARREST (ANSI EXPORT SPEC) (SN 0300189898 through 0300200789) 228
FIGURE 5-15. PLATFORM ASSEMBLY - 5FT/1.52M - FALL ARREST (ANSI EXPORT SPEC) (SN 0300200790 through 0300208529) 230
FIGURE 5-16. PLATFORM ASSEMBLY - 6FT/1.83M - FALL ARREST (SN 0300189898 through 0300200789) 232
FIGURE 5-17. PLATFORM ASSEMBLY - 6FT/1.83M - FALL ARREST (SN 0300200790 through 0300208529) 234
FIGURE 5-18. TRAY ASSEMBLY 236
FIGURE 5-19. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION 238
FIGURE 5-20. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - UL LISTED 240
FIGURE 5-21. PLATFORM CONSOLE AND FOOTSWITCH INSTALLATION - WITH SKYGUARD (SN 0300200790 through 0300208529) 242
FIGURE 5-22. PLATFORM CONSOLE ASSEMBLY 244
FIGURE 5-23. PLATFORM CONSOLE ASSEMBLY - UL LISTED 248
FIGURE 5-24. PLATFORM CONSOLE ASSEMBLY - WITH SKYGUARD (SN 0300200790 through 0300208529) 252
FIGURE 5-25. LIGHT PANEL DECAL INSTALLATION 256
FIGURE 5-26. JIB SWITCH INSTALLATION - E450AJ/M450AJ 258
FIGURE 5-27. SEALED ENCLOSURES - UL LISTED 260
FIGURE 5-28. CONTROLLER ASSEMBLY - DRIVE AND STEER 262
FIGURE 5-29. CONTROLLER ASSEMBLY - LIFT AND SWING 264
FIGURE 5-30. FOOTSWITCH ASSEMBLY 266
FIGURE 5-31. MOTOR CONTROLS INSTALLATION - M450AJ 268
FIGURE 5-32. SKYGUARD SYSTEM INSTALLATION (SN 0300189898 through 0300200789) 270

MidWestTech | JLG E450A, E450AJ, M450AJ Boom Lift Parts Manual | Publication 3121649 Order the manual at mid-west-tech.com >

FIGURE 5-33. SKYGUARD SYSTEM INSTALLATION (SN 0300200790 through 0300208529) 272
FIGURE 5-34. CROSS RAIL INSTALLATION 274
FIGURE 5-35. PIPE RACK INSTALLATION 276

SECTION 6 - CYLINDER 279

FIGURE 6-1. JIB CYLINDER ASSEMBLY - E450AJ/M450AJ 280
FIGURE 6-2. LIFT CYLINDER ASSEMBLY - LOWER - E450A (ORIGINAL EQUIPMENT) 282
FIGURE 6-3. LIFT CYLINDER ASSEMBLY - E450A (SERVICE REPLACEMENT) 284
FIGURE 6-4. LIFT CYLINDER ASSEMBLY - LOWER - E450AJ/M450AJ (ORIGINAL EQUIPMENT) 286
FIGURE 6-5. LIFT CYLINDER ASSEMBLY - LOWER - E450AJ/M450AJ (SERVICE REPLACEMENT) 288
FIGURE 6-6. LIFT CYLINDER ASSEMBLY - MID - E450A (ORIGINAL EQUIPMENT) 290
FIGURE 6-7. LIFT CYLINDER ASSEMBLY - MID - E450A (SERVICE REPLACEMENT) 292
FIGURE 6-8. LIFT CYLINDER ASSEMBLY - MID - E450AJ/M450AJ (ORIGINAL EQUIPMENT) 294
FIGURE 6-9. LIFT CYLINDER ASSEMBLY - MID - E450AJ/M450AJ (SERVICE REPLACEMENT) 296
FIGURE 6-10. LIFT CYLINDER ASSEMBLY - UPPER - E450A (ORIGINAL EQUIPMENT) 298
FIGURE 6-11. LIFT CYLINDER ASSEMBLY - UPPER - E450A (SERVICE REPLACEMENT) 300
FIGURE 6-12. LIFT CYLINDER ASSEMBLY - UPPER - E450AJ/M450AJ (ORIGINAL EQUIPMENT) 302
FIGURE 6-13. LIFT CYLINDER ASSEMBLY - UPPER - E450AJ/M450AJ (SERVICE REPLACEMENT) 304
FIGURE 6-14. MASTER CYLINDER ASSEMBLY - E450A 306
FIGURE 6-15. MASTER CYLINDER ASSEMBLY - E450AJ/M450AJ 308
FIGURE 6-16. LEVEL (PLATFORM SLAVE) CYLINDER ASSEMBLY - E450A 310
FIGURE 6-17. LEVEL (PLATFORM SLAVE) CYLINDER ASSEMBLY - E450AJ/M450AJ 312
FIGURE 6-18. STEER CYLINDER ASSEMBLY 314
FIGURE 6-19. TELESCOPE CYLINDER ASSEMBLY - E450A (ORIGINAL EQUIPMENT) 316
FIGURE 6-20. TELESCOPE CYLINDER ASSEMBLY - E450A (SERVICE REPLACEMENT) 318
FIGURE 6-21. TELESCOPE CYLINDER ASSEMBLY - E450AJ/M450AJ (ORIGINAL EQUIPMENT) 320
FIGURE 6-22. TELESCOPE CYLINDER ASSEMBLY - E450AJ/M450AJ (SERVICE REPLACEMENT) 322
FIGURE 6-23. COUNTERBALANCE VALVE ASSEMBLY 324

SECTION 7 - HYDRAULIC 327

FIGURE 7-1. HYDRAULIC DIAGRAM - E450A 328
FIGURE 7-2. HYDRAULIC DIAGRAM - E450AJ 332
FIGURE 7-3. HYDRAULIC DIAGRAM - M450AJ 336
FIGURE 7-4. HYDRAULIC DIAGRAM LIST 340

SECTION 8 - ELECTRICAL 341


FIGURE 8-1. ELECTRICAL DIAGRAM LIST 342
FIGURE 8-2. AC PLUGS AND SOCKETS INSTALLATION - CEE7 POST GROUND - 2 X 4 BOX (CE SPEC) 344
FIGURE 8-3. AC PLUGS AND SOCKETS INSTALLATION - CEE7 SIDE GROUND - 2 X 4 BOX (CE SPEC) 346
FIGURE 8-4. AC PLUGS AND SOCKETS INSTALLATION - AFSINT 107-2-01 KEYED GROUND - 2 X 4 BOX (CE SPEC) 348
FIGURE 8-5. AC PLUGS AND SOCKETS INSTALLATION - IEC 60309 YELLOW (CE SPEC) 350
FIGURE 8-6. AC PLUGS AND SOCKETS INSTALLATION - IEC 60309 BLUE (CE SPEC) 352
FIGURE 8-7. AC PLUGS AND SOCKETS INSTALLATION - CEE7 POST GROUND (CE SPEC) 354
FIGURE 8-8. AC PLUGS AND SOCKETS INSTALLATION - CEE 7 SIDE GROUND (CE SPEC) 356
FIGURE 8-9. ANALYZER HARNESS ASSEMBLY 358
FIGURE 8-10. BATTERY CHARGER ASSEMBLY 360
FIGURE 8-11. BATTERY CHARGER HARNESS (SN 0300189898 through 0300196080) 362
FIGURE 8-12. BATTERY CHARGER INDICATOR HARNESS - CE SPEC (SN 0300200790 through 0300208529) 364
FIGURE 8-13. BEACON LIGHT HARNESS (BLUE BEACON ONLY) 366
FIGURE 8-14. BOOM LIMIT SWITCH HARNESS - LOWER 368
FIGURE 8-15. BOOM LIMIT SWITCH HARNESS - UPPER 370
FIGURE 8-16. BREAKER BOX KIT WITH TWO BREAKERS - CE SPEC 372
FIGURE 8-17. BREAKER BOX KIT WITH THREE BREAKERS - CE SPEC 374
FIGURE 8-18. CHARGER CORD PLUG INSTALLATION - 220V - CEE7 POST GROUND (CE SPEC) 376
FIGURE 8-19. CHARGER CORD PLUG INSTALLATION - 220V - CEE7 SIDE GROUND (CE SPEC) 378
FIGURE 8-20. CHARGER CORD PLUG INSTALLATION - 220V - AFSINT 107 KEYED GROUND (CE SPEC) 380
FIGURE 8-21. CHARGER CORD PLUG INSTALLATION - 110V - IEC 60309 - YELLOW (CE SPEC) 382
FIGURE 8-22. CHARGER CORD PLUG INSTALLATION - 220V - IEC 60309 - BLUE (CE SPEC) 384
FIGURE 8-23. CONTACTOR CABLE KIT - E450A/E450AJ 386
FIGURE 8-24. CONTACTOR CABLE KIT - M450AJ 388
FIGURE 8-25. CONTACTOR PLATE ASSEMBLY AND HARNESSES 390
FIGURE 8-26. CONTACTOR PLATE ASSEMBLY AND HARNESSES - UL LISTED 392
FIGURE 8-27. CONTACTOR PLATE KIT - E450A/E450AJ - UL/EE 394
FIGURE 8-28. DRIVE ORIENTATION HARNESS 396

MidWestTech | JLG E450A, E450AJ, M450AJ Boom Lift Parts Manual | Publication 3121649 Order the manual at mid-west-tech.com >

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
101	2920151	1	Light (Located on Ground Control Box)	
102	4460226	2	Socket, Female	
103	4460424	1	Connector - 2 Position	
104	4922926	1	Harness, Indicator Lamp (Not Shown - Located at Ground Control Box)	
104	4460320	1	Plug, Male - 2 Position	
104	4460227	2	Pin, Male	
104	4460042	1	Terminal, Ring	
104	4460313	1	Terminal, Ring	
104	4460265	1	Connector - 9 Position	
104	4460226	3	Socket, Female	


MidWestTech | JLG E450A, E450AJ, M450AJ Boom Lift Parts Manual | Publication 3121649 Order the manual at mid-west-tech.com >

FIGURE 8-66. SKYGUARD CAN HARNESS (SN 0300200790 through 0300208529)



MidWestTech | JLG E450A, E450AJ, M450AJ Boom Lift Parts Manual | Publication 3121649 Order the manual at mid-west-tech.com >

FIGURE 9-6. DECAL INSTALLATION - CE SPEC - M450AJ (SN 0300200790 through 0300208529)



MidWestTech | JLG E450A, E450AJ, M450AJ Boom Lift Parts Manual | Publication 3121649 Order the manual at mid-west-tech.com >