Illustrated Parts Manual

Models
600S
660SJ

SN 0300235168 to SN 0300272445*
SN B300002655 to SN B300005754*

*** See Revision Log Page for exceptions**

P/N
3121729

April 22, 2020 - Rev J

ANSI

CE

AS/NZS

An Oshkosh Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SECTION 1 - FRAME 15

FIGURE 1-1. AXLE INSTALLATION - FRONT 16
FIGURE 1-2. AXLE INSTALLATION - REAR (4WS ONLY) 18
FIGURE 1-3. STEER INSTALLATION - WITHOUT TOW PACKAGE 20
FIGURE 1-4. STEER INSTALLATION - WITH TOW PACKAGE 22
FIGURE 1-5. WHEEL DRIVE INSTALLATION - 4WD/2WS 24
FIGURE 1-6. WHEEL DRIVE INSTALLATION - 4WD/4WS 26
FIGURE 1-7. DRIVE HUB ASSEMBLY 28
FIGURE 1-8. DRIVE MOTOR ASSEMBLY 32
FIGURE 1-9. TRACTION VALVE ASSEMBLY 34
FIGURE 1-10. TIRE & WHEEL INSTALLATION - IN355-55 D625 PNEUMATIC (AVAILABLE ON ALL SPECS EXCEPT AUSTRALIAN, CE & CHINA SPECS) 36
FIGURE 1-11. TIRE & WHEEL INSTALLATION - IN355-55 D625 PNEUMATIC NON-MARKING (AVAILABLE ON ALL SPECS EXCEPT AUSTRALIAN, CE & CHINA SPECS) 38
FIGURE 1-12. TIRE & WHEEL INSTALLATION - IN355-55 D625 PNEUMATIC WITH TIRE SEALANT (AVAILABLE ON ALL SPECS EXCEPT AUSTRALIAN, CE & CHINA SPECS) 40
FIGURE 1-13. TIRE & WHEEL INSTALLATION - IN355-55 D625 FOAM FILLED (AVAILABLE ON ALL SPECS) 42
FIGURE 1-14. TIRE & WHEEL INSTALLATION - IN355-55 D625 FOAM FILLED NON-MARKING (AVAILABLE ON ALL SPECS) 44
FIGURE 1-15. TIRE & WHEEL INSTALLATION - 41-18LL X 22.5 PNEUMATIC TURF & SAND (AVAILABLE ON ALL SPECS EXCEPT AUSTRALIAN, CE & CHINA SPECS) 46
FIGURE 1-16. TIRE & WHEEL INSTALLATION - 41-18LL X 22.5 FOAM FILLED TURF & SAND (AVAILABLE ON ALL SPECS EXCEPT AUSTRALIAN & CE SPECS) 48
FIGURE 1-17. FRAME COVERS INSTALLATION - 2WS 50
FIGURE 1-18. FRAME COVERS INSTALLATION - 4WS 52
FIGURE 1-19. TOW BAR INSTALLATION (OPTIONAL) 54

SECTION 2 - TURNTABLE 57

FIGURE 2-1. VALVE INSTALLATION - 600S WITH 2WS 58
FIGURE 2-2. VALVE INSTALLATION - 600S WITH 4WS 60
FIGURE 2-3. VALVE INSTALLATION - 660SJ WITH 2WS 62
FIGURE 2-4. VALVE INSTALLATION - 660SJ WITH 4WS 64
FIGURE 2-5. MAIN VALVE ASSEMBLY - 2WS 66
FIGURE 2-6. MAIN VALVE ASSEMBLY - 4WS 70
FIGURE 2-7. AXLE VALVE ASSEMBLY 74
FIGURE 2-8. SWING DRIVE INSTALLATION 76
FIGURE 2-9. SWING MOTOR/HUB ASSEMBLY 78
FIGURE 2-10. TURNTABLE BEARING AND LUBE INSTALLATION 82
FIGURE 2-11. TURNTABLE LOCK INSTALLATION 84
FIGURE 2-12. ROTARY COUPLING INSTALLATION - 2WS 86
FIGURE 2-13. ROTARY COUPLING ASSEMBLY - 2WS 88
FIGURE 2-14. ROTARY COUPLING INSTALLATION - 4WS 90
FIGURE 2-15. TANKS INSTALLATION - DIESEL MACHINES (POLY FUEL TANK) 92
FIGURE 2-16. TANKS INSTALLATION - DIESEL MACHINES (STEEL FUEL TANK) 94
FIGURE 2-17. TANKS INSTALLATION - GAS MACHINES 96
FIGURE 2-18. HYDRAULIC TANK ASSEMBLY 98
FIGURE 2-19. BATTERY AND AUXILIARY PUMP INSTALLATION 100
FIGURE 2-20. BATTERY AND AUXILIARY PUMP W/DISCONNECT SWITCH INSTALLATION 102
FIGURE 2-21. ELECTRICAL COMPONENTS INSTALLATION - 600S WITH 2WS 104
FIGURE 2-22. ELECTRICAL COMPONENTS INSTALLATION - 600S WITH 4WS 106
FIGURE 2-23. ELECTRICAL COMPONENTS INSTALLATION - 660SJ WITH 2WS 108
FIGURE 2-24. ELECTRICAL COMPONENTS INSTALLATION - 660SJ WITH 4WS 110
FIGURE 2-25. GROUND CONTROL PANEL ASSEMBLY - 600S 112
FIGURE 2-26. GROUND CONTROL PANEL ASSEMBLY - 660SJ 114
FIGURE 2-27. KEYSWITCH INSTALLATION - 600S (ALL SPECS EXCEPT AUSTRALIAN AND CE SPECS) 116
FIGURE 2-28. KEYSWITCH INSTALLATION - 600S (CE SPECS) 118
FIGURE 2-29. KEYSWITCH INSTALLATION - 660SJ (ALL SPECS EXCEPT CE SPECS) 120
FIGURE 2-30. KEYSWITCH INSTALLATION - 660SJ (CE SPECS) 122
FIGURE 2-31. STROBE LIGHT INSTALLATION - AMBER (OPTIONAL) 124
FIGURE 2-32. STROBE LIGHT INSTALLATION - BLUE (OPTIONAL) (SN 0300235168 through 0300259907, SN B30002655 through B300005754) 126
FIGURE 2-33. STROBE LIGHT INSTALLATION - BLUE (OPTIONAL) (SN 0300259908 through 0300272445) 128
FIGURE 2-34. STROBE LIGHT INSTALLATION - RED (OPTIONAL) (SN 0300235168 through 0300259907, SN B30002655 through B300005754) 130

MidWestTech | JLG 600S, 660SJ Boom Lift Parts Manual | Publication 3121729 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE 2-35. STROBE LIGHT INSTALLATION - RED (OPTIONAL) (SN 0300259908 through 0300272445) 132
FIGURE 2-36. HOODS INSTALLATIONS - ABS (DEUTZ D2.9L4 - 49HP ENGINE) 134
FIGURE 2-37. HOODS INSTALLATIONS - ABS (DEUTZ D2011, DEUTZ TD2.9L4 - 67HP AND FORD ENGINES) 138
FIGURE 2-38. HOOD ASSEMBLY - TANK SIDE (ABS) 142
FIGURE 2-39. HOOD ASSEMBLY - ENGINE SIDE (ABS) 144
FIGURE 2-40. HOODS INSTALLATIONS - STEEL (DEUTZ D2.9L4 – 49HP ENGINE) 146
FIGURE 2-41. HOODS INSTALLATIONS - STEEL (DEUTZ D2011, DEUTZ TD2.9L4 – 67HP AND FORD ENGINES) 150
FIGURE 2-42. HOOD ASSEMBLY - TANK SIDE (STEEL) 154
FIGURE 2-43. HOOD ASSEMBLY - ENGINE SIDE (STEEL) 156
FIGURE 2-44. COVERS INSTALLATION 158

SECTION 3 - ENGINE 161

FIGURE 3-1. DEUTZ D2011 ENGINE INSTALLATION - WITHOUT ARCTIC PACKAGE 162
FIGURE 3-2. DEUTZ D2011 ENGINE AND PUMPS SUB-ASSEMBLY - WITHOUT ARCTIC PACKAGE 166
FIGURE 3-3. DEUTZ D2011 ENGINE ASSEMBLY - WITHOUT ARCTIC PACKAGE 168
FIGURE 3-4. DEUTZ D2011 ENGINE INSTALLATION - WITH ARCTIC PACKAGE 172
FIGURE 3-5. DEUTZ D2011 ENGINE AND PUMPS SUB-ASSEMBLY - WITH ARCTIC PACKAGE 176
FIGURE 3-6. DEUTZ D2011 ENGINE ASSEMBLY - WITH ARCTIC PACKAGE 178
FIGURE 3-7. DEUTZ D2011 ENGINE COMPONENTS 182
FIGURE 3-8. DEUTZ D2011 (STAGE V) ENGINE INSTALLATION 186
FIGURE 3-9. DEUTZ D2011 (STAGE V) ENGINE AND PUMPS SUB-ASSEMBLY 188
FIGURE 3-10. DEUTZ D2011 (STAGE V) ENGINE ASSEMBLY 190
FIGURE 3-11. DEUTZ D2011 (STAGE V) ENGINE COMPONENTS 194
FIGURE 3-12. DEUTZ D2.9L4 - 49HP ENGINE INSTALLATION - WITHOUT ARCTIC PACKAGE 198
FIGURE 3-13. DEUTZ D2.9L4 - 49HP ENGINE AND PUMPS SUB-ASSEMBLY - WITHOUT ARCTIC PACKAGE 202
FIGURE 3-14. DEUTZ D2.9L4 - 49HP ENGINE ASSEMBLY - WITHOUT ARCTIC PACKAGE 204
FIGURE 3-15. DEUTZ D2.9L4 - 49HP ENGINE INSTALLATION - WITH ARCTIC PACKAGE 208
FIGURE 3-16. DEUTZ D2.9L4 - 49HP ENGINE AND PUMPS SUB-ASSEMBLY - WITH ARCTIC PACKAGE 212
FIGURE 3-17. DEUTZ D2.9L4 - 49HP ENGINE ASSEMBLY - WITH ARCTIC PACKAGE 214
FIGURE 3-18. DEUTZ D2.9L4 - 49HP ENGINE COMPONENTS 218
FIGURE 3-19. DEUTZ TD2.9L4 - 67HP ENGINE INSTALLATION - WITHOUT ARCTIC PACKAGE 222
FIGURE 3-20. DEUTZ TD2.9L4 - 67HP ENGINE AND PUMPS SUB-ASSEMBLY - WITHOUT ARCTIC PACKAGE 226
FIGURE 3-21. DEUTZ TD2.9L4 - 67HP ENGINE ASSEMBLY - WITHOUT ARCTIC PACKAGE 228
FIGURE 3-22. DEUTZ TD2.9L4 - 67HP ENGINE INSTALLATION - WITH ARCTIC PACKAGE 234
FIGURE 3-23. DEUTZ TD2.9L4 - 67HP ENGINE AND PUMPS SUB-ASSEMBLY - WITH ARCTIC PACKAGE 238
FIGURE 3-24. DEUTZ TD2.9L4 - 67HP ENGINE ASSEMBLY - WITH ARCTIC PACKAGE 240
FIGURE 3-25. DEUTZ TD2.9L4 - 67HP ENGINE COMPONENTS 246
FIGURE 3-26. BREATHER HEATER INSTALLATION - DEUTZ D2.9L4 - 49HP AND DEUTZ TD2.9L4 - 67HP ENGINES WITH ARCTIC PACKAGE 252
FIGURE 3-27. FORD ENGINE INSTALLATION - WITHOUT ARCTIC PACKAGE 254
FIGURE 3-28. FORD ENGINE AND PUMPS SUB-ASSEMBLY - WITHOUT ARCTIC PACKAGE 258
FIGURE 3-29. FORD ENGINE ASSEMBLY - WITHOUT ARCTIC PACKAGE 260
FIGURE 3-30. FORD ENGINE INSTALLATION - WITH ARCTIC PACKAGE 266
FIGURE 3-31. FORD ENGINE AND PUMPS SUB-ASSEMBLY - WITH ARCTIC PACKAGE 270
FIGURE 3-32. FORD ENGINE ASSEMBLY - WITH ARCTIC PACKAGE 272
FIGURE 3-33. FORD ENGINE PREP ASSEMBLY - PUMP COUPLING 278
FIGURE 3-34. FORD ENGINE COMPONENTS 280
FIGURE 3-35. PUMP COUPLING KIT (DEUTZ ENGINES) 284
FIGURE 3-36. PISTON PUMP ASSEMBLY 286
FIGURE 3-37. FUEL FILTER INSTALLATION (POLY FUEL TANK) 290
FIGURE 3-38. FUEL FILTER INSTALLATION (STEEL FUEL TANK) (DEUTZ D2011 ENGINES) 292
FIGURE 3-39. FUEL PUMP AND FILTER INSTALLATION (STEEL FUEL TANK) (DEUTZ D2.9L4 - 49HP AND DEUTZ TD2.9L4 - 67HP ENGINES) 294
FIGURE 3-40. LP TANK AND BRACKETS INSTALLATION (FORD ENGINE) 296
FIGURE 3-41. MUFFLER INSTALLATION - SPARK ARRESTING (DEUTZ D2011 ENGINES) (OPTIONAL) 298
FIGURE 3-42. MUFFLER INSTALLATION - CATALYTIC (DEUTZ D2011 ENGINES) (OPTIONAL) 300
FIGURE 3-43. MUFFLER INSTALLATION - SPARK ARRESTING (FORD ENGINES) (OPTIONAL) 302
FIGURE 3-44. EXHAUST PIPE INSTALLATION (DEUTZ D2011 ENGINES) 304
FIGURE 3-45. ENGINE HOOD BAFFLES INSTALLATION - ABS HOODS (DEUTZ D2.9L4 - 49HP ENGINES) 306
FIGURE 3-46. ENGINE HOOD BAFFLES INSTALLATION - ABS HOODS (DEUTZ D2011, DEUTZ TD2.9L4 - 67HP AND FORD ENGINES) 308
FIGURE 3-47. ENGINE HOOD BAFFLES INSTALLATION - STEEL HOODS (DEUTZ D2.9L4 - 49HP ENGINES) 310
FIGURE 3-48. ENGINE HOOD BAFFLES INSTALLATION - STEEL HOODS (DEUTZ D2011, DEUTZ TD2.9L4 - 67HP AND FORD ENGINES) 312
FIGURE 3-49. NOISE REDUCTION PACKAGE 314
FIGURE 3-50. TRAY JACK INSTALLATION (DEUTZ D2.9L4 - 49HP ENGINES) 316

MidWestTech | JLG 600S, 660SJ Boom Lift Parts Manual | Publication 3121729 Order the manual at mid-west-tech.com >

FIGURE 3-51. TRAY JACK INSTALLATION (DEUTZ D2011, DEUTZ TD2.9L4 - 67HP AND FORD ENGINES) 318
FIGURE 3-52. MOTOR MOUNT INSTALLATION - WITHOUT GENERATOR (DEUTZ D2011 ENGINES) 320
FIGURE 3-53. MOTOR MOUNT INSTALLATION - WITH GENERATOR (DEUTZ D2011 ENGINES) 322
FIGURE 3-54. MOTOR MOUNT INSTALLATION - WITHOUT GENERATOR (DEUTZ D2.9L4 - 49HP ENGINES) 324
FIGURE 3-55. MOTOR MOUNT INSTALLATION - WITHOUT GENERATOR (DEUTZ TD2.9L4 - 67HP ENGINES) 326
FIGURE 3-56. MOTOR MOUNT INSTALLATION - WITH GENERATOR (DEUTZ D2.9L4 - 49HP ENGINES) 328
FIGURE 3-57. MOTOR MOUNT INSTALLATION - WITH GENERATOR (DEUTZ TD2.9L4 - 67HP ENGINES) 330
FIGURE 3-58. BELT WITHOUT GENERATOR INSTALLATION (FORD ENGINES) 332
FIGURE 3-59. 2500W GENERATOR INSTALLATION - 220V/50HZ (DEUTZ D2011 ENGINES) (OPTIONAL) 334
FIGURE 3-60. 2500W GENERATOR INSTALLATION - 110V/60HZ (DEUTZ D2011 ENGINES) (OPTIONAL) 336
FIGURE 3-61. 2500W GENERATOR INSTALLATION - 110V/60HZ (DEUTZ D2.9L4 - 49HP ENGINES) (OPTIONAL) 338
FIGURE 3-62. 2500W GENERATOR INSTALLATION - 110V/60HZ (DEUTZ TD2.9L4 - 67HP ENGINES) (OPTIONAL) 342
FIGURE 3-63. 2500W GENERATOR INSTALLATION - 110V/60HZ (FORD ENGINES) (OPTIONAL) 346
FIGURE 3-64. 4000W GENERATOR INSTALLATION - 220V/50HZ (DEUTZ D2011 ENGINES) (OPTIONAL) 348
FIGURE 3-65. 4000W GENERATOR INSTALLATION - 110V/60HZ (DEUTZ D2011 ENGINES) (OPTIONAL) 352
FIGURE 3-66. 4000W GENERATOR INSTALLATION - 110V/60HZ (DEUTZ D2.9L4 - 49HP ENGINES) (OPTIONAL) 356
FIGURE 3-67. 4000W GENERATOR INSTALLATION - 110V/60HZ (DEUTZ TD2.9L4 - 67HP ENGINES) (OPTIONAL) 360
FIGURE 3-68. 7500W SKYPOWER GENERATOR INSTALLATION - 220V/50HZ (DEUTZ D2011 ENGINES) (OPTIONAL) 364
FIGURE 3-69. 7500W SKYPOWER GENERATOR INSTALLATION - 110/60HZ (DEUTZ D2011 ENGINES) (OPTIONAL) 368
FIGURE 3-70. 7500W SKYPOWER GENERATOR INSTALLATION - 110V/60HZ (DEUTZ D2.9L4 - 49HP ENGINES) (OPTIONAL) 372
FIGURE 3-71. 7500W SKYPOWER GENERATOR INSTALLATION - 110V/60HZ (DEUTZ TD2.9L4 - 67HP ENGINES) (OPTIONAL) 376
FIGURE 3-72. 7500W SKYPOWER GENERATOR INSTALLATION - 110V/60HZ (FORD ENGINES) (OPTIONAL) 380

SECTION 4 - BOOM 383

FIGURE 4-1. BOOM INSTALLATION - 600S 384
FIGURE 4-2. BOOM INSTALLATION - 660SJ 388
FIGURE 4-3. BOOM ASSEMBLY - 600S 392
FIGURE 4-4. BOOM ASSEMBLY - 660SJ 396
FIGURE 4-5. JIB ASSEMBLY - 660SJ (USA BUILT MACHINES) 400
FIGURE 4-6. JIB ASSEMBLY - 660SJ (CHINA BUILT MACHINES) 402
FIGURE 4-7. PLATFORM ROTATOR ASSEMBLY - 600S 404
FIGURE 4-8. PLATFORM ROTATOR ASSEMBLY - 660SJ 406
FIGURE 4-9. POWER TRACK INSTALLATION 408
FIGURE 4-10. BOOM VALVES INSTALLATION - 600S WITH 2WS 410
FIGURE 4-11. BOOM VALVES INSTALLATION - 600S WITH 4WS 412
FIGURE 4-12. BOOM VALVES INSTALLATION - 660SJ WITH 2WS 414
FIGURE 4-13. BOOM VALVES INSTALLATION - 660SJ WITH 4WS 416
FIGURE 4-14. PLATFORM VALVE ASSEMBLY - 600S 418
FIGURE 4-15. PLATFORM VALVE ASSEMBLY - 660SJ 420
FIGURE 4-16. BOOM SENSORS INSTALLATION - 600S 422
FIGURE 4-17. BOOM SENSORS INSTALLATION - 660SJ 424
FIGURE 4-18. PLATFORM SUPPORT INSTALLATION - WITHOUT LSS (SN 0300235168 through 0300251320, SN B300002655 through B300003386) 426
FIGURE 4-19. PLATFORM SUPPORT INSTALLATION - WITHOUT LSS (SN 0300251321 through 0300272445, SN B300003387 through B300005754) 428
FIGURE 4-20. PLATFORM SUPPORT INSTALLATION - WITH LSS 430

SECTION 5 - PLATFORM 433

FIGURE 5-1. PLATFORM ASSEMBLY - 30IN X 3FT (76CM X .91M) - DROP BAR ENTRY 434
FIGURE 5-2. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) WITH SWING GATE 436
FIGURE 5-3. PLATFORM ASSEMBLY - 30IN X 4FT (76CM X 1.22M) WITH DROP BAR 438
FIGURE 5-4. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M) WITH SWING GATE 440
FIGURE 5-5. PLATFORM ASSEMBLY - 30IN X 5FT (76CM X 1.52M) WITH DROP BAR 442
FIGURE 5-6. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH SWING GATE 444
FIGURE 5-7. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH DROP BAR 446
FIGURE 5-8. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) WITH FALL ARREST (ANSI, ANSI EXPORT, CHINA AND CSA SPECS) 448
FIGURE 5-9. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) TRI-ENTRY WITH SWING GATE 450
FIGURE 5-10. PLATFORM ASSEMBLY - 36IN X 6FT (91.5CM X 1.83M) TRI-ENTRY WITH DROP BAR 452
FIGURE 5-11. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH SWING GATE 454
FIGURE 5-12. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH TRI-ENTRY (1 GATE/2 DROP BARS) 456
FIGURE 5-13. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH DROP BAR 458
FIGURE 5-14. PLATFORM ASSEMBLY - 36IN X 8FT (91.5CM X 2.44M) WITH TRI-ENTRY (3 DROP BARS) 460

MidWestTech | JLG 600S, 660SJ Boom Lift Parts Manual | Publication 3121729 Order the manual at mid-west-tech.com >

FIGURE 2-13. ROTARY COUPLING ASSEMBLY - 2WS

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	1001188334	Ref	ROTARY COUPLING ASSEMBLY	G
10	See Note	NSS	Housing (Note: Purchase Complete Assembly)	
20	See Note	NSS	Shaft (Note: Purchase Complete Assembly)	
30	70005710	1	Spacer	
40	70005711	1	Spacer	
50	70005712	1	Fitting	
55	70005713	1	Circlip	
60	4360517	1	Sensor	
60	4460320	1	Plug, Male - 2 Position	
60	4460227	2	Socket, Female	
70	70006537	2	Bolt	
75	70006538	2	Washer	
300	70005716	1	Seal Kit (Includes Items 350-390)	
350	See Note	NSS	Ring, Wear (Note: Use Item 300)	
360	See Note	NSS	Seal (Note: Use Item 300)	
370	See Note	NSS	Wiper (Note: Use Item 300) (Not Shown)	
380	See Note	NSS	Wiper (Note: Use Item 300)	
390	See Note	NSS	Seal, Rod (Note: Use Item 300)	

MidWestTech | JLG 600S, 660SJ Boom Lift Parts Manual | Publication 3121729 Order the manual at mid-west-tech.com >

FIGURE 4-18. PLATFORM SUPPORT INSTALLATION - WITHOUT LSS (SN 0300235168 through 0300251320, SN B300002655 through B300003386)

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	0272070	Ref	PLATFORM SUPPORT INSTALLATION	H
1	0100011	AR	Compound, Locking	
2	0641812	8	Bolt 1/2 x 1-1/2	
3	0642684	1	Bolt 1 x 10-1/2	
4	0681608	8	Bolt 3/8 x 1	
5	3300243	1	Nut 1	
6	3311805	8	Nut 1/2	
7	4846573	1	Support	
8	4891600	8	Washer 3/8	
9	4891800	8	Washer 1/2	
10	4892600	1	Washer 1	
11	1001216630	2	Decal - Tie Down/No Lift	
	1001202688	Ref	VALVE MOUNT INSTALLATION	C
101	0100011	AR	Compound, Locking	
106	3900283	4	Screw 3/8 x 3/4	
107	4711600	4	Washer 3/8	
108	1001206920	1	Mount, Valve	

MidWestTech | JLG 600S, 660SJ Boom Lift Parts Manual | Publication 3121729 Order the manual at mid-west-tech.com >

FIGURE 5-46. WELDER ASSEMBLY

ITEM	PART NUMBER	QTY	DESCRIPTION	REV
	4530028	Ref	WELDER ASSEMBLY	B
		Ref	Note: For Other Components, contact your Miller Welder Dealer.	
1	7027773	1	Cover, Top	
1	7027774	1	Decal - Static Precautionary Warning	
2	See Note	NSS	Panel, LH Side (Note: Part of Item 1. Purchase Item 1)	
3	See Note	NSS	Panel, RH Side (Note: Part of Item 1. Purchase Item 1)	
4	7024467	1	Cable, Power	
4	7027775	1	Decal - Electrical Shock Warning (Not Shown)	
5	7027776	1	Handle, Carrying	
101	7024462	1	Panel, Front	
102	7024463	1	Panel, Console	
103	7024469	1	Switch with Lead	
104	7024470	1	Knob	
105	7024471	1	Knob	
106	7024472	1	Receptacle with Leads and Plugs	
107	7024473	2	Receptacle, Twistlock Female	
108	7024474	2	Insulator	
109	7024475	2	O-Ring	
110	7027777	1	Nameplate	
111	7027779	1	Circuit Card Assembly (Process Control)	
112	7024478	2	Nut	
113	7027778	1	Circuit Card Assembly (Operator Interface)	
201	7024462	1	Panel, Rear	
202	7027780	1	Panel, Cover	

MidWestTech | JLG 600S, 660SJ Boom Lift Parts Manual | Publication 3121729 Order the manual at mid-west-tech.com >