Illustrated Parts Manual

Models
3507, 3508
3509, 3512,
3513, 4007
4008, 4009
4012, 4013

3121853

Revised
April 3, 2014

An Oshkosh Truck Corporation Company

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE NO.	TITLE	PAGE NO.
SECTION 1 –		
	FRAME & ATTACHING PARTS	**1-1**
1-1	Basic Components Installation	1-2
1-2	Engine Hood Installation	1-4
1-3	Engine Cover Installation	1-6
1-4	Toolbox Installation	1-10
1-5	Counterweight Assembly	1-12
1-6	Headlight & Mirror Bracket	1-14
1-7	Rear Boom Cover Installation	1-16
1-8	Axle Installation	1-18
1-9	Fenders Installation	1-26
1-10	Stabilizer Installation	1-28
1-11	Stabilizer Installation for Platform	1-30
1-12	Stabilizer Installation Equipped W/LMIS	1-32
SECTION 2 –		
	BOOM	**2-1**
2-1	Boom Assembly	2-2
2-2	First Boom Section Assembly	2-6
2-3	Second Boom Section Assembly	2-10
2-4	Third Boom Section Assembly	2-14
2-5	Quick Switch Assembly	2-16
SECTION 3 –		
	ATTACHMENTS	**3-1**
3-1	Manure Bucket	3-2
3-2	4 in 1 Bucket	3-4
3-3	Fork Mounted Hook	3-6
3-4	Buckets	3-8
3-5	Carriage Assembly w/Loadguard	3-10
3-6	Side Shift Carriage Assembly	3-12
3-7	Fork Positioning Carriage Assembly	3-14
3-8	Fork Tines	3-16
3-9	Fork Tine Extension	3-18
3-10	Truss Boom	3-20
3-11	Platform Assembly, Adapter & Pedestal	3-22
3-12	Platform Assembly, Base & Railings	3-24
3-13	Platform Assembly, Electrical	3-26
3-14	Platform Assembly, Miscellaneous	3-30
3-15	Concrete Ladle	3-32
3-16	Crane Hook	3-34
3-17	Extending Jib (Australia)	3-36
3-18	Adjustable Boom Truss (Australia)	3-38

MidWestTech | JLG 3507, 3508, 3509, 3512, 3513, 4007, 4008, 4009, 4012, 4013 Telehandl... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE NO.	TITLE	PAGE NO.
SECTION 4 – ENGINE & ATTACHING PARTS		**4-1**
4-1	Engine Installation	4-2
4-2	Engine Assembly	4-8
4-3	Tank & Fuel Supply Installation	4-14
4-4	Cooling System Installation	4-18
4-5	Air Cleaner Installation	4-20
4-6	Muffler Installation	4-26
4-7	Air Collector, Condenser & Radiator	4-30
4-8	Transmission Assembly	4-34
4-9	Transmission Assembly - Converter Housing	4-36
4-10	Transmission Assembly - Case & Plate	4-38
4-11	Transmission Assembly - Torque Converter	4-40
4-12	Transmission Assembly - Gear Group	4-42
4-13	Transmission Assembly - Pump Drive Group	4-46
4-14	Transmission Assembly - Charge Pump	4-48
4-15	Transmission Assembly - Reverse Idler	4-50
4-16	Transmission Assembly - Forward & Reverse Shaft	4-52
4-17	Transmission Assembly - High 4th & 3rd Shaft	4-54
4-18	Transmission Assembly - 1st & 2nd Shaft	4-58
4-19	Transmission Assembly - Output Shaft	4-60
4-20	Transmission Assembly - Control & Modulation Valve Assembly	4-62
4-21	Transmission Assembly - Drive Plate	4-70
4-22	Transmission Assembly - Drop Box	4-72
SECTION 5 – DRIVE TRAIN		**5-1**
5-1	Front Axle Assembly	5-2
5-2	Front Axle Assembly - Differential Housing Components	5-4
5-3	Front Axle Assembly - Internal Differential Housing Components	5-6
5-4	Front Axle Assembly - External Axle Components	5-8
5-5	Front Axle Assembly - Brake Components	5-12
5-6	Front Axle Assembly - Steering Components	5-14
5-7	Front Axle Assembly - Oscillation Support Components	5-16
5-8	Rear Axle Assembly	5-18
5-9	Rear Axle Assembly - Differential Housing Components	5-20
5-10	Rear Axle Assembly - Internal Differential Components	5-22
5-11	Rear Axle Assembly - External Axle Components	5-24
5-12	Rear Axle Assembly - Brake Components	5-28
5-13	Rear Axle Assembly - Steering Components	5-30
5-14	Rear Axle Assembly - Oscillation Support Components	5-32
5-15	Tire & Wheel Assembly	5-34

MidWestTech | JLG 3507, 3508, 3509, 3512, 3513, 4007, 4008, 4009, 4012, 4013 Telehandl... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FIGURE NO.	TITLE	PAGE NO.
SECTION 6 – CAB		**6-1**
6-1	Cab Installation	6-2
6-2	Interior Installation	6-6
6-3	Cab Door Installation	6-8
6-4	Cab Windows Installation	6-10
6-5	Wiper System Installation	6-12
6-6	Driver Seat Assembly	6-14
6-7	Mechanical Seat Installation	6-16
6-8	Mechanical Suspension Seat Assembly	6-18
6-9	Air Duct Installation	6-20
6-10	Air Circulation Installation	6-22
6-11	Air Conditioning Unit Installation	6-24
SECTION 7 – CONTROLS		**7-1**
7-1	Steering Column Assembly & Attaching Parts	7-2
7-2	Console Box Assembly	7-4
7-3	Accelerator Pedal Assembly	7-6
7-4	Parking Brake Installation	7-8
SECTION 8 – HYDRAULIC CIRCUITS		**8-1**
8-1	Frame & Cab	8-2
8-2	Drive Pump to Main Valve	8-6
8-3	Lifting Hydraulics	8-8
8-4	Working Hydraulics	8-12
8-5	Hydraulic System w/Auxiliary	8-20
8-6	Leveling Hydraulics	8-28
8-7	Stabilizing Hydraulics	8-30
8-8	Lift System Equipped For Platform	8-32
8-9	Drive Pump to Main Valve Equipped For Platform	8-36
8-10	Drive Pump to Main Valve Equipped For Platform (Australia)	8-38
SECTION 9 – HYDRAULIC COMPONENTS		**9-1**
9-1	Lift Cylinder Assembly	9-2
9-2	Extend/Retract Cylinder Assembly	9-18
9-3	Tilt Cylinder Assembly	9-38
9-4	Compensation Cylinder Assembly	9-42
9-5	Sway Cylinder Assembly	9-48
9-6	Stabilizer Cylinder Assembly	9-54
9-7	Attachment Lock Cylinder Assembly	9-60
9-8	Main Control Valve Assembly	9-64

MidWestTech | JLG 3507, 3508, 3509, 3512, 3513, 4007, 4008, 4009, 4012, 4013 Telehandl... Order the manual at mid-west-tech.com >

Figure 4-5 Air Cleaner Installation

Item	Part Number	Qty.	Description	Rev.
	2120188	Ref	NATURALLY ASPIRATED AIR CLEANER INSTALLATION, (includes all items)	B
1	2120186	1	AIR CLEANER ASSY, (includes item 25 thru 28)	
2	3929780	1	CLAMP, MOUNTING	
3	91083129	1	REDUCING ELBOW	
4	3574617	1	MOUNT PLATE	
5	2988212	1	ELBOW FITTING	
6	2913166	1	LOW PRESSURE INDICATOR	
7	09523572	1	ELBOW, 90 DEGREES	
8	4805794	1	PIPE, SUCTION	
9	8002927	1	PRECLEANER	
	7028095	1	COVER	
	7028096	1	BOWL	
	7028097	1	CLAMP	
10	4811900	4	FLAT WASHER, 8mm	
11	0760812	4	HEX HD CAPSCREW, M8X25, GR8.8	
12	1349717	1	CLAMP	
13	5220800	2	NUT, 8mm	
14	0760814	2	HEX HD CAPSCREW, M8X30, GR8.8	
15	2973384	1	REINFORCEMENT RING	
16	2991568	3	CLAMP	
17	1380161	4	CLAMP	
18	4568860	1	INTAKE TUBE	
19	4568905	1	TUBE	
20	77383126	1	ELBOW, 45 DEGREES	
21	91083126	1	AIR INTAKE ELBOW	
22	4100083	4	REDUCING INSERT SLEEVE	
23	0100085	AR	GLUE ADHESIVE	
25	7028118	1	COVER	
26	10733183	1	VACUATOR	
27	80273010	1	PRIMARY ELEMENT, (outer)	
28	80273042	1	SAFETY ELEMENT, (inner)	

MidWestTech | JLG 3507, 3508, 3509, 3512, 3513, 4007, 4008, 4009, 4012, 4013 Telehandl... Order the manual at mid-west-tech.com >

Figure 8-1 Frame & Cab

Item	Part Number	Qty.	Description	Rev.
	8001852	Ref	HYDRAULIC SYSTEM, (frame & cab), (includes items 1 thru 58)	O
1		Ref	FRONT AXLE, (see Figure 5-1 for details)	
2		Ref	REAR AXLE, (see Figure 5-8 for details)	
4	8001645	1	DIRECTIONAL VALVE ASSY	
	8007879	2	COIL	
	7024014	2	POLE TUBE	
	8007877	2	SEAL KIT	
8	2142713	5	FITTING	
10	2140224	1	FITTING	
12	2471354	4	FEMALE SCREW, 18X1.5X32mm	
13	462780	8	SEAL RING	
16	2656664	1	FITTING	
17	8001629	1	HOSE	
18	8001631	1	HOSE	
19	8001632	1	HOSE	
21	2902527	4	FITTING	
24	8002096	1	TUBE	
25	8002097	1	TUBE	
26	2477156	2	HOSE	
28	2140223	1	FITTING	
29	2142103	2	FITTING	
30	1616551	2	FITTING, PRESSURE CHECK	
31	1631629	2	FITTING	
32	8002323	2	TUBE	
33	8002324	2	TUBE	
35	8005789	1	PRESSURE SWITCH	
36	8002838	1	FITTING, BULKHEAD	
37	0760614	2	HEX HD CAPSCREW, 6X30mm, GR8.8	
38	3290601	2	HEX NUT, 6mm	
39	4811700	2	FLAT WASHER, 6mm	
53	3970214	1	FITTING	
54	2966454	4	CLIP	
55	5200810	8	BOLT, 8X20mm	
56	2443576	8	CLIP	
58		Ref	PARKING BRAKE, (see Figure 7-4 for details)	
59	2142204	1	SWIVEL NUT RUN TEE, **(S/N 1160001630 & After), (see Figure 8-2 for Before S/N 1160001630)**	
60	2131216	1	PRESSURE GAUGE ADAPTER, **(S/N 1160001630 & After), (see Figure 8-2 for Before S/N 1160001630)**	
61	4360585	1	PRESSURE SWITCH, **(S/N 1160001630 & After), (see Figure 8-2 for Before S/N 1160001630)**	
62	1074306	1	O-RING, **(S/N 1160001630 & After), (see Figure 8-2 for Before S/N 1160001630)**	
63		Ref	MAIN VALVE ASSY, (see Figure 9-8 for details)	
64		Ref	HYDRAULIC TANK, (see Figure 9-10 for details)	
75	8006329	Ref	HYDRAULIC SYSTEM, (cab), (includes items 80 thru 104)	
80	8002321	1	RESERVOIR, COMPENSATOR	
81	8007622	1	BRAKE HOSE	
82	2985639	1	CLIP	

MidWestTech | JLG 3507, 3508, 3509, 3512, 3513, 4007, 4008, 4009, 4012, 4013 Telehandl... Order the manual at mid-west-tech.com >

Figure 11-2 Decals - Cab

Item	Part Number	Qty.	Description	Rev.
	8008178	Ref	DECAL INSTALLATION, (cab), (includes items 1 thru 47)	B
1	8005608	1	DECAL JOYSTICK	
2	8005671	2	DECAL	
3	8005672	1	DECAL	
4	8005673	1	DECAL	
5	8005674	1	DECAL	
6	2447967	1	DECAL - OIL	
7	8005670	1	DECAL	
8	8008651	1	DECAL	
9	8008196	1	DECAL - FUSE	
10	8005870	1	DECAL - ESCAPE HATCH	
11	8008804	1	DECAL	
12	8008805	1	DECAL	
20	1705979	1	DECAL, 105 DB	
	1705980	1	DECAL, 106 DB	
			DECAL - MODEL OPTIONS, (includes items 32-41)	
32	8008523	1	MODEL 3507	
33	8008525	1	MODEL 3508	
34	8008526	1	MODEL 3509	
35	8008527	1	MODEL 3512	
36	8008528	1	MODEL 3513	
37	8008529	1	MODEL 4007	
38	8008530	1	MODEL 4008	
39	8008531	1	MODEL 4009	
40	8008532	1	MODEL 4012	
41	8008533	1	MODEL 4013	
48		Ref	COVER, RIGHT SIDE, (see Figure 6-2, item 8 for details)	
49		Ref	WEIGHT INDICATOR, (see Figure 10-1, item 22 for details)	
106	8466306	1	LEVEL INDICATOR GAUGE, **(AUS)**	
108	1001095303	1	WALL MOUNT CONTAINER, **(AUS)**	
109	1001104090	.4m	TAPE, **(AUS)**	
110	1001110729	1	LANYARD ASSEMBLY, **(AUS)** (includes items 251 thru 253)	
151	1001104090	AR	TAPE, **(AUS)**	
152	1001104541	1	KEY RING, **(AUS)**	
153	1001110722	1	WIRE LANYARD, **(AUS)**	
201	8009119	1	CAPACITY CHART BOOKLET, **(CE - 3507, FIXED AXLE)**	7
	8008822	1	FORKS CAPACITY CHART	
	8008853	1	$1m^3$ BUCKET CAPACITY CHART	
	8008854	1	$2m^3$ BUCKET CAPACITY CHART	
	8009160	1	3,4m & 3,9m TRUSS BOOM CAPACITY CHART	
	8009515	1	FORK MOUNTED HOOK CAPACITY CHART	
	1706275	1	3,6m TRUSS BOOM CAPACITY CHART	
	1706420	1	SIDE SHIFT CARRIAGE CAPACITY CHART	
202	8009120	1	CAPACITY CHART BOOKLET, **(CE - 3507, OSCILLATING AXLE)**	7
	8003342	1	FORKS CAPACITY CHART	
	8008855	1	$1m^3$ BUCKET CAPACITY CHART	
	8008856	1	$2m^3$ BUCKET CAPACITY CHART	
	8009161	1	3,4m & 3,9m TRUSS BOOM CAPACITY CHART	

MidWestTech | JLG 3507, 3508, 3509, 3512, 3513, 4007, 4008, 4009, 4012, 4013 Telehandl... Order the manual at mid-west-tech.com >