VERSATILE

Service Manual

NEW HOLLAND

Tractor
150, 160

40015011

MidWestTech | New Holland 150, 160 Tractor Service Manual | Publication 40015011

Order the manual at mid-west-tech.com >

SECTION 1: SPECIFICATIONS AND DATA

Table of Contents

1 INTRODUCTION

2 HOISTS AND JACKS

3 SPECIFICATIONS

3.1 Dimensions 1-3
3.2 Tires 1-3
3.3 Engine 1-3
3.4 Cooling System 1-3
3.5 Electrical System 1-4
3.6 Transmission 1-4
3.7 Drive Hydrostatics 1-4
3.8 Air Cleaner 1-4
3.9 Brakes 1-4
3.10 Drivelines 1-4
3.11 Axles 1-4
3.12 Steering 1-4
3.13 Hydraulic System 1-4
3.14 Frame 1-4
3.15 Drawbar 1-5
3.16 Cab 1-5
3.17 Instrument Panel 1-5
3.18 Control Console 1-5
3.19 Power Take-Off 1-5
3.20 Three-Point Hitch 1-5
3.21 Options 1-5

4 FUELS, FLUIDS AND LUBRICANTS

4.1 Fuels 1-6
4.2 Fluids 1-6
4.2.1 Coolant 1-6
4.2.2 Hydraulic Fluid 1-6
4.2.3 Transmission Fluid 1-7
4.2.4 Brake Fluid 1-7
4.3 Lubricants 1-7
4.3.1 Grades 1-7
4.3.2 Engine Oil 1-7
4.3.3 Differentials and Dropboxes 1-7
4.3.4 PTO Gearbox 1-7
4.3.5 Grease 1-7

5 LUBRICATION

5.1 General 1-7

MidWestTech | New Holland 150, 160 Tractor Service Manual | Publication 40015011 Order the manual at mid-west-tech.com >

6 BELTS AND FILTERS

6.1 General 1-10

7 STORAGE

7.1 General 1-10
7.2 Preparation of Engine for Storage 1-10
7.3 Preparation of Tractor for Storage 1-10
7.4 Storing Batteries 1-11
7.5 Preparation After Storage 1-11
7.6 Engine Start Up After Storage 1-12

MidWestTech | New Holland 150, 160 Tractor Service Manual | Publication 40015011 Order the manual at mid-west-tech.com >