Combines
TX Series

TX36 - Complete
TX66 & TX68 - Mechanical
Information Only


SERVICE MANUAL



NEW HOLLAND

40483610 6/95

MidWestTech | New Holland TX36, TX66, TX68 Combine Service Manual | Publication 404... Order the manual at mid-west-tech.com >



CONTENTS

INTRODUCTION	01.00
TRACTION	02.00
HEADER	03.00
STRAW ELEVATOR	04.00
HYDROSTATIC SYSTEM	05.00
MAIZE HEADER	06.00
ENGINES	07.00
BASIC ELECTRICITY	08.00
AIR CONDITIONING	22.00
SPECIAL TOOLS	23.00
THRESHING TF/TX SERIES	26.00
SEPARATION TF/TX SERIES	27.00
CLEANING TF/TX SERIES	28.00
GRAIN STORAGE TF/TX SERIES	29.00
HYDRAULIC SYSTEM TF/TX SERIES	30.00
ELECTRICAL SYSTEM TF/TX SERIES	31.00
FUNCTIONAL ADJUSTMENTS TF/TX SERIES	32.00
STRAW CHOPPER CLUTCH AND CHAFF SPREADER GEARBOX ON TX	33.00

MidWestTech | New Holland TX36, TX66, TX68 Combine Service Manual | Publication 404... Order the manual at mid-west-tech.com >