SERVICE MANUAL

FORD GASOLINE AND DIESEL INDUSTRIAL ENGINES

BSG	326	(158 CID)
BSG	333	(201 CID)
BSD	326	(158 CID)
BSD	329	(175 CID)
BSD	333	(201 CID)
BSD	442	(256 CID)
BSD	442T	(256 CID)
BSD	666	(401 CID)
BSD	666T	(401 CID)

SPERRY NEW HOLLAND

MidWestTech | Sperry New Holland Ford BSG 326, 333, 329, 442, 442T, 666, 666T Gas, Diesel Engine Service Manual | Publication 40540151

Order the manual at mid-west-tech.com >

CONTENTS

BASIC ENGINE
- Identification 4
- Description 4
- Diagnosis & Testing 7
- Overhaul 9
- Cleaning & Inspection 22
- Disassembly & Assembly 29

IGNITION SYSTEM
- Identification 40
- Description & Operation 40
- Diagnosis & Testing 43
- Adjustments 46
- Removal & Installation 47
- Cleaning & Inspection 55

FUEL SYSTEMS
- Identification 57
- Description & Operation 57
- Adjustments 59
- Disassembly & Assembly 60
- Diagnosis & Testing 63
- Diesel Fuel Systems Description 65
- Fuel Lines 67
- Fuel Filter 67
- Distribution Type Field Injection Pump 68
- In-Line Type Fuel Injection Pump 73
- Injectors 82
- Diagnosis & Testing 84
- Turbocharger 87

STARTING
- Description & Operation 96
- System Components 96
- 4.5 In. Gasoline Engine Starter Operation 98
- 4.5 In. & 5.0 In. Diesel Engine Starter Operation 99
- Diagnosis & Testing 100
- Starter Removal & Installation 103
- Overhaul 103
- 4.5 Inch Gasoline Engine Starter 104
- 4.5 & 5.0 In. Diesel Engine Starter 107
- Starting Motor Relay 112
- Starting System Troubleshooting 112

COOLING
- Description & Operation 114
- Diagnosis & Testing 115
- Adjustments 117
- Removal & Installation 117
- Cleaning & Inspection 118

SPECIFICATIONS
- General Specifications 119
- Service Bulletin 133

MidWestTech | Sperry New Holland Ford BSG 326, 333, 329, 442, 442T, 666, 666T Gas, Di... Order the manual at mid-west-tech.com >