OPERATOR'S MANUAL

Skid-Steer Loader
L-250

Serial Number 751251 and Above

Issue 3-89



NEW HOLLAND

FORD
NEW HOLLAND

Reprinted

MidWestTech | New Holland L-250 Skid Steer Loader Operator's Manual | Publication 4202... Order the manual at mid-west-tech.com >

SERVICE AND LUBRICATION CHART

	Maximum Hourly Interval (Hours of Operation)				
	10	50	100	200	500
Check engine oil level	X*				
Check hydraulic oil level	X				
Squeeze air cleaner dust nipple (optional equipment)	X				
Lubricate belt idler arm	X				
Check belt tension	X**	X			
Check tire pressure		X			
Check battery	X				
Back flush air through engine shrouding		X			
Change engine oil		X***			
Check final drive chain tension		X**	X		
Clean hydraulic oil screen		X**		X	
Check hardware for loosening		X**		X	
Check final drive idler bracket bolt torque			X		
Clean chain case breathers (2)			X		
Replace engine oil filter			X***		
Remove engine shrouding and clean fins				X	
Check or replace spark plugs			X		
Check RPM and timing			X		
Replace in-line fuel filter				X	
Clean foam pre-cleaner on carburetor air filter		X****			
Replace paper element on carburetor air filter				X****	
Remove carbon deposits from cylinder heads				X	
Re-tighten axle bearings					X
Clean breather valve				X****	
Change hydraulic oil					X
Re-torque wheel lug bolts		X**		X	
Check breaker points			X		
Replace points and condenser				X	
Check valve clearance		X		X	
Check engine compression				X	

*Twice a day during 50-hour initial run-in
**First time only
***After first 25-hour break-in oil is changed
****More often under dusty or dirty conditions

MidWestTech | New Holland L-250 Skid Steer Loader Operator's Manual | Publication 4202... Order the manual at mid-west-tech.com >