
OPERATOR'S MANUAL

HAYLINER® 275

42027514

NEW HOLLAND



MidWestTech | New Holland Hayliner 275 Square Baler Operator's Manual | Publication 42027514

Order the manual at mid-west-tech.com >

CONTENTS

ADJUSTMENT
- Bale Shape 23
- BALER SERVICE CHART 41
- PTO Slip Clutch 6
- Feeder Carriage 23
- Knife Adjustment 25
- KNOTTER
  - Bill Hook 37
  - Knotter/Twister Brake 32
  - Knife Arm 37
  - Knotter Stack 35
  - Knotter/Twister Stop 30
  - Removing End Play 36
  - Twine Disc 36
  - Twine Finger 33
  - Twine Holder 36
- KNOTTER SERVICE CHART 39
- METERING WHEEL LOCATION 30
- NEEDLES
  - Adjustment 33
  - Timing 31
  - Needle latch 7
- NEEDLE YOKE ROD 29
- PICKUP
  - Lift Spring 22
  - Over-Running Clutch 8
  - Slip Clutch 8
  - Wheel 21
  - Windguard 21
- PLUNGER BEARING ADJUSTMENT 25
- ROLLER CHAINS 59
- TWISTER
  - Adjustments 49-54
  - Assembly 48
  - Disassembly 46
  - Forming the Twist 44
  - Servicing 45
  - Service Chart 55

GENERAL
- Optional Equipment 60
- Ordering Parts 59
- Safety Precautions 6
- Specifications 3
- Warranty 2

LUBRICATION 9

MAINTENANCE
- MAIN GEARBOX 57
- PICKUP
  - Cam Follower 58
  - Fingers 57
  - Tooth Pipe 58
- PTO DRIVE 57
- STORING THE BALER 59
- TIRE PRESSURES 57
- "LOCTITE" 58

OPERATION
- Attaching the Baler (P.T.O.) 13
- Attaching the Baler (Engine) 15
- Before Using your Baler 4
- Bale Length 20
- Bale Tying 20
- Bale Weight 19
- Hydraformatic 61
- Multi-Luber® 63
- Slip Clutch Adjustment 6
- Starting the Baler 20
- Threading the Baler 16-19
- Transporting Baler (Engine) 15
- Transporting Baler (P.T.O.) 14
- Twister 43-45
- Windrow Preparation 20
- Wind Guard 21
- Tying 20
- HIGHWAY SAFETY 65

BALER PROTECTION
- NEEDLE LATCH 7
- PTO SLIP CLUTCH 6
- OVER-RUNNING CLUTCH 6
- SHEARBOLTS
  - Flywheel 6
  - Knotter/Twister Drive 8

MidWestTech | New Holland Hayliner 275 Square Baler Operator's Manual | Publication 42... Order the manual at mid-west-tech.com >